


116SHO3100



SHOP MANUAL

(FOR ENGINE DETAILS REFER ENGINE SHOP MANUAL)



BD80

BULLDOZER

(WITH BEML BS6D125-1 ENGINE)

BEML LIMITED

INDIA

FOREWORD

This MANUAL is published for the information and guidance of shop personnel entrusted with the task of servicing the BEML BD80 Bulldozer and provides instruction to be adhered to in disassembling and re-assembling of the machines of this model in the shop. The instructions are given mainly in the form of procedures and, in each section of the manual are preceded by an outline description of each major component in respect of mechanical construction, functions and other pertinent items.

TERMINOLOGY

Effort has been made in the preparation of this manual to use the most common shop terms in order to avoid ambiguity and equivocation. Some key terms used however, require explanation in advance as to their meanings. The major key terms used in this manual have the following meanings

Clockwise (C.W.) and Counterclockwise (C.C.W.)

A circular direction, C.W. or C.C.W., is in the mind of the viewer standing in front and ahead of the machine, except when a driven component is discussed. Such a component as the oil pump the component is considered singly and as viewed from its driving side.

Terms of Servicing Criteria

BASIC SIZE: This term is universally defined as the theoretical or nominal standard size(diameter, length, thickness, etc) from which variations are made, and is used in this sense throughout.

ASSEMBLY STANDARD: *This is a dimensional value or a range of dimensional values to be adhered to in assembling components. An assemblage is required to satisfy the assembly standard specified for it.*

STANDARD CLEARANCE: *This refers to a clearance range, within which a distance of separation occurring in a full assembly or sub-assembly of replacement parts must take its value. Such an assembly or subassembly is permitted to be installed or mounted in place only when this requirement is satisfied.*

CLEARANCE LIMIT: *(maximum allowable clearance): A running clearance between a shaft and its hole, for instance, will increase as the shaft or hole wears progressively. A clearance limit is provided for each critical or important clearance and, if such a clearance is found to have increased upon disassembling beyond the clearance limit specified for it, the parts associated with that clearance must be corrected to take a value within the limit.*

SERVICE LIMIT: *An extra stock is provided in some parts subject to wear, so that these parts may be repaired upon disassembling. There are many such parts that can be reused repeatedly until their extra stock is used up by grinding, cutting etc. A service limit is the minimum or the maximum dimension (thickness, diameter, etc.) specified for such a part. Any part found to have exceeded its service limit is not repairable: its serviceability has ended and a replacement part must be used in re-assembling.*

CONTENTS

SECTION	01	Specifications
SECTION	02	General Instructions
SECTION	03	Engine Removal and Installation
SECTION	04	Main Clutch
SECTION	05	Transmission
SECTION	06	Bevel Gear and Bevel Gear Shaft
SECTION	07	Steering System
SECTION	08	Final Drive
SECTION	09	Control System
SECTION	10	Undercarriage
SECTION	11	Miscellaneous Mountings
SECTION	12	Electrical System
SECTION	13	Hydraulic System
SECTION	14	Dozer Attachment
SECTION	15	Maintenance Standards

SPECIFICATION

Index

SPECIFICATIONS	01—01
POWER TRAIN	01—06

Specifications

	Operating Weight			21,550 kg (47,512 lb)	
Chassis	Flywheel horsepower			180HP(134kW) @ 1850 rpm	
	Drawbar horsepower			148HP(110kW) @ 1850rpm	
	Max. drawbar pull			19,800 kg (43,651 lb)	
	Ground pressure			0.65 kg/cm² (9.1 PSI)	
	Travel Speeds	Forward	1st	2.4 km/h	(1.5 MPH)
			2nd	3.4	(2.1 MPH)
			3rd	5.2	(3.2 MPH)
			4th	7.4	(4.6 MPH)
			5th	10.0	(6.2 MPH)
		Reverse	1st	3.1	(1.9 MPH)
			2nd	4.5	(2.8 MPH)
			3rd	6.7	(4.2 MPH)
			4th	9.6	(6.0 MPH)
	Overall length			5890 mm	(231.9")
	Overall width			4260 mm	(167.7")
	Overall height (top of exhaust pipe)			3060 mm	(120.5')
	Ground clearance (excl. grouser)			400 mm	(15.7")
	Drawbar height above ground (excl. grouser)			470 mm	(18.5")
	Track gauge			2000 mm	(78.7")
	Lift above ground			1260 mm	(49.6')
	Drop below ground			530 mm	(20.9")
	Tilting adjustment			500 mm	(19.7")

Specifications

Engine	Model	BS6D125-1
	Type	Water cooled, 4, cycle, turbo charged direct Injection diesel engine.
	Starting method	By starting motor
	NO. of cylinders - bore X stroke	6 - Ø125 x 150 mm
	Piston displacement	11000 cc
	Dry weight (excl. radiator)	1523 kg (3,358 lb)
	Flywheel horsepower	180 FHP
	Rated RPM	1850 RPM
	Max. torque	80 kg-m (579 ft-lb)/1100 rpm
	Specific Fuel consumption	227 gm/kwh
	Air cleaner	Dry, horizontal type. (with Precleaner and dust indicator)
Fuel tank Capacity		420 ltr.
Radiator type		Continuous finned flat tube type
Clutch	Type	Wet, multi-disc, over center engagement
Transmission	Type	Constant-mesh
	Gear shift	F5- R4
Bevel gear	Type	Spiral bevel gear, single reduction
	Lubrication	Splash lubrication
Steering clutch	Type	Wet, multiple disc hydraulic w/spring type
	Control	w/Hydraulic booster, hand operated
Final Drive	Type	Wet, contracting band, foot operated
Steering brake	Type	Spur gear double reduction


Specifications

Undercarriage	Suspension	Semi-rigid, equalizer bar
	No. of carrier rollers (upper)	2 (each side)
	No. of track rollers (lower)	6 (each side)
	Shoe type	Single grouser
	No. of shoes	38 (each side)
	Shoe width (std.)	560 mm (22.0")
	Grouser height	65 mm (2.6")
	Pitch	216 mm (8.5")
	Width of optional shoe	610 mm (24.0")
Drawbar	Type	Pin, fixed type
	Pin dia.	57 mm (2.24")
Blade	Blade width	4260 mm (167.7")
	Blade height	1060 mm (41.7")
	Blade capacity	3.55 m ³
	Max. lift above ground	1260 mm (49.6")
	Max. drop below ground	530 mm (20.9")
	Angling adjustment	25° (each side)
Blade cylinder	Cylinder bore X O.D.	120 mm X 136 mm (4.724" X 5.3543")
	Stroke x rod dia.	1014 mm X 65 mm (39.92" X 2.56")
	Pressure setting	140 kg/cm ² (2,000 PSI)
Accelerator lever	Idle -Full	8.4 kg (19 lbs)
	Full Idle	9.8 kg (22 lbs)

Specifications

Transmission lever	Gear shift force	5.3-6.5 kg (12-14 lbs)
	Forward-Reverse lever force	4.8-5.9 kg (11-13 lbs)
Steering lever		0.7-4.2 kg (1.5 ~ 9.2 lb)
Brake pedal		23-27 kg (51 ~ 60 lbs)
Main clutch lever		5-6 kg (11 ~ 13 lbs)
Control valve	Location	built-in hydraulic tank
	Valve type	Spool
	Valve positions	Raise, hold lower, float
Hydraulic Tank	Type	Equipped with built in control valve
	Capacity	105 litres
	Location	On R.H. fender
	Hydraulic oil	Engine oil
Capacities	Cooling water	65 ltr.
	Fuel tank	420 ltr.
	Main clutch	25 ltr.
	Transmission (incl. steering case)	75 ltr.
	Final drive (each)	36 ltr.
	Recoil spring case	10 ltr.
	Undercarriage (each side)	3 ltr.


Specifications



BD80 BULLDOZER



POWER TRAIN



- | | | |
|----------------------------------|---------------------|------------------------|
| 1. Engine | 5. Counter shaft | 10. Bevel gear |
| 2. Hydraulic oil pump drive gear | 6. Main shaft | 11. Final drive |
| 3. RPCU drive shaft | 7. Sprocket | 12. Intermediate shaft |
| 4. Main clutch oil pump drive | 8. Steering clutch | 13. Main clutch |
| | 9. Bevel gear shaft | 14. Steering oil pump |

GENERAL INSTRUCTIONS

INDEX

INSTRUCTIONS FOR DISASSEMBLING	02-01
INSTRUCTIONS FOR RE-ASSEMBLING	02-01
INSTRUCTIONS FOR ADJUSTMENT	02-02
INSTRUCTIONS FOR USE OF HAND TOOLS	02-02
INSTRUCTIONS FOR HANDLING BEARING IN DISASSEMBLING/ RE-ASSEMBLING	02-02
INSTRUCTIONS FOR HANDLING OIL SEALS	02-03
INSTRUCTIONS FOR HANDLING SNAP RINGS	02-04
INSTRUCTIONS FOR HANDLING GASKETS AND PACKINGS	02-04

General Description

The BEML BD80 Bulldozer is a semi-rigid crawler machine designed specifically for heavy duty services, The BS6D125-1 Diesel Engine is used to power this bulldozer and is electrically started to ensure easy start.

The main clutch is of the wet, multiple disc type being power assisted to reduce operator's fatigue. The transmission is of the constant mesh type, of varying size and design being in constant mesh helical gears and rotating at all times to eliminate crashing of the gears. The main clutch is interconnected with the

interlocking device that prevents the transmission gear from jumping out of place during operation- as well as making the engagement of the main clutch impossible while the transmission is half-positioned..

The steering clutch are the wet, multiple disc type.- each being power assisted to reduce operator's fatigue.

The final drives are of the spur gear, double reduction type that is lubricated by splash. The BD80; Bulldozer uses Hydraulic oil as a means of operating the blade equipment - Raise. Hold, Lower and Float positions.



BD80 BULLDOZER

General Instructions

INSTRUCTIONS FOR DISASSEMBLING WORK

1. Before starting to disassemble any part of the machine, study the parts book and service manual, giving particular attention to the servicing criteria and standards indicated in these publications to gain a full understanding of the mechanical component to be disassembled. Knowledge of the construction and functions of the component is an essential factor for successful servicing work.

2. When draining out lubricants and hydraulic oil, be sure to take note of the colour, viscosity and cleanliness with which the oil comes out. Oil in service often suggests the condition of the parts served, particularly when the oil lubricates gears or bearings.

3. It is advisable and often mandatory to put matching marks across mating joint lines before separating or removing parts, and to scribe identification marks on identical parts such as pistons and valves in the engine. This provision that you make at the time of disassembling will greatly facilitate your reassembling work.

4. Disassembly requires that you carefully note the orientation or position of each part, as necessary, and the sequence of taking one part

after another from the machine. What you have so noted at the time of disassembling will be an assurance of your restoring or re-assembling the parts correctly.

5. Be sure to use the special disassembling tool wherever its use is specified in the procedure. If the special tool is not available, some tool similar to it should be used. Use of the special tool is prescribed where common tools can cause damage of one type or another to the parts involved.

6. Tapered parts or press-fitted parts are expected to be tight in place and not to yield easily to hand pulling. If such a part is noted to be loose, be sure to inspect it for wear with greater care.

7. Parts taken off after disassembling should be washed clean and set aside in an order making proper provision to protect them against dust. Use two kinds of washing fluid one for removing dirt and one for clean washing. Filters, magnetic plugs and breathers are the parts that must be cleaned particularly and carefully.

8. Make shim stock available in all thicknesses for use at the time of re-assembling.

INSTRUCTIONS FOR RE-ASSEMBLING WORK

1. Before starting to assemble, make sure all parts are clean. Replacement parts are usually coated with an anti-rust compound; remove the compound by wiping or washing.

2. Installation of bearings, bushes, oil seals and the like require the use of special driving-in or forcing out tools in most cases. Driving such a

part into its position by directly hitting it with a hammer is a bad practice: always use a piece of wood or soft metal to transmit the hammer blow to the part.

3. Spring, plain tongue or toothed washers, cotter pins and locking wires are highly important parts but, because of their small size,

General Instructions

Adjusting Work, Tools, etc.

liable to be forgotten at the time of re-assembling. When fitting such fastening parts as bolts and nuts, check to be sure whether locking means are specified or not for the fastening parts.

4. Use a torque wrench wherever its use is prescribed or a torque limit is specified. When securing a cover or similar part having many bolts, be sure to adhere to the standard shop practice of tightening the securing bolts

gradually to distribute the pressure evenly.

5. Matching marks are not marks for identifying mating parts: they are meant to be indexed and aligned as accurately as possible. Ignoring this fact may result in a costly major repair.

6. Clean tools, clean work benches and tables are keys to successful assembling work, cleanliness saves working time and promotes accurate assembling.

INSTRUCTIONS FOR ADJUSTING WORK

1. Most of the assembling operations are completed with adjusting work. Be sure to check your list so that none of such components will be left unadjusted. Track tension and control

Linkage play is typical items of adjustment that demand your greater attention in re-assembling work.

INSTRUCTIONS FOR USE OF HAND TOOLS

1. Use good and correct hand tools. Use of defective or wrong hand tools would lead to improper assembling or damage of the parts.

2. Never use any special tool or purposes other than the one for which It Is Intended, or you will damage the machine or the tool.

INSTRUCTIONS FOR HANDLING BEARING IN DISASSEMBLING/RE-ASSEMBLING WORK

1. Dust is one of the 'common enemies' of all bearings. Dust can often be a cause of bearing noise and accelerates deterioration of the lubricating oil in service.

2. When replacing a bearing, unpack the replacement bearing only when all preparatory steps for bearing installation have been completed.

3. While installing a bearing be sure to position it properly, forcing it all the way against the wall (stepped shoulder or seat).

4. Use of proper type of bearing puller (some of which serve also as Installers) is involved in general disassembling/re-assembling work. Be sure to use these tools where their use is specified. DRIVING a bearing in with a HAMMER is. In most cases, the same thing as driving a sure cause of trouble into the machine.

5. For the washing fluid to be used in cleaning bearings, Benzene or Benzoyl is recommendable. Kerosene and diesel fuel oil may be used If compressed air is available for blowing dust off, but with the oils alone fine dust entrapped within a bearing is hard to remove.

General Instructions

Oil Seals

6. After washing and cleaning bearings, and pending their Installation, coat them lightly with grease.

7. Spherical roller bearings should be Installed

with particular attention to the positioning. Secure them correctly to eliminate excessive clearance at either end face, or the bearings will wear off prematurely in service.




INSTRUCTIONS FOR HANDLING OIL SEALS

1. While installing an oil seal, make sure the oil seal is so positioned as to bring its lip to the correct side.

2. The lip of an oil seal in place is required to present a sharp tip angle for satisfactory sealing action. Thus it is highly essential to handle all seals carefully, in order to protect their lips against damage. For instance, winding the wire of tag around an oil seal is a bad protect and should never be attempted.

Oil the seal just before forcing it into the bore at the time of Installing it, or the seal might become scarred due to the friction of dry rubbing faces during initial operation.

Use a guide to slip the seal into bore when installing it as shown in Fig. A. If such a guide is not available, prepare a makeshift guide with a sheet of brass, as shown in fig. B. Use of the guide is particularly necessary where the shaft has a keyway or a shoulder.



General Instructions

Snap Rings, Gasket etc.

3. Fig. C Illustrates the proper way of forcing the oil seal into the bore, 'Note that an adapter is used to apply pressure uniformly to the, end face of the seal. The forcing adapter should be 0.5-1 mm smaller In diameter than the bore, and its

end should be shaped to take blows from a mallet or hammer. The surface of the shaft, upon which the seal is mounted, must be smooth and free of -any scratch mark.

INSTRUCTIONS FOR HANDLING SNAP RINGS

1. While handling a snap ring be careful not to twist it nor to deform its corners and ends. Try to preserve its springiness: never expand and contract it successively. After fitting it to the shaft,

check to be sure the ring is properly seated.

2. Always use the ring expander in removing and installing sharp rings.

INSTRUCTIONS FOR HANDLING GASKETS AND PICKINGS

1. A copper packing removed from the machine should not be re-used. However, a packing of this type, found to be in good condition after it is annealed, may be re-used.

2. Sealing sheets pickings gaskets and the like are not to be re- used.

3. Leather pickings, before installation, should

be soaked in oil so that they will become pliable.

4. Protect the surfaces of "O" rings and "V" pickings against damage. Winding wire directly around them is a bad practice.

5. A gasket should be fitted at the time of re-assembling, with both its surfaces coated with a bonding agent.

General Instructions

Weight Data

WEIGHT DATA

<i>Item</i>	<i>Weight</i>	
<i>GROSS VEHICLE WEIGHT</i>	<i>20710 kg</i>	<i>(45665.550lb)</i>
<i>NET VEHICLE WEIGHT (tare weight)</i>	<i>19970 kg</i>	<i>(44033.850lb)</i>
<i>TRACTOR WEIGHT</i>	<i>16990 kg</i>	<i>(37462.950lb)</i>
<i>Cooling water fuel oil, etc.</i>	<i>640 kg</i>	<i>(1411.200lb)</i>
<i>Engine (incl. P.T.O.)</i>	<i>1620 kg</i>	<i>(3572.100lb)</i>
<i>Radiator</i>	<i>240 kg</i>	<i>(529,200 lb)</i>
<i>Fuel system</i>	<i>190 kg</i>	<i>(418.950lb)</i>
<i>Electrical system</i>	<i>210 kg</i>	<i>(463.050lb)</i>
<i>Main clutch (incl. universal joint)</i>	<i>200 kg</i>	<i>(441.000lb)</i>
<i>Transmission</i>	<i>670 kg</i>	<i>(1477.350lb)</i>
<i>Steering clutches</i>	<i>2000 kg</i>	<i>(4410.000lb)</i>
<i>Final drives</i>	<i>1700 kg</i>	<i>(3748.500.lb)</i>
<i>Brakes</i>	<i>160 kg</i>	<i>(352.800lb)</i>
<i>Track frames</i>	<i>4140 kg</i>	<i>(9128.700lb)</i>
<i>Track shoes</i>	<i>3110 kg</i>	<i>(6857.550lb)</i>
<i>Control system</i>	<i>290 kg</i>	<i>(637.450lb)</i>
<i>Suspension system</i>	<i>370 kg</i>	<i>(815,850 lb)</i>
<i>Outfitting's</i>	<i>1200 kg</i>	<i>(2646.000.lb)</i>
<i>Operator's seat</i>	<i>80 kg</i>	<i>(176400lb)</i>
<i>Drawbar</i>	<i>170 kg</i>	<i>(374.850lb)</i>
<i>Hydraulic system (incl. 110 lit. of oil)</i>	<i>1020 kg</i>	<i>(2249,100 lb)</i>

WEIGHTS OF MAJOR ASSEMBLIES

<i>Assembly or component</i>		
<i>Cross-drive case + main frame</i>	<i>1560 kg</i>	<i>(3439.800lb)</i>
<i>Clutch assembly (Brake drum discs, plates</i>	<i>120 kg</i>	<i>(264,600lb)</i>
<i>pressure plate, Inner drum, pistons) (each)</i>	<i>170 kg</i>	<i>(374.850lb)</i>
<i>Sprocket</i>	<i>200 kg</i>	<i>(441,000 lb)</i>
<i>Equalizer bar</i>	<i>330 kg</i>	<i>(727.650lb)</i>
<i>Framework</i>	<i>60 kg</i>	<i>(132,300lb)</i>
<i>Radiator undercover</i>	<i>150 kg</i>	<i>(330.750 lb)</i>
<i>Engine undercover (incl. hook)</i>	<i>150 kg</i>	<i>(330,750lb)</i>
<i>Transmission undercover</i>	<i>170 kg</i>	<i>(374,850lb)</i>
<i>Fender right</i>	<i>160 kg</i>	<i>(352.800 lb)</i>
<i>Fender left</i>	<i>170 kg</i>	<i>(374.850lb)</i>
<i>Blade cylinder stay</i>	<i>220 kg</i>	<i>(485.100lb)</i>
<i>Hydraulic oil tank (incl. valve)</i>	<i>110 kg</i>	<i>(242.550lb)</i>
<i>Blade cylinder (each)</i>		

ENGINE REMOVAL AND INSTALLATION

INDEX


RADIATOR	03-01
ENGINE REMOVAL (Including P.T.O. and Main Clutch Assembly)	03-03
P.T.O. SYSTEM	03-06
ENGINE INSTALLATION	03-08
ENGINE CENTERING	03-08

Engine Removal & Installation


Radiator

REMOVAL


1. Dismount the pre-cleaner (1), exhaust pipe (2) and engine hood (3).



2. Open the drain valve (1) to drain out cooling water.




3. Remove the clips (1) (2) (3), and disconnect the rubber hoses (4) (5) (6).



4. Remove the radiator guards (1) (2).



5. From the bottom side of the radiator disconnect the pipe (1) leading to the water pump.




Engine Removal


RADIATOR

Removal

6. Loosen the bolts (1) and detach the fan guard (2).




7. Remove nuts (1) and take out the fan from the pulley (2).



8. Remove the stays and hydraulic cylinders. (by referring to "REMOVAL OF STAYS AND HYDRAULIC CYLINDERS").

9. Disconnect the 'headlight wiring at each side of the machine.


10. At each side, loosen the bolts (1) (2), drive out the dowel pins (3) (4) and suspend the radiator assembly by using an overhead lifting device.




Engine

REMOVAL


1. Dismount the air cleaner exhaust pipe and engine hood.
2. Close the fuel valve under the fuel tank.
3. Drain oil in the hydraulic oil tank.
4. Remove all floor plates.
5. Disconnect control link rods for brakes and steering clutches.
6. Disconnect all pipes from the hydraulic oil tank.
7. Remove the step board support at each side.
8. Remove the slays and hydraulic cylinders (by referring-to "REMOVAL OF STAYS AND HYDRAULIC CYLINDERS").
9. Disconnect all tubes from the engine. These tubes lead to the radiator.
10. Disconnect the battery cable (1).




11. Remove bolts (2) securing the step board support (1).



12. Remove the bolts and nuts (1) (2) and dismount the muffler (3).



13. Remove the engine mounting bolts (1) at the rear end of the engine.




Engine Removal


ENGINE (INCL. PTO & MAIN CLUTCH ASSEMBLY)

Removal

14. Remove the engine mounting bolts (1) (2) at the front end of the engine.



15. Attach the lifting gear to the engine and lift the assembly of engine, PTO, main clutch assembly and Instrument panel out of the chassis and place it on the floor.



Notes: 1. EXERCISE UTMOST CARE IN LIFTING THE ENGINE ASSEMBLY OFF THE CHASSIS. SO AS NOT TO DAMAGE ANY PART OF THE ENGINE AS WELL AS OTHER PARTS. ADHERE TO THE FOLLOWING RULES IN THIS. LIFTING OPERATION:

2. MAKE SURE THE LIFTING CABLE IS FREE OF TWISTS, RUST OR BREAK IN ANY STRAND.
3. TAKE OUT THE ADJUSTING SHIMS THAT WILL COME OUT FROM EACH ENGINE SUPPORT, AND MARK THEM CLEARLY SO THAT

THEY CAN BE PUT BACK IN THE SAME PLACE FROM WHERE THEY HAVE BEEN REMOVED.

4. AFTER PLACING THE ENGINE ASSEMBLY ON WOODEN BLOCKS LAID ON THE FLOOR, MAKE SURE THAT THE ENGINE IS SUPPORTED PROPERLY BEFORE SLACKENING THE LIFTING CABLE.
5. CARRY OUT THE STEPS (1) (11) FOR REMOVAL AS OUTLINED IN "RADIATOR REMOVAL". REFER TO "HYDRAULIC TANK REMOVAL FOR STEPS (3) (7).

Engine Removal


P.T.O. SYSTEM

Disassembling, etc.


P.T.O. System

REMOVAL


1. Drain the hydraulic oil tank, and disconnect all pipes from this tank (by referring to "HYDRAULIC TANK REMOVAL").
2. Remove all floor plates.
3. Disconnect oil pipes from the hydraulic oil pump.
4. Remove the bolts (1) and take off the pump (2).




5. Remove the bolts (1) (2) and disconnect the pipes (3) (4).




6. Remove the nipples (1) (2) (3) (4) (5) and take out the pipes (6) (7) (8) and (9) (10).




7. Remove the bolts (1) and detach the PTO device by levering.



8. Hitch a lifting sling to the PTO as shown and remove it.



DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

1. Bolt	8. Nut	14-2. Bearing	20-3. Shaft
2. Spring washer	9. Lock	14-3. Case	21. Bolt
3. Cover	10. Collar	15. Gasket	22. Spring washer
4. Gasket	11. Bolt	16. Gear	23. Cover
5. Bolt	12. Spring washer	17. Gear	24. Gasket
6. Spring washer	13-1. O-ring	18. Gear	25. Bearing
7-1. O-ring	13-2. Bearing	19. Snap ring	26. Ring
7-2. Cover	13-3. Bearing cage	20-1. Key	27. Bearing
7-3. Oil seal	14-1. Bearing	20-2. Bearing	28. Case

CLEANING AND INSPECTION

1. Clean all parts Inspect gear teeth for wear.
2. Inspect shaft splines and oil seals for wear.

ASSEMBLING

1. Build up the P.T.O. system completely on the bench and secure the assembly to the flywheel case.

Engine Removal

Installation - Engine Centering

INSTALLATION


To re-mount the engine, reverse the removal procedure outlined above adhering to the following rules:

1. Be sure to restore the adjusting shims to the engine mountings. Place the mounting brackets tentatively on the frame and check their geometrical arrangement to be sure, roughly, that the engine will center itself properly when it is positioned over the mounting.
2. After the engine unit is secured to the main frame, center the main-clutch to the transmission by referring to the transmission main shaft.
3. Tighten the engine mounting bolts equally and gradually, passing the wrench from one mounting to another and completing the tightening by torqueing each bolt up to the specified torque value.

ENGINE CENTERING

Fix a dial gauge to rear end of Inertia brake and; with the gauge spindle pointed against the coupling on transmission main shaft rotate the latter shaft to read two run outs face (gauge spindle held against the end face of coupling) and radial (gauge spindle held against the peripheral face of coupling).

The engine may be considered to be properly centered if the two run outs measured are within 0.25mm if not, re-position the engine in place by increasing or decreasing the adjusting shims used in engine mountings




MAIN CLUTCH

INDEX

DESCRIPTION	04- 01
OIL PUMP	04-06
MAIN CLUTCH REMOVAL	04-07
DISASSEMBLING	04-12
CLEANING AND INSPECTION	04-17
ASSEMBLING	04-17
HYDRAULIC BOOSTER	04-19
ENGAGING OPERATION	04-20
DISENGAGING OPERATION	04-21
DISASSEMBLING	04-24
CLEANING AND INSPECTION	04-25
INERTIA BRAKE	04-26
CLUTCH ADJUSTMENT	04-27
INERTIA BRAKE ADJUSTMENT	04-27
LUBRICATION SYSTEM	04-29

Main Clutch

DESCRIPTION




MAIN CLUTCH

- | | | |
|-------------------|-------------------|---------------------------|
| 1. Adjusting ring | 6. Adjust bolt | 11. Release yoke |
| 2. Lock plate | 7. Clutch shaft | 12. Brake lining, inertia |
| 3. Lock nut | 8. Disc | 13. Brake drum, inertia |
| 4. Brake lever | 9. Pressure plate | |
| 5. Set bolt | 10. Clutch cover | |

Main Clutch

Description

The main clutch is a multi-disc over-centre wet type having toggle links for pressing together the discs and plates. It is secured to the engine flywheel and housed in the main clutch casing bolted to the flywheel casing. A hydraulic booster is provided on the clutch to minimize the effort required at the clutch control lever. The booster is mounted on the upper part of the clutch casing.



- | | |
|-------------------------|--------------------------|
| 1. Main clutch shaft | 16. Coupling flange |
| 2. Hub | 17. Joint cup |
| 3. Disc | 18. Bearing |
| 4. Plate | 19. Bearing cage |
| 5. Pressure plate | 20. Brake lining |
| 6. Flywheel | 21. Brake band |
| 7. Clutch case | 22. Relief valve |
| 8. Clutch cover bracket | 23. Adjusting bolt |
| 9. Spring | 24. Strainer |
| 10. Adjusting ring | 25. Magnet plug |
| 11. Collar | 26. Return spring |
| 12. Release collar | 27. Release yoke |
| 13. Plate | 28. Hub (pressure plate) |
| 14. Bearing cup | 29. Link assembly |
| 15. Hydraulic booster | 30. Bearing |

Hydraulic oil, supplied to the booster and circulated by force feeding through the running parts of the main clutch, comes from a gear pump driven from the P.T.O. located above the clutch casing.

An inertia brake, consisting of a drum and band, provided next to the flanged end of the main clutch shaft. This brake, positioned just outside the clutch casing, brakes and stops the shaft quickly on clutch disengagement. By this feature, transmission shaft is prevented from coasting, and the grating of gears in each shifting operation.


The main clutch assembly and its associated components are so designed and positioned as to permit easy access and to facilitate inspection and servicing.

Two plates (driving) and three discs (driven) are alternately stacked between flywheel and pressure plate. Driving plate and the pressure plate engage by sliding in the flywheel which is having formed teeth in it. The driven discs are similarly meshed with the hub by means of their internal teeth. The hub is splined to the forward end of the clutch shaft. Thus, the driving plates and pressure plate rotate with the engine and the driven discs with the clutch shaft. The main clutch transmits drive when its plates and discs are pressed together.

The flanged end of the clutch shaft is supported by a roller bearing. An oil seal is provided on this bearing to protect it from external dust and dirt and to prevent leakage of oil from the clutch housing. A universal joint is placed between the flanged end and the transmission main shaft. There are two spiders in the universal joint. The forward end of the clutch shaft is splined to the hub, which is supported by the bearing; fitted in the central bore of the flywheel.

Main Clutch

Description



MAIN CLUTCH BOOSTER

- | | | | | | |
|----|------------|----|---------|----|------------|
| 1. | Yoke shaft | 4. | Cover | 7. | Piston |
| 2. | Yoke | 5. | Springs | 8. | Valve body |
| 3. | Lever | 6. | Spool | 9. | Coupling |

Main Clutch


Description

The gear pump, secured to the P.T.O. case, lifts oil in the main clutch casing through an oil strainer located at the bottom of the casing and pumps it to the hydraulic booster. Through the

ferrule and oil passage of the booster, the oil enters its valve body, wherein it acts on the piston in either direction, depending on the position of the spool relative to the piston.

The booster is primarily a means of multiplying the push or pull (applied from the clutch control lever to the extending end of the booster spool through an Intermediate lever). The linkage from the clutch control lever through the booster spool to the release collar within the main clutch is a continuous, mechanically connected line capable of directly transmitting the effort to the

collar even in the absence of hydraulic pressure. With the hydraulic pressure available to the booster the effort is greatly assisted by the booster so that a far less effort is required of the operator to operate the clutch control lever for engagement and disengagement of the main clutch.



Oil leaving the booster is led to the oil cooler, from which it returns to the main clutch, wherein it flows first in the Internal oil passage provided through the axis of the clutch shaft, comes out of the forward end of the shaft, and then spills off through the disc-carrying hub to cool and lubricate the surfaces of the plates and discs by radially flowing along the grooves cut on these surfaces. By centrifugal force, the oil is flung

outward to lubricate the peripheral teeth of the plates and drips down by gravity to the bottom of the clutch casing.

The pressure plate is pressed forward by return coil springs in the direction of releasing or loosening the plates and discs. The force for keeping the clutch engaged is applied by 5 sets of toggle links positioned around the clutch shaft,

Main Clutch

Description


each consisting of a weight link, two rollers, a link and pins and forming a radially oriented toggle mechanism. The outer end of each toggle is pinned to the adjusting ring, and the inner end to the collar, which is complete with another collar (release collar) and mounted, slid ably on the clutch shaft. The two rollers are at the knee of the

toggle. Moving the collar toward flywheel causes the knee rollers of each toggle to push against the pressure plate and thereby press the plates and discs together against the flywheel. Pulling the collar backward releases the force and the return springs assist the plates and discs to separate resulting interruption of the flow of drive.

Main Clutch

Description

OIL PUMP



MAIN CLUTCH OIL PUMP

- | | | |
|-------------------|-------------------|-----------------|
| 1. Oil seal | 5. Drive gear | 9. Housing |
| 2. Bracket | 6. Gear case | 10. Reamer bolt |
| 3. Needle bearing | 7. Spacer | |
| 4. Driven gear | 8. Needle bearing | |

The oil pump is a gear type pump with precisely machined components. It is located on the left rear face of the P.T.O. case above the flywheel casing, and is driven by a gear (forward of the flywheel) on the engine crankshaft through a train of gears in the P.T.O. Thus, the pump runs with the engine and delivers pressurized oil to the booster and other running parts of the main clutch as long as the engine is running.

Part of the oil delivered by it goes back to the P.T.O. to lubricate the P.T.O. gears.


Moving the clutch control lever to engage or disengage the clutch results in a momentary interruption of oil flow to the clutch. During this short duration, the pressure of the oil is fully utilized in actuating the piston within the booster valve body.

Main Clutch



REMOVAL

MAIN CLUTCH REMOVAL

1. Remove the bolts (1) (2) (3) and floor plates (4) (5) (6)




2. Remove the engine under guard.
3. Take out the plug (1) by unscrewing it with a wrench, and drain the hydraulic oil tank.





4. Drain the main clutch housing by removing the plug 1.

5. Draw off the pins (1) (2) from the steering clutch control rods (3) (4). Disconnect these rods on the steering case side.




6. Draw off the pins (1) (2) (3) and take down the brake control rods (4) (5) and main clutch control rod (6). Remove the nut (7) and remove the main-clutch control rod (8).




Main Clutch


REMOVAL




7. Remove the bolts (1) (2) and detach the flange (3) (4) from the hydraulic tank (5).




8. Remove the bolts (1) and disconnect the hosepipe (3) from the pump (2). Remove the bolts (4) and take out the pipe (6) from the pump (5).




9. Remove the brake support beam by removing the bolts (1) on both sides.



10. Remove the bolts (1) and take out the main clutch housing cover plate (2').




11. Remove the pin (1) to disconnect the main clutch control lever (2) from the booster rod (3).




Main Clutch

REMOVAL


12. Take down the main clutch booster (3) by removing the bolts (1) (2),




13. Remove the nuts (1) and bolts (2) and take out the flange (3).





14. Remove the bolts (1) (2), and remove the caps (3) (4) and spiders (5) (6).



15. Disconnect the pipe (2) by removing the bolts (1).




16. Disconnect the flange of the pipe (2) from the pump (1). Remove the flange (4) from the hydraulic tank (3). Remove the pipe (5).




Main Clutch

REMOVAL


17. Remove the bolts (1) to detach the flange (2). Disconnect joint (3) to remove the pipes (4) (5). Remove the bolts (6) and valve (7).




18. Remove the bolts (1) and disconnect the pipe (2)




19. Take down the pump (1). Disconnect the joint (2). Remove the bolts (3) and Cover (4).



20. Disconnect the joint (1) and pipe (3) from the pump (2).




21. Remove the bolts (1) and disconnect the pipe from the clutch oil strainer.




Main Clutch

REMOVAL


22. Disconnects joints (1) (2) (3), remove the bolt and tubes (4) (5). Remove the bolts (6) and take out the P.T.O. assembly (7).



23. Remove the bolts (1) securing the clutch: turn the clutch and remove these bolts one after another. Remove the nuts (2) securing the clutch housing.




24. Remove the bolts (1) and flange (2).



25. Screw the bolt (1) into clutch housing and take a hitch on the housing by hooking the lifting sling to this bolt. While drawing out the clutch shaft (2), detach the clutch assembly and lift it out by operating the hoist.



DISASSEMBLING



MAIN CLUTCH


PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

1-1. Spring	4-23. Shaft	11. Lock
1-2. Cotter pin	4-24. Ball	12. Lock
1-3. Washer	4-25. Lever	13. Bracket
1-4. Lever	4-26. Bush	14-1. Cotter pin
1-5. Bolt	4-27. Pin	14-2. Bush
1-6. Nut	4-28. Lock	14-3. Ring
1-7. Cover	4-29. Bolt	14-4. Bolt
2. Gasket	4-30. Nut	14-5. Lock
3-1. Bolt	4-31. Bush	14-6. Plate
3-2. Spring Washer	4-32. Bearing	14-7. Plate
3-3. Drum	4-33. Lever	14-8. Cotter pin
3-4. Drive shaft	4-34. Nut	14-9. Block
4-1. Bolt	4-35. Spring washer	14-10. Collar
4-2. Spring washer	4-36. Gasket	14-11. Plate
4-3. Gasket	4-37. Bolt	14-12. Pin
4-4. Cotter pin	4-38. Spring washer	14-13. Link pin
4-5. Nut	4-39. Retainer	14-14. Roller
4-6. Screen	4-40. Gasket	14-15. Link
4-7. Gasket	4-41. Snap ring	14-16. Pin
4-8. Spacer	4-42. Bearing	14-17. Link weight
4-9. Stud	4-43. Oil seal	14-18. Bush
4-10. Cover	4-44. Stud	14-19. Bush
4-11. Bolt	4-45. Cover	14-20. Collar
4-12. Spring Washer	4-46. Clutch case	15. Disc
4-13. Cap	5. Lock	16. Plate
4-14. Oil Gauge	6. Collar	17. Bolt
4-15. Tube	7. Spring	18-1. Snap ring
4-16. Gasket	8-1. Hub	18-2. Hub
4-17. Bush	8-2. Dowel pin	18-3. Lock
4-18. Bolt	8-3. Guide	18-4. Snap ring
4-19. Spring washer	8-4. Washer	18-5. Bearing
4-20. Snap ring	B-5. Pressure plate	18-6. Retainer
4-21. Key	9. Nut	
4-22. Yoke	10. Spring washer	


Main Clutch

Disassembling

1. Take out spring (1), and remove the cotter pin (2). lever (3). bolt (4) and nut (5) from the cover (6).




4. Pull off the cotter pin (1) remove the nut (2) and take out the screen (3)




2. Remove the bolts (1) and draw off the drum (2) and drive shaft (3).



5. Remove the bolts (1) and take out the oil gauge assembly.




3. Remove the bolts (1) and take out the oil strainer.




Main Clutch

Disassembling


6. Remove the bolt (1), yoke (2) and lever (3) while drawing out the shaft.




9. Depress the spring, using the spring compressing tool, and remove the lock (5).




7. Remove the nuts (1) and detach the cover assembly.



10. Remove the collars (6) and springs (7).



8. Remove the bolts (1) and take out the cover (2), retainer (3), bearing (4) and seal (5).



11. Remove the hub (8-1) and pressure plate (8-5).




Main Clutch

Disassembling


12. Remove the nut (9), and lock (11)




13. Extract the cotter pin (14-1), draw out the bush (14-2) to the underside and take out the ring (14-3).



14. Remove the bolts (14-4) and locks (14-5) detach the plate (14-6), Pull off the cotter pin (14-8), slide out the block (14-9), remove the collar (14-10).



15. At each toggle mechanism, drive out the pin (14-12) and link pin (1-13), and remove the rollers (14-14), link (14-15) and link weight (14-17) from the collar (14-20).



16. Slide out the clutch plates and discs remove the bolts (17) and draw off the hub assembly.



Main Clutch

Assembling

CLEANING AND INSPECTION

1. Clean the clutch discs and plates. Check each part for distortion and inspect the friction surfaces for score marks, uneven wear or stepped wear.

Determine if each part is re-usable after repairing.



2. Inspect the teeth, internal and external, associated with clutch plates and discs for wear or damage.
3. Inspect the ball end of the yoke actuating the lever for wear or damage.
4. Check the yoke actuating lever for distortion or any defective condition.
5. Check the bush on yoke actuating lever for

wear or damage.

6. Inspect the block acted on by the yoke for wear or damage.
7. Inspect the toggle parts, checking the pins and link pins for distortion and rollers for wear or damage.
8. Check the clutch springs for wear or signs of fatigue.
9. Inspect the oil seal for condition. Examine that part of drive shaft where the oil seal is located and see if the shaft is excessively worn or not.
10. Inspect, the internal surfaces of the flywheel for any signs of abnormal condition.

ASSEMBLING

1. Connect each assembly of the link pin (14-13), rollers (14-14) link (14-15) and link weight (14-17) to the collar (14-20) by inserting the pin (14-12). Be sure to punch on the pins to lock them in place.
2. Insert the bushes (14-2) into the rings (14-3), and lock each bush by inserting the cotter pin (14-1). Be sure to bend the pin legs around bush.




Main Clutch

Assembling


3. Secure the main clutch assembly to the flywheel by tightening the bolts (1): the installing procedure is the reverse of the removal step (23). Turn the collar to bring the block to top and bottom positions.



4. Before inserting the drive shaft, check to be sure that the blocks for securing the clutch case are correctly engaged with the yoke



5. Grease the drive shaft (3) as shown, so that it will not damage the oil seal and, just before the splined forward end of it reaches the hub, turn the shaft, by hand to be sure it will rotate smoothly. Thereupon, gently push in the drive shaft to feed its splined end into the hub.




6. Install the main-clutch booster.
7. Install the P.T.O. and restore the pipes and other parts.

Engine Removal

HYDRAULIC BOOSTER

Description

HYDRAULIC BOOSTER



MAIN-CLUTCH BOOSTER

- | | | |
|---------------|-----------|--------------------------|
| 1. Yoke shaft | 4. Cover | 7. Piston |
| 2. Yoke | 5. Spring | 8. Valve body A, B, C, D |
| 3. Lever | 6. Spool | Valve parts |
| | | 9. Coupling |

The hydraulic booster is composed of the parts such as: the valve body or case secured to the main clutch casing; the piston capable of sliding axially in the bore of the valve body and having four valve ports (A), (B), (C) and (D) in its bore; the spool fitted with a very small sliding clearance in the bore of the piston and connected with a linked lever at its extended end two springs interposed between piston and spool a coupling screwed into the output end of the piston; and a built-in safety valve.

The coupling serves as a seat for the ball end of the lever whose other end is keyed to the yoke

shaft. The release collar in the main clutch is actuated coupling end of the booster piston through the yoke.

Absence of hydraulic pressure to the booster does not nullify the effect of the linkage between the control lever and release collar. The relationship between spool and piston in the valve body, moving the control lever will actuate the release collar; though a greater operating effort is required in such a case.

With the booster in neutral slate, the springs hold the spool in hydraulically balanced condition.


ENGAGING OPERATION

Pulling the clutch lever towards operator causes the spool to move against the springs slightly towards the right from its neutral position, thereby closing ports (B) and (D). Hydraulic oil flows into the annular space (P) around the piston to push it in the direction of (R). This movement forces the release collar towards the flywheel to press the plates and discs together in the main clutch.

The amount of spool displacement is equal to the amount of piston movement. In other words,

the piston follows the spool whenever the latter is made to move.

When the main clutch has been engaged, with the piston having followed the spool all the way, the internal valve parts open to balance the hydraulic forces acting on the piston, releasing the control lever under this condition removes the pull on the spool, and allows the spool to move slightly towards the coupling side by spring force, thus opening the valve ports fully.



CLUTCH "ON"

Engine Removal

HYDRAULIC BOOSTER


Description

DISENGAGING OPERATION

As the clutch control lever is pushed away, the spool compresses the spring slightly and moves towards the left, closing ports (A) and (C). This admits hydraulic pressure into the space (Q) to move the piston towards the left and disengage the clutch. In this case too the piston moves by an amount equal to the spool displacement. As

the clutch becomes disengaged the piston moves back just a little to open the ports and balance the hydraulic forces acting on it.


Whenever the piston is hydraulically moved by the pressure applied inside the space (Q), the oil trapped in the other space escapes through the outlet port and flows towards the main clutch.



CLUTCH "ON"

HYDRAULIC BOOSTER

Description



1. Valve body
2. Cap
3. Spring
4. Valve seat
5. Needle valve

Relief Valve

This valve is built in the booster case. It is a spring loaded piston valve set to pop open at about 14 kg/cm² of rising pressure and has its piston head exposed to the inlet oil passage of the booster.

The need of a relief valve for the booster inlet line will be seen in the light of the fact that if the clutch control lever is kept pulled after the main clutch has been engaged, for instance the spool in the booster would hold the internal valve ports in closed condition to block up the discharge line of the oil pump.

The pump, being a positive displacement type, needs some oil flow as long it is running. If the

flow is so stopped the pressure in the line will build up rapidly and the booster or the pump will be damaged.

The relief valve checks such a pressure rise within a safe limit. Oil led out through the relieving action of the relief valve flows into the line connecting the booster outlet to the cooler. In addition to this led-out oil, a small amount of oil is constantly spilled towards the main clutch through an oil outlet provided in the right-hand section of the valve, even when the operator happens to keep the clutch control lever pushed or pulled fully.

Main Clutch

HYDRAULIC BOOSTER

Description

The constant spillage curbs the speed of pressure buildup to some extent in the event of the condition outlined above, so that safety valve


will not be forced to open if the pressure rise is moderate or, in the case of disengaging operation, until the inertia brake begins to act on a coating clutch shaft.

Main Clutch

Disassembling

HYDRAULIC BOOSTER

DISASSEMBLING




HYDRAULIC CLUTCH BOOSTER

PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|------------------|------------------|--------------------|
| 1. Bolt | 9-2. Snap ring | 10-1. Nut |
| 2. Spring washer | 9-3. Washer | 10-2. Packing |
| 3-1. Oil seal | 9-4. Spring | 10-3. Spring |
| 3-2. Cover | 9-5. Spring | 10-4. Needle valve |
| 4. Gasket | 9-6. Spacer | 10-5. Valve seat |
| 5. Bolt | 9-7. Coupling | 11. Gasket |
| 6. Spring washer | 9-8. Nut | 12. O-ring |
| 7. Cover | 9-9. Lock washer | 13. Valve body |
| 8. Gasket | 9-10. Valve | |
| 9-1. Snap ring | 9-11. Piston | |

1. Loosen the bolts (1) and remove the cover (3-2). Remove the cover (7). Draw out the valve assembly (9).
2. Take out the relief valve assembly (10). (Refer illustration)



CLEANING AND INSPECTION

1. Clean all parts thoroughly by washing in solvent.
2. Inspect the sliding surfaces of the valve for wear or any scratches.
3. Inspect the sliding surfaces, of the piston and valve body for wear or damage, giving particular attention to that part of the valve body in which the piston is inserted.
4. Inspect the socket seat of the coupling for the ball end of the lever, and see for excessive wear of the seat.
5. Inspect the relief valve; and needle valve for wear of the valve seat.
6. Check the springs for signs of fatigue or damage.

INERTIA BRAKE


Description

INERTIA BRAKE

The inertia brake band is held by the brackets secured to the main clutch casing and presses the bottom half of the drum.

The band lining, secured to the band by riveting, is made of a thermally strong heat conductive material which possesses a high coefficient of friction.

The vertical brake lever has its bottom part pivoted on the clutch casing and bottom end engaged with the free end of the brake band at a bracket. The top end is interconnected to the main clutch control linkage in such a way that the brake will apply when the clutch is made to disengage.



INERTIA BRAKE


- | | | |
|-------------------------------|------------------------------|-------------------------------|
| 1. Main clutch case | 6. Inertia brake lever | 10. Inertia brake adjust bolt |
| 2. Main clutch booster | 7. Brake lever adjust bolt | 11. Brake lever |
| 3. Oil filler | 8. Booster lever adjust bolt | 12. Main clutch drive shaft |
| 4. Main clutch cover | 9. Main clutch booster valve | 13. Brake band |
| 5. Inertia brake lever spring | | 14. Brake lining |

Main Clutch

INERTIA BRAKE

Description

CLUTCH ADJUSTMENT



Shut down the engine and keep the decompression lever in "START" position. Remove the cover of the inspection access opening. Shift the transmission to a speed position so that the main clutch shaft will not turn during the adjustment.

Loosen nut (2) and lock plate (1). Turn the flywheel 180°, and loosen the other lock plate. Turn the adjusting ring in place with a wrench or bar applied to a weight link.

Turning the adjusting ring clockwise (as viewed from rear side) will tighten the clutch, and vice versa.

INERTIA BRAKE ADJUSTMENT

1. Disengage the main clutch by releasing the control lever. After the disengaging the clutch the clutch control lever would move back just a little. This movement is due to booster piston returning to its neutral position under the force of return spring. The inertia brake comes into force when the piston has completed this return movement.

The adjusting screw (2) is to be used with reference to the position of the clutch control lever.

2. Loosen the lock nut, and tighten the adjusting

Note: 1. THERE ARE TWO LOCK PLATES, WHICH ARE LOCATED DIAMETRICALLY OPPOSITE TO EACH OTHER. THE ADJUSTING RING MAY BE TURNED IN PLACE WHEN BOTH LOCK PLATES ARE LOOSENED. BE CAREFUL NOT TO DROP THE NUTS WHILE LOOSENING THESE PLATES.

2. THE STARTING MOTOR MAY BE USED TO TURN THE FLYWHEEL TO BRING THE LOCK PLATE TO THE OPENING OF THE CLUTCH HOUSING. THIS METHOD OF TURNING IS POSSIBLE ONLY WHEN THE ENGINE IS IN DECOMPRESSED POSITION.

3. WHEN TURNING THE ADJUSTING RING IN PLACE, BE CAREFUL NOT TO MAR OR NICK THE SIDE OF THE CAM.

Criteria for adjustment:

- (a) The force required for operating the clutch (under the condition of the engine in shutdown) should not exceed 45-50 Kg. The adjusting ring is the means of meeting this requirement.
- (b) After repositioning the adjusting ring, be sure to secure the two lock plates reliably and to tighten bolts fully.

screw (2) to obtain a clearance between the two levers (1) and (5).

3. Loosen the lock nut, and tighten the adjusting screw (3) so as not to touch the brake lever (5).

4. Lightly push the brake lever to make the brake lining barely touch the drum. While holding the lever in this position, turn back the adjusting screw (2) until the two levers (1) and (5) contact, and then turn in the screw 1.2 rotations.

5. Turn the screw (3) until it advances far enough to touch the brake lever (5). Turning the screw back 1.2 rotations from that position

INERTIA BRAKE

Description

should result in contact of the brake lever at its both faces with screw (3) and lever (1). After the adjustment has been completed, check to be sure that the clearance between the drum and the brake lining is 0.8 mm.


6. Tighten the lock nuts good and hard.

Note: ADJUSTING SCREWS (2) (6) WILL BE EFFECTIVE AS LONG AS THE WEAR IN THE BRAKE IS NOT ADVANCED TOO FAR IF EITHER ADJUSTING SCREW IS FOUND INEFFECTIVE IN THE ABOVE PROCEDURE, OR

WHEN THE BRAKE LINING HAS BEEN RENEWED, ADOPT THE FOLLOWING PROCEDURE.

Extra Step

After completing the steps 1,2 and 3, loosen the lock nut and tighten the adjusting screw (6) until the brake lever assumes a nearly vertical position with the brake lining coming into contact with the drum. Tighten the lock nut fully, and proceed the remaining steps 4.5 and 6 accordingly.




INERTIA BRAKE

- | | |
|-----------------|-----------------|
| 1. Return lever | 5. Brake lever |
| 2. Adjust screw | 6. Adjust screw |
| 3. Bolt | 7. Brake drum |
| 4. Lever | 8. Brake lining |

LUBRICATION SYSTEM

LUBRICATION OF MAIN CLUTCH AND P.T.O.



MAIN CLUTCH OIL CIRCUIT

The main clutch oil pump mounted on the P.T.O case above the engine flywheel casing sucks the oil from the flywheel casing through the strainer located within the casing and supplies pressurized oil, to the hydraulic booster on the main clutch casing. From the booster, oil flows through the oil cooler and enters the main clutch

to lubricate and cool the running parts of the clutch. Part of the cooled oil flows into the P.T.O. to lubricate the P.T.O. gears.


A relief valve is provided in the oil line from the booster to the oil cooler. The relieved oil from relief valve is led into the flywheel casing.

TRANSMISSION

INDEX

DESCRIPTION	05-02
FLOW OF DRIVE	05-02
REMOVAL	05-04
DISASSEMBLING	05-07
CLEANING AND INSPECTION	05-16
ASSEMBLING	05-16
TRANSMISSION SHIFT MECHANISM	05-17
DESCRIPTION	05-17
INTERLOCK SYSTEM	05-18
GEARSHIFT LEVER	05-20
GEARSHIFT FORK DISASSEMBLING	05-22
LUBRICATION SYSTEM	05-23
LUBRICATION OF TRANSMISSION	05-23

Transmission



TRANSMISSION

- | | | | |
|---------------------------------|------------------------------|--------------------------------|-------------------------------------------|
| 1. Bearing cage | 14. Bearing | A. Main shaft gear | M. Intermediate 4th speed gear |
| 2. Coupling ring | 15. Intermediate shaft | B. Main shaft reverse gear | N. Intermediate 3rd speed gear |
| 3. Oil seal | 16. Drain plug (magnet) | C. Main shaft 5th speed gear | O. Intermediate 2nd speed gear |
| 4. Main 'shaft cover | 17. Bearing | D. Countershaft gear | P. Intermediate 1 st speed gear |
| 5. Bearing cage | 18. Holder | E. Countershaft gear | Q. Forward 5th speed clutch gear |
| 6. Front cover | 19. Intermediate shaft cover | F. Countershaft 4th gear | R. Forward reverse clutch gear |
| 7. Transmission case | 20. Bearing cage | G. Countershaft 5th speed gear | S. Forward reverse 3rd and 4th speed gear |
| 8. Collar | 21. Countershaft cover | H. Countershaft 3rd speed gear | T. Forward reverse 1st and 2nd speed gear |
| 9. Main shaft | 22. Bearing | I. Countershaft 2nd speed gear | |
| 10. Bearing | 23. Holder | J. Countershaft 1st speed gear | |
| 11. Nut | | K. Intermediate forward gear | |
| 12. Bearing | | L. Intermediate reverse gear | |
| 13. Countershaft (bevel pinion) | | | |

Transmission

Description

DESCRIPTION

The transmission is of a constant-mesh type consisting of three clusters of helical gears on shafts - Main shaft, Counter shaft with a bevel pinion and intermediate shaft - all assembled in a single separate case. The transmission assembly as a unit can be removed from the machine without affecting any other components.

Controlled by two shift levers, the transmission provides 5 forward and 4 reverse speeds. One of the shift levers is for actuating the shifter forks within to select the speeds. The other lever is for selecting FORWARD or REVERSE. The gears on the shafts are of two kinds constant mesh helical gears and clutch gears. Some constant-mesh helical gears are mounted over roller bearings or splined to the shaft.

Each clutch gear consists of an outer ring with internal teeth and an inner ring (or boss) which is externally toothed and internally splined to run with the shaft. The outer ring is clutched by a shifter fork and slid ably meshed with its inner ring or hub so that the clutch gear as a whole runs with the shaft. In operation, the outer ring is actuated axially (along the shaft) by the fork to slide onto the mating external teeth formed on an adjacent constant-mesh gear. This displacement couples that constant-mesh gear to the shaft, thereby transmitting drive from shaft to gear or from gear to shaft, depending on which clutch gear is moved.

How these constant-mesh gears are selectively coupled with respective shaft to form a specific train of gears will be noted in the chart which follows:

DIRECTION	SPEED	DRIVE TRANSMITTING GEAR TRAIN	
FORWARD	1st	A-E-D-K	P - J
	2nd		O - I
	3rd		N - H
	4th		M - F
	5th	C-G	
REVERSE	1st	B-L	P - J
	2nd		O - I
	3rd		N - H
	4th		M - F

FLOW OF DRIVE

How drive flows through the transmission will be seen In the following description of the control operation for FORWARD FIRST taken as an example:

Shifting the FORWARD-REVERSE lever to (F)

position (for forward drive) causes F-R clutch gear on intermediate shaft to mesh with FORWARD gear (K). Next, shifting the SPEED lever to FIRST causes FIRST clutch gear on intermediate shaft to engage with adjacent gear (P) which is in constant mesh with gear (J)

Transmission


Description

splined to counter shaft. Under this condition, drive is transmitted from main shaft through gears (A),(E),(D),(K) and (P) to gear (J). Gear (A) runs with main shaft. Gears (E), (D) merely spin around countershaft and serve as an idler between gear (A) and gear (K). The F-R clutch gear couples gear (K) to intermediate shaft for forward drive. The FIRST (SECOND) clutch gear couples intermediate shaft to gear (P) to drive countershaft through gear (J).

The power for driving the work attachment is


taken from the rear end of the main shaft.

The axial position of the countershaft is set by the shim (standard: 0.3 mm) located at its forward end. For adjustment of the backlash and tooth-contact pattern in the bevel gear drive, countershaft is to be axially displaced by increasing or decreasing the amount of shim and the bevel gear too is to be similarly displaced along the axis of bevel gear shaft in the steering clutch-case.




Removal

1. Remove the floor plates.
2. Drain oil in hydraulic tank.
3. Remove the transmission under guard.
4. Drain the oil in transmission case removing the drain plug (1).




5. Disconnect the steering clutch control rods.
6. Disconnect the brake control rods and main-clutch control rods.
7. Remove all pipes standing in the way of the brake pedal support being removed and remove the support.
8. Remove the main-clutch booster.
9. Disconnect and remove the universal joint.

10. Remove the bolts (1) and detach the flange (2) for the oil strainer.







11. Pullout the cotter pin (1) and remove the pin (2) disconnecting the forward-reverse lever rod (3).




Transmission

Removal

12. Disconnect the battery cord remove the (1) (2), take out the side frames (3) (4) and remove the batteries (5) (6).




13. Remove the bolts (1) inside the battery box. Remove the bolts (2) (3) securing the operator's seat support, and take out the seat by lifting it with a hoist.



14. Remove the transmission case valve.

15. Remove the flange for connection with the universal joint,


16. Remove the bolts (1) (2) and take out the strainer (3).




Transmission

Description


17. Remove nuts (1). Pass the lifting sling under the transmission case to take a hitch on it, detach the case keeping in suspension from the steering case. Move the case slightly forward and carry it out of the machine by operating the crane.





18. Remove bolts (1) and remove the cover (shifter housing) from the transmission case. Use the hoist and lifting sling to remove the cover.



19. Remove bolts (1) (2) securing the fore and rear brackets, and take out the shifter fork assembly.




20. Remove bolt (1) and remove lock plate (2). Slowly take out shaft (3) and take out shifter forks (4) (5) (6) one by one as the shaft comes out.



Note: STEPS - (1) ~ (3) (5) ~ (9) (14)(15) ARE OUTLINED IN DETAIL IN CORRESPONDING STEPS OF MAIN-CLUTCH REMOVAL PROCEDURES.

TRANSMISSION

DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

1. Bolt	21. Shim	35-7. Collar
2. Spring washer	22-1. O-ring	35-8. Collar
3. Bolt	22-2. O-ring	35-9. Coupling gear
4. Spring washer	22-3. Bearing	35-10. Guide gear
5-1. Oil seal	22-4. Cage	35-11. Inner race
5-2. Cage	23. Cover	35-12. Bush
6-1. Seal ring	24. Collar	35-13. Collar
6-2. Holder	25-1. Inner race	35-14. Bush
7. Bolt	25-2. Bush	35-15. Gear
8. Spring washer	25-3. Collar	35-16. Collar
9-1. O-ring	25-4. Bush	35-17. Gear
9-2. Cover	25-5. Driven gear	35-18. Gear
10. Bolt	26-1. Guide gear	35-19. Key
11. Lock	26-2. Coupling gear	35-20. Key
12-1. Seal ring	27. Collar	35-21. Key
12-2. Holder	28. Bearing inner race	35-22. Key
13. Bolt	29-1. Bearing outer race	35-23. Main shaft
14. Spring washer	29-2. Bearing outer race	36-1. Coupling gear
15-1. O-ring	29-3. Gear	36-2. Guide gear
15-2. Cover	30. Collar	36-3. Inner race
16. Bolt	31. Collar	36-4. Bush
17. Lock	32-1. Inner race	36-5. Collar
18-1. Seal ring	32-2. Bush	36-6. Bush
18-2. Holder	32-3. Collar	36-7. Gear
19-1. O-ring	32-4. Bush	36-8. Spacer
19-2. Bearing	32-5. Gear	36-9. Inner race
19-3. Bearing cage	33. Spacer	36-10. Bush
20-1. O-ring	34-1. Inner race	36-11. Collar
20-2. Bearing	34-2. Bush	36-12. Bush
20-3. Bearing cage	34-3. Collar	36-13. Gear
	34-4. Bush	36-14. Coupling gear
	34-5. Gear	35-15. Guide gear
	35-1. Bolt	35-16. Inner race
	35-2. Lock	36-17. Bush
	35-3. Stopper	
	35-4. Pin	
	35-5. Nut	
	35-6. Bearing inner race	

Transmission

Disassembling

36-18. Collar

36-19. Bush

36-20. Gear

36-21. Bolt

36-22. Lock

36-23. Holder

36-24. Bearing inner race

36-25. Collar

36-26. Key

36-27. Key

36-28. Intermediate shaft

37-1. Dowel pin

37-2. Bearing inner race

37-3. Collar

37-4. Gear

37-5. Gear

37-6. Gear

37-7. Gear

37-8. Collar

37-9. Gear

37-10. Bearing inner race

37-11. Key

37-12. Key

37-13. Countershaft

38. Snap ring

39. Snap ring

40. Bearing outer ring

41. Snap ring

42. Snap ring

43. Bearing outer ring

44. Set screw

45. Dowel pin


46. Bearing outer race

47. Transmission case


Transmission

Disassembling


1. Place the transmission on a stable support, setting it up on its end as shown. Remove bolts (1) and cage securing bolts (3).




4. Straighten the lock plate (11), remove bolts (10) and remove holder (12) and lock plate.




2. Using jacking bolts, detach and remove cage (5).




5. Remove bolts (13) and remove cover (15)



3. Take out holder (6). Remove bolts (7) and remove cover (9).




6. Straighten the lock plate, remove bolts (16) and remove holder (18) and lock plate (17).



Transmission

Disassembling

7. Using jacking bolts; extract bearing cage (19). Similarly force out cages (20) (22).




8. Lift the Cover (23) off the transmission case.



9. Remove collar (24) and take out gear (25).



10. Take out guide gear (26-1) & coupling (26-2).



11. Mount the gear extractor as shown, and take out gear (29).



12. Take out: collar (27), bearing rollers and inner race (28) and gear (29), in that order.



Transmission

Disassembling


13. Take out collar (30) and collar (31). Remove gear (32).



14. Screw an eye bolt into the end face of the main shaft and take up the weight of the main shaft assembly (35) with a hoist. Take out gear (34), and lift the shaft assembly out of the transmission case.




15. Screw an eye bolt into the end face of the intermediate shaft, and lift the shaft assembly (36) out of the transmission case.



16. Screw an eye bolt into the end face of the countershaft, and lift the shaft assembly (37) out of the case.




17. Remove bolts (1) on the main shaft assembly (35), and remove lock (2) and stopper (3).




Transmission

Disassembling


18. Pullout pin (4) and remove nut (5).




20. Slide out guide gear (10) and gear (15).




19. Mount the bearing remover on the main shaft assembly removed. By operating the remover, draw out bearing (6), collar (7) and collar (8).



21. Take collar (16) off the shaft and remove gear (17).




22. Remove gear (18) and recover keys (19) (20) (21) (22) from the shaft.




Transmission

Disassembling


23. From the intermediate shaft (36), slide out coupling gear (-1) guide gear (-2) and gear (-7).




24. Take off spacer (8) and gear (13).




25. Draw out coupling gear (14), guide gear (15) and gear (20) from the intermediate shaft.



26. Using pliers, draw dowel pin(1) off the counter shaft (37).



27. Remove from the counter shaft the following parts: Bearing (2) collar (3) gear (4), gear (10) gear (6), gear (7), collar (8), gear (9) and bearing (10), in that order.



TRANSMISSION SHIFT MECHANISM

Description

Cleaning and Inspection, etc.

CLEANING AND INSPECTION

1. *Clean all parts thoroughly by washing.*
2. *Inspect gear teeth and splines for wear or damage.*
3. *Check the tips of shifter forks for wear or damage.*
4. *Inspect oil seals for damage.*
5. *Inspect the parts of the shafts where oil seals are located, and see if the surfaces are excessively worn or otherwise damaged.*


ASSEMBLING

Observe the following instructions in assembling the transmission:

1. *The three shaft assemblies are to be inserted into the transmission case in the order of countershaft, intermediate shaft and main shaft. Build up each assembly to the extent of the completeness in which it was removed in disassembling.*
2. *Be sure to discriminate one coupling gear from another, and to match the guide gears correctly to the respective coupling gears. Install the case cover (23) after all these gears have been put in.*
3. *Use three long bolts in fitting the bearing cages (19)(20)(22) into the case cover, and secure each cage by tightening its Securing bolts. Be sure to insert a proper amount of shim between cage (22) and cover (23) to obtain a proper mesh on each gear.*
4. *When securing the shifter fork brackets, check to be sure the tips of each fork are correctly riding on its coupling gear and then tighten the bolts on the brackets.*
5. *After all the shaft assemblies are installed, turn each gear by hand to see if it rotates smoothly or not.*
6. *After the shifter housing (case) is put on, operate the control levers to be sure the shifter forks will move properly and then secure the case in place by tightening the securing bolts.*

Transmission

TRANSMISSION SHIFT MECHANISM



- | | |
|------------------------------------------|------------------------------------------|
| 1. Forward-Reverse selector lever | 13. 1st and 2nd shift fork lever |
| 2. Forward-Reverse shifter lever | 14. Gear fork sub-shaft |
| 3. Gearshift lever | 15. 1st and 2nd shift fork |
| 4. Lever | 16. 3rd and 4th shift fork |
| 5. Boot | 17. 5th shift fork |
| 6. Gate | 18. Forward and reverse shift fork |
| 7. Interlock shaft | 19. 3rd and 4th shift fork lever |
| 8. Plunger | 20. Forward and Reverse shift fork leave |
| 9. 1st-2nd shift fork shaft | 21. Lever |
| 10. 3rd-4th shift fork shaft | 22. Dowel pin |
| 11. Forward and Reverse shift fork shaft | 23. Front bracket |
| 12. 5th shift fork shaft | |


DESCRIPTION

The shift transmission has four shifter forks. Three of them are controlled by the gearshift lever extending straight up through the cowl part of the shifter housing, the fourth one (FORWARD- REVERSE fork) being controlled by the other lever located by the side of the gearshift lever.

An interlock system is included in this mechanism to allow shifting of gears only when the main clutch is disengaged.

The bottom portion of the gearshift lever is pivoted in a box- like gate, which is in turn pivoted with pins to the housing. The gate determines the lateral position of the lever, allows the lever to move only one shift fork at a time, and urges the lever towards its centre position.

The cowl or top part of the housing is enclosed with a rubber boot to prevent entry of dust or water into the transmission.



INTERLOCK SYSTEM

- | | | |
|-------------------------|-----------------------|-----------------------|
| 1. Clutch gear | 6. Dowel pin | 11. Interlock shaft |
| 2. Fork | 7. Boot | 12. Main clutch shaft |
| 3. Sub-fork shaft | 8. Gearshift lever | 13. Gear |
| 4. Gearshift fork | 9. Plunger | |
| 5. Gearshift fork shaft | 10. Main clutch lever | |

The system consists of four interlocking plungers, each loaded with a coiled spring, and a recessed Interlocking shaft interconnected to the main clutch control lever, the point of interconnection being at the shifter housing.


The plungers are arranged in a row and slide in vertical holes provided in a bracket, which is bolted to the top of the transmission case and located within the shifter housing. The four shifter fork shafts extend through this bracket,

one shaft under one Interlocking plunger. That portion of each shaft under the plunger is dented at two (FIFTH SPEED shaft) or three (other three shafts) adjacent places such that the tip of the plunger drops into one of these dents arresting the shafts.

The recessed Interlocking shaft is directly above the row of plungers and limits the upward movement of these plungers except when the shaft turns and thereby allow each plunger to

Transmission

rise and slide out of the dent. By this arrangement, the shifter fork shafts are locked in their arrested positions as long as the main clutch is engaged. To say it in other words, the main clutch has to be disengaged first in order to shift the transmission to any speed position or back to neutral.



Disengaging the main clutch causes the interlocking shaft to turn to the unlocking position mentioned above. The Interlocking system also prevents the clutch gears within the

Transmission from slipping off due to tooth wear to excessive angling of the machine in traveling condition or to a sudden change of load.

One more interlocking arrangement comprising a dowel pin, a point dent on FIFTH SPEED shaft and a long dent on FORWARD-REVERSE shaft is provided in the shift mechanism. It is located at the forward end of FIFTH SPEED shaft and interlocks this shaft to FORWARD-REVERSE shaft for the purpose of eliminating fifth reverse speed in the transmission.

The dowel pin is slidably contained in a hole provided in the fore bracket, through which the four shifter fork shafts extend forward. The pin is positioned between FORWARD-REVERSE shaft and FIFTH SPEED shaft and has its one end riding on and within the long dent and other end riding on FIFTH-SPEED shaft.


FORWARD-REVERSE shaft can be moved forward (for forward drive) or backward (for reverse drive) and this stroke corresponds to the length of its long dent.

On the other hand, FIFTH-SPEED shaft can be moved forward, causing the dowel pin to ride out of its point dent, only if the other end of the pin is near the rear end slope of the long dent this shaft will not move forward if the pin is up against the fore end slope of the long dent, simply because, under such condition, it cannot force the pin to ride out of the point dent.

Thus, with FORWARD-REVERSE shaft in reverse position, the speed lever will not move into the position for FIFTH-SPEED.

GEARSHIFT LEVER

DISASSEMBLING




PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|-------------------|-------------------|-------------------|
| 1. Nut | 22-1. Pin | 38. Collar |
| 2. Lock | 22-2. Lock washer | 39-1. Key |
| 3. O-ring | 22-3. Adapter | 39-2. Shaft |
| 4. Spring | 23. Cover | 40. Oil seal |
| 5. Stopper | 24. Cotter pin | 41. Bearing |
| 6. Nut | 25. Nut | 42. Bearing |
| 7. Lock | 26. Screw | 43. Bolt |
| 8. O-ring | 27. Clip | 44. Spring washer |
| 9. Spring | 28. Cotter pin | 45. Cover |
| 10. Stopper | 29. Washer | 46. Gasket |
| 11. Bolt | 30. Pin | 47. Lock wire |
| 12. Spring washer | 31-1. Bush | 48. Screw |
| 13. Nut | 31-2. Bush | 49. Shaft |
| 14. Screw | 31-3. Gate | 50. Collar |
| 15. Clamp | 32-1. Bush | 51. Oil seal |
| 16. Boot | 32-2. Lever | 52. Bush |
| 17. Cotter pin | 33. Bolt | 53. Bush |
| 18. Cover | 34. Spring washer | 54. Case |
| 19. Spring | 35. Lock wire | |
| 20. Cover | 36. Screw | |
| 21. Gasket | 37. Lever | |

Gearshift Fork

DISASSEMBLING




PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

1.H Lock wire
 H2. Screw
 3. Lever
 4. Fore bracket
 5-1. Lock wire
 45-2. Screw
 5-3. Fork
 5-4. Shaft
 H6-1. Lock wire
 H6-2. Lock wire
 6-3. Boss

6-4. Shaft
 H7-1. Lock wire
 H7-2. Screw
 7-3. Lever
 7-4. Shaft
 H8-1. Lock wire
 H8-2. Screw
 8-3. Lever
 8-4. Shaft
 9-1. Bolt
 9-2. Lock washer


9-3. Plate
 9-4. Plunger
 9-5. Spring
 9-6. Plunger
 9-7. Spring
 9-8. Plunger
 9-9. Spring
 9-10. Plunger
 9-11. Spring
 9-12. Rear bracket

H Not shown in the illustration



1. Bolt
2. Cover
3. Nut
4. Strainer case
5. Magnet
6. Screen

STEERING OIL STRAINER



TRANSMISSION LUBRICATING SYSTEM

- | | | | |
|-----------------------------------|---------------------------|---------------------------|-------------------------------|
| 1. Water inlet
(From radiator) | 4. Oil filter | 9. Bevel pinion gear | 14. Transmission |
| 2. Water outlet
(To engine) | 5. Steering oil pump | 10. Main shaft | 15. Transmission front
end |
| 3. Oil cooler | 6. Relief valve | 11. Counter shaft | |
| | 7. Steering control valve | 12. Intermediate shaft | |
| | 8. Steering case | 13. Steering oil strainer | |

BEVEL GEAR AND BEVEL GEAR SHAFT

INDEX


DESCRIPTION	06-01
REMOVAL	06-02
DISASSEMBLING	06-03
INSPECTION	06-05
ASSEMBLING	06-05
TOOTH CONTACT ADJUSTMENT	06-06

Bevel Gear and Bevel Gear Shaft

Description

Bevel Gear and Bevel Gear Shaft

DESCRIPTION



BEVEL GEAR SHAFT COMPARTMENT

- | | | |
|---------------------|---------------------------|--------------------|
| 1. Bevel gear shaft | 4. Tapered roller bearing | 6. Bevel gear case |
| 2. Bevel gear | 5. Bearing cage | 7. Shim |
| 3. Reamer bolt | | |

Bevel Gear and Bevel Gear Shaft

Description Removal

The bevel gear drive is that part of the drive line where the output of the transmission is divided into two crosswise directions toward the right and the left, for driving the Sprocket wheels through steering clutches and final drive gear trains. Its major components are the bevel pinion, extending from the counter shaft of the transmission, and the bevel gear (2) mounted rigidly on the cross shaft (bevel gear shaft) (1).


Bevel gear (2) is secured to the flanged portion

of shaft (1) by 8 reamer bolts (3). Shaft (1) is supported in Journals in tow cages (5), right and left, by tapered roller bearings (4). The assembly of these components is housed in the steering case (6).


The backlash between bevel gear and pinion is specified. Backlash adjustment can be effected by reducing or increasing the thickness of shims (7) on each bearing case (5) to reposition the cage in place.

REMOVAL

1. Open each track chain. Lift the rear end off the floor by supporting it under the bevel gear case so that the sprockets can be turned by hand.



2. Drain oil from the bevel gear shaft compartment by removing the plug (1) at the bottom




3. Drain oil from the hydraulic oil tank by removing drain-plug. (Refer to "CONTROL VALVE".)
4. Remove the step board assembly, operator's seat, batteries, fuel tank, oil filter, and hydraulic tank. (Refer to the chapters on removal of these items.)
5. Disconnect all pipes from the top Cover of the bevel gear case.
6. Disconnect all the rods of the control lever. (Refer to "STEERING CONTROL REMOVAL")
7. Disconnect the control link rod, for braking, and steering clutches on each side. (Refer to "STEERING CONTROL REMOVAL").
8. Remove the control valve off from its place.
9. Take off the cover of the bevel gear case.
10. Remove the steering clutches and brake bands. (Refer to "STEERING CONTROL LEVER").

Bevel Gear and Bevel Gear Shaft

Disassembling

Disassembling




PARTS ARE TO BE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|-----------------|-------------------|--------------------------|
| 1. Nut | 10-3. Hub | 23. Lock washer |
| 2. Washer | 11. Bolt | 24-1. Bearing cage |
| 3. Collar | 12. Washer | 24-2. Shim |
| 4. Dowel pin | 13. Bolt | 24-3. Bearing outer race |
| 5-1. Seal ring | 14. Washer | 25-1. Bearing cage |
| 5-2. Seal ring | 15. Flange | 25-2. Shim |
| 5-3. Hub | 16. Flange | 25-3. Bearing outer race |
| 6. Nut | 17. Bolt | 26-1. Seal ring |
| 7. Washer | 18. Spring washer | 26-2. Seal ring |
| 8. Collar | 19. Bolt | 26-3. Seal ring |
| 9. Dowel pin | 20. Spring washer | 26-4. Bevel gear shaft |
| 10-1. Seal ring | 21. Reamer bolt | 27. Bevel gear |
| 10-2. Seal ring | 22. Nut | |


Bevel Gear and Bevel Gear Shaft

Disassembling


1. Remove the nut. (1)




4. Remove the bolts (17).




2. Using the special tool (No. 09780-00000) as shown pull out the hub (5).




5. Back off the reamer bolts (21) and detach bevel gear shaft (26) while suspending the bevel gear.



3. Remove the bolts (11) (13) securing the flange (15), and detach the flange.




6. Remove the bearing cage (24) and bevel gear shaft (26).



Bevel Gear and Bevel Gear Shaft

Inspection , etc.

7. *Detach the bearing cage (25) and bevel gear (27).*



INSPECTION

1. *Clean the bevel gear and check it for gear tooth wear, spalling or any other damage.*
2. *Inspect the fit of bevel gear shaft for any damage. Also examine the seal ring contacting surface for condition.*

ASSEMBLING

1. *Before building up the bevel gear group at the time assembling, thoroughly clean the steering clutch cases and bevel gear case.*
2. *Assemble the bevel gear group by reversing the procedure for disassembling.*
3. *After assembling, check and adjust the gear backlash and tooth contact in the bevel gear drive.*


Bevel Gear and Bevel Gear Shaft

Tooth Contact Adjustment


TOOTH CONTACT ADJUSTMENT

Roll a tooth contact pattern on the bevel gear and pinion using red-lead paste, to determine


whether or not the gear and pinion are properly positioned relative to each other.




Tooth contact pattern is uniform and extends about 80% of the tooth face from the toe.




High Contact




Low Contact




Toe Contact




Heel contact



Move pinion closer to gear. - Backlash will decrease. Increase the backlash by moving gear away from pinion. Move pinion away from gear.



Move pinion away from gear. Backlash will increase. Decrease the backlash by moving gear closer to pinion.



Move gear away from pinion. Backlash will increase. Decrease the backlash by moving pinion closer to gear.



Move gear closer to pinion. Backlash will decrease. Increase the backlash by moving pinion away from gear.


STEERING SYSTEM

INDEX

STEERING CLUTCHES	07-01
DESCRIPTION	07-02
STEERING BRAKES	07-04
DESCRIPTION	07-04
1. Forward crawling	07-04
2. Reverse crawling	07-04
REMOVAL	07-05
DISASSEMBLING	07-07
CLEANING AND INSPECTION	07-08
ASSEMBLING	07-08
MOUNTING	07-08
STEERING CONTROL VALVE	07-09
DESCRIPTION	07-09
DISASSEMBLING	07-14
INSPECTION	07-15
ASSEMBLING	07-15
GEAR PUMP	07-16
FILTER	07-17

STEERING SYSTEM

STEERING CLUTCHES



STEERING SYSTEM

- | | | |
|---------------------|---------------|----------------|
| 1. Bevel gear shaft | 6. Brake drum | 11. Hub |
| 2. Disc | 7. Piston | 12. Bevel gear |
| 3. Plate | 8. Spring | 13. Tube |
| 4. Pressure plate | 9. Tube | 14. Flange |
| 5. Inner drum | 10. Cage | |

Steering System

STEERING CLUTCHES

Description

DESCRIPTION


The steering system consists of two steering clutches, and two brake drums with the brake hand on either side of the bevel gear; hydraulic control valve, hydraulic pump etc.

The two steering clutch assemblies, one at each end of cross shaft (1), are identical in all respects except for one being a right-hand clutch and the other being a left-hand clutch.

Each clutch assembly is a combination of a drum type brake and a multi-disc wet type clutch, consisting of discs (2), plates (3),

pressure plate (4), Inner drum (5), brake drum (6), piston (7) and spring (8).

Springs (8) are so loaded as to keep the clutch engaged that is, to clamp discs (2) and plates (3) together and thereby transmit drive from shaft (1) to the final drive gear train. The clutch in this engaged condition is tight enough only to transmit drive for standing start or towing. It is the hydraulic pressure supplied to the clutch .at 10Kg/cm² that holds the clutch engaged or disengaged for earth moving work.



STEERING CLUTCH

- | | | |
|---------------------|---------------|----------------|
| 1. Bevel gear shaft | 6. Brake drum | 11. Hub |
| 2. Disc | 7. Piston | 12. Bevel gear |
| 3. Plate | 8. Spring | 13. Tube |
| 4. Pressure plate | 9. Tube | 14. Flange |
| 5. Inner drum | 10. Cage | |

STEERING CLUTCHES

Description

1. Steering Clutch in Engaged Position.

In the normal condition of the clutch, that is, in the hydraulically engaged condition, the steering clutch lever is in released a position and hydraulic pressure is applied from the control valve through tube (9), cage (10), hub (11) and inner drum (5) having an oil passage, to piston (7).


Piston (7) pushes the pressure plate (4) toward the bevel gear (12) side and holds the stack of discs (2) and plates (3) tight. The cumulative surface friction in the stack, so compressed tight, makes the stack behave like a solid body and transmit drive to the final drive gear train.

As piston (7) moves towards bevel gear side the oil on the other side of it, flows back to the control valve and is spilled into the drain line. The relief

valve provided in the control valve, from which hydraulic pressure is directed to the clutch, is set for 10.3 Kg/cm².

2. Steering Clutch In disengaged position

Pulling the steering clutch lever to disengage the clutch, causes the hydraulic pressure to take a new course. The new course is through tube (13), flange (14) and oil passage provided in the cross shaft (1), to piston (7). With the pressure being transmitted through this course, piston (7) pushes the pressure plate from opposite direction i.e. away from bevel gear (12) side, and release the stack of discs (2) and plates (3) from engaging. The oil in the space between piston and inner drum (5) becomes displaced and flows back to the control valve, from which it passes into the drain line.



1. Steering control valve lever
2. Spring
3. Brake lock lever
4. Brake pedal
5. Steering lever
6. Lock plate
7. Brake shaft pedal
8. Rod
9. Spring
10. Lever (Steering brake)
11. Steering brake Cover
12. Steering control valve assembly

STEERING LINKAGES

Steering System


STEERING BRAKES

Description

Steering Brakes

The two band-and-drum steering brakes are controlled by the respective brake pedals. The brake band has its inner face fitted with a lining. This lining is secured to the band by riveting.

The anchored point of the brake band shifts automatically when the drum changes its direction, as will be noted in the following illustration of the brake operation.



STEERING BRAKES

1. Forward crawling

Suppose the tractor is rolling forward and consider one of the brake drums to be rotating counter clockwise (for the purpose of illustration). As the brake pedal is depressed just a little, the friction between the drum (1) and band (2) causes the band to rise pushing pin (4) through pawl (3) into the groove provided in the bracket (5).

Depressing the brake pedal further will pull lever (6) in the direction (P) to move lever (7) in the

same direction as (P) with pin (4) acting as the pivot. This applies a pull to one end of the brake band by its pin (8) so that the band encloses the drum with full braking force.

2. Reverse Crawling

Suppose the same brake and directional designation as above, the brake drum now turns clockwise as the tractor rolls backward. Depressing the brake pedal just a little causes

STEERING CLUTCHES

Description


band (2) to displace itself in clockwise direction due to the friction between brake and drum. A downward pull acts on pin (8) and this applies a pull to pin (10) through the rod, forcing the pin into the groove of bracket (5).

Depressing the pedal further will pull lever (6) in the direction (P), making lever (7) pivot around pin (10) and move in the same direction. As a result, pawl (3) pushes the end of the downward to apply braking force to the drum.


REMOVAL

While removing and replacing the steering system, be sure to handle the complete assembly of the clutch and brake band as unit.


1. Dismount the fuel tank and operator's seat. (Refer to "FUEL TANK REMOVAL" and "OPERATOR'S SEAT REMOVAL")
2. Take out all floor plates
3. Disconnect oil lines (1) (2), and separate rubber hoses (3) (4). Disconnect the steering control rods (5) (6) and brake control rods (7) (8), respectively.



4. Remove the bolts (1) (2) and take out the control valve assembly (3).




5. Remove the bolts (1) and take off the cover (2). Remove the bolts to take off the cover (4).




Steering System

Removal



6. Remove the Cover (1) and take out the spring (2).




7. Pull out the cotter pin (2) on the pin (3). Pull out the pin (3) and remove the yoke (1). Remove the bolts (4) and dismount the brake link assembly.



8. Remove the clutch mounting bolts (1) on both sides one at a time, by gradually rotating the sprocket until all bolts are removed. Using an overhead crane take out the clutch assembly (2) with the brake band.




DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|-------------------|----------------|-------------------|
| 1. Brake drum | 6. Disc | 9. Spring |
| 2. Bolt | 7. Plate | 10-1. Snap ring |
| 3. Nut | 8-1. Key | 10-2. Ring plate |
| 4. Lock plate | 8-2. Seal ring | 10-3. Clutch drum |
| 5. Pressure plate | 8-3. Seal ring | |
| | 8-4. Piston | |

Note: WHILE REMOVING NUTS (3) IN PLACE, BE SURE TO PLACE A RETAINER SO AS NOT TO ALLOW SPRING (9) TO POP UP FROM THE CLUTCH DRUM.



Steering System

Cleaning and Inspection, etc.

CLEANING AND INSPECTION

1. *Inspect the clutch linings for wear or contact pattern.*
2. *Examine the clutch plates and discs for wear, deformation, erratic wear pattern, including stepped or uneven wear, or scar or groove marks. Clean these parts thoroughly.*
3. *Examine the teeth of drums, plates and discs for wear or damage.*
4. *Inspect the adjusting bolts for wear or damage.*
5. *Inspect the brake linings for contact pattern or wear and check the lining rivets for tightness.*
6. *Inspect the brake bands for damage*
7. *Examine the friction surfaces of the brake drums for wear or damage.*
8. *Examine the pistons, particularly the piston ring grooves, for wear or damage.*
9. *Check the clutch piston seal rings for wear.*
10. *Examine the friction surfaces of clutch inner drums and the pistons for wear or damage.*
11. *Inspect the brake control linkages for wear or damage.*

ASSEMBLING

Note: REVERSE THE PROCEDURE OF DISASSEMBLING WHEN SECURING THE PISTON (FOR THE CLUTCH) TO THE PLATE, BE SURE TO LOCK THE SECURING NUTS IN PLACE.


MOUNTING

Replace in position the steering clutch brake assembly by adhering to the following note:

Note: IN CASE WHEN THE CLUTCH COUPLING BEARING HUB AND FINAL DRIVE FLANGE HAVE BEEN REPLACED BY THE

NEW ONES, THE STEERING CLUTCH ASSEMBLY SHOULD BE MOUNTED IN PLACE ONLY AFTER THESE TWO PARTS HAVE BEEN ALIGNED PROPERLY.

Steering Control Valve



STEERING CONTROL VALVE

This valve is located below the operator's seat and mounted on the top of the steering case. It is an assembly of valves two control valves of spool type and relief valve of spring-loaded piston type. These valve elements are built in a single body the relief valve being a separate element mounted top of the body.

Two levers (steering clutch levers) one for each spool, are provided, to operate the spools manually and thus change the course of hydraulic pressure transmission for controlling the respective steering clutch.


The relief valve is on the upstream side of the two control valves and limits the pressure being applied from a gear pump through a filter. The specified pressure setting is 10.3 Kg/cm². The Inlet port is designated as "A".

A relatively large amount of oil is supplied by the gear pump so that the relief valve is normally in relieving condition, under which its spring (1) is compressed by oil pressure within spool (2) while this spool itself is in a displaced position keeping the relieving port (B) open.

Description


STEERING CONTROL VALVE

STEERING SYSTEM



STEERING CONTROL VALVE

Description




RELIEF VALVE

1. Spring

2. Spool

1. Left steering clutch "ON" - Right steering clutch "ON".



L.H. Clutch "ON"

R.H. Clutch "ON"

STEERING CONTROL VALVE SYSTEM

Steering System


STEERING CONTROL VALVE

Description

When the steering clutch levers are in normal position (corresponding to the engaged position) hydraulic oil passes through Spools (1) (2) and

enters the right and left lines for keeping the right-hand and left-hand steering clutches engaged.

2. Left steering clutch "OFF" - Right Steering clutch "ON".



L.H. Clutch "OFF"


R.H. Clutch "ON"

Pulling the left steering clutch lever move spool (1) in direction (P) to open port (A) communicating to the disengaging side of piston in the left steering clutch, and disengaging L.H. Steering clutch position, Port (B) is open and

hydraulic oil is supplied through this port which communicates to the engaging side of piston in the right-hand steering clutch, causing the R.H. steering clutch engaged.

With the right steering clutch in released

3. Left steering clutch "ON" - Right steering clutch "OFF".



L.H. Clutch "ON"

R.H. Clutch "OFF"


Pulling the right clutch lever moves spool (2) in the direction (P) to open port (B), which causes the disengagement of R.H. clutch.

With the left steering clutch lever released, port (A) is open. The L.H. clutch would be engaged.

STEERING CONTROL VALVE

Description

4. Left steering clutch "OFF" - Right steering clutch "OFF"



L.H. Clutch "OFF"

R.H. Clutch "ON"

With both steering clutch levers pulled into disengaging position spools (1) (2) remain displaced in the direction (P), keeping both ports (A) (B) open to apply pressure to the


disengaging side of piston in each steering clutch. The steering clutches on both sides would be disengaged.

Steering System

Description

DISASSEMBLING

Before removing the steering control valve, refer to "STEERING SYSTEM" for details.



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | | |
|-------------------|---------------------|---------------------|-------------------|
| 1. Bolt | 10. Bolt | 21-5. Oil seal | 30-4. Key |
| 2. Spring washer | 11. Spring washer | 21-6. Bushing | 30-5. Oil seal |
| 3. Bolt | 12. Cover | 21-7. Shaft | 30-6. Bushing |
| 4. Spring washer | 13. Gasket | 22. Lock wire | 30-7. Shaft |
| 5. Bolt | 14. Lock wire | 23. Set screw | 31. Bolt |
| 6. Spring washer | 15. Set screw | 24. Bolt | 32. Spring washer |
| 7-1. Snap ring | 16. Bolt | 25. Spring washer | 33. Plate |
| 7-2. Stopper | 17. Spring washer | 26. Key | 34-1. Snap ring |
| 7-3. O-ring | 18. Key | 27. Collar | 34-2. Washer |
| 7-4. Piston | 19-1. Cotter pin | 28-1. Cotter pin | 34-3. Spring |
| 7-5. Relief valve | 19-2. Washer | 28-2. Washer | 34-4. Spool |
| 7-6. Spring | 19-3. Pin | 28-3. Pin | 35-1. Snap ring |
| 7-7. Snap ring | 19-4. Roller | 28-4. Roller | 35-2. Washer |
| 7-8. Stopper | 20. Collar | 28-5. Lever | 35-3. Spring |
| 7-9. O-ring | 21-1. Bolt | 29. Collar | 35-4. Spool |
| 7-10. Housing | 21-2. Spring washer | 30-1. Bolt | |
| 8. O-ring | 21-3. Lever | 30-2. Spring washer | |
| 9. O-ring | 21-4. Key | 30-3. Lever | |

INSPECTION

1. *Examine the sliding surface of the spools for rusting or signs of improper sliding contact.*
2. *Inspect the valve body for cracks or any other damage, and check running clearance around each spool in the bore.*
3. *Check springs for elastic property by measuring the free length, as-Installed length and the preload. Also Inspect each spring from damage.*

ASSEMBLING

To build up the steering control valve, observe the following Instructions:


1. *When assembling a valve, body, make sure that the valve moves smoothly into the bore of the valve body.*
2. *When fitting the oil seals in place, take care not to damage or form scratches on them.*

Steering System

GEAR PUMP

Description

Gear Pump



STEERING OIL PUMP

- | | | | |
|----|----------------|-----|----------------|
| 1. | Oil seal | 6. | Needle bearing |
| 2. | Bracket | 7. | Housing |
| 3. | Needle bearing | 8. | Reamer bolt |
| 4. | Drive gear | 9. | Bolt |
| 5. | Gear case | 10. | Driven gear |

The steering oil pump, located on the left side of the engine, on the flywheel housing, is a gear pump. It is driven by the crankshaft through a gear train.


It draws oil from the steering case through the strainer and delivers pressurised oil to the steering control valve as long as the engine is running.

This gear pump, like any other gear pump, is a precisely finished device, with its pumping gears, bores and side plates machined to much looser tolerances.

The figure indicates various component parts of pump. For full details of parts please refer to parts catalogue.

Filter

STEERING CONTROL OIL FILTER



1. Cover
2. Air vent plug
3. Bolt
4. Filter case
5. Element

The filter is mounted on the side frame, on the left side of the flywheel housing. It filters the oil discharged by the steering oil pump.

The element used for filtering oil is of paper type.


FINAL DRIVE

INDEX

DESCRIPTION	08-01
REMOVAL	08-02
DISASSEMBLING	08-03
CLEANING AND INSPECTION	08-08
ASSEMBLING	08-08

Final Drive

DESCRIPTION



FINAL DRIVE

- | | | | | | |
|----|----------------------|-----|-----------------------|-----|--------------------|
| 1. | <i>Bearing</i> | 6. | <i>Flange</i> | 11. | <i>Sprocket</i> |
| 2. | <i>Floating seal</i> | 7. | <i>Gear</i> | 12. | <i>Nut</i> |
| 3. | <i>Floating seal</i> | 8. | <i>Sprocket shaft</i> | 13. | <i>Track frame</i> |
| 4. | <i>Second pinion</i> | 9. | <i>Hub</i> | | |
| 5. | <i>1st pinion</i> | 10. | <i>Second gear</i> | | |

Final Drive

Description

The final drive gear train is in two-stage reduction with two spur gears and two pinions, all housed in a case bolted to the steering case.

No. 1 pinion has the Inner end of its shank inserted into the Involute-splined hub of the brake drum flange and the outer end held in the final drive case. No.1 gear, meshed with No. 1 pinion, keyed to the shank of No.2 pinion to form a built-up gear member. No.2 gear, meshed with No.2 pinion, is bolted to the flanged part of the sprocket wheel hub. This hub is mounted over the roller bearings on the sprocket wheel shaft, and the sprocket wheel is bolted to the flanged portion of this hub with 6 keys.

The pinion bearings are of roller type. The bearings by which the assembly of the hub and sprocket wheel rotate around the sprocket wheel are of the spherical type.


The sprocket wheel shaft, extending through the final drive case, is press-fitted through the steering case and has its inboard end rigidly gripped and secured to the mid-section underside of the steering case, while its outboard end is connected to the track frame by means of support bracket doweled and bolted to the top of this frame. Thus the rear section of the tractor chassis loads on the track frames, right and left through the two sprocket wheel shafts.

The running clearance between the final drive case and the sprocket wheel complete with the hub is provided with a floating seal mechanism, which positively keeps off dirt and water to protect the oil within the final drive case.


The bottom section of the case forms an oil bath, from which oil is splashed up to lubricate the internal running members including the roller bearings.

REMOVAL

1. Open the tracks. Disassemble the track frame. (Refer to "TRACK REMOVAL" and "TRACK GROUP REMOVAL").
2. Remove the steering clutches and brake assemblies.
3. Remove oil in each final drive case by draining.




DISASSEMBLING



Final Drive

Disassembling



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING


- | | | |
|-------------------|---------------------|----------------------|
| 1. Bolt | 15. Lock washer | 25-4. O-ring |
| 2. Spring washer | 16-1. Seal ring | 25-5. Bearing |
| 3. Cover | 16-2. O-ring | 25-6. Bolt |
| 4. Gasket | 16-3. Bolt | 25-7. Spring washer |
| 5. Nut | 16-4. Spring washer | 25-8. Cover |
| 6. Lock | 16-5. Cover | 25-9. Shim |
| 7. Spacer | 16-6. O-ring | 25-10. O-ring |
| 8-1. Seat ring | 16-7. Sprocket | 25-11. Bearing |
| 8-2. O-ring | 17. Retainer | 25-12. Seal ring |
| 8-3. Bushing | 18. O-ring | 25-13. O-ring |
| 8-4. Support | 19. Bolt | 25-14. Bolt |
| 9. Bolt | 20. Spring washer | 25-15. Spring washer |
| 10. Spring washer | 21. Bolt | 25-16. Cover |
| 11. Stopper | 22. Spring washer | 25-17. O-ring |
| 12. Dowel pin | 23. Bolt | 25-18. Case |
| 13-1. Seal ring | 24. Spring washer | 26. Gasket |
| 13-2. O-ring | 25-1. Bolt | 27. Dowel pin |
| 13-3. Nut | 25-2. Spring washer | 28. Spacer |
| 14. Bolt | 25-3. Bracket | 29. Seal |

Final Drive


Disassembling

30-1. Key	31-4. Key	41-1. Shim
30-2. Nut	31-5. Pinion	41-2. O-ring
30-3. Lock	32. Bearing, inner race	41-3. Bearing
30-4. Reamer bolt	33. Bolt	41-4. Oil seal
30-5. Gear	34. Nut	41-5. Bearing cage
30-6. Bearing	35. Lock	42. Ring
30-7. Bearing	36. Spacer	43. Lock pin
30-8. Sprocket hub	37. Flange	44. Nut
31-1. Bearing inner race	38. Pinion	45. Key
31-2. Washer	39. Bolt	46. Shaft
31-3. Gear	40. Spring Washer	


4. Remove the bolts (1), and take off the cover (2) and gasket.




6. Remove the nut (13). Parts 13-1 thru. 13-3 are to be removed.



5. Remove the nut (5), take off the lock (6) and spacer (7). Dismount the support assembly (8). This removal involves parts 8-1 thru. 8-4.




7. Remove the bolts (14), take off the lock (15) and draw off the sprocket assembly (16) complete with the retainer (17).




Final Drive

Disassembling

8. Draw the sprocket (16) off the hub with a special tool (No. 09713-00000). Parts 16-1 thru 16-7 are to be removed.




11. Draw off the gear (30) with a special tool (No. 09703-00000). Parts 30-1 thru 30-8 are to be removed.




9. Remove the bolts (19) (21) and spring washer (23).




12. Draw out the gear and pinion (31) Parts 31-1 thru 31-5 are to be removed.



10. With an overhead crane, hang the case (25). Parts 25-1 thru. 25-18 are to be removed.




13. With a puller, remove the bearing inner race (32) from the shaft.




Final Drive

Disassembling


14. Flatten the lock (35) and remove the nut (34).



17. Remove the bolts (39) and the bearing case (41) by using jacking screws. Parts 41-1 thru 41.5 are to be removed.





15. Take out the flange (37) with a Puller (No.09710-00000).



18. With a special tool (No.09717-00000), draw out the sprocket shaft (46). (Normally this shaft need not be removed).

Note: UNLESS IT IS NECESSARY DON'T REMOVE THE SHAFT.

16. Draw out the pinion (38).



Final Drive

Cleaning and Inspection, etc.

CLEANING AND INSPECTION

1. *Wash all removed parts clean, and dry them with compressed air if available.*
2. *Inspect each final drive case for cracks or any other damage. Repair or replace the case if necessary.*
3. *Check the gear teeth for wear. Inspect the gear teeth for contact pattern.*
4. *Check wear of the reamer bolts, with which the last gear is secured to the sprocket hub.*
5. *Check the sprocket shaft for straightness. Repair or replace the shaft if necessary.*
6. *Check the teeth of the sprocket for radial wear by using the contour gauge. Measure the tooth width to determine the extent of lateral wear. Repair the teeth, or replace the sprocket as necessary.*

ASSEMBLING

Instructions to be followed in assembling and mounting the final drive groups are as follows:

1. *Before installing the final drive case in place make sure that the gasket between this case and the steering case is of the prescribed thickness.*
2. *Where a replacement final drive case is to be installed, tentatively build the final drive gear train with the replacement case in place making sure each gear is properly aligned, and then fix the position of the final drive case anew with respect to the steering case by dowelling.*
3. *When mounting sprocket wheels center the wheel relative to the sprocket shaft and push the wheel slowly onto the sprocket hub so as not to disturb the seal rings in the place.*
4. *Use extreme care in handling floating seals not to drop them on the floor.*
5. *Before fitting the floating seal rings, make sure that rings are all clean. Apply oil to the faces of rings just before putting them in the place.*
6. *Apply grease to the oil seals and O-rings before fitting them in the place.*

CONTROL SYSTEM

INDEX


DESCRIPTION	09-01
FUEL CONTROL LEVER	09-02

Control System

The Operator's seat is located on the rear side of the Tractor. Tractor speed change levers and the hydraulic blade control lever for dozer blade operation are located on the right side of the Operator's seat.

The two steering clutch levers right and left are located in front of the Operator's seat. The corresponding brake pedals are positioned on the floor board along with pedal locking levers for the purpose of parking.

Fuel control lever is on the right side of the steering clutch levers. Pulling down the fuel control lever allows a higher quantity of the fuel injected and the engine runs at full speed. The rotary disc of the fuel control lever is spring loaded, so that by the friction of this disc, the lever is forced to stay in any position selected within its range. The Engine idles with the lowest idling speed if the lever is pushed all the way up against its stopper.




- | | |
|---------------------------------|----------------------------------|
| 1. Steering clutch lever (L.H.) | 6. Brake Pedal (R.H.) |
| 2. Steering clutch lever (R.H.) | 7. Forward and Reverse lever |
| 3. Fuel Control lever | 8. Gear Shift lever |
| 4. Main Clutch lever . | 9. Hydraulic blade control lever |
| 5. Brake Pedal (L.H.) | |

Control System

Description _____

Fuel Control Lever



FUEL CONTROL LEVER

- | | | | |
|----|--------------------|----|-----------|
| 1. | Fuel control lever | 4. | Dashboard |
| 2. | Clutch | | |
| 3. | Governor | | |


UNDER CARRIAGE

INDEX

GENERAL	10-01	Removal	10-14
Removal	10-02	Disassembling	10-15
Mounting	10-03	Inspection	10-15
		Assembling and Mounting	10-15
TRACK FRAMES			
Description	10-04		
TRACKS		TRACK ROLLERS	
Description	10-05	Description	10-16
Removal	10-06	Removal	10-17
Disassembling	10-07	Disassembling	10-18
Inspection	10-07	Inspection	10-19
Assembling	10-07	Assembling	10-19
Mounting	10-07		
IDLERS		RECOIL SPRING	
Description	10-08	Description	10-20
Removal	10-09	Removal	10-21
Disassembling	10-10	Disassembling	10-21
Cleaning and Inspection	10-11	Inspection	10-22
Assembling	10-11	Installation	10-23
Mounting	10-12		
CARRIER ROLLERS		EQUALIZER SYSTEM	
Description	10-13	Description	10-24
		Removal	10-25
		Inspection	10-25

UNDERCARRIAGE

General



UNDERCARRIAGE

- | | | |
|---------------------------|-------------------|-----------------------|
| 1. Sprocket cover | 4. Carrier roller | 7. Track frame |
| 2. Sprocket | 5. Track shoe | 8. Track roller |
| 3. Removal spring housing | 6. Idler | 9. Track roller guard |

Each track group consists of a track frame on which the sprocket wheel, idler wheel, carrier rollers and track rollers are mounted, and includes a track, that is a looped chain complete with shoes.


The sprocket wheel is driven from No.2 spur gear in the final drive and pulls the track by its sprockets or teeth. By reaction occurring in this pulling action, the sprocket wheel exerts forward

or backward thrust to the track frame, depending on the direction of its rotation. The track frame with its track rollers riding on the track, moves forward or backward relative to the ground, thus propelling the tractor as a whole. The carrier rollers support the upper span of the track and the idler keeps the track in proper tension and, with its recoil spring absorbs shocks occurring when it comes across with the obstacles during operation.

Undercarriage



Removal

REMOVAL



- | | | |
|----------------|--------------------------|-------------------------|
| 1. Track frame | 4. Recoil spring housing | 7. Track roller |
| 2. Sprocket | 5. Sprocket cover | 8. Guard, Track rollers |
| 3. Idler | 6. Carrier-roller | 9. Track shoe |


1. Open the tracks. (Refer to "TRACK REMOVAL").
2. Lift the chassis off the floor with hydraulic jacks or an overhead crane, and block up the chassis. The blocks are to be placed against the embossed parts of steering case through which sprocket shafts extend (rear end) on.




Undercarriage

Removal, Mounting

3. Remove the bolts (1) and the sprocket side cover (2).




5. Remove the bolts (2) to detach the track frame (3) from the sprocket bearing (1).



4. Lift the track frame assembly from above by hitching a lifting cable to the carrier rollers.



6. Remove the bolts (1) and the diagonal brace cap (2). The track frame assembly is now ready to be carried away in suspension.



MOUNTING

To mount the track frame to the chassis, reverse the removal procedure, adhering to the following Instructions :


1. Before mounting the track assembly, make sure that the equalizer bar is correctly positioned in its place.
2. Torque limits are specified for the bolts

securing the diagonal brace caps and the sprocket shaft bearings to track frames.

3. Before securing the sprocket shaft bearings in the place, check the centre-to-centre distance between the front idlers as 2000 ± 8 mm.

Description

Track Frames




TRACK FRAME

- | | | |
|---------------------------|-------------------|-----------------------|
| 1. Carrier roller bracket | 4. Sprocket cover | 6. Track frame |
| 2. Carrier roller | 5. Diagonal brace | 7. Track roller guard |
| 3. Recoil spring cover | | |

The track frame is a built-up steel structure shaped to present a box-like construction in cross section and fabricated with steel plates by welding. It is designed particularly strong to withstand the severe shock loads to which it is subjected during duty operation or under traveling condition.

The diagonal brace whose inner end is rotatably connected to the sprocket wheel shaft below the steering case, is welded to inside of the track frame so that the brace holds the frame in proper geometrical relationship with respect to the main frame and permits the frame to rock around the sprocket shaft. With this arrangement, Idler is capable to move up-and-down.

Tracks



- 1. Shoe bolt
- 2. Dust seal

- 3. Track link
- 4. Bushing

- 5. Shoe
- 6. Pin

DESCRIPTION


DUST SEAL

The track is an endless chain of identical segments, each segment being composed of two rail links, right-hand and left-hand a pin for connecting two segments, a bush for spacing the two rail links apart, and a shoe bolted to the links,

The trailing link ends of one segment are overlapped on the leading link ends of the following segment, the former end coming on the inner side of the latter end. Two rails are formed by the links so linked up.

The trailing ends are capable of turning around the pin, while the leading ends are press-fitted to the pin. A dust seal is fitted in the counter bore of the pin hole of each leading end. This seal is located between two overlapped link ends and keeps off dust, dirt and grits to protect the running clearance between the pin and bush. If the seals are not provided, the tracks, would rapidly stretch in service to result in the fast wear between the sprockets and roller flanges.

Two master pins are provided in each track. A connection made with a master pin and bush can be more easily undone. Whenever the track has to be opened, the chain should be opened at the master pin. The master pin and bush are different from other pins and bushes. The ends of each master pin are stepped for identification.





Removal

REMOVAL


1. Loosen plug(1) to relieve the pressure (grease) in the grease cylinder in order to slacken the tracks.

Note: IF NO GREASE BLEEDS OUT, DRIVE THE MACHINE BACK AND FORT GIVING A JERK. THIS WILL FORCE OUT SOME GREASE AND SLACKEN THE TRACK CHAIN.



3. Where the existing tracks are to be replaced by another set of tracks, line up the replacing tracks on the floor to form extensions of the ones to be replaced, and drive the machine over to the new tracks.

2. With a hydraulic jack press, remove, the master pin out to open the links. After both track links have been opened, drive the machine to lay the tracks down on the floor. Be sure to use a special tool (No. 09731800000) to open the tracks.




TRACKS

Disassembling, etc.

DISASSEMBLING

1. Remove the shoe bolts (1) and remove shoe (2). Repeat this step to remove all shoes.



2. Using the press, force out one pin after another, starting from the end where master bushing (3) is located. Adhere to the following Instructions.


Note: 1. BEFORE PUSHING EACH PIN OUT, MAKE SURE IT WILL SLIDE OUT WITHOUT GALLING THE BORE IN THE LINK,

2. IF THE PRESS FOR DISASSEMBLING TRACKS IS NOT AVAILABLE, THE TRACK MAY BE CUT WITH A CUTTING TORCH TO REMOVE ANY PORTION OF THE TRACK FOR RENEWAL. THE FLAME CUTTING PROCEDURE IS AS FOLLOWS:

- (i) CUT THE PAIR OF LINKS IN

INSPECTION

1. Inspect each track shoe for cracks or wear of its grouser.
2. Inspect the links, bushings and dust seals for wear, and check the link height and



THE MIDDLE.

- (ii) REMOVE A 15-MM LONG MID-PORTION OF EACH BUSHING BY FLAMECUTTING.
- (iii) TO REMOVE THE HALF PIN FROM THE PRECEDING LINK, APPLY FLAME TO THE EMBOSSED END OF THE LINK AND DRIVE THE HALF PIN OUT.
- (iv) REMOVE OTHER HALF LINKS (1) (2) FROM THE FOLLOWING LINKS.
- (v) WHEN CONNECTING NEW LINKS TO TAKE THE PLACE OF THE PAIR REMOVED BY FLAME-CUTTING, BE SURE TO USE DUST SEALS AT BOTH END OF EACH NEW BUSHING.

bushing O.D. Also check the overall stretch, if any, in each track chain.

3. Check the shoe mounting bolts for tightness. Replace excessive worn bolts

ASSEMBLING

Reverse the disassembling procedure, by adhering to the following rule :

1. Apply oil to the bushings and pins before press-fitting them into the links.


MOUNTING

While mounting the tracks on the track frames, move the machine back and forth so

as to connect the tracks at front idlers master pins.

Description

Idlers



IDLER

- | | | |
|------------------|------------------|------------------|
| 1. Guide plate | 4. Floating seal | 7. Idler bearing |
| 2. Idler bracket | 5. Idler | 8. Track frame |
| 3. Idler shaft | 6. Idler bearing | |

DESCRIPTION


The idler is made of High tensile Alloy Steel Casting present a box-like shape in its radial cross-section. It is rotating on the idler shaft. The idler shaft, extending through the bushed bore of the idler hub, is fitted at its two ends in the two sliding brackets, to which a yoke is bolted.

The running clearance between Idler shaft and bush is filled with oil. This oil is hermetically contained by two floating seals.


The brackets are held to the track frame by the two spring-loaded guide plates and slide on the top of the track frame in fore-aft direction along the guideways.

REMOVAL


1. Open the tracks. (Refer to "TRACK REMOVAL").
2. Remove the bolts (1) (2) and take off covers (3) (4).



3. Remove the bolts (1) and dismantle the carrier roller and bracket (2) as an assembly




4. Remove the bolts (3) on the flange to disconnect the cylinder (1) and rod (2).




5. Remove two rubber pads (1).




6. Remove the bolts (1) securing the idler guide in the place.



7. Lift up the equalizer bar seat complete with the idler assembly, using an overhead crane.



DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING.

1. Bolt	14-4. Shims	22-4. Dowel pin
2. Spring washer	14-5. Bracket (R.H.)	22-5. O-ring
3. Scraper (L.H.)	15. Seal ring	22-6. Bearing
4. Bolt	16. O-ring	23. Bolt
5. Spring washer	17-1. Bolt	24. Lock washer
6. Scraper (R.H.)	17-2. Spring washer	25-1. Shaft
7. Bolt	17-3. Guide plate	25-2. O-ring
8. Spring washer	17-4. Shims	25-3. O- ring
9. Yoke	17-5. Bracket (L.H.)	25-4. Seal ring
10. Nut	18. Seal ring	25-5. O-ring
11. Spring washer	19. O-ring	25-6. Bearing
12. Washer	20. Bolt	25-7. Dowel pin
13. Bolt centering	21. Lock washer	25-8. O-ring
14-1. Bolt	22-1. Seal ring	25-9. Bearing
14-2. Spring washer	22-2. O-ring	26. Idler
14-3. Guide plate	22-3. Bearing	

CLEANING AND INSPECTION

1. *Inspect the idler for cracks or any other damage. Check its O.D and the width of its peripheral land to determine the amount of wear.*
2. *Check the shaft O.D and bearing I.D to determine the amount of wear. Check also*
3. *Check wears on the thrust surfaces of the shaft bearing flange and bushing.*

ASSEMBLING

To assemble the idlers, reverse the disassembling procedure, adhering to the following instructions:

1. *The bushings of the idlers are to be pressed into the bore with the use of the same press for the track roller removal.*
2. *When fitting the idler bushings, first position each bushing with its bolt holes aligned to*
3. *those in the idler and then start pushing them into the bore. Of the two bushings for each idler, one is to be forced in from the outer side and the other from inner side.*
3. *Before installing the idler shaft set bolts apply LOCK TIGHT to these bolts, and tighten them to the specified torque limits.*

MOUNTING


MOUNTING

To mount the idlers, reverse the removal procedure by adhering to the following instructions.


1. Adjust the thickness of shim (3) to obtain a clearance of not more than 1 mm between the idler shaft guide (2) and the track frame (1).
2. Each idler shaft is to be so positioned as to bring its lubricant-charging end to outer side of the following track frame.

R.H. track frame outer side

L.H. track frame outer side



Carrier Rollers



- | | | |
|---------------------------|-------------------|-------------------------|
| 1. Carrier roller bracket | 4. Floating seal | 7. Taper roller bearing |
| 2. Carrier roller shaft | 5. Seat | 8. Cover |
| 3. Seal guide | 6. Carrier roller | 9. Oil plug |

Two carrier rollers are provided in each track group to support the upper span of the track between the idler and the sprocket wheel.

Each carrier roller rotates on its shaft whose one end is gripped in a bracket and other end extend like a cantilever. The bracket is bolted to the top of the track frame. Two tapered roller bearings are positioned between the shaft and the roller. At each end of the roller in place, a floating seal is provided to hermetically contain the lubricating oil in the cavity around the shaft.

The floating seal used on the carrier rollers are basically similar to other floating seals in design. Sealing action is accomplished in these seals by a number of successive annular sliding contacts interposed between two end members one being stationary and the other being rotary. The sliding speed of each contact is but a fraction of the rotating speed of the rotary member relative to the stationary member.

Removal



Floating Seal

Specifically the floating seal of a carrier roller consists of the seal support, two seal rings mating to each other by precisely finished faces, two a-rings each provided on


a seal ring, and additional O-ring. Because of the low sliding speed the wear of these sliding parts of the seal is greatly minimized.

REMOVAL

1. *Open the tracks. (Refer to "TRACK REMOVAL").*
2. *Remove the bolts (1) securing the roller shaft, and remove the roller assembly from support (2). If the shaft does not come off the support easily, (lightly tap on the bearing side to shake the shaft loose).*
3. *The carrier roller can be removed without the removal of the track chain. This can be done by slackening the track as much as possible and by jacking up the upper span of track from bottom, with hydraulic Jack on the recoil spring cover.*



DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|------------------|----------------|---------------------|
| 1. Bolt | 6-2. O-ring | 7-6. O-ring |
| 2. Spring washer | 6-3. Shaft | 7-7. Seal guide |
| 3-1. Cover | 7-1. Seat | 7-8. Dowel pin |
| 3-2. O-ring | 7-2. O-ring | 7-9. Dowel pin |
| 4. Snap ring | 7-3. O-ring | 8-1. Bearing |
| 5. Nut | 7-4. Seal ring | 8-2. Bearing |
| 6-1. Snap ring | 7-5. Seal ring | 8-3. Carrier roller |

INSPECTION


1. Check the track and flange faces of each carrier roller for wear.
2. Inspect the bearing for any sign of wear.
3. Check the roller shaft for wear or any other abnormalities.
4. Check the bracket support for cracks, distortion or any; other abnormalities.

ASSEMBLING AND MOUNTING

Reverse the removal and disassembling procedure by adhering to the following instructions:

1. Take care in installing the bearing not to damage it.
2. When mounting the carrier roller on the support, position the roller shaft by correctly aligning the support and the seal guide at the dowel pin hole. Insert the pins and tighten the bolts on the support with the roller shaft held in that position.

Track Rollers



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|------------------------------|------------------------------|--------------|
| 1. Track roller shaft | 5. Track roller | 9. Dowel pin |
| 2. Track frame | 6. Floating seal | 10. Bush |
| 3. Track roller shaft collar | 7. Thrust key | 11. Guard |
| 4. Bearing | 8. Track roller shaft collar | |

Six track rollers are distributed along at the bottom of the track frame there being a total of 12 track rollers for the tractor. These rollers ride on the rail links of the track and support the weight of the tractor.

Some of these track rollers are of single flange type while the remaining are of the double-flange type. The centre flange serves to take up the lateral thrust in either direction.

Taking the track rollers one by one according to the type of flanges, from the front end toward the rear, the six are arranged in the order of SINGLE, DOUBLE, SINGLE, SINGLE, DOUBLE AND SINGLE.

The end clearance of the track roller is predetermined and does not lead to adjustment. A floating seal is provided at each end of the roller for preventing dirt, grit or water from entering the running clearance between the roller and its shaft.


TRACK ROLLES

Removal


REMOVAL

1. Open the tracks. Detach each track frame from the chassis. Set the removed track frame upside down on the floor.

2. Remove the bolts (1) (2) and guard (3) on each side: Remove each track roller assembly from the track frame by removing its securing bolts (4).



DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|-----------------------|-------------------|-----------------|
| 1. Snap ring | 7. Spring washer | 11-2. O-ring |
| 2. Thrust key | 8-1. Seal ring | 11-3. Shaft |
| 3-1. Seal ring | 8-2. O-ring | 11-4. Seal ring |
| 3-2. O-ring | 8-3. Bushing | 11-5. O-ring |
| 3-3. Bracket | 6-4. Dowel pin | 11-6. Building |
| 4. Snap ring | 8-5. O-ring | 11-7. Dowel pin |
| 5-1. Seal ring | 8-6. Bearing | 11-8. O-ring |
| 5-2. O-ring | 9. Bolt | 11-9. Bearing |
| 5-3. Bracket (collar) | 10. Spring washer | 12. Roller |
| 6. Bolt | 11-1. O-ring | |

TRACK ROLLERS

Inspection, etc.

INSPECTION

1. *Check the wear of each track roller by measuring the collar O.D. at the track faces and flanges.*
2. *Inspect the track roller shaft for damage, distortion or any other defects.*
3. *Measure the shaft O.D., bushing I.D. and*

thickness of the centre flange (of the shaft) to determine the amount of wear. Clean the shaft and roller, and clear the oil passage through the shaft with compressed air.

4. *Inspect the roller shaft collars for wear.*

ASSEMBLING

To assemble the track roller, reverse the removal and disassembling procedures by adhering to the following instructions:

1. *Use the press to install the bushings in the track roller, being sure to align the bore of the track roller with the bushing bore.*


2. *After the bushing is securely pressed in place, insert the track roller shaft in the roller. In the same manner as outlined above, install the bushing on the other side.*

Undercarriage

RECOIL SPRING

Description

Recoil Spring



RECOIL SPRING

- | | | |
|---------------------------|-----------------------------|-------------------|
| 1. Idler yoke | 5. Idler adjusting cylinder | 9. Track roller |
| 2. Carrier roller | 6. Piston | 10. Guiding guard |
| 3. Carrier roller bracket | 7. Recoil spring | 11. Track frame |
| 4. Rod | 8. Recoil spring cylinder | |

The recoil spring assembly, located at the middle of the track frame and enclosed in a housing, serves to provide a cushion back in the idler through the yoke, rod and grease filled cylinder, Its "recoiling" action - yielding to an opposing force and bouncing back upon renewal of the force - occurs when the idler encounters an obstacle or load during operation.

Track tension depends on the static force the recoil spring applies to the idler and can be varied for adjustment by increasing or decreasing the amount of grease in the Idler adjustment cylinder, which is a part of the recoil spring assembly.

RECOIL SPRING


Removal, etc.

Removal

1. Stretch the tracks. (Refer to "TRACK REMOVAL").
2. Separate the track frame groups from the chassis. (Refer to "REMOVAL OF TRACK FRAME GROUP")
3. Remove the plug, and pump out the oil in the recoil spring housing, if the recoil spring housing contains the oil. Otherwise it is not necessary.



DISSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISSEMBLING

- | | | |
|-------------------|--------------------|---------------------|
| *1. Bolt | 8-5. Seal | 10-1. Bolt |
| *2. Spring washer | 8-6. Seal | 10-2. Spring washer |
| *3. Cover | 8-7. Piston | 10-3. Lock |
| *4. Gasket | 9-1. Gasket | 10-4. Nut |
| 5. Bolt | 9-2. Bolt | 10-5. Rod |
| 6. Spring washer | 9-3. Spring washer | 10-6. Stopper |
| 7. Cylinder | 9-4. Snap ring | 10-7. Pilot |
| 8-1. Ring | 9-5. Bushing | 10-8. Seat |
| 8-2. Ring | 9-6. O-ring | 10-9. Spring |
| 8-3. Gasket | 9-7. Cover | |
| 8-4. Back-up ring | 9-8. Cover | |


* Not shown in the figure

Undercarriage


RECOIL SPRING

Disassembling, etc.

1. Remove the bolts (1) securing the cover (3) in the place lift out the cover and gasket.



2. Remove the bolts (5), lift out the cylinder (7) and the cover (9) in the place, and drive out the spring assembly to the front.



3. When removing the recoil spring from the pilot, use the press (or special tool No.09730-00000) to compress the spring and, after taking down the nut, gradually release the press to detach the spring and pilot



INSPECTION

1. Inspect each recoil spring for damage, and check its free length and any sign of cracks.

2. Inspect the adjusting cylinder for wear or damage on its internal and external surfaces.


3. Check the bushings inside the recoil spring housing for wear.

4. Check the pistons and seal rings for wear, or any sign of damage.

INSTALLATION

Build up each recoil spring assembly on the track frame according to the following instructions :

1. *Use a press to assemble the recoil spring and seat. After the spring has been installed inside the spring housing as shown in the figure below make sure if there is a clearance of 10 mm between the spring seat and the nut.*
2. *When positioning the grease fittings on the adjusting cylinders, have the cylinders packed with a proper amount of grease and apply also grease to the sliding face of the pistons and to the cylinder bores. The piston rings must be positioned in such a way that the ring gaps should not falling in one time.*
3. *Before inserting the piston into the bore of the cylinder, have the direction of its nipple toward the inspection opening provided on the cover so as to make the nipple accessible for charging grease through the opening.*
4. *After the recoil spring has been assembled in the place on the track frame, and approx. 3 quarts of engine oil into its spring housing. This oil will prevent the spring from rusting.*




Note: IF THE GREASE WAS APPLIED ON THE RECOIL SPRING FOR RUST PREVENTION INSTEAD OF THE OIL IN THE HOUSING; APPLY ONLY GREASE TO THE RECOIL SPRING AFTER CLEANING AND INSPECTION BEFORE INSTALLATION IN THE HOUSING.

Undercarriage

EQUALIZER SYSTEM

Description

Equalizer System



EQUALIZER SYSTEM

- | | | | | | |
|----|---------|----|---------------|----|------------|
| 1. | Support | 3. | Rubber pad | 5. | Centre pin |
| 2. | Seat | 4. | Equalizer bar | 6. | Bush |

The equalizer system is a means of distributing the weight of the front portion of the tractor chassis equally to the two track groups. It consists of a beam whose centre point is pivoted to the cross bar of the chassis.

The beam ends rise on the curved surface of seat pieces which rest in the cradles (support brackets) bolted to the top of the track frames. Two steel-faced rubber pads are interposed between the seat and the support cradle.

The equalizer beam is capable of rocking around

its centre pin, so that the updown motion of one track frame with respect to the other track frame, as when the tractor crawls on rough ground will not tilt or pitch the front end of the tractor chassis. Track frame vibrations during travelling are absorbed by the rubber pads for improved comfort of the operator.



The centre pin is equipped with a dust seal and designed to require no periodical lubrication. This pin is to be lubricated at the time of overhaul.

EQUALIZER SYSTEM

Removal, etc.

REMOVAL

1. Detach the engine underguard and transmission underguard. (Refer to "ENGINE REMOVAL.")
2. Open the tracks. Separate track frame group from the chassis. (Refer to "TRACK REMOVAL" and "REMOVAL OF TRACK FRAME GROUP".)
3. Suspend one end of equalizer bar (1) with the cable sling. Remove the bolts (2)
4. Press out the pin (1) with the special tool as shown. Remove bushing. Lower the end of the equalizer bar suspended (3) and carry it out of the machine.



INSPECTION

1. Inspect the equalizer bar for cracks, damage or any sign of fatigue.
2. Check the centre pin and bushing for wear.
3. Inspect the resting surface at each end of the equalizer bar for wear or galling.

MISCELLANEOUS MOUNTINGS


INDEX

OUTER FITTINGS	11-01
DESCRIPTION	11-01
OPERATORS SEAT	11-03
DESCRIPTION	11-03
REMOVAL	11-04
INSPECTION	11-04
FUEL TANK	11-05
DESCRIPTION	11-05
REMOVAL	11-06
DISASSEMBLING	11-07
CLEANING AND INSPECTION	11-08
ASSEMBLING	11-08
DRAWBAR	11-09
DESCRIPTION	11-09

Miscellaneous Mounting

Outer Fittings

DESCRIPTION



- | | | |
|----------------------|-----------------|----------------------------------|
| 1. Radiator mask | 6. Cover | 11. Transmission case underguard |
| 2. Radiator guard | 7. Dash board | 12. Cover plate |
| 3. Radiator cover | 8. Side Fender | 13. Engine underguard |
| 4. Engine hood catch | 9. Cover plate | 14. Hook |
| 5. Engine hood | 10. Cover plate | 15. Front cover |

The major outer fittings are the engine hood and its associated parts the backboard or bulkhead complete with the dashboard; the anti-slip floorboard assembly providing a floor at the control area, the side fenders for the operators convenience in mounting and dismounting the

tractor; the radiator mask and bottom plate; the engine underguard assembly extending all the way to the steering case and protecting the engine and transmission against damage.

Miscellaneous Mounting

OUTER FITTINGS

Description

The solenoid switch which is an Integral part of the Starter, operates in two stages. In first stage the solenoid switch contacts close and a small current passes through the auxiliary field winding causing the armature to rotate slowly. Simultaneously, the complete armature assembly is drawn towards the driving end of the machine by the magnetic field set upon the windings and pinion is brought into the mesh with the engine flywheel gear. In the second

stage the contacts close the circuit to the main series winding. The Starter then exerts full torque on the engine. The auxiliary windings are arranged so as to hold the pinion in mesh until the starting switch is released.


The Starter is also fitted with an overload clutch interposed in the drive between armature and pinion, to safe-guard the pinion teeth against damage due to excessive- load.

OPERATOR'S SEAT

Description

Operators Seat

DESCRIPTION



OPERATORS SEAT

- | | | |
|--------------------------|----------------|--------------------|
| 1. Frame and Battery box | 4. Back seat | 7. Plate |
| 2. Seat | 5. Frame | 8. Adjusting lever |
| 3. Arm rest | 6. Couch screw | |

The seat is of a single-seating arm chair type with heavily padded comfort parts a seat a back and two arm rests.


Miscellaneous Mounting

OPERATOR'S SEAT

Removal, etc

REMOVAL

1. Remove the bolts (1) and dismount the seat (2) and plate (3) as an assembly



INSPECTION


1. Inspect the cushion seat, back rest and arm rests for damage.
2. Check the seat positioning mechanism for locking action, and inspect the parts of this mechanism for any damage.

Fuel tank

Description

Fuel tank

DESCRIPTION



FUEL TANK

- | | | |
|----------------|------------------------|-------------------|
| 1. Fuel tank | 5. Plug | 9. Drain valve |
| 2. Cap body | 6. Joint | 10. Strainer case |
| 3. Strainer | 7. Fuel shut-off valve | 11. Strainer |
| 4. Level guage | 8. Strainer ass'y | 12. Strainer cap |

The fuel tank is located behind the operators seat and mounted on the tank base, secured to the steering case. Two wheel valves are provided under the tank one is in the line to the fuel P.T. pump through the float tank, and the other is in the drain line.

The oil filler, located at the tank top, has a strainer and a cap complete with a guage stick. A small orifice is provided in this cap for allowing the tank to breathe. The cap is so designed that water such as rain drops will not enter through this orifice.

Miscellaneous Mounting


FUEL TANK

Removal


REMOVAL

1. Open the drain valve (1) at the bottom of the fuel tank to drain the fuel tank. Disconnect Joints (2).

2. Remove the tank mounting bolts. Using an overhead crane lift the fuel tank off the machine.



DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|------------------|--------------------|-----------------|
| 1. Nut | 7-6. O-ring | 14-3. Tube |
| 2. Bolt | 7-7. O-ring | 14-4. Sleeve |
| 3. Spring washer | 7-8. Strainer case | 14-5. Valve |
| 4. Washer | 8. Bolt | 14-6. Flange |
| 5. Joint Bolt | 9. Spring washer | 15. Cap |
| 6. Gasket | 10. Flange | 16. Level guage |
| 7-1. Eye joint | 11. O-ring | 17. Ring |
| 7-2. Valve | 12. Bolt | 18. Strainer |
| 7-3. Nipple | 13. Spring washer | 19. Fuel tank |
| 7-4. Elbow | 14-1. O-ring | |
| 7-5. Strainer | 14-2. Clip | |

Cleaning and Inspection, etc.

CLEANING AND INSPECTION

1. *Check the fuel tank for cracks or damage. Thoroughly clean the interior of the tank.*
2. *Thoroughly clean strainers.*

ASSEMBLING

Build up the fuel tank by adhering to the following Instructions:


1. *Renew gaskets and O-rings at the time of assembly.*
2. *Before Installing the flange, strainers and Joints in the place, make sure these parts are thoroughly cleaned in a clean solvent and free from any foreign particles.*

DRAWBAR

Description

DRAWBAR

DESCRIPTION



DRAWBAR

- | | | |
|------------|----------|----------|
| 1. Bracket | 3. Latch | 5. Chain |
| 2. Drawbar | 4. Pin | |

The drawbar assembly is secured to the rear-face of the steering case and positioned at the lower part of this face, It is fixed in place and consists of two brackets a bar and a pin and lock,


The lock consists of a bolt and nut with a cotter pin and prevents the drawbar pin from jumping out of its place.

ELECTRICAL SYSTEM

INDEX


DESCRIPTION	12-01
ALTERNATOR	12-02
REGULATOR	12-02
BATTERIES	12-02
STARTING MOTOR	12-02

ELECTRICAL SCHEMATIC DIAGRAM WITH BEML (BS6D125) ENGINE SL. NO.: 14288 & UP



Contd.....

BD80 BOLDOZER



CONNECTION TABLE - LIGHT SWITCH

SWITCH POSITION	TERMINAL CODE			
	B	1	P	H
OFF	○			
1st	○	○	○	
2nd	○	○	○	○

CONNECTION TABLE - KEY SWITCH


SWITCH POSITION	TERMINAL CODE					
	B	BR	R1	R2	C	ACC
OFF	○					
R1	○	○	○			○
ACC	○	○	○	○	○	○
START	○	○	○	○	○	○

HYDRAULIC SYSTEM

INDEX

Description	13-02
HYDRAULIC OIL PIPING	13-02
CONTROL VALVE	13-02
RELIEF VALVE	13-05
REMOVAL	13-06
DISASSEMBLING	13-08
INSPECTION	13-09
GEAR PUMP	13-10
HYDRAULIC OIL FILTER	13-11
REMOVAL	13-12
DISASSEMBLING	13-13
CLEANING AND INSPECTION	13-14
ASSEMBLING	13-14
CYLINDERS	13-15
HYDRAULIC CYLINDER	13-16
REMOVAL	13-16
DISASSEMBLY	13-17
CLEANING AND INSPECTION	13-17
ASSEMBLING	13-18
QUICK DROP VALVE DISASSEMBLING	13-18
INSPECTION	13-18
CYLINDER STAY	13-19
REMOVAL	13-19
DISASSEMBLING	13-20
CLEANING AND INSPECTION	13-20
ASSEMBLING	13-20

Hydraulic System



- | | | |
|------------------------|------------------|-------------------------|
| 1. Hydraulic of filter | 4.. Relief valve | 7. Suction valve |
| 2. Hydraulic oil tank | 5. Gear pump | 8. Blade lift cylinders |
| 3. Control valve | 6. Check valve | |

Hydraulic System

Description

DESCRIPTION

The hydraulic system is the means of making hydraulic power available for actuating the earth moving attachments such as angle dozer etc. The major components of hydraulic system are:

Hydraulic Oil Tank located on the right side of the Operators seat, which consists of control valve assembly; the Gear Pump mounted on the Flywheel housing and driven by the Power Take Off gears; the Hydraulic cylinders for moving the blade; filter, oil pipings control levers, valves etc.

The hydraulic oil In the Oil Tank is drawn by the Gear Pump and supplied to the Control Valve within the Oil Tank. A Relief Valve is provided in the circuit for limiting the line pressure to the specified value.

The Oil Tank holds hydraulic oil and houses Control Valve, Check Valve, Suction Valve and Strainer.


The Strainer is provided in the filler at the top of the Tank. The Filler cap is complete with the gauge stick.

HYDRAULIC OIL PIPING

Strong tubes capable of withstanding high internal pressure of the system are used throughout together with high pressure flexible tubing for connecting the metal tubes to the hydraulic cylinders.

Joints in the pipings are provided with O-rings for ensuring perfect tightness against oil leakage and against entry of air and dust into lines.

CONTROL VALVE



DESCRIPTION

The Control Valve is a single spool, multiport type. The spool and bore are finished to very close tolerances.

The spool for actuating the cylinders is controlled by a control lever located on the right-side of the Operators seat, which provides four operations for the blade viz. RAISE, LOWER, HOLD, FLOAT.

A Check Valve is built in the Control Valve assembly which prevents reverse flow of oil. The pressurised oil is directed to the cylinders in the desired direction by the spool positioned by the Control lever.

A Section Valve is also provided within the Hydraulic Tank. This Valve operates whenever vacuum is created in the hydraulic cylinder and thereby allows the oil in the tank to be sucked through the Control Valve into the cylinders so that the piston in the cylinders will be free from vacuum pressure, which would interfere with the smooth movement of the piston. The vacuum in the cylinders would be created when the blade is moving down with its own way in lowering and floating operations.

The oil returning from the cylinders, flows into the tank through the filter.





Hydraulic System

CONTROL VALVE

Description

Pulling or pushing the lever from HOLD position switches spool into RAISE or LOWER position, respectively, in that order. Releasing the lever in RAISE or LOWER position allows it to snap back into HOLD position because of a return spring acting on the lever.

Pushing the lever farther from LOWER position shifts it into FLOAT position and arrest the lever in this position. Under this condition, the cylinders receive no hydraulic force for the oil merely circulates through the control valve back to the oil tank.




In the case of a twin-spool or triple-spool control valve the FLOAT position mentioned above is eliminated by means of a return spring set in such a way as to prevent the lever from moving into that position. This feature is provided because, in a machine equipped with a ripper or a tilt dozer, the floating action of the blade is not called for.

RELIEF VALVE

Disassembling
Inspection

RELIEF VALVE



- | | | |
|-----------|---------------|---------------|
| 1. Plug | 4. Puppet | 7. Valve body |
| 2. Spring | 5. Valve seat | 8. Valve |
| 3. Case | 6. Spring | 9. Shim |

The Relief Valve is provided in the hydraulic circuit between the pump and the control valve. It consists of a puppet type pilot valve and a main valve with a balance hole in it.

pressure setting is Increased or decreased by removing or adding the shims at the adjusting nut. The standard shim thickness is 3 mm (1 mm of this thickness corresponds to 25.6 kg/cm²).

The Relief Valve is set at 140 kg/cm². The

Hydraulic System

CONTROL VALVE


Removal

REMOVAL


1. Drain the hydraulic oil tank by removing the drain plug (1).




2. Disconnect the oil pipes (1)(2) and control linkage at (3) from the hydraulic oil tank.



3. Disconnect the pipes (1) (2) and (3) from the hydraulic Oil tank.




4. Remove the mounting bolts, (1) and move the tank to the floor with a crane.




CONTROL VALVE

Removal


5. Remove the bolts (1) joining the two tank halves together, and remove the outer half (2).



7. Disconnect the flanges (1) (2). Remove the bolts securing the control valves to the tank, and detach the valves.




6. Remove the bolts (1) and clips (2),



Disassembling

Disassembling


CONTROL VALVE



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|------------------|----------------|-------------------|
| 1. Bolt | 8-2. Spring | 10. Bolt |
| 2. Spring washer | 8-3. Guide | 11. Spring washer |
| 3-1. Spring | 8-4. Ball | 12. Cover |
| 3-2. Valve | 8-5. Snap ring | 13-1. Spacer |
| 3-3. Valve body | 8-6. Collar | 13-2. O-ring |
| 4. Bolt | 8-7. Spring | 14. Spring |
| 5. Spring washer | 8-8. Collar | 15. Valve |
| 6. Bolt | 8-9. Detent | 16. Valve body |
| 7. Spring washer | 8-10. Cover | |
| 8-1. Plug | 9. Valve | |

Relief Valve



RELIEF VALVE

- | | | |
|------------------|-------------|-----------------|
| 1. Bolt | 5. Spring | 6-5. Puppet |
| 2. Spring washer | 6-1. Plug | 6-6. Case |
| 3-1. Valve body | 6-2. Shim | 6-7. Valve seat |
| 3-2. O-ring | 6-3. Shim | |
| 4. Valve | 6-4. Spring | |

INSPECTION


1. Examine the spools for the condition of sliding surfaces, giving particular attention to any signs of erratic contact or of rusting.
2. Inspect the valve body for cracks or damage, and check the clearance around the spool in the bore.
3. Measure the free length, as-installed length and preload of the valve springs, and inspect them for defects.
4. Check valve element for seating contact pattern.

Hydraulic System

GEAR PUMP

Description

Gear Pump




HYDRAULIC OIL PUMP

- | | | |
|-------------------|-----------------|--------------------|
| 1. Oil seal | 8. Seal plate | 15. Backup ring |
| 2. Needle bearing | 9. Backup ring | 16. Needle bearing |
| 3. Bush | 10. U-ring | 17. Bush |
| 4. Driven gear | 11. Backup ring | 18. Drive gear |
| 5. Gear case | 12. Cover | 19. Bush |
| 6. Bush | 13. Backup ring | 20. Needle bearing |
| 7. Needle bearing | 14. U-ring | 21. Bracket |

The gear pump is installed on the power take-off located on the right-hand upper part of the flywheel housing. It is driven by P.T.O gears. It

draws oil from the hydraulic oil tank and pumps it to the control valve in the tank.

Hydraulic Oil Filter



HYDRAULIC OIL FILTER

- | | | |
|-------------------|------------------|------------|
| 1. Filter housing | 5. Spring | 9. Rod |
| 2. Filter element | 6. Cover | 10. Valve |
| 3. Spring | 7. Air vent plug | 11. Spring |
| 4. Valve | 8. Bolt | 12. Seat |

This filter is of paper element type. It is located behind the hydraulic tank. The oil leaving the Control Valve passes through the filter, from out to inside and flows back to tank.


It is provided with a by-pass valve, which bypasses oil to the tank, when the filter element is clogged.

Removal


REMOVAL

1. Remove the drain plug and drain the hydraulic tank. (Refer to "HYDRAULIC TANK REMOVAL".)

2. Remove the bolts (1) (2) securing the hydraulic filter (3) to the hydraulic tank, and remove the filter.



DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|------------------|-----------------|-------------------|
| 1. Bolt | 5-1. Cotter pin | 6. Filter element |
| 2. Spring washer | 5-2. Seat | 7. Joint |
| 3-1. Plug | 5-3. Spring | 8. Filter element |
| 3-2. O-ring | 5-4. Valve | 9. Filter housing |
| 3-3. O-ring | 5-5. Cotter pin | |
| 3-4. Cover | 5-6. Valve | |
| 4. Spring | 5-7. Rod | |

CLEANING AND INSPECTION

Inspect the valve, noting the condition of sliding and setting contacts and examine the

valve internal faces for signs of rusting.


ASSEMBLING

Build up the filter by adhering to the following instructions:

- 1. When putting the filter cover on, be sure to apply grease to the O-Ring.*
- 2. After the oil filter is installed, fill the hydraulic tank with oil completely, driving all air out of the filter through its vent hole which is normally closed with bolt (1).*



Cylinders



HYDRAULIC CYLINDER

- | | | | |
|----|-------------------|----|---------------|
| 1. | <i>Piston rod</i> | 3. | <i>Piston</i> |
| 2. | <i>Cylinder</i> | 4. | <i>Nut</i> |

Hydraulic System

CYLINDERS

Description Removal

Two cylinders for holding the blade in suspension are anchored to the sides of the radiator guard.

In cylinders the piston rod is plated with hard chrome for increased resistance to wear, and the piston is equipped with piston rings and U-ring to positively seal the sliding clearance.

The Hydraulic cylinders are provided with a Quick Drop Valve at the head end of the cylinder. The purpose of this Quick Drop Valve is to increase the lowering speed of the blade. The oil passing from the bottom end of the cylinder flows to the top of the cylinder through the Quick Drop Valve and thereby increasing the lowering speed of the blade.



Hydraulic Cylinder

REMOVAL


1. Disconnect the cylinder piston rods from the blade. (Refer to "DOZER EQUIPMENT REMOVAL".)

2. Disconnect the rubber hoses (2)(3) from the cylinder (1).

3. Remove the bolts (1) (2) securing bearing caps (3) (4) to the cylinder support yoke and detach the caps. Dismount the cylinder as an assembly (5) from the machine.



DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|-------------------|--------------------|----------------------|
| 1. Bolt | 8-7. O-ring | 9-7. U-packing |
| 2. Spring washer | 8-8. Ring support | 9-8. Snap ring |
| 3. Blade cylinder | 8-9. Piston ring | 9-9. Bushing |
| 4. O-ring | 8-10. Sleeve | 9-10. Cylinder head |
| 5. Back-up ring | 8-11. Valve | 10-1. Bolt |
| 6. Nut | 8-12. Sleeve | 10-2. Spring washer |
| 7. Spacer | 8-13. Piston | 10-3. Blushing |
| 8-1. Plate | 9-1. Bolt | 10-4. Shim |
| 8-2. Dowel pin | 9-2. Spring washer | 10-5. Ball bearing |
| 8-3. U-Ring | 9-3. Plate | 10-6. Bushing |
| 8-4. Ring support | 9-4. Dust seal | 10-7. Shim |
| 8-5. Plate | 9-5. Box | 10-8. Rod |
| 8-6. Dowel pin | 9-6. Back-up ring | 11. Quick drop valve |

CLEANING AND INSPECTION

1. Clean the cylinder bore, piston and piston rod. for wear or any damage.
2. Inspect the piston, piston rod and other parts
3. Do not disassemble the valves within the pistons unless absolutely necessary.

Hydraulic System

CYLINDERS

Assembling etc.


ASSEMBLING

Build-up the cylinder by adhering to the following instruction:

1. When Inserting the piston into the cylinder bore make sure if the U-rings slide in smoothly Without folding back or cocking.

QUICK DROP VALVE

DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

1-1. Bolt	1-10. O-Ring	3-1. Bolt
1-2. Washer spring	1-11. Spring	3-2. Washer
1-3. Bolt	1-12. Valve	3-3. Flange
1-4. Washer spring	2-1. Bolt	3-4. O-Ring
1-5. Bolt	2-2. Washer	3-5. O-Ring
1-6. Washer spring	2-3. Flange	3-6. O-Ring
1-7. Bolt	2-4. O-Ring	3-7. O-Ring
1-8. Washer spring	2-5. Spring	3-8. O-Ring
1-9. Elbow	2-6. Valve	3-9. Orifice

INSPECTION

1. Examine the spools for the condition of sliding surfaces, giving particular attention to any signs of erratic contact or of rusting.

2. Inspect the valve body for cracks or damage, and check the clearance around the spool in the bore.


3. Measure the free length as installed length and preload of the valve springs, and inspect them for defects.

4. Check valve element for seating contact pattern.

Cylinder Stay


REMOVAL

1. Disconnect the cylinder rod from the blade (Refer to "DOZER EQUIPMENT REMOVAL".)
2. Lift out the engine hood from the machine. (Refer to "ENGINE AND RADIATOR REMOVAL".)
3. Disconnect all rubber hoses running between the engine and the radiator.
4. Disconnect the pipes (1) (2) from the hydraulic cylinder on each side of the machine.
5. Carefully hold the stay with an overhead hoist and a cable. Remove the stay securing bolts (4)(5) on each side of the machine, and separate each stay assembly from the machine.
6. Dismount the cylinder as an assembly on each side by removing bolt (6). (Refer to "HYDRAULIC CYLINDER REMOVAL").



Disassembling etc. _____

DISASSEMBLING



PARTS ARE ENUMERATED IN THE SEQUENCE OF DISASSEMBLING

- | | | |
|--------------|----------------|--------------|
| 1-1. Bushing | 1-4. Dowel pin | 2-1. Stay |
| 1-2. Seal | 1-5. Yoke | 2-2. Bushing |
| 1-3. Bushing | | |

CLEANING AND INSPECTION

1. Clean all parts thoroughly and inspect for wear or any sign of damage.
2. Replace the seals whenever they are disassembled for reconditioning or servicing:
3. Visually inspect the yoke and stay for any worn threads and damage.
4. Examine worn or damaged bushings.

ASSEMBLING

Assemble the stay in the reverse sequence of disassembling by adhering to the following note:

BEFORE ASSEMBLING THE YOKE IN POSITION, MAKE SURE THERE EXISTS A 5 TO 6 MM CLEARANCE BETWEEN THE YOKE AND THE STAY.


DOZER ATTACHMENT

INDEX

DESCRIPTION	14-03
REMOVAL	14-05
DISASSEMBLING	14-06
CLEANING AND INSPECTION	14-07
ASSEMBLING	14-07
MOUNTING	14-07

Dozer Attachment

DESCRIPTION



HYDRAULIC ANGLE DOZER

- | | | |
|-------------|-------------------------|----------------|
| 1. Blade | 3. Side arm | 6. Turning cap |
| 2. Brace | 4. Centre cutting edges | 7. 'C' Frame |
| 5. End bits | | |

Dozer Attachment

Description

The blade is a welded structure of steel plates reinforced with ribs.

The bottom part of the blade is fitted with two numbers replaceable cutting edges and two end bits on either side. These edge pieces are made of high-strength alloy steel and secured in place by special wear resistance bolts and nuts. The centre cutting edges are having double edges. When one side is worn off, the other side edge can be used by turning the cutting edge. This provides new wearing surface for another life of this cutting edge.

The blade is mounted on a 'C' frame with a centre pin and arms and blades on either side of the 'C' frame. The arms are secured with pins to

the blade at the front and to the 'C' frame at the rear.

The blade can be angled upto 25° on either side by changing the position of the arms to any of the three brackets provided at both sides of 'C' frame.

The 'C' frame is welded box section having ample strength to withstand shock-loads encountered by this size of the machine.

The ends of the 'C' frame are pivoted at the trunnions provided on either side track frames.


The power cylinders are located at both sides of the yoke to raise or lower the 'C' frame.

Dozer Attachment


Removal

REMOVAL


1. Lower the blade to the ground securely, placing blocks of proper size under the frame as shown.




2. Remove the split pin (1) and pull out the lock pin (2). Drive out the pin (3) to disconnect the 'C' frame (4) from the hydraulic cylinder rods (5), on each side of the machine.



3. Retract the piston rods to its the end of stroke in the cylinder, and secure them to the cylinder hooks to the pins (1) Located on the radiator guard, clamp them so that the cylinder is properly placed in that Position.




4. Remove the bolts. (1) securing the caps (2) to the main frame, detach the caps, blade and frames resting on the floor.



Dozer Attachment

Description _____

DISASSEMBLING



PARTS ARE ENUMERATED IN THE ORDER OF DISASSEMBLING

1-1. Pin	1-14. Bracket	2-1. Pin , cotter	2-14. Pin
1-2. Pin cotter	1-15. Pin cotter	2-2. Washer	2-15. C Frame Assy.
1-3. Pin	1-16. Pin	2-3. Pin	3-1. Nut
1-4. Pin	1-17. Pin	2-4. Blade, Angle	3-2. Washer, spring
1-5. Screw	1-18. Nut	2-5. Pin, cotter	3-3. Bolt
1-6. Bolt	1-19. Washer, spring	2-6. Nut	3-3A. Bolt
1-7. Washer, spring	1-20. Bolt	2-7. Washer	3-4. Bit end
1-8. Bolt	1-21. Bolt	2-8. Shaft	3-5. Edge, cutting
1-9. Washer, spring	1-22. Washer, spring	2-9. Holder	3-6. Nut
1-10. Pin, cotter	1-23. Cap	2-10. Bushing	3-7. Bolt
1-11. Pin	1-24. Shaft	2-11. Joint	3-8. Washer, spring
1-12. Pin	1-25. Screw	2-12. Pin, cotter	3-9. Cover
1-13. Brace	1-26. Arm	2-13. Pin	

Dozer Attachment

Disassembling, Cleaning and Inspection, etc.

Note: MINOR ITEMS SUCH AS THE PINS AND CAPS SHOULD BE REPLACED TO THEIR ORIGINAL POSITIONS TO PREVENT THEM FROM MISSING UPON DISASSEMBLY OF THE DOZER AND FRAMES.

CLEANING AND INSPECTION

1. *Examine the blade for wear, deformation, defective and also its welded portions for cracks.*
2. *Check the pins and holes for wear or damage.*
3. *Check the cutting edges and end bits for wear. Also examine mounting bolts for wear, breakage.*
4. *Check both stud ball head and blade ball bore for wear or any sign-of damage.*
5. *Check if there is a proper clearance between the trunnion bushing and frame bushing.*
6. *Check for bending and any defect in the arm.*
7. *Check other parts such as the pins and pin holes for wear or damage.*

ASSEMBLING

1. *Install the arm assembly on the blade securely. Adjust the clearance between the stud ball and the blade ball by adding or removing shims.*
2. *Secure the blade to the frame. Adjust the length of each arm equally and secure the arms to the frame.*
3. *Adjust the brace until equal length is obtained. Install the brace to the frame. Stud, ball-to-blade ball clearance may be adjusted properly by adding or removing shims.*

MOUNTING

To mount the dozer equipment to the machine, reverse the sequence of removal as outlined in the instructions above.

MAINTENANCE STANDARDS

CONTENTS

01	MAIN CLUTCH	15-01
02	HYDRAULIC BOOSTER	15-04
03	MAIN CLUTCH PUMP	15-07
04	TRANSMISSION	15-09
05	SHIFTER / MAIN CLUTCH LEVER	15-11
06	STEERING CLUTCHES	15-13
07	STEERING OIL PUMP	15-16
08	BRAKES / BRAKE PEDALS	15-19
09	STEERING BRAKE	15-20
10	STEERING LEVER / TRANS. CONTROL LEVER / ACCELERATOR LEVER	15-21
11	TRACK / TRACK FRAME GROUP	15-22
12	IDLER	15-25
13	CARRIER ROLLER	15-26
14	TRACK ROLLERS	15-27
15	TRACK FRAME GROUP	15-28
16	HYDRAULIC SYSTEM	15-29


Maintenance Standards

Unit : mm (in)


System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
MAIN CLUTCH	Bearing 06040-06015	Hub O.D.	75 (2.953)	+ 0.012(0.000472) -0.007(0.000276)			
		Retainer I.D.	115 (4.491)	-0.010(0.00039) -0.045(0.001772)			
	Bearing 06042-00214	Shaft O.D.	70 (2.756)	+ 0.039 (0.000 1535) + 0.020(0.000787)			
		Cover I.D.	125 (4.884)	-0.012(0.000472) -0.055(0.0002165)			
	Bush	Shaft O.D.	60 (2.362)	-0.25(0.00984) -0.30(0.01181)			
		Bush (as assembled) I.D.	60 (2.362)	+0.074(0.002913)			
		Clearance		0.25~0.374 (0.0098~0.0147)		0.5 (0.020)	
	Shaft O:D and Oil seal I.D.		85 (3.3464)	-0.087(0.003425)	84.9 (3.3425)	84.85 (3.340)	
	Disc	Thickness	7 (0.276)	± 0. 1 (0.0039)		5.5 (0.022)	
		Face runout		0.3(0.00118)		0.5 (0.197)	
	Drive plate	Thickness	6.5 (0.254)	+0.3(0.00118)			
		Face runout		0.00591 (0.15)		0.3 (0.00118)	
	Disc-to-hub backlash			0.52~0.63 (0.0204 ~ 0.0248)		1.0 (0.039)	
	Drive plate-to-flywheel backlash			0.4~0.55 (0.0016 ~ 0.0217)		1.0 (0.039)	
	Thrust washer 141-10-11451	Thickness	3 (0.118)	-0.10(0.00394) -0.15(0.00591)			
		Face runout		0.3(0.0012)		0.5 (0.020)	
	Spring 150-10-11221	Free length	64 (2.520)			61 (2.402)	
		As-installed length	50 (1.969)				
		Load kg (lb)	39.5 (87.1)	±3.95(8.7)		31.6 (70)	
	Spring 175-10-12651	Free length	61.9 (2.437)			59.4 (2.338)	
		As-installed length	49.7 (1.957)				
		Load kg (lb)	8.45 (18.632)	± 0.84 (1.8522)		8.75 (19.251)	
	Spring 170-10-12210	Free length	112 (4.409)			114.5 (4.507)	
		As-installed length	125 (4.884)				
		Load kg (lb)	31 (68.335)	± 3.1 (6.8355)		25 (55.125)	
	Brake band lining	Thickness	6 (0.236)			3.7 (0.1457)	

Maintenance Standards


Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
BOOSTER	Spool-to-valve clearance	A		0.030~0.061 (0.0013~ 0.0024)		0.1 (0.0039)	
		B		0.030~0.061 (0.0013~0.0024)		0.1 (0.0039)	
	Valve-to-cover clearance	C		0.030.0.069 (0.0013.0.0027)		0.1 (0.0039)	
	Valve-to-body clearance	D		0.030.080 (0.0013~0.0032)		0.1 (0.0039)	
		E		0.020~0.060 (0.0008~0.0024)		0.1 (0.0039)	
	Spool O.D. and Oil seal I.D.		22 (0.866)	-0.007(0.000027) -0.028(0.000110)			

MAIN CLUTCH



HYDRAULIC BOOSTER



Maintenance Standards

Maintenance Standards

Unit : mm (in)

System	Item	Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
	Spring 170.10-15262	Free length	54.4 (2.141)		49.9 (1.964)	
		As-Installed length	32 (1.260)			
		Load Kg (lb)	23 (51)	±2.3(5.1)	18.4 (41)	
	Spring 170.10-15272	Free length	50.5 (1.988)		46.1 (1.814)	
		As-Installed length	28.5 (1.122)			
		Load Kg (lb)	11 (24.255)	± 1.1 (2.4255)	8.8 (19.404)	
	Spring 170.10-15340	Free length	75 (2.953)		73.2 (2.881)	
		As-Installed length	51 (2.008)			
		Load Kg (lb)	14 (30.870)	± 0.6(1.3230)	13.0 (28.665)	
	Needle bearing, 150.11-13322	Pin O.D.	22 (0.866)	-0.013(0.0000512)		
		Lever I.D.	30 (1.181)	+0.012(0.0000472) -0.009(0.000035)		
	Bush 170.10-18111	Pin O.D.	12 (0.472)	-0.016(0.000063) -0.043(0.00169)		
		Bush I.D. (assembled)	12 (0.472)	+0.018(0.000709)		
		Clearance		0.016-0.061 (0.00063 - 0.00240)	0.15 (0.00591)	
	Socket I. D. and Ball dia.			0.3-0.5 (0.0118 -0.0197)	1.0 (0.039)	
	Bush 170.10-16120	Shaft O.D.	34 (1.339)	-0.025(0.00009)		
		Bush I.D. (assembled)	34 (1.339)	+0.064(0.00025) + 0.025 (0.00009)		
		Clearance		0.025-0.089 (0.00009 -0.00035)	0.15 (0.0059)	
	Bush 175.10-12230	Shaft O.D.	27 (1.063)	-0.020(0.00007) -0.041 (0.0016)		
		Bush I.D. (assembled)	27 (1.063)	+0.021 (0.00082)		
		Clearance		0.020-0.062 (0.00007-0.0024)	0.15 (0.0059)	
	Side Clearance	Gear case width	38 (1.496)	+0.035(0.00137) +0.025(0.00098)		Selection assembly
		Gear width (each)		-0.020(0.00078) - 0.030(0.00118)		
		Gear-to-case side clearance		0.045-0.055 (0.00177~0.00217)	0.080 (0.00314)	
		End play	0.020~ 0.025 (0.00078~ 0.0009)			

Maintenance Standards

Unit : mm (in)


System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
MAIN CLUTCH PUMP	Gear-to-housing clearance	Bore dla. (each)	53.3 (2.0984)	+0.095(0.0037) +0.080(0.0031)		+ 0.25 (0.0098)	Distance between centre line of gears
		Gear O.D. (each)		-0.060(0.00236) -0.075(0.0029)			
		Inlet side		0.09~0.10 (0.0035 - 0.0039)			
		Top or bottom side		0.07~0.08 (0.0028~0.0031)			
		Outlet side		0.05~0.06 (0.0019~0.00236)		+ 0.18 (0.0070)	

Maintenance Standards

Unit : mm (in)


System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks								
MAIN CLUTCH PUMP	Needle bearings	Bearing to housing circumference clearance		0.188 ~ 0.346 (0.0074~0.0136)	0.45 (0.0177)		Measure the clearance at eccentricized bearing outer race								
		Bearing I.D.	27 1.063)	+0.033(0.00129) + 0.020(0.00078)											
		Shaft O.D.		+0 -0.009(0.00035)											
		Shaft to bearing clearance	0.020 (0.00078) ~0.042 ~(0.00016)	0.030(0.00118)	0.056 (0.00196)		Selection assembly								
	Gears	Module X No. of teeth	3(0.118) X 15												
		Displacement over a given number of teeth (2 teeth)	14.699 (0.5786)	-0.06(0.00023) -0.11 (0.0043)											
		Backlash		0.12~0.22 (0.0047 ~ 0.00866)	0.35 (0.01377)										
	Oil seal	Shaft dia.	25 (0.984)	+0 -0.052(0.00020)	24.5 (0.964)										
		Oil seal I.D.	23.5 (0.9251)												
	Spline	O.D. X teeth X module	25 x 13 x 1.667 (0.9842 x 13 x 0.0656)				Backlash 0.3(0.01181)								
		Displacement over a given number of teeth (3 teeth)	13.516 0.5321	-0.087 (0.00342) - 0.129 (0.00507)											
Tightening torque kg. m (ft-lb)		12 (87 ft-lb)	± 0.6(4.3 ft-lb)												
Discharge flow		Discharge pressure : 4 kg/cm ² (640 PSI), Oil temp : 50° ~ 55°C (122°~131°F)													
		<div>Performance criteria</div> <table><tr><th>Pressure</th><th>rpm</th><th>Efficiency (%)</th></tr><tr><td>45 kg/cm² (640 PSI)</td><td>2000</td><td>50%</td></tr><tr><td>45 kg/cm² (640 PSI)</td><td>1200</td><td></td></tr></table>					Pressure	rpm	Efficiency (%)	45 kg/cm ² (640 PSI)	2000	50%	45 kg/cm ² (640 PSI)	1200	
Pressure	rpm	Efficiency (%)													
45 kg/cm ² (640 PSI)	2000	50%													
45 kg/cm ² (640 PSI)	1200														
TRANSMISSION	Centering the engine	Runout		0.5 (0.017685)max.		With dial guage									
		Face runout		0.5 (0.017685)max.											
	Gear backlash	116 TM 51353 116 TM 51742 150-15-12630 & 116 TM 51078		0.23 – 0.46 (0.0090 – 0.0181) 0.23 – 0.46 (0.0090 – 0.0181)		(0.02952)									
		Other gears		0.24 – 0.49 (0.0094 – 0.0192)		0.75 (0.02952)									

MAIN CLUTCH PUMP




1. Insert the oil seals and needle bearing so as to set the surface on which their serial numbers are stumped to outside. Cost the inside of oil seal grease before inserting.
2. Before tightening the bolts, adjust the gear side clearances to 0.055~0.060 mm (0.0022~0.0024).

TRANSMISSION



Maintenance Standards

Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
TRANSMISSION	Bearing 116 TM 91335	Shaft O.D.	70 (2.765)	+0.039 (0.00153) + 0.020 (0.0007)			Mounted on main shaft
		Cage I.D.	150 (5.909)	-0.012 (0.00047) -0.052 (0.00204)			
	Bearing 06041-00311	Shaft O.D.	55 (2.165)	+0.039 (0.00153) +0.020 (0.0007)			
		Cage I.D.	120 (4.72)	-0.010 (0.00003) -0.045 (0.00177)			
	Bearing 116 TM 91854	Shaft O.D.	50 (1.969)	+0.033 (0.00012) +0.017 (0.00006)			Mounted on counter shaft and intermediate shaft.
		Cage I.D.	110 (4.330)	-0.010 (0.00003) -0.045 (0.00177)			
	Bearing 06041-00312	Shaft O.D.	60 (2.362)	+0.039 (0.00153) + 0.020 (0.0007)			Mounted on counter shaft
		Case I.D.	130 (5.118)	-0.012 (0.00047) -0.052 (0.00204)			
	Bearing 116 TM 91757	Shaft O.D.	65 (2.559)	+0.030 (0.00118) +0.11 (0.00043)			Mounted on Intermediate shaft
		Gear I.D.	120 (4.727)	-0.010 (0.00039) -0.045 (0.00177)			
	Bearing 116 TM 92862	Shaft O.D.	70 (2.75)	+0.030 (0.00118) +0.011 (0.00043)			
		Gear I.D.	125 (4.884)	-0.012 (0.00047) -0.052(0.0020)			
	Bearing 116 TM 92907	Shaft O.D.	85 (3.346)	+ 0.045 (0.00177) + 0.023 (0.00090)			
		Case I.D.	180 (7.086)	-0.120 (0.00047) -0.052 (0.00204)			
	Joint dia. and Oil dia		90 (3.543)	-0.087 (0.00342).	109.85 (4.324)	109.9 (4.326)	
	Bush 116 TM 11777	Inner race O.D.	88 (3.465)	-0.100 (0.00393) -0.135 (0.00531)			
		Bush I.D. (assembled)	88 (3.465)	+ 0.035 (0.00137)			
		Clearance		0.100-0.170 (0.003937 0.00669)		0.2 (0.0078)	
	Seal ring 116 TM 91302	Holder O.D.	a 125 (4.884)	-0.2(0.0078) -0.3(0.0118)			
		Cage I.D.	b 125 (4.884)	+0.15(0.00590) +0.10(0.00393)			
		Clearance	c	0.05 ~ 0.15 (0.0020 ~ 0.0059)		0.4 (0.0157)	
	Dialing 116 TM 91546	Cover I.D.	d 95 (3.740)	+0.054(0.00212)			
		Clearance	e	0.2 ~ 0.35 (0.00787 0.01377)		0.4 (0.0157)	
	Spring 113 BR 11914	Free length	51.8 (2.039)			47.4 (1.866)	
		As-installed length	30 (1.181)				
		Load Kg (lb)	3 (6.615)	±0.3(0.6615)		2.4 (5.2920)	

Maintenance Standards

Unit : mm (in)

System	Item	Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
SHIFTER	Shaft-to-inerlock bracket clearance		0.020~0.074 (0.00078 ~ 0.00291)		0.1 (0.0039)	
	Shaft-to-shift forks clearance		0.040 ~ 0.094 (0.001574 ~ 0.003700)			
	Bush 116 TM 92875	Shaft O.D.	24 (0.945)	-0.040(0.001572) -0.061 (0.0024)		
		Bush I.D. (as assembled)	24 (0.945)	+0.021 (0.000826)		
		Clearance		0.040 ~ 0.082 (0.00157 ~ 0.00328)	0.1 (0.0039)	
	Spring 116 TM 12416	Free length	45 (1.772)		43.0 (1.692)	
		As-installed length	34.6 (1.362)			
		Load Kg(lb)	18 (39.690)	± 1.8(3.9690)	14.4 (31.7520)	
	Bush 116 TM 2315	Shaft O.D.	32 (1.260)	-0.025(0.00098) -0.064(0.00251)		
		Bush I.D. (as assembled)	32 (1.260)	+ 0.039(0.001535)		
		CLEARANCE		0.025 ~ 0.103 (0.000984 ~ 0.004055)	0.15 (0.0059)	
	Shaft-to-oil seal clearance		32 (1.260)	-0.025 (0.00098) -0.064(0.00251)		1.253 (31.85)
	Needle bearing 06120-02520	Shaft O.D.	30 (1.181)	-0.013(0.00051)		
		Case I.D.	37 (1.457)	-0.008(0.00031) -0.033(0.00129)		
	Needle bearing 0612002520	Shaft O.D.	25 (0.984)	-0.013(0.00051)		
		Case I.D.	32 (1.260)	-0.008(0.00031) -0.033(0.00129)		
	Shaft-to-oil seal clearance		30 (1.181)	-0.013(0.00051)		29.85 (2.4251)
	Spring 116 TM 12295	Free length	64 (2.520)			61.6 (1.1751)
		As-installed length	52 (2.047)			
		Load Kg (lb)	6 (0.591)	± 0.6(1.3230)		4.8 (10.584)
	Bush 116 TM 12246	Pin O.D.	15 (0.591)	-0.016(0.00062) -0.034(0.001338)		
		Bush I.D. (as assembled)	15 (0.591)	+0.027(0.00106)		
		Clearance		0.016~0.061 (0.00062~0.00240)	0.1 (0.00393)	
	Bush 116 TM 92275	Pin O.D.	14 (0.551)	-0.032(0.001259) -0.059(0.00232)		
		Bush I.D. (as assembled)	14 (0.551)	+0.027(0.00106)		
		Clearance		0.032 ~ 0.086 (0.001259 ~ 0.00338)	0.1 (0.00393)	


Maintenance Standards

Unit : mm (in)


System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
SHIFTER	Spring 110 TM 11536	Free length	35 (1.378)			32.6 (1.283)	
		As installed length	23 (0.906)				
		Load Kg (lb)	3 (6.615)	±0.3(0.615)		2.4 (5.2920)	
MAIN CLUTCH LEVER	Needle bearing 06120-02520	Shaft O.D.	25 (0.984)	-0.013 (0.0005)			
		Bearing I.D.	32 (1.260)	-0.008(0.000031) -0.033 (0.00129)			
	Shaft dia. and Oil seal dia.		25 (0.984)	-0.013(0.00005)		24.85 (0.9783)	
	Spring 150.43.12380	Free length	68 (2.677)			64.4 (2.535)	
		As installed length	50 (1.969)				
		Load Kg (lb)	15 (33.075)	± 1.5(3.3075)		12 (26.460)	

Maintenance Standards

Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
P T O	Bearing 06040 ~ 06314	Gear shaft O.D.	70 (2.756)	+0.039(0.001521) +0.020(0.00078)			
		Case I.D.	150 (5.869)	-0.012(0.000468) -0.052(0.002028)			
	Bearing 06041 ~ 01016	Gear shaft O.D.	80 (3.150)	+0.039(0.001521) + 0.020 (0.00078)			
		Case I.D.	125 (4.884)	-0.012(0.000468) -0.052(0.002028)			
	Bearing 06040 ~ 06212	Gear O.D.	60 (2.362)	+0.039(0.001521) +0.020(0.00078)			
		Case I.D.	110 (4.294)	-0.010(0.00039) -0.045(0.001755)			
	Bearing 06040 ~ 06209	Gear O.D.	45 (1.772)	+ 0.033(0.001287) +0.017(0.000663)			
		Case I.D.	85 (3.345)	-0.010(0.00039) -0.045(0.001755)			
	Needle bearing 116 UJ 11024	Spider O.D.	25.486 (1.002954)	-0.021 (0.000819)			
		Bearing I.D.	30.22 (1.18958)	+0.021 (0.000819)			
UNIVERSAL JOINT	Bevel gear backlash			0.25~0.33 (0.00915 ~ 0.01287)		0.75 (0.02925)	M = 8.8 ratio (numbers of teeth) 49/15
	Tapered roller bearing	Shaft O.D.	65 (2.559)	+ 0.039(0.001521) +0.020(0.00078)			
		Cage I.D.	140 (5.475)	-0.012(0.000468) -0.052(0.002028)			
	Disc	Thickness	4.7 (0.1833)	± 0.1 (0.0039)		3.7 (0.1443)	
		Flatness		0.15(0.00585)			
	Drive plate	Thickness		-0.15(0.00585)			
		Flatness		0.2(0.0078)			
	Disc to brake drum clearance			0.3~0.4 (0.0117 ~ 0.0156)		1.0 (0.039)	
	Drive plate to drum clearance			0.3~0.4 (0.0117 ~ 0.0156)		1.0 (0.039)	
	Brake drum face runout			0.04(0.00156)			
	Brake drum radial runout			0.1 (0.0039)			
	Piston O.D.	a	170 (6.656)	-0.45(0.01755) -0.55(0.02145)			
	Drum I.D.	b	170		+0.063 (0.002457)		
	Piston-to-seal ring clearance	c		0.07~0.18 (0.00273 -0.00702)			
	Flange O.D.	d	144.5 (5.6515)	0 -0.1 (0.0039)			
	Bearing cage I.D.	e	145 (5.632)	+ 0.063(0.002457)			
STEERING CLUTCHES							

STEERING CLUTCHES




Maintenance Standards

Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
STEERING CLUTCHES	Flange-to-seal ring clearance	f		0.07 ~ 0.18 (0.00273 ~ 0.00702)	0.4 (0.0156)		
	Shaft O.D.	g	89 (3.504)	-0.1 (0.0039)			
	Flange I.D.	h	90 (3.543)	+0.054(0.002106)			
	Shaft-to-seal ring clearance	i		0.07 ~ 0.18 (0.00273 ~ 0.00702)	0.4 (0.0156)		
	Spring 175-22-11180	Free length	132.9 (5.1951)			126.9 (4.9257)	
		As-installed length	87 (3.425)				
		Load	135 kg (298 lb)	± 13.5 kg (29.8 lb)		121.5 kg (268 lb)	

Maintenance Standards

Unit : mm (in)


System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
STEERING OIL PUMP	Spool in valve body			0.04~0.05 (0.00156~0.00195)			145-14-23710 & 154-21-15210 
	Valve to housing clearance			0.02~0.03 (0.00078~0.00117)			
	Spring 170-43-22240	Free length	60.15 (2.3679)			58.7 (2.3103)	
		As-installed length	53 (2.087)				
		Load	10 kg (22lb)	± 1.0 kg (2.2 lb)		8 kg (18 lb)	
	Spring 154-21-15220	Free length	42 (1.654)				
		As-installed length	40 (1.575)				
		Load	5.23 kg (11.5lb)	± 0.5 kg (1.1 lb)		4.2 kg (9.3lb)	
	Lever shaft dia. and oil seal I.D.		25 (0.984)	-0.020 (0.00078) -0.041 (0.001599)		24.85 (0.97815)	
	Lever to plunger clearance	J					
	Side clearance			0.075 ~ 0.085 (0.0029 ~ 0.0033)		0.115 (0.0045)	Side clearance = gear case width-gear width
	Shaft-to-needle bearing clearance (after press fitting)		25 (0.984)	0.008 ~ 0.051 (0.00031 ~ 0.0020)		0.081 (0.0032)	
	Top clearance			0.075 ~ 0.090 (0.002925 ~ 0.00351)		0.120 (0.0047)	Top clearance = (gear I.D.-gear O.D.)/2
	Gear backlash			0.12 ~ 0.21 (0.0047 ~ 0.0082)		0.33 (0.0129)	
	Gear	O.D.	53.3 (2.098)	-0.070(0.00275) -0.085(0.003315)			
		Face width	42 (1.654)	-0.050(0.00195) -0.060(0.00234)		-0.160 (0.0062)	
		Shaft dia.	25 (0.984)	-0.009(0.000351)		-0.039 (0.001521)	
	Gear case	Bore dia.	53.3 (2.0987)	+ 0.095(0.003705) + 0.080(0.00312)	+ 0.155 (0.006045)		
		Width	42 (1.654)	+0.035(0.001365) + 0.025(0.000975)			
	Spline displacement over three teeth		13.516 (61 ft. lb)	-0.110(0.00429) -0.166(0.006474)	Backlash 0.3 (0.0117)		Backlash 0.3 (0.0017)
	Tightening torque kg.m (ft. lb)		8.5 (61 ft. lb)	± 0.5(3.6ft. lb)			
	Capacity:		Discharge pressure 30 kg/cm ² (427 PSI); Oil temperature 50 ~ 55°C (122 ~ 131°F)				
			Performance criteria				
			Pump RPM	Actual capacity 4m	Calculated capacity 4m	Volumetric efficiency %	
			1150	37.7 min.	46.0	82 min.	
			2300	82.6 min.	92.0	90 min.	
			Service limit				
			1150			60	
			2300			75	

Maintenance Standards

Unit : mm (in)

System	Item	Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
BRAKES	Brake-band lining thickness	9.5 (0.3735)			5.0 (0.197)	
	Brake drum O.D.	425 (16.844)			420 (16.547)	
	lining to brake drum clearance		0.3(0.0117)			
	Shaft dia. and oil seal I.D.	55 (2.165)	-0.019(0.00741)			
	Shaft dia. and oil seal I. D.	40 (1.575)	-0.016(0.000624)			
	Needle bearing 154-33-11360	Shaft O.D.	55 (2.165)	-0.019(0.000741)		
		Cover I.D.	68 (2.677)	-0.009(0.000351) -0.039(0.001521)		
		Shaft O.D.	40 (1.575)	-0.0016(0.000624)		
		Cover I.D.	47 (1.850)	-0.008(0.000312) 0.033(0.001287)		
	Spring 150-33-12171	Free length	78.3 (3.0827)		82 (3.228)	
		As-Installed length	97 (3.82)			
		Load	20 Kg (44 lb)	+ 1.6 kg (3.5 lb)	16 Kg (35 lb)	
	Spring 100-33-13120	Free length	42.4 (1.6696)		43.4 (1.7086)	
		As-Installed length	47 (1.8656)			
		Load	4.54 kg. (10 lb)	± 0.5 kg (1.1lb)	3.6 kg (7.916)	
BRAKE PEDALS	Needle bearing 06120-03520	Shaft O.D.	35 (1.378)	-0.016(0.000624)		
		Pedal I.D.	42 (1.654)	-0.008(0.000312) -0.033(0.001287)		
	Needle bearing 06120-03520	Shaft O.D.	35 (1.378)	-0.016(0.000624)		
		Bearing I.D.	42 (1.654)	-0.008(0.000312) -0.033(0.001287)		
	Shaft to oil seal		35 (1.3780)	-0.018(0.000702)		
	Spring 154-44-11820	Free length	274 (10.793)		278 (10.951)	
		As-installed length	290 (11.423)			
		Load	29.9 kg (66 lb)	+ 2.4 kg (5.3 lb)	23.9 kg (53 lb)	
		Free length	79 (3.110)		81 (3.189)	
		As-Installed length	85 (3.346)			
		Load	5.36 kg (12 lb)		3.6 kg (8 lb)	

STEERING BRAKE






Maintenance Standards

Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
STEERING LEVER	Needle bearing 06120-02520	Shaft O.D.	25 (0.984)	-0.013(0.000507)			
		Lever I.D.	32 (1.260)	-0.008 (0.000312) -0.033 (0.001287)			
	Shaft to oil seal fit		25 (0.984)	-0.013(0.000507)			
TRANSMISSION CONTROL LEVER	Needle bearing 06120-02520	Shaft O.D.	25 (0.984)	-0.013(0.000507)			
		Lever I.D.	32 (1.260)	-0.008(0.000312) -0.033(0.001287)			
	Needle bearing 06120-02520	Shaft O.D.	25 (0.984)	-0.013(0.000507)			
		Bracket I.D.	32 (1.260)	-0.008(0.000312) -0.033(0.001287)			
	Shaft to oil seal fit		25 (0.984)	-0.013(0.000507)			
	Spring 154-44-12460	Free length	79 (3.110)			81 (3.189)	
		As-Installed length	85 (3.346)				
		Load	5.36 kg (12 lb)			3.6 kg (8 lb)	
ACCELERATOR LEVER	Needle bearing 06120-02520	Shaft O.D.	25 (0.984)	-0.013(0.000507)			
		Lever I.D.	32 (1.260)	-0.008(0.000312) -0.033(0.001287)			
	Needle bearing 06120-02520	Shaft O.D.	25 (0.984)	-0.013(0.000507)			
		Bracket I.D.	32 (1.260)	-0.008(0.000312) -0.033(0.001287)			
	Shaft to oil seal fit		25 (0.984)	-0.013(0.000507)			
	Governor lining thickness		2.5 (0.0984)			2.0 (0.078)	
	Spring 150-43-14421	Free length	53.5 (2.1065)			51.2 (2.0158)	
		As-Installed length	42 (1.654)				
		Load	56 kg (123 lb)	± 5.6kg (12.34587lb)		45 kg (99 lb)	
	Spring 150-43-14950	Free length	43.2 (1.7008)				
		As-installed length	35 (1.378)			41.4 (1.6296)	
		Load	8 kg. (18 lb)			6.4 kg (14lb)	
	Spring 154-44-12460	Free length	79 (3.110)			81 (3.189)	
		As-Installed length	85 (3.346)				
		Load	5.36 kg (12 lb)			3.6 kg (8 lb)	


Maintenance Standards

Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
TRACK	Link pitch		216 (8.510)	± 0.1 (0.0039)	*219 (8.628)	227 (8.943)	 <p>Note : *When maximum value is reached, repair by inverting pin and bush. Other worn parts can be repaired by depositing</p>
	Single-grouser height	A	65 (2.559)	±1 3(0.118)	25 (0.984)	20 (0.787)	
	Link height		123 (4.846)	±0.1	115.5 (5.2195)	113 (4.412)	
	Bush O.D.		71 (2.795)	+ 0.314 (0.012246) +0.174(0.006786)	*68 (2.667)	59 (2.323)	
	Bush to link fit			0.102~ 0.314 (0.003978 ~ 0.012246)			
	Pin to link fit	Pin	47 (1.850)	0.138~ 0.3 (0.005382~ 0.117)			
		Link	46.8 (1.8422)				
	Pin to bush clearance			0.1~ 0.7 (0.0039 ~ 0.0273)			
	Master bush to link fit			0.102 -0.314 (0.003978 - 0.012246)			
	Master pin to link fit			0.078~ 0.17 (0.003042 ~ 0.00663)			
	Master pin to master bush clearance			0.3 ~ 0.8 (4.0117~ 0.0312)			
	Shoe bolt torque limit		87 kg.m (629.271 ft.lb)	±7 kg.m (50.631 ft.lb)			
TRACK FRAME GROUP	Track center-to-center distance		2000 (78.8)			15 (0.591)	per 1000mm (39.4 in) of length
	Track frame distortion					7 (0.276)	per 300mm (11.82
	Track frame twist					3 (0.118)	
	Idler-side track frame opening					5 (0.197)	
	Guard to track pin clearance	A		12(0.472)		20 (0.787)	
	Guide width	A	134 (5.279)			140 (5.475)	
	Guide width	B	132 (5.200)				
	Guide-to-track frame clearance	C		0.5(0.0195)	*3 (0.118)	3 (0.118)	
	Guide to-track frame clearance	D		2(0.078)			

Maintenance Standards

Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
TRACK FRAME GROUP	Idler	Flange O.D.	A	774 (30.493)		760 (29.942)	
		Riding face O.D.	B	730 (28.761)		715 (28.171)	
		Flange width	C	95.6 (3.7634)		79.6 (3.1334)	
		Riding face width	D	49.5 (1.9485)		51.5 (2.0275)	
		Idler width	E	204 (8.037)		194 (7.641)	
		Shaft end play			0.4 ~ 0.85 (0.0156 ~ 0.0331)		1.5 I (0.0591)
		Shaft to bush clearance			0.27 ~ 0.394 (0.01053 ~ 0.015366)		1.5 (0.0591)
		Shaft O.D.	F	72 (2.835)	-0.21 (0.000819) -0.26 (0.01014)		70.5 (2.7755)
		Shaft flange width	G	20 (0.787)	-0.05 (0.00195)		18.5 (0.7285)
	Track Roller	Flange O.D.	A	257 (10.1124)	±0.5 (0.0195)		247 (9.730)
			A	249 (9.809)			239 (9.415)
		Riding face O.D.	B	222 (8.746)	±0.5 (0.0195)		207 (8.156)
		Riding face width	C	55.6 (2.188)			66.6 (2.6214)
			C	51.6 (2.244)			68.6 (2.7004)
		Flange width	D	17.3 (0.6811)			6 (0.236)
			D	18.2 (0.7168)			6 (0.236)
		Shaft end play			0.4 ~ 0.85 (0.0156 ~ 0.03315)		1.5 (0.0591)
		Shaft-to-bush clearance			0.27 ~ 0.394 (0.01053 ~ 0.01536)		1.5 (0.0591)
		Roller-to-bush clearance			0.017 ~ 0.15 (0.0066 ~ 0.0059)		
		Shaft O.D.	E	70 (2.756)	-0.21 (0.00819) -0.26 (0.01014)		68.5 (2.6965)
		Shaft flange width	F	20 (0.787)	-0.05 (0.00195)		18.5 (0.7285)
	Carrier Roller	Flange O.D.	A	200 (7.88)			190 (7.483)
		Riding face O.D.	B	168 (6.577)			155 (6.105)
		Riding face width	C	57 (2.244)			66 (2.598)
		Flange width	D	16 (0.630)			7 (0.276)
		Roller end play			0.1 ~ 0.13 (0.0039 ~ 0.00507)		
		Tapered roller bearing	Shaft O.D.	55 (2.165)	+0.021 (0.000819) +0.002 (0.00078)		
			Roller I.D.	100 (3.9)	-0.024 (0.000936) -0.059 (0.002301)		

Maintenance Standards


Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
TRACK FRAME GROUP	Floating Seal	Step in mating face	0.7 (0.0273)	± 0.2(0.0078)			
		Surface roughness		0.2 ~ 5(max) (0.0078 ~ 0.197)			
	Recoil spring	Free Length	823 (32.426)			803 (31.638)	
		As-installed Length	675 (26.593)				
		Load	14050 kg (30974lb)	± 1125 kg (2480 lb)		12250 kg (27006 lb)	
		Adjusting cylinder-to-bush Clearance	100 (3.94)	0.086 ~ 0.21 (0.00335 ~ 0.00819)		0.5 (0.0195)	
		Clearance between sprocket wheel Shaft and diagonal brace bush	90 (3.543)	0.036 ~ 0.106 (0.001404 ~ 0.004134)		0.5 (0.0195)	


Maintenance Standards

IDLER


Unit: mm




CARRIER ROLLER



TRACK ROLLERS




TRACK FRAME GROUP




Maintenance Standards

Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
HYDRAULIC SYSTEM	Blade Lift Cylinder	Piston O.D. A	120 (4.727)	-0.4(0.0156) -0.8(0.0312)			
		Piston ring O.D. B	120 (4.727)	-0.12(0.00468) -0.26(0.01014)			
		Piston to piston ring clearance C		0.14 ~ 0.68 (0.00546 ~ 0.02652)		0.1 (0.0039)	
		Piston rod O.D. and bush I.D. (1.969)	65 (2.559)	0.155 ~ 0.249 (0.006045 ~ 0.009711)		1 (0.039)	
		Ball bearing I.D. and pin O.D. (1.969)	50 (1.969)	0.050 ~ 0.151 (0.00195 ~ 0.005889)		1 (0.039)	
		Cylinder trunnion to bush fit	65 (2.559)	0.100 ~ 0.220 (0.0039 ~ 0.00858)		1 (0.039)	
		Yoke to bush (large) fit	115 (4.531)	0.072 ~ 0.180 (0.002808 ~ 0.00702)		1 (0.039)	
		Yoke to bush (small) fit	76 (2.992)	0.060 ~ 0.152 (0.00234 ~ 0.005928)		1 (0.039)	
	Control Valve	Spool to valve body fit	45 (1.772)	0.020 ~ 0.025 (0.00078 ~ 0.000975)	0.035 (0.001365)		
		Check valve to valve body fit	38 (1.496)	0.025 ~ 0.089 (0.000975 ~ 0.003471)			
		Relief valve to valve body fit	38 (1.496)	0.020 ~ 0.030 (0.00078 ~ 0.00117)	0.04 (0.00156)		
		Suction valve to valve body fit	44 (1.732)	0.020 ~ 0.030	0.04		
		Safety valve to valve body fit	24 (0.945)	0.015 ~ 0.020 (0.000585 ~ 0.00078)	0.030 (0.00117)		
		Safety valve to valve Bodyfit	7 (0.276)	0.012~0.025 (0.000468 ~ 0.000975)	0.035 (0.001365)		
		Spring 154-60-11831	103 (4.058)			94.2 (3.7088)	
			72 (2.835)				
			12 kg (26lb)	± 0.5 kg (1.1 lb)		0.6 kg (2.1 lb)	
		Spring 980-78-14180	95.3 (3.7517)			91.5 (3.6025)	
			76 (2.992)				
			7.5 kg (17 lb)	± 0.7 kg (1.5 lb)		6.0 kg (13 lb)	
		Spring 154 60 11280	72.5 (2.8545)			67.2 (2.6458)	
			46 (1.8)				
			13.76 kg (30lb)	± 0.6 kg (1.3 lb)		11.0 kg (24 lb)	
		Spring 110 eV 11132	44.4 (1.7476)			43.2 (1.7008)	
			38 (1.496)				
			24.8 kg (55 lb)	± 0.99 kg (2.2 lb)		20.0 kg (44 lb)	
		Spring 154-60-11930	94.2 (3.7088)				
			50 (1.969)				
			1.32 kg (2.9 lb)	± 0.053 kg (0.11 lb)		1.2 kg (2.6 lb)	

Maintenance Standards

Unit : mm (in)

System	Item		Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks
HYDRAULIC SYSTEM	Control Valve	Spring 141-60-12561	Free length	66.4 (2.6136)		65.5 (2.5785)	
			As-Installed length	60.25 (2.37175)			
			Load	23.35 kg (51 lb)	± 0.7 kg (1.5 lb)	20 kg (44 lb)	
		Spring 141-60-12570	Free length	69.4 (2.7326)		68.75 (2.70625)	
			As-installed length	66.25 (2.60775)			
			Load	8.82 kg (19 lb)	+0.4 kg (0.9 lb)	7.0 kg (15 lb)	
		Spring 154-60-12240	Free length	111.5 (4.3925)			
			As-installed length	50 (1.96)			
			Load	15 kg (33 lb)	± 0.5 kg (1.1 lb)	12 kg (26 lb)	
	Ripper Cylinder	Piston ring O.D. and cylinder tube I.D.		150 (5.909)	-0.075 (0.002925) + 0.15(0.00585)	0.5 (0.0195)	
		Piston rod O.D. and bush I.D.		65 (2.559)	0.247-0.507 (0.009633 ~ 0.019773)	1 (0.0394)	
		Pin O.D. and bush I.D.		75 (2.953)	0.100 ~ 0.344 (0.0039 ~ 0.013416)	1 (0.0394)	
	Tilt Cylinder	Piston ring O.D. and cylinder tube I.D.		225 (8.858)	-0.096(0.0037) +0.15(0.0059)	0.5 (0.0195)	
		Piston rod and bush I.D.		90 (3.543)	- 0.120 ~ 0.261 (0.0047 ~ 0.01012)	1 (0.0394)	
		Pin O.D. and bush I.D.		60 (2.362)	0.5 ~ 0.8 (0.0195 ~ 0.0312)		
	Hydraulic Oil Pump	Gear-to-bush clearance			0.10 ~ 0.15 (0.0039 ~ (0.00585)	0.20 (0.0078)	Clearance as measure in this place 
		Case-to-bush clearance			0.050 ~ 0.070 (0.0020 ~ 0.0027)		
		Bush-to- bush clearance			0.03 ~ 0.05 (0.0012 ~ 0.0020)		
		Gear top clearance		84 (3.307)	0.090 ~ 0.120 (0.0035 ~ 0.0047)	0.135 (0.0052)	
		Depth of score mark on case bore			0 ~ 0.02(0.00078)		
		Fit on needle bearing	Bush	56.5 (2.2245)	-0.003(0.00012) -0.006(0.00023)		
			Shaft	38 (1.496)	0.025 ~ 0.051 (0.0010 ~ 0.0020)	0.10 (0.0039)	
		Gear	Backlash		0.19 ~ 0.31 (0.0074 ~ 0.0121)	0.45 (0.0176)	
		Full length of bush	Bracket side	42.5 (1.673)	-0.020(0.00078)	42.1 (1.657)	
			Cover side	44.5 (1.752)	-0.020(0.00078)	44.1 (1.736)	
		Parts Dimensions	Shaft dia.	38 (1.496)	-0.010(0.00039)		
			Bush I.D.				
			Case bore dia.	84 (3.307)	+0.035 (0.001365) + 0.015 (0.000585)		

Maintenance Standards

Unit : mm (in)

System	Item			Basic Size	Standard Clearance or Assembly Standard	Repairable Size Limit	Clearance Limit or Service Limit	Remarks	
HYDRAULIC SYSTEM		Parts Dimensions	Gear O.D.	84 (3.307)	-0.130(0.00507) -0.145(0.005655)			Backlash 0.30 (0.012)	
			Spline displacement over three teeth	13.656 (0.53758)	-0.087(0.003393) -0.129(0.005031)				
	Hydraulic Oil Pump	Bolt Tightening Torque Kg. m (ft. lb)		15 ~ 18 (108 ~ 130 ft. lb)					
		Capacity		Discharge pressure	140 kg/cm ² (1991 PSI)	Oil temperature 45 ~ 55°C (113 ~ 131° F)			
				Performance criteria					
				Pump RPM	Actual capacity l/min	Calculated capacity l/min		Volumetric efficiency %	
				1000	142.5 min.	162.0		88 min.	
				2000	301.0 min.	324.0		93 min.	
				Service limit					
				1000	113.5			70	
				2000	275.5			85	

Notes