SE 170 M 06 00 07






SHOP MANUAI

BS(A)6D170-1 SERIES DIESEL ENGINE

BEML LIMITED MYSORE, INDIA.

CONTENTS

00	SAFETY AND FORWARD	00-001
11	GENERAL	11-001
12	STRUCTURE AND FUNCTION	12-001
13	TESTING AND ADJUSTING	13-001
14	DISASSEMBLY AND ASSEMBLY	14-001
15	MAINTENANCE STANDARD	15-001
16	REPAIR AND REPLACEMENT OF PARTS	16-001





GENERAL PRECAUTIONS

Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully BE-FORE operating the machine.

- 1. Before carrying out any greasing or repairs, read all the precautions given on the decals which are fixed to the machine.
- 2. When carriyng out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
- Always wear safety glasses when hitting parts with a hammer.
- Always wear safety glasses when grinding parts with a grinder, etc.
- If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
- 4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the opera-

tion. Before starting work, hang UNDER REAIR signs on the controls in the operator's compartment.

- 5. Keep all tools in good condition and learn the correct way to use them.
- 6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.

PREPARATIONS FOR WORK

- 7. Before adding oil or making any repairs, part the machine on hard, level ground, and block the wheels or tracks to prevent the machine from moving.
- 8. Before starting work, lower blade, ripper, bucket or any other work equipment to the ground. If this is not possible, insert the safety pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.

- 9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
- 10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

PRECAUTIONS DURING WORK

- 11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out.Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.
- The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned. Wait for the oil and water to cool before carrying out any work on the oil or water circuits.
- Before starting work, remove the leads from the battery. Always remove the lead from negative (-) terminal first.
- 14. When raising heavy components, use a hoist or crane.

Check that the wire rope, chains and hooks are free from damage.

Always use lifting equipment which has ample capacity.

Install the lifting equipment at the correct places. Use a hoist or crane and operate slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.

15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.

- 16. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.
- 17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips on to the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.
- 18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.
- Be sure to assemble all parts again in their original places.
 Replace any damaged parts with new parts.
- When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
- 20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also, check that connecting parts are correctly installed.
- 21. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
- 22. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
- 23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.
- 24. Take care when removing or installing the tracks of track-type machines.When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

FOREWORD

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into chapters for each main group of components; these chapters are further divided into the following sections.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjust ments to be made at completion of the checks and repairs.

Troubleshooting charts correlating "Problems" to "Causes" are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your **beml** Regional Office for the latest information.

HOW TO READ THE SHOP MANUAL

HOW TO READ THE SHOP MANUAL

VOLUMES

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

Chassis volume :	: Issued for every machine				
	mod	el			
Engine volume :	Issue	ed fo	r each engine series.		
Electrical volume Attachments volu	e	:)	Each issued as		
		}	one volume to		
Attachments volu	me	:]	cover all models		

These various volumes are designed to avoid duplicating the same information. Therefore to deal with all repairs for any model, it is necessary that chassis, engine, electrical and attachment volumes are ready.


DISTRIBUTION AND UPDATING

Any additions, amendments or other changes will be sent to **beml** Regional office. Get the most upto-date information before you start any work.

FILING METHOD

- 1. See the page number on the bottom of the page. File the pages in correct order.
- 2. Following examples show how to read the page number.

Example.



3. Additional pages: Additional pages are indicated by a hyphen (-) and number after the page number. File as in the example. Example:

REVISED EDITION MARK ((1) (2) (3) ...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

REVISIONS

Revised pages are shown at the LIST OF RE-VISED PAGES on the between the title page and SAFETY page.

SYMBOLES

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks
		Special safety precautions are necessary when performing the work.
Ŷ	Safety	Extra special safety precautions are necessary when performing the work because it is under internal pressure.
*	Caution	Special technical precautions or other precautions for preserv ing standards are necessary when performing the work.
kg	Weight	Weight of parts or systems. Caution necessary when selecting hoisting wire, or when working posture is important, etc.
2 kgm	Tighten- ing torque	Places that require special attention for the tightening torque during assembly.
<u>k</u>	Coat	Places to be coated with adhesives and lubricants etc.
	Oil, water	Places where oil, water or fuel must be added, and the capacity.
<u>.</u>	Drain	Places where oil or water must be drained, and quantity to be drained.

HOISTING INSTRUCTIONS

HOISTING INSTRUCTIONS

Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is indicated clearly with the symbol

- 1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
 - Check for removal of all bolts fastening the part to the relative parts.
 - Check for existence of another part causing interference with the part to be removed.

2. Wire ropes

1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes							
(Standard "Z" or"S" twist ropes							
without	without galvanizing)						
Rope diameter (mm)	Allowable load (tons)						
10	1.0						
11.2	1.4						
12.5	1.6						
14	2.2						
16	2.8						
18	3.6						
20	4.4						
22.4	5.6						
30	10.0						
40	18.0						
50	28.0						
60	40.0						

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.


2) Sling wire ropes from the middle portion of the hook.

Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result.



kg


Hooks have maximum strength at the middle portion.



- Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.
 - Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.
- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.When hoisting a load with two or more ropes, the force subjected to each rope will increase with

the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150° .



00-005



STANDARD TIGHTENING TORQUE

1. STANDARD TIGHTENING TORQUE OF BOLTS AND NUTS

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in section of **"Disassembly and Assembly**

Thread diameter of bolt (mm)	width across flat (mm)	kgm	Nm
6	10	$\begin{array}{c} 1.35 \pm 0.15 \\ 3.2 \pm 0.3 \\ 6.7 \pm 0.7 \\ 11.5 \pm 1.0 \\ 18.0 \pm 2.0 \end{array}$	13.2±1.4
8	13		31.4±2.9
10	17		65.7±6.8
12	19		112±9.8
14	22		177±1.9
16	24	28.5±3	279±29
18	27	39±4	383±39
20	30	56±6	549±58
22	32	76±8	745±78
24	36	94.5±10	927±98
27	41	135±15	$ \begin{array}{r} 1320 \pm 140 \\ 1720 \pm 190 \\ 2210 \pm 240 \\ 2750 \pm 290 \\ 3280 \pm 340 \end{array} $
30	46	175±20	
33	50	225±25	
36	55	280±30	
39	60	335±35	

This torque table does not apply to the bolts with which nylon packings or other non-ferrous metals washers are to be used, or which require tightening to otherwise specified torque.


* Nm (newton meter): 1 Nm = 0.1 kgm

2. TIGHTENING TORQUE OF SPLIT FLANGE BOLTS

Thread diameter of bolt	Width across flats	Tightenii	ng torque
(mm)	(mm)	kgm	Nm
10 12 16	14 17 22	6.7±0.7 11.5±1 28.5±3	65.7±6.8 112±9.8 279±29

Use these torques for split flange bolts.

STANDARD TIGHTENING TORQUE



Use these torques for nut part of flared.

3.

OF FLARED

Thread diameter of nut part	width across flats of nut part	Tightenir	ng torque
(mm)	(mm)	kgm	Nm
14	19	2.5±0.5	24.5±4.9
18	24	5±2	49±19.6
22	27	8±2	78.5±19.6
24	32	14±3	137.3±29.4
30	36	18±3	176.5±29.4
33	41	20±5	196.1±49
36	46	25±5	245.2±49
42	55	30±5	294.2±49

COATING MATERIALS



The recommended coating materials prescribed in **beml** Shop Manuals are listed below.

Nomenclature	BEML code	Applications			
	LT-1A	Used to apply rubber pads, rubber gaskets, and cork plugs			
	LT-1B	Used to apply resin, rubber, metallic and non-metallic parts when a fast,			
		strong seal is needed			
Adhesives	LT-2*	Preventing bolts, nuts and plugs from loosening and leaking oil.			
	LT-3	Provides an airtight, electrically insulating seal.			
		Used for aluminum surfaces.			
	LT-4	Used to coat plugs (plate shaped, bowl shaped) and holes, and mating			
		portion of shaft.			
	LG-1	Used with gaskets and packings to increase sealing effect.			
	LG-3	Heat-resistant gasket for precombustion chambers and exhaust piping.			
	LG-4	Used by itself on mounting surfaces on the final drive and transmission			
Sealant gasket		cases. (Thickness after tightening: 0.07 - 0.08 mm)			
	LG-5	Used by itself to seal grease fittings, tapered screw fittings and tapered			
		screw fittings in hydraulic circuits of less than 50 mm in diameter.			
	LG-6	Silicon base type used in combination with LG-1 and LG-4.			
	LG-7	Has a shorter curing time than LG-6, and is easier to peel off.			
Antifriction compound		Applied to bearings and taper shafts to facilitate press-fittings and to			
(Lubricant including	LM-P	prevent sticking, burning or rusting.			
molybdenum disulfide)					
Grease	G2-L1	Applied to bearings, sliding parts and oil seals for lubrication, rust			
(Lithium grease)	-	prevention and facilitation of assembling work.			
Vaseline Used for protecting battery electrode terminals from corrosion.					
	*LT-2 is al	so called LOCTITE in the shop manuals.			

ELECTRIC WIRE CODE



ELECTRIC WIRE CODE

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires. This wire code table will help you understand WIRING DIAGRAMS. Example: 5WB indicates a cable having a nominal number 5 and white coating with black stripe.


CLASSIFICATION BY THICKNESS

Nominal	Copper Wire					
number	Number	Dia.of strands	Cross section	Cable O.D	Current rating	Applicable circuit
	strands	(mm)	(mm²)	(mm)	(A)	
0.85	11	0.32	0.88	2.4	12	Starting, lighting, signal etc.
2	26	0.32	2.09	3.1	20	Lighting, signal etc.
5	65	0.32	5.23	4.6	37	Charging and signal
15	84	0.45	13.36	7.0	59	Starting (Glow plug)
40	85	0.80	42.73	11.4	135	Starting
60	127	0.80	63.84	13.6	178	Starting
100	217	0.80	109.1	17.6	230	Starting

CLASSIFICATION BY COLOR AND CODE

Prior- ity	Classi- ficatior		Charging	Ground	Starting	Lighting	Instrument	Signal	Other
1	Pri-	Code	W	В	В	R	Y	G	L
	mary	Color	White	Black	Black	Red	Yellow	Green	Blue
2		Code	WR	-	BW	RW	YR	GW	LW
		Color	White & red	-	Black & White	Red & White	Yellow &Red	Green & White	Blue & White
3		Code	WB	-	BY	RB	YB	GR	LR
		Color	White & Black	-	Black & Yellow	Red & Black	Yellow & Black	Green & Red	Blue & Red
4	Aux-	Code	WL	-	BR	RY	YG	GY	LY
	iliary	Color	White & Blue	-	Black & Red	Red & Yellow	Yellow & Green	Green & Yellow	Blue & Yellow
5		Code	WG	-	-	RG	YL	(GB)	(LB)
		Color	White & Green	-	-	Red & Green	Yellow & Blue	(Green & Black)	(Blue & Black)
6		Code	-	-	-	RL	YW	(GL)	-
		Color	-	-	-	Red & Blue	Yellow & White	(Green & Blue)	-

ENGINE 11 GENRAL



SPECIFICATION	11-002
GENERALASSEMBLY DRAWING	11-006
WEIGHT TABLE	11-018
ENGINE PERFORMANCE CURVE	11-019

SPECIFICATIONS

	Engine model		BS6D170-1		
	Applicable machine		BD155 / BP70	BD355/BD355X/BP100	
Т	umber of cylinder - Bore x Stroke otal piston displacement iring order	mm cc	6 - 170 x 170 23,150 1 - 5 - 3 - 6 - 2 - 4		
Dimensions	Overall length Overall width Overall height (Excluding exhaust pipe) Overall height (Including exhaust pipe)	mm mm mm mm	1,873 1,190 1,922	1,873 1,265 1,922	
Performance	Flywheel horsepower Maximum torque High idling Low idling Minimum fuel consumption ratio	HP/rpm kgm/rpm rpm g/HP.h	320/2,000 144/1,400 2,200 650 168	410/2,000 176/1,400 2,200 650 164	
D	ry weight	kg	2,620	2,700	
	uel pump overnor		Bosch PE-PD type Bosch RSUV centrifugal, all-speed type		
L	ubricating oil amount (refill capacity	r) 👔	58 (43)	58 (43)	
С	oolant amount	8	143	163	
Aternator Starting motor Battery			24V, 35A (STD) 24V, 50A (OP.) 24V, 11KW x 1 12V, 200Ah x 2	24V, 35A (STD) 24V, 50A (OP.) 24V, 11KW x 1 12V, 200Ah x 2	
Turbocharger Air compressor After cooler			Komatsu KTR110/TEL-K36. - -	Komatsu KTR110/TEL-K36. - -	


SPECIFICATIONS


Engine model			BSA6D170-B-1	
	Applicable machine	BE1000		
Т	Number of cylinder - Bore x Stroke mm Total piston displacement cc Firing order		6 - 170 x 170 23,150 1 - 5 - 3 - 6 - 2 - 4	
Dimensions	Overall length Overall width Overall height (Excluding exhaust pipe) Overall height (Including exhaust pipe)	mm mm mm	2,373 1,190 1,080	
Performance	Flywheel horsepower Maximum torque High idling Low idling Minimum fuel consumption ratio	HP/rpm kgm/rpm rpm g/HP.h	$542/1,700260/1,3001,850 \pm 50675 \pm 25155$	
D	Dry weight kg		2,555	
Fuel pump Governor		Bosch PE-P type Bosch RSUV centrifugal, all-speed type		
Lubricating oil amount (refill capacity)		63 (51)		
Coolant amount		160		
Aternator Starting motor Battery		24V, 50A 24V, 7.5kW x 2 12V, 200Ah x 2		
Turbocharger		Komatsu KTR110 Diesel Kiki		
Air compressor Other			single cylinder double acting type With after cooler	


Engine model		BSA6D170A-1			
Applicable machine		BH60	BH70	210M	
No. of cylinders - Bore x Stroke mm Total piston displacement cc Firing order		6 - 170 x 170 23150 1 - 5 - 3 - 6 - 2 - 4			
Dimensions	Overall length Overall width Overall height (Including Fan)	mm mm mm		2002 1137 1678	
Performance	Flywheel horsepower Max. torque High idling speed Low idling speed Min. fuel consumption ratio	kW Bhp/rpm N.m/rpm kgm/rpm rpm rpm g/kWh	504 @ 2100 675 @ 2100 2750 @ 1400 280 @ 1400 2330 ~ 2400 900 ~ 950 212	33 @ 2100 725 @ 2100 2975 @ 1400 303 @ 1400 2330 ~ 2400 900 ~ 950 211	483 @ 2100 647 @ 2100 2618 @ 1400 267 @ 1400 2330 ~ 2400 900 ~ 950 215
D	bry weight	kg	2660	2660	2635
Fuel pump Governor		Bosch type mechanical			
Lubricating oil amount (refill capacity)		8	64 (52)		
Coolant amount (Engine only)		8	200	200	160
Aternator Starting motor Battery			24V, 50A 24V, 7.5 kW x2 12V, 200Ah x 2		
Turbocharger		TV7701 (TEL) TEL			
Air compressor		ZEXEL			
Others		'			


Engine model			BSA6D1	70A-1
	Applicable machine		BDG500	BDG550
Т	fumber of cylinder - Bore x Str otal piston displacement iring order	roke mm cc	6 - 170 x 1 23,150 1 - 5 - 3 - 6 -	
Dimensions	Overall length Overall width Overall height (Excluding exhaust pipe)	mm mm mm	2002 1048 2015	3
Performance	Flywheel horsepower High idling speed Low idling Min. fuel consumption ratio	kW Bhp/rpm rpm rpm g/kWh	426 @ 1500 580 @ 1500 1560 Max. 975 ~ 1025 214	468 @ 1500 637 @ 1500 1560 Max. 975 ~ 1025 212
	Dry weight	kg	265	50
	uel pump overnor		Bosch type Mechanical, centrifu	
Lubricating oil amount (refill capacity)			67 (50)	
Coolant amount		٩	83	
S	ternator tarting motor attery		24V,	. 30A 9kW 0Ah x 2
Turbocharger			KTR	150
0	ther		-	


GENERAL ASSEMBLY DRAWING

































WEIGHT TABLE

No.	ITEM	COMPONENT	BS6D170-1	BSA6D170-1
1	Turbocharger	KTR 110 / KKK	22	-
2	Cylinder head assembly	Cylinder head, vlaue and Valve spring	37	37
3	Cylinder block assembly	Cylinder block, Main bearing cap Cylinder liner	675	675
4	Gear case cover		48	48
5	Timing gear case		30	30
6	Oil pan		45	45
7	Flywheel assembly	Flywheel, Ring gear	83.6	-
8	Flywheel housing		163	-
9	Crankshaft assembly	Crankshaft, Crank gear	270	270
10	Camshaft assembly	Camshaft, cam gear and thrust plate	31	31
11	Piston and connecting rod assembly	Piston, piston ring, piston pin and connecting rod	21	21
12	Oil pump		21	21
13	Fuel injection pump		31	30
14	Water pump		20	20
15	Alternator		9.5	10
16	Starting motor		20	18
17	Air compressor		-	-
18	After cooler		-	43.5

ENGINE PERFORMANCE CURVE

BS6D170-1 (for BD155A-1)


Flywheel horsepower: 320 HP/2,000 rpm Maximum torque: 144 kgm/1,400 rpm Minimum fuel consumption ratio: 168 g/HP.h



BS(A)6D170-1

(BS6D170-1) (for BD355A-3)

Flywheel horsepower: 410 HP/2,000 rpm Maximum torque: 176 kgm/1,400 rpm Minimum fuel consumption ratio: 164 g/HP.h




BSA6D170-B-1 BE1000-1

Flywheel horsepower: 542 HP/1,700 rpm


Maximum torque: 260 kgm/1,300 rpm

Minimum fuel consumption ratio: 155 g/HP.h



BSA6D170A-1 For BH60


Flywheel horsepower	: 504 kW @ 2100 rpm
Max. torque	: 2750 Nm @ 1400 rpm
Min. fuel consumption ratio	: 212 g/ (kW-hr.)



Engine speed (r/min)

BSA6D170A-1 For BH70


Flywheel horsepower	:	533 kW @ 2100 rpm
Max. torque	:	2975 Nm @ 1400 rpm
Min. fuel consumption ratio	:	211 g/ (kW-hr.)



Engine speed (r/min)

BSA6D170A-1 For 210M


Flywheel horsepower	: 483 kW @ 2100 rpm
Max. torque	: 2618 Nm @ 1400 rpm
Min. fuel consumption ratio	: 215 g/ (kW-hr.)



Engine speed (r/min)

BSA6D170A-1 For BDG500


Flywheel horsepower : 580 HP @ 1500 rpm



BSA6D170A-1 For BDG550

Flywheel horsepower

: 637 HP @ 1500 rpm




ENGINE 12 STUCTURE AND FUNCTION



GENERAL STRUCTURE	12-002
INTAKE AND EXHAUST SYSTEM	
Turbocharger	12-004
After-cooler	12-005
ENGINE BODY	
Cylinder head	12-006
Valve system	12-008
Cylinder block	12-010
Main circulation part	12-012
Timing gear	12-014
Flywheel and flywheel housing	12-016
LUBRICATION SYSTEM	
Lubrication system chart	12-017
Oil pump	12-018
Oil filter and safety valve	12-019
Oil cooler	12-020
Oil pump relief valve	12-021
Oil cooler by-pass valve	12-021
Piston cooling valve	12-022
Mechanical pump	12-023
FUEL SYSTEM	
Fuel system chart	12-024
Fuel injection pump	12-025
Fuel injection nozzle	12-027
Fuel injection pump drive	12-028
Fuel filter	12-029
Starting aid	12-030
COOLING SYSTEM	
Cooling system chart	12-031
Water pump	12-032
Fan drive	12-033
Tension pulley	12-034
Corrosion resistor	12-035
Thermostat	12-036
ACCESSORY	
Air compressor mounting	12-037
ELECTRICAL SYSTEM	
Alternator with regulator	12-038
Starting motor	12-042
Wiring diagram	12-047
5 5	-

GENERAL STRUCTURE


BS6D170-1



- 1. Crank pulley
- 2. Thermostat
- 3. Cylinder head
- 4. Fuel injection nozzle
- 5. Rocker arm housing cover
- 6. Piston pin
- 7. Intake valve
- 8. Exhaust valve

- 9. Camshaft
- 10. Rocker arm shaft
- 11. Push rod
- 12. Tappet
- 13. Rocker arm housing
- 14. Cylinder block
- 15. Rear seal
- 16. Vibration damper


- 17. Front seal
- 18. Oil pump
- 19. Connecting rod cap
- 20. Oil pan
- 21. Main bearing cap
- 22. Crankshaft
- 23. Ring gear
- 24. Flywheel



- 25. Cylinder liner
- 26. Piston
- 27. Oil cooler
- 28. Fuel injection pump
- 29. Piston cooling nozzle
- 30. Connecting rod

INTAKE AND EXHAUST SYSTEM TURBOCHARGER

KTR110



- 1. Blower housing
- 2. Blower impeller
- 3. Clamp
- 4. Center housing
- 5. Journal, bearing
- 6. Shield
- 7. Turbine impeller
- 8. Flinger
- 9. Thrust bearing
- 10. Turbin shaft
- 11. Turbine housing

12-0)4
------	----


BS(A)6D170-1

- a. Oil inlet (from oil filter)
- b. Oil outlet (to oil pan)
- c. Air inlet
- d. Air outlet
- e. Exhaust inlet
- f. Exhaust outlet

TURBOCHARGER

Туре	:KTR110
Overall length	:290 mm
Overall width	: 305 mm
Overall height	:267 mm
Weight	: 19 kg
Maximum allowable rotation	: 94,000rpm
Maximum charging	: 46 kg/min.
Maximum allowable temperature (inlet)	$:750^{\circ}$ C max.
Direction of rotation (view from blower side)	: Right
Lubrication method	: Forced
	lubrication
	with engine
	oil


AFTER - COOLER




- 1. Cover
- A: From water pump
- 2. After-cooler body B: To water manifold

BS(A)6D170-1


ENGINE BODY CYLINDER HEAD







- 1. Water manifold
- 2. Cylinder head
- 3. Rocker arm housing
- 4. Rocker arm housing cover
- 5. Valve guide
- 6. Nozzle holder sleeve
- 7. Tube

- a. Coolant (to radiator)
- b. Fuel (return)
- c. Oil (from main gallery)
- d. Tap for water temperature gauge sensor





Section A - A






Cylinder head

- Direct-injection type, injection nozzle, 4-valve type
 Separate type (1-head for 1-cylinder)

Valve seat

. Press fitted into cylinder head of intake valve and exhaust valves.

VLAVE SYSTEM




- 1. Intake valve
- 2. Exhaust valve
- 3. Rocker arm
- 4. Collar
- 5. Camshaft gear (No. of teeth:48) 12. Lower spring seat
- 6. Camshaft
- 7. Adjustment screw

- 8. Lock nut
- 9. Upper spring seat
- 10. Valve spring (outer)
- 11. Valve spring (inner)
- 13. Push rod
- 14. Cam roller

- 15. Cam follower pin
- 16. Cam follower
- 17. Cam follower shaft
- 18. Adjustment screw
- 19. Lock nut
- 20. Cross head
- a. Oil (from oil pump)

18

12



13

14

15


16

17

Intake side of No. 1 cylinder

Exhaust side of No. 1cylinder


Valve timing



Cam shaft


- Special cast/forged alloy, 7 bearings
- Cam face and journal face: High frequency hardening

CYLINDER BLOCK



- 1. Front cover
- 2. Cylinder block
- 3. Cylinder liner
- 4. Crevice seal
- 5. O-ring (nitrile rubber: black)
- 6. O-ring (silicone rubber: red)
- 7. Front seal

- 8. Main bearing
- 9. Thrust bearing
- 10. Cam bushing
- 11. Piston cooling nozzle
- 12. Main bearing cap
- 13. Main bearing cap bolt
- 14. Oil level gauge




Cylinder block

- Crankshaft: Seven bearingsCamshaft: Seven bearings

Cylinder liner

- . Wet type liner, tufftride treatment on bore surface . Crevice seal, two O-rings

MAIN CIRCULATION PART




- 1. Piston pin
- 2. Connecting rod
- 3. Connecting rod bushing
- 4. Piston
- 5. Top ring
- 6. 2nd ring
- 7. Oil ring
- 8. Crank pulley (Outside diameter: 200 mm)

- 9. Vibration damper
- 10. Crank gear (No. of teeth: 36)
- 11. Connecting rod bearing
- 12. Crankshaft
- 13. Thrust bearing
- 14. Main bearing
- 15. Connecting rod cap
- 16. Connecting rod bolt

Crankshaft

- Special cast/forged alloy, seven bearings
- . Journal face: High frequency hardening

ALUMINUM PISTON TYPE



Main bearing and connecting rod bearing

- . 3-layer Kelmet. Upper main bearing: with oil groove

Piston

- Lo-Ex aluminum alloy
 Groove of top ring: Niresist is cast on top ring.
 Thermal flow solid type (BS6D170-1)
 Thermal flow shaker type
 (BSA6D170-1)
 (DSA6D170-1)
 (DSA6D

- (BSA6D170-B-1)
- . Forced cooling with piston cooling


Connecting rod

. Forged alloy steel

Piston	Piston	ring			
Solid type	Shaker type	Engine	Top ring	2nd ring	Oil ring
			2-face keystone barrel face	2-face keystone inner cut taper face	Bevel cutter with coil expander
p me		BS6D170-1			
AN	60	BSA6D170-B-1	Hard chrome plating	Hard chrome plating	Hard chrome plating
				T	<u> </u>


BS(A)6D170-1


TIMING GEAR





- 1. Idler gear (No. of teeth: 57)
- 2. Cam gear (No. of teeth: 48)
- 3. Compressor driving gear (No. of teeth: 24)
- 4. Injection pump driving gear (No. of teeth: 48)
- 5. Idler gear (No. of teeth: 45)


- 6. Idler gear (No. of teeth: 30)
 - 7. Crankshaft gear (No. of teeth: 36)
 - 8. Oil pump driving gear (No. of teeth: 33)
- 9. Idler gear (No. of teeth: 41)
- 10. Water pump driving gear (No. of teeth: 20)













Section D - D (without timer)

FLYWHEEL AND FLYWHEEL HOUSING






- 1. Ring gear
- 2. Flywheel
- 3. Rear seal
- 4. Flywheel housing
- 5. Drain plug


Ring gear

No. of teeth	Applicable machine		
118	BE1000		
138	BD355A BD155		


Tightening order of flywheel mounting bolt



LUBRICATION SYSTEM CHART



OIL PUMP




- 1. Oil pump driving gear (No. of teeth: 33)
- 2. Oil pump body
- 3. Bushing
- 4. Drive shaft
- 5. Bushing
- 6. Pump cover
- 7. Driven shaft
- 8. Driven gear (No. of teeth: 12)
- 9. Bushing

Oil pump

- . Gear Pump type
- Oil pump speed: Engine speed x 1.091

OIL FILTER AND SAFETY VALVE



OIL COOLER

BS6D170-1 BSA6D170-1


1. Cooler cover

- 2. Cooler element
- 3. Drain cock
- a. Coolant (from water pump)
- b. Oil (from oil pump)
- c. Oil (to engine each component)


Oil cooler

- . Heat exchanged: Min. 45000 Kcal/hr.
- . Heat-transmitting area: $2.94\ m^2$
- . Oil flow capacity: 180 litre/min.
- . Water flow capacity: 890 litre/min.

OIL PUMP RELIEF VALVE



OIL COOLER BY-PASS VALVE



- 1. Plug
- 2. Valve spring
- 3. Valve body
- 4. Relief valve
- 5. Ball type valve (Main relief valve)
- 6. Main relief valve spring
- a. From oil pump
- b. To oil pan
- c. From main gallery

Main relief valve

• Cracking pressure (difference pressure): 8 ± 1 kg/cm²

Oil-line check valve


. Cracking pressure: $3.3 \pm 0.3 \text{ kg/cm}^2$

- 1. Cap
- 2. Valve spring
- 3. Valve body
- 4. By-pass valve
- a. From oil pump
- b. To oil filter

Oil cooler by-pass valve

. Cracking pressure: 4.5 \pm 0.5 kg/cm²


PISTON COOLING VALVE



- 1. Cap
- 2. Valve spring
- 3. Oil filter adapter
- 4. Piston cooling valve
- a. From oil pump
- b. To piston cooling nozzle
- c. To cylinder block

Piston cooling valve +0.3. Cracking pressure: 1.3 - 0.1 kg/cm²


MECHANICAL PUMP



Mechanical pump

- . Capacity: $10 \pm 1 \operatorname{cc/hx} 2$
- The mechanical pump is a worm pump used to increase the wear resistance of the intake valve seat.The pump is driven by the slit shaft connected to the camshaft.
- . The oil is sent from the main gallery into the pump and sent out from the two outlets of the pump to the two intake manifolds through the oil tubes. The oil is sprayed in the intake manifolds by the intake air onto the seats of the valves to reduce the wear of the seats.


FUEL SYSTEM FUEL SYSTEM CHART



- 1. Fuel tank
- 2. Fuel filter
- 3. Fuel injection pump
- 4. Feed pump
- 5. Fuel injection nozzle


FUEL INJECTION PUMP

BS6D170-1, BSA6D170-B-1



- 1. Injection pump driving gear (No. of teeth: 48)
- 2. Injection pump drive shaft
- 3. Service meter output
- 4. Fuel injection pump
- 5. Feed pump
- 6. Governore.
- 7. Relay
- 8. Solenoid
- 9. Fuel filter


- a. Fuel (from fuel tank)
- b. Fuel (to fuel filter)
- c. Fuel (from injection pump)
- d. Fuel (to nozzle holder)
- e. Oil (from main gallery)
- f. Oil (to oil pan)



Fuel injection pump

- . Marker
- . Type . Governor
- : Diesel Kiki
- : PES-PD type: RSUV, centrifugal type, all-peed type
- . Lubrication method
- : Forced lubrication with engine oil

FUEL INJECTION NOZZLE




- 1. Nozzle holder
- 2. Nozzle spring
- 3. Nozzle
- 4. Retaining cap
- 5. Adjustment shim
- a. Fuel inlet
- b. Fuel return (To fuel tank)

Fuel injection nozzle

- . Marker: Diesel Kiki
- . Type: Bosch DLL-S type, multiple hole type

FUEL INJECTION PUMP DRIVE

For PES-PD type injection pump




- 1. Fuel injection pump drive shaft
- 2. Nut
- 3. Tachometer drive gear (No. of teeth: 14)
- 4. Drive housing
- 5. Pinion gear housing
- 6. Tachometer drive shaft
- 7. Pinion gear (No. of teeth: 14)
- 8. Bushing

Tachometer drive

. Tachometer drive shaft speed = Engine speed x 1/2

FUEL FILTER




STARTING AID AUTO PRIMING SYSTEM (APS)

1. Glow plug

- 2. Clamp
- 3. Wiring harness
- 4. Cover
- 5. Nozzle

- 6. Hose
- 7. Bracket
- 8. Hose
- 9. Valve
- a. To heater switchb. To APS controller
- c. To APS controller
- d. To heater switch
- e. From fuel filter (fuel)


COOLING SYSTEM CHART



- 1. Water pump
- 2. Oil cooler
- 3. Corrosion resistor
- 4. Cylinder liner
- 5. Cylinder block
- 6. Thermostat switch

- 7. Water manifold
- 8. Thermostat
- 9. Radiator
- 10. Fan
- A. From oil pump (oil)
- B. To engine each component (oil)

WATER PUMP



- 1. Pump body
- 2. Impeller
- 3. Floating seal
- 4. Water seal
- 5. Pump shaft (rear)
- 6. Pump shaft (front)
- 7. Inlet housing


- A. From radiator
- B. To oil cooler

Water pump

- Water pump speed =Engine speed x 1.8
- . Flow capacity: 1050 liter/min. (3,600 rpm)

FAN DRIVE AND TENSION PULLEY

. FAN DRIVE (for BE1000)



. Tension spring	Outside diameter for pulley			Unit : mm	
. Tension shaft	Applicable machine	Fan pulley	Crankshaft pulley	Tension pulley	
. Tension pulley . Fan pulley	BE1000	347	200	150	
. I all pulley					


5. Fan belt

6. Crankshaft pulley

7. Fan

1.
 2.
 3.
 4.


. TENSION PULLEY (For BE1000)



Section A – A

- 1. Tension pulley shaft
- 2. Roller bearing
- 3. Tension pulley bracket
- 4. Tension pulley (Outside diameter: 150 mm)
- 5. Oil seal
- 6. Ball bearing
- 7. Spacer
- 8. Stopper

CORROSION RESISTOR



THERMOSTAT


- 1. Seal
- 2. Thermostat
- 3. Valve
- 4. Body
- 5. Piston
- 6. Sensor
- 7. Sleeve
- 8. Wax
- a. From engine each component
- b. To water pump
- c. To radiator

OPERATION


Function

- . Opening temperature: $76.5 \pm 2^{\circ}C$
- Full opening temperature: 90° C Valve lift: Minimum 10 mm

ACCESSORY AIR COMPRESSOR MOUNTING




- 1. Flange
- 2. Coupling
- 3. Air compressor
- 4. Air governor
- a. From intake manifold (air)
- b. To air tank (air)
- c. To thermostat housing (cooling water)
- d. From oil cooler (cooling water)



Air circuit diagram


ELECTRICAL SYSTEM ALTERNATOR WITH REGULATOR




Wiring diagram


Engine	Applicable machine model	TypeSpecificationsPulley outside diameter (mm)		Weight (kg)	
BS6D170-1	BD155	Nikko Denki, Open type	24V, 50A	95	9.5
	BD355	Nikko Denki, Closed type	24V, 13A	95	9.5

ALTERNATOR BUILT-IN REGULATOR





- 1. Alternator
- 2. Regulator





Wiring diagram


Engine	Applicable machine model		Specifications	Pulley outside diameter (mm)	Weight (kg)
BSA6D170-1	BE1000	Nikko Denki, Open type	24V, 50A	95	12


ALTERNATOR

For BH60,BH70 & 210M










1. Alternator

2. Alternator pulle

B.E.F.R: Terminal

Engine	Applicable machine model		Specifications	Pulley outside diameter (mm)	Weight (kg)
	BH60	SAWAFUJI	24V, 50A	95	12
BSA6D170A-1	BH70	SAWAFUJI	24V, 50A	95	12
	210M	SAWAFUJI	24V, 50A	95	12

BDG500, BDG550




B.E.F.R: Terminal


Engine	Applicable machine model	Туре	Specifications	Pulley outside diameter (mm)	Weight (kg)
BSA6D170AG-1	BDG500	LUCAS TVS	24V, 30A	85	10
	BDG550	LUCAS TVS	24V, 30A	85	10

STARTING MOTOR

BD155, BD355




- 1. Pinion gear
- 2. Starting motor assembly
- 3. Magnetic switch
- 4. Safety relay




B, C, E, R, S: Terminal


Engine	Applicable machine model	Туре	Specifications	Weight (kg)
BS6D170-1	BD155	SAFUge Denki, Sealed type	24V, 11KW	21.5
	BD355	SAFUge Denki, Sealed type	24V, 11KW	21.5

BE1000





- 1. Pinion gear
- 2. Starting motor assembly
- 3. Magnetic switch
- 4. Safety relay





F

₩,

Engine	ne Applicable Type		Specifications	No. of pinion teeth	Weight (kg)
BSA6D170-1	BE1000	Nikko Denki, Sealed type	24V, 7.5KW	11	18

BH60, BH70 & 210M






Engine	Applicable machine model	Туре	Specifications	Number of Pinion teeth	Weight (kg)
	BH60	SM130PE LUCAS TVS	24V, 7.5kW x 2	11	30
BSA6D170A-1	BH70	SM130PE LUCAS TVS	24V, 7.5kW x 2	11	30
	210M	SM130PE LUCAS TVS	24V, 7.5kW x 2	11	30


STARTER MOTOR (Nikko Denki) For BH70

For Engine Sl. No. Z557660001




B,C,E,R,S: TERMINALS

- 1. Pinion gear
- 2. Starting motor assembly
- 3. Magnetic switch
- 4. Safety relay



Engine	Applicable machine model	Туре	Specifications	Number of Pinion teeth	Weight (kg)
BSA6D170A-1	BH70	Nikko Denki, Sealed type	24V, 7.5kW x 2	11	18


BDG500, BDG550




3.	Starting motor

Engine	Applicable machine model	Туре	Specifications	Number of Pinion teeth	Weight (kg)
BSA6D170AG-1	BDG500	DELCO REMY	24V, 9kW	11	32
	BDG550	DELCO REMY	24V, 9kW	11	32

WIRING DIAGRAM (MECHANICAL GAUGES & SENSORS) For BDG500 & BDG550 (500kVA & 550kVA DG SET ENGINES)





WIRING DIAGRAM FOR PRICOL ENGINE SAFETY SYSTEM For 500kVA, 550kVA

ENGINE 13 TESTING AND ADJUSTING



ENGINE BODY

Adjusting valve clearance	13-003
Measuring compression pressure	13-004
FUEL SYSTEM	
Testing and adjusting fuel	
injection timing	13-005
Adjusting fuel injection pressure	13-007
Calibration data injection pump	13-008
COOLING SYSTEM	
Fan belt tension	13-016
Replacing fan belt and adjust	
auto tensioner	13-017
PERFORMANCE TEST	
Run-in standard	13-018
Performance test criteria	13-020
Testing and adjusting tool list	13-025
Testing and adjusting data	13-026
TROUBLESHOOTING	13-030

Men carrying out testing and adjusting, or troubleshooting, stop the machine on level ground, fit safety pins, block the wheels, and apply the parking brake.

When carrying out operations with two or more workers, always use signals, and do not allow any unauthorized person near the machine.

When checking the water level, if the radiator cap is removed when the engine is hot, boiling water will spurt out and may cause burns, so always wait for the engine to cool down before checking the water level.

A Be extremely careful not to touch any hot parts.



Be extremely careful not to get caught in the fan or any other rotating parts.


When removing the plugs or caps from places under hydraulic pressure, water pressure, or air pressure, release the internal pressure first. Fit the measuring tools securely before carrying out any testing, adjusting, or troubleshooting.

- When using the standard values table for judgement in testing, adjusting, or troubleshooting, it is × necessary to be careful of the following points.
- The standard values for the new machines in the standard values table are values given as reference 1. from the standards for new machines and machines shipped from the factory. They should be used as values for estimating wear during operation or as target values when carrying out repairs.
- 2. The failure judgement standard values in the standard value table are values using estimated values based on the results of various tests and standard values for machines shipped from the factory. Use these values for reference together with the repair and operation history of the machine when judging failures.
- 3. Do not use this standard values table as a standard for judging claims.

ENGINE BODY ADJUSTING VALVE CLEARANCE

Method of adjusting valve clearance

- 1. Remove the cylinder head cover.
- 2. Rotate the crankshaft in the normal direction to set No.1 cylinder at compression top dead center, and align pointer (3) with the 1.6 TOP mark on vibration damper (2). When rotating, check the movement of the intake valve of No.6 cylinder.
 - When No. 1 cylinder is near compression top dead center, the No.6 intake valve moves (is open).
- 3. Adjust the clearance of the valves marked in the valve arrangement chart.
- 4. Next, rotate crankshaft one turn in the normal direction and adjust the valve clearance of the remaining valves marked ○.



Valve arrangement

٨	Cylinder No.		1	:	2	3	3		4	Ę	5	6	;
X=	Exhaust valve		•		0		•		0		•		0
۷	Intake valve	•		•		0		•		0		0	


- ★ To adjust the valve clearance loosen locknut
 (8) of adjustment screw (7), insert feeler
 gauge A between crosshead (6) and rocker
 arm (5), and turn the adjustment screw until
 the clearance is a sliding fit.
 - ★ Valve clearance (cold, warm)


	Unit: mm
Intake valve	Exhaust valve
0.4	1.0

5. Tighten the locknut to hold the adjustment screw in position.

Locknut: 6.9±1 kgm

- ★ It is also possible to turn the crankshaft 120° each time and adjust the intake and exhaust valves of each cylinder according to the firing order.
 - Firing order: 1-5-3-6-2-4
- ★ After tightening the locknut, check the clearance again.





MEASURING COMPRESSION PRESSURE

Method of measuring compression pressure



 \checkmark When measuring the compression pressure, be careful not to touch the exhaust manifold or muffler, or to get caught in rotating parts.

- ★ Measure the compression pressure with the engine warmed up (oil temperature: 40-60°C)
- 1. Adjust valve clearance. For details, see 12 ADJUSTING VALVE CLEARANCE.
- 2. Remove the nozzle holder assembly of the cylinder to be measured.
 - ★ Be careful not to let any dirt or dust get in.
- 3. Install adapter A1 in the mount of the nozzle holder assembly of the cylinder to be measured, and tighten to the specified torque.


kgm Torque: 2.75 ± 0.25 kgm


- 4. Connect compressor gauge A to the adapter.
- 5. Place the fuel control lever in the NO INJEC-TION position. Crank the engine with the starting motor and measure the compression pressure.




 \bigwedge If the fuel control lever is not placed in the NO INJECTION position, the fuel will spurt out.

- ★ If the adapter mount is coated with a small amount of oil, it will reduce the leakage.
- ★ For details of the standard value for the compression pressure, see TABLE OF VALUES FOR TESTING, ADJUSTING AND TROUBLESHOOTING.







FUEL SYSTEM TESTING AND ADJUSTING FUEL INJECTION TIMING

There are the following methods of testing and adjusting the fuel injection timing of the injection pump.

- Aligning match mark when assembling the injection pump to the original engine without repair.
- Delivery valve method when assembling the injection pump that has been repaired or replaced.
- When using the delivery valve method, always replace the copper gasket and O-ring of the delivery valve with new parts. Prepare these parts before starting the operation.

★ Set the No. 1 cylinder at the compression top dead center, then test and adjust.

For details, see ADJUSTING VALVE CLEAR-ANCE

- Testing and adjusting by aligning match mark (flange type)
- 1. Turn the crankshaft back approx. 45° from No.1 cylinder TOP.
- 2. Rotate the crankshaft slowly in the normal direction to align pointer (with the injection timing line on crankshaft damper (1).
- 3. Check that line **a** at the fuel injection pump end and line **b** at the drive housing end are aligned.
 - ★ If the lines are not aligned adjust at the oblong hole of the flange.


Bolt nut: 6.75 ± 0.75 kgm


- '<u>S</u> and adjusting by aligning match mark (iaminated coupling type)
- 1. Follow the same procedure as for steps 1 and 2 for the flange type.
- 2. Check that the lines on the coupling and bearing cover of the fuel injection pump are aligned.
 - ★ If the lines are not aligned adjust at the oblong hole of the coupling.


Bolt nut: Width across flats of Tightening torque for

Injection	nut for coupling	bolt of oblong hole		
pump type	oblong hole	kgm		
Bosch	19	9.0±0.5		
PE-P, PE-PD				
Bosch	21	7.75 ± 0.25		
PE-ZWx				
Bosch	21	16.0 ± 1.0		
PE-ZWy				

* 6162-73-1653 and 6162-73-1682 are the injection pump only









- Testing fuel injection timing by delivery valve method
- Prepare new parts for the copper gasket and Oring of the delivery valve before starting the operation.
- 1. Disconnect fuel injection pipe (1) of the No.1 cylinder.
- 2. Remove delivery valve holder (2), take out delivery valve (3) and spring (4), then install delivery valve holder (2) again.
- 3. Place the fuel control lever at the FULL position.
 - ★ For injection pumps with a stop lever set to the OPERATION position.
- 4. Turn the crankshaft back 40-50° from top dead center.
- 5. Operate the feed pump and rotate the crankshaft slowly in the normal direction. Check the point where the fuel stops flowing from delivery valve holder (2).
- 6. Check that the fuel injection timing line on crankshaft pulley (5) and pointer (6) are aligned at the point where the fuel stops flowing.
 - ★ BEYOND injection timing line: Timing RE TARDED
 - ★ BEFORE injection timing line: Timing AD-VANCED
- ★ If the test shows that the fuel injection timing is incorrect, adjust at the oblong hole of the flange portion or at the oblong hole at the laminated coupling.
- 7. Remove delivery valve holder (2), assemble delivery valve (3) and spring (4), then install delivery valve holder (2) again.
 - ★ When assembling again, wash with fuel and be careful not to let any dirt dust stick to any parts.
 - ★ Always replace the copper gasket and O-ring of the delivery valve with new parts.


Delivery vavle holder: 11.5 ± 0.5 kgm Note: 14.0 ± 1.0 kgm for the EP11 injection pump on the BWD600

8. Connect fuel injection pipe (1).

Sleeve nu: 2.2 ± 0.2 kgm








- 1. Remove retaining cap(1).
- 2. Remove nozzle (2), spring seat (3), and zozzle spring (4).
- 3. Adjust the injection pressure (valve cracking pressure) by adjusting shim thickness (5).
 - ★ Injection pressure adjusted per 0.1 mm shim Thickness: Approx. 15kg/cm²

Retaining cap: 9 ± 1 kgm

4. After adjusting the thickness of shims, check the fuel injection pressure using nozzle tester.



Engine modelShim contourShim thickness
(Range)Shim thickness
(Interval)BS6D170-1a = 4.5 mm
b = 11.5 mm0.50 - 1.54 mm0.02 mm

Part No.	Thickness (mm)	Part No.	Thickness (mm)	
51Z7182481	0.50	51Z7182554	0.78	
51Z7182498	0.54	51Z7182562	0.82	
51Z7182505	0.58	51Z7182579	0.86	
51Z7182513	0.62	51Z7182587	0.90	
51Z7182521	0.66	51Z7182595	0.94	
51Z7182538	0.70	51Z7182602	0.98	
51Z7182546	0.74	51Z7182619	1.00	

DATA FOR INJECTION PRESSURE ADJUSTMENT SHIMS

Pump Assembly Number

51Z7183153 (106692-4622)				
(): Manufacturer's part No.				
Injection Pump				
Pump Type Manufacturer				
PES-6PD DIESEL KIKI				

Applicable Machine		le Engine
Serial No.	Model	Serial No.
	BS6D170-1	
		Serial No. Model

Injection Timing


Rotating direction	Counterclockwise
	viewed from drive end
Injection order	1 - 5 - 3 - 6 - 2 - 4
Injection interval	$60^{\circ} \pm 30'$
Plunger pre-stroke mm	2.4 ± 0.05
Delivery valve Retraction volume mm ³ /st	90

Engine specification					
Rated horsepower	HP/rpm	320/2,000			
Maximum torque	kgm/rpm	144/1,400			
High idling	rpm	2,150 to 2,250			
Low idling	rpm	600 to 700			
Pump tester capaci for Service standard	Motor 7.5 kW				

Calibration Standard

Conditions			Service standard		Manufacture standard					
 Service standard 	Nozzle part no.			(105780-0000)		51Z7180601(105015-5210)				
indicates data using	Nozzle hold	ler part no.			(105780-2090)		51Z71	51Z7180586 (105041-7020)		
calibration test parts • Manufacture	Injection pi	pe								
standard is data	$(O/D \times I/D)$	× length)	mm		$8 \times 3 \times 600$		8	$8 \times 2.4 \times 1,400$		
for factory test.	Test oil				ASTM D975 N	No. 2 diese	l fuel or	equivalent		
	Oil tempera	ture	°C			43 t	o 47			
	Nozzle ope	ning pressu	ire kg/cm ²	2 175			255			
	Transfer pu	oump pressure kg/cm ²		1.6		1.6				
Injection volume				Serv	Service standard (cc/100 st)		Manufacture standard (cc/100		rd (cc/100st)	
-	Rack	Rack	Pump			Maximum			Maximum	
	point	Position	Speed			variance			variance	
	(mm)	(rpm)	Basis		Allowance	between	Basis	Allowance	between	
						cylinder			cylinder	
 Rack positions 					Each cylinder			Each cyl.		
B to E are the refer-	Basic point	9.0	1000	24.58	23.88 to 25.28		20.60			
ence volume when	В	9.5	700	25.27	★ 24.77 to 25.77		23.00	*		
adjusting the injec- tion volume.	С	5.2	325	2.77	★ 2.7 to 3.27	± 0.277	35.00	*		
• Marks * are average	D				*			*		
volumes.	Е				*			*		

Governor performance (325 - 1000 rpm)



Pump Assembly Number

51Z7183089 (106692-4970)

((): Manufacturer's part No.				
	Injection	Pump			
	Pump Type	Manufacturer			
	PES-6PD	ZEXEL			

			FUEL SYST	EM
Applicable Machine		Applicable Engine		
/lodel	Serial No.	Model Serial No.		
355A-3		BSA6D170-1		

Injection Timing

Rotating direction	Counterclockwise viewed from drive end
Injection order	1 - 5 - 3 - 6 - 2 - 4
Injection interval	$60^{\circ} \pm 30'$
Plunger pre-stroke mm	2.4 ± 0.05
Delivery valve retraction volume mm ³ /st	90

Engine specification


Rated horsepower	HP/rpm	410/2,000				
Maximum torque	kgm/rpm	176/1,400				
High idling	rpm	2,150 to 2,250				
Low idling	rpm	600 to 700				
Pump tester capaci for Service standar	Motor 7.5 kW					

Calibration Standard


Calibi ation Standa									
Conditions				S	Service standa	ard	Manu	lfacture st	andard
Service standard	Nozzle part no.			(105780-0000)			51Z7180601(105015-5210)		
indicates data us-	Nozzle holo	ler part no.		(105780-2090)			51Z7180586 (105041-7020)		
ing calibration test parts	Injection pi	pe							
Manufacture	$(O/D \times I/D$	×length)	m		$8 \times 3 \times 600$		$8 \times 2.4 \times 1,450$		
standard is data for	Test oil				ASTM D975 N	No. 2 diese	l fuel or	equivalent	
factory test.	Oil tempera	ture	°C			43 t	o 47		
	Nozzle opening pressure kg/cm ²			175		225			
	Transfer pump pressure kg/cm ²		1.6		1.6				
Injection volume			Service standard (cc/100 st)		Manufactur standard (cc/100st)				
	Rack	Rack	Pump			Maximum			Maximum
	point	Position	Speed			variance			variance
		(mm)	(rpm)	Basis	Allowance	between	Basis	Allowance	
						cylinder			cylinder
 Rack positions 					Each cylinder			Each cyl.	
B to E are the refer-	Basic point	(11.0)	1000	29.00	28.50 to 29.50		26.00		
ence volume when	В	(11.2)	700	30.70	* 30.20 to 31.20		28.00	*	
adjusting the injec- tion volume.	С	(5.8)	325	2.75	* 225 to 3.25	± 0.275	35.00	*	
• Marks * are average	D				*			*	
volumes.	Е				*			*	

Model BD355A-3

Governor performance (325 - 1000 rpm)



Boost compensator performance (400 rpm)



FUEL SYSTEM

Pump Assembly Number

52Z7180372 (106682-4560)		
(): Manufacturer's part No.		
Injection Pump		
Pump Type	manufacturer	
PE-6P	DIESEL KIKI	

Applicable Machine		Applicable Engine		
Model	Serial No.	Model	Serial No.	
BE1000-1		BSA6D170-1		

Injection Timing


Rotating direction	Counterclockwise viewed from drive end
Injection order	1 - 5 - 3 - 6 - 2 - 4
Injection interval	$60^{\circ} \pm 30'$
Plunger pre-stroke mm	3.2 ± 0.05
Delivery valve retraction volume mm ³ /st	120


Engine specification

Rated horsepower	HP/rpm	542/1,700
Maximum torque	kgm/rpm	260/1,300
High idling	rpm	1,800 to 1,900
Low idling	rpm	650 to 700
Pump tester capaci for Service standar	Motor 7.5 kW	


Calibration Standard

	uu								
Conditions			Service standard		Manufacture standard				
Service standard	Nozzle part no.			(105780-0050)		52Z7180267 (105015-6700)			
indicates data using calibration test parts	Nozzle holo	ler part no.			(105780-2090)		52Z7180259 (105041-7060)		
(Nozzle, Nozzle	Injection pi	pe							
holder and injection	$(O/D \times I/D$	× length)	m		$8 \times 4 \times 1000$		$8 \times 2.4 \times 1,450$		
pipe)	Test oil				ASTM D975 I	No. 2 diese	l fuel or	equivalent	
• Manufacture	Oil tempera	ture	°C			43 t	o 47		
standard is data usi- ng factory test parts	Nozzle opening pressure kg/cm ²			175		265			
(For reference)	Transfer pump pressure kg/cm ²			1.6		1.6			
Injection volume				Ser	vice standard (c	c/100 st)	Manufa	cture standar	·d (cc/100st)
-	Rack	Rack	Pump			Maximum			Maximum
	point	Position	Speed			variance			variance
		(mm)	(rmp)	Basis	Allowance	between	Basi	Allowance	between
						cylinder			cylinder
Rack positions					Each cylinder			Each cyl.	
B to E are the refer-	Basic point	15.7	850	40.15	39.95 to 40.35	+1.204	35.5		
ence volume when	В	Approx.6.6	335	3.26	★ 2.76 to 3.76	± 0.489	3.5	*	
adjusting the injec- tion volume.	С				*			*	
• Marks * are average	D				*			*	
volumes.	Е				*			*	





Boost compensator performance (500 rpm)



Boost pressure (mmHg)

Line 0 : At boost pressure 300 mmHg or more Line 0 : At boost pressure 0 mmHg

53Z7100024	
Injection	Pump
Pump Type	manufacturer
NP-PE6 ZW	ZEXEL

Injection Timing

Calibration Standard

•	
Rotating direction	Counterclockwise
	viewed from drive end
Injection order	1 - 5 - 3 - 6 - 2 - 4
Injection interval	$60^{\circ} \pm 30'$
Plunger pre-stroke mm	-
Delivery valve	
retraction volume mm ³ /st	-

Applicable Machine	Applicable Engine		
BH60	BSA6D170A-1		

Engine specification (reference only)

Rated horsepower	kW/rpm	522/2100
Maximum torque	Nm/rpm	2785/1400
High idling	rpm	2330 to 2400
Low idling	rpm	900 to 950

Conditions **Manufacture standard** Service standard Service standard Nozzle part no. _ _ indicates data using Nozzle holder part no. _ _ calibration test parts Injection pipe (Nozzle, Nozzle $(O/D \times I/D \times length)$ $8 \times 2.4 \times 1400$ $8 \times 4 \times 1400$ holder and injection mm pipe) Test Fuel ASTM D975 No. 2 diesel fuel Manufacture °C 40 to 45 Fuel temperature standard is data usi-Nozzle opening pressure kg/cm² 300 175 ng factory test parts Transfer pump pressure kg/cm² 1.6 1.6 (For reference) Manufacture standard (cc/100st) Service standard (cc/100 st) **Injection volume** Rack Pump Maximum Maximum Position Speed variance variance Basis Allowance Allowance between (mm) (rmp) between Basi cylinder (Each cylinder) ★ cylinder (Each cylinder) \star 1050 36.5 36.5 to 37.0 ≤1.5 27.5 - 28.5 28 ≤ 1.1 -Average of 6 465 3.5 3.0 to 4.0 ≤0.5 6 5.0-7.0 ≤0.5 cylinders 39.8 to 49.8 700 40.8 _ ≤1.5 30 29.5 - 30.5 ≤1.1

\$: READINGSARE WITHOUT BOOST COMPENSATION

53Z7102041	
Injection	Pump
Pump Type	manufacturer
NP-PE6ZW	ZEXEL

Injection Timing

Counterclockwise viewed from drive end
1 - 5 - 3 - 6 - 2 - 4
60° ± 30'
-
-

Applicable Machine		ble Engine	
BH70	BSA6L	0170A-1	
Engine specification	on (refer	ence only))
Rated horsepower k	W/rpm	551/21	00
Maximum torque N	lm/rpm	3010/14	-00
High idling r	pm	2330 to 2	2400
Low idling r	pm	900 to	950

Calibration Standard

Conditions	Conditions				Manufacture standard			Service standard		
 Service standard 	Nozzle part no.				_			_		
indicates data using	Nozzle hold				-			-		
calibration test parts (Nozzle, Nozzle	Injection pi	pe								
holder and injection	$(O/D \times I/D)$	×length)	m		$8 \times 2.4 \times 140$	0		$8 \times 4 \times 1400$		
pipe)	Test Fuel				AS	STM D975	No. 2 di	esel fuel		
• Manufacture	Fuel temperature °C			40 to 45						
standard is data usi-	Nozzle ope	Nozzle opening pressure kg/cm ²		300			175			
ng factory test parts (For reference)	Transfer pu	imp pressu	re kg/cm ²	1.6			1.6			
Injection volume				Manufacture standard (cc/100st)		Service standard (cc/100 st)		cc/100 st)		
, °		Rack	Pump			Maximum			Maximum	
		Position	Speed			variance			variance	
		(mm)	(rmp)	Basis	Allowance	between	Basi	Allowance	between	
			(Ea	ch cylinder) *	cylinder	(Each	cylinder) *	cylinder		
		-	1050	38.5	37.9 to 38.9	≤1.5	29.6	29.1 - 30.1	≤1.1	
★ Average of 6		-	465	3.5	3.0 to 4.0	≤0.5	6	5.0-7.0	≤0.5	
cylinders		-	700	43.9	43.4 to 44.4	≤1.5	33	32.5 - 33.5	≤1.1	

\$: READINGSARE WITHOUT BOOST COMPENSATION

53Z7102041	
Injection	Pump
Pump Type	manufacturer
NP-PE6 ZW	ZEXEL

Injection Timing

, <u> </u>	
Rotating direction	Counterclockwise viewed from drive end
Injection order	1 - 5 - 3 - 6 - 2 - 4
Injection interval	$60^{\circ} \pm 30'$
Plunger pre-stroke mm	-
Delivery valve retraction volume mm ³ /st	-

Applicable Machine	Applicable Engine
210M	BSA6D170A-1

Engine specification (reference only)

0 1	·	•
Rated horsepower	kW/rpm	501/2100
Maximum torque	Nm/rpm	2618/1400
High idling	rpm	2330 to 2400
Low idling	rpm	900 to 950

Calibration Standard

Conditions	Conditions				nufacture sta	ndard	Service standard		
 Service standard 	Nozzle part no.				-			-	
indicates data using	Nozzle hold	ler part no.			-			-	
calibration test parts (Nozzle, Nozzle	Injection pi	pe							
holder and injection	$(O/D \times I/D)$	×length)	mm		$8 \times 2.4 \times 140$	0		$8 \times 4 \times 1400$	
pipe)	Test Fuel				AS	STM D975	No. 2 di	esel fuel	
Manufacture	Fuel temperature°CNozzle opening pressurekg/cm²				40 t	to 45			
standard is data usi- ng factory test parts			300			175			
(For reference)	Transfer pu	mp pressu	re kg/cm ²	1.6			1.6		
Injection volume				Manufacture standard (cc/100st)		Service standard (cc/100 st)		cc/100 st)	
-		Rack	Pump			Maximum			Maximum
		Position	Speed			variance			variance
		(mm)	(rmp)	Basis	Allowance	between	Basi	Allowance	between
			(Eac	ch cylinder) *	cylinder	(Each	cylinder) *	cylinder	
		-	1050	35.5	34.5 to 35.5	≤1.5	27	26.5 - 27.5	≤1.1
★ Average of 6		-	465	3.5	3.0 to 4.0	≤0.5	6	5.0-7.0	≤0.5
cylinders		-	700	39.0	38.5 to 39.5	≤1.5	29	28.5 - 29.5	≤1.1

\$: READINGSARE WITHOUT BOOST COMPENSATION

-

Pump Assembly Number

54Z7100054	
Injection	Pump
Pump Type	manufacturer
PE-ZWX	ZEXEL

Injection Timing

Rotating direction	Counterclockwise
	viewed from drive end
Injection order	1 - 5 - 3 - 6 - 2 - 4
Injection interval	$60^{\circ} \pm 30'$
Plunger pre-stroke mm	-
Delivery valve	
retraction volume mm ³ /st	-

Applicable Machi	plicable Machine Ap		ble Engine	
BDG500		BSA6D		
Engine specifica	tio	n (refer	ence only)	
Rated horsepower	kV	W/rpm	426/15	00
Maximum torque	Nm/rpm			
High idling	rp	m	1560 M	lax.
Low idling	rp	m	975 to	1025

Calibration Standard

Conditions				Ma	nufacture sta	ndard	Se	rvice stand	lard
 Service standard 	Nozzle part no.				_			-	
indicates data using	Nozzle hold	ler part no.			-			-	
calibration test parts (Nozzle, Nozzle	Injection pi	pe							
holder and injection	$(O/D \times I/D)$	×length)	m		$8 \times 2.4 \times 140$	0	$8 \times 4 \times 1400$		
pipe)	Test Fuel				AS	STM D975	No. 2 die	esel fuel	
Manufacture	Fuel temperature°CNozzle opening pressurekg/cm²			40 to 45					
standard is data usi- ng factory test parts				300			240		
(For reference)	Transfer pu	imp pressu	re kg/cm ²	1.6			1.6		
Injection volume				Manuf	acture standard	(cc/100st)	Service	e standard (cc/100 st)
		Rack	Pump			Maximum			Maximum
		Position	Speed			variance			variance
		(mm)	(rmp)	Basis	Allowance	between	Basi	Allowance	between
				(Ead	ch cylinder) *	cylinder	(Each	cylinder) *	cylinder
★ Average of 6		-	750	40.5	39.5 to 41.5	≤1.5	27	26.5 - 27.5	≤1.1
cylinders		-	500	3.5	3.0 to 4.0	≤0.5	6	5.0-7.0	≤0.5

54Z7100054	
Injection	Pump
Pump Type	manufacturer
PE-ZWX	ZEXEL

Injection Timing

Rotating direction	Counterclockwise viewed from drive end
Injection order	1 - 5 - 3 - 6 - 2 - 4
Injection interval	60° ± 30'
Plunger pre-stroke mm	-
Delivery valve	
retraction volume mm ³ /st	-

Applicable Machine	Applicable Engine
BDG550	BSA6D170AG-1


Engine specification (reference only)

0 1		•
Rated horsepower	kW/rpm	468/1500
Maximum torque	Nm/rpm	
High idling	rpm	1560 Max.
Low idling	rpm	975 to 1025


Calibration Standard

Conditions	Conditions				nufacture sta	ndard	Service standard		
 Service standard 	Nozzle part no.				-			-	
indicates data using calibration test parts	Nozzle hold	ler part no.			-			-	
(Nozzle, Nozzle	Injection pi	pe							
holder and injection	$(O/D \times I/D)$	× length)	mm		$8 \times 2.4 \times 140$	0		$8 \times 4 \times 1400$	
pipe)	Test Fuel				AS	STM D975	No. 2 di	esel fuel	
• Manufacture standard is data usi-	Fuel temper	ature	°C	40 to 45					
ng factory test parts	Nozzle oper	• •	-	300			240		
(For reference)	Transfer pu	imp pressu	re kg/cm ²	1.6			1.6		
Injection volume				Manuf	acture standard	(cc/100st)	Service	e standard (cc/100 st)
-		Rack	Pump			Maximum			Maximum
		Position	Speed			variance			variance
		(mm)	(rmp)	Basis	Allowance	between	Basi	Allowance	between
				(Ead	ch cylinder) *	cylinder	(Each	cylinder) *	cylinder
★ Average of 6		-	750	44	043 to 45	≤1.5	27	26.5 - 27.5	≤1.1
cylinders		-	500	3.5	3.0 to 4.0	≤0.5	6	5.0 - 7.0	≤0.5

COOLING SYSTEM FAN BELT TENSION



- 1. Adjusting nut
- 2. Washer
- 3. Tension spring
- 4. Adjustment bolt
- 5. Tension pulley
- A. Protrusion of adjustment bolt




Q area

		Unit: mm
Engine model	Applicable machine	Dimension A
DS(D170.1	BD155	70.5
BS6D170-1	BD355	72 5
BSA6D170-1	BE1000	60 5

REPLACING FAN BELT AND ADJUSTING AUTO TENSIONER


• Replacing

- 1. Loosen locknut (1) and turn back adjustment screw (2) as far as bracket (3).
- 2. Insert a bar with a length of approx. 50 cm in the hole (Ø18) in bracket (7), then pull strongly to the front and hold in position.
- 3. The spring will extend and the tension pulley will move to the inside. Remove the old belts and replace it with new bolts.
 - ★ Replace the V-belts in a set (3 belts).



• Adjusting

- 1. Tighten adjustment screw (2), and when the tip of adjustment screw (2) comes into contact with tension pulley lever (4), tighten adjustment screw (2) a further half turn, then lock it in position with locknut (1).
 - 5 kgm Locknut: 29.5 ± 2 kgm
- If a gap appears between tension pulley lever
 (4) and the tip of adjustment screw (2) during operation, adjust in the same way.
- ★ If the fan belt screeches, adjust in the same way.



PERFORMANCE TEST

RUN-IN STANDARD

Engine model	Applicable machine	Item		1	2	3	4	5	6
		Running time	(min	3	6	3	3	10	5
		Engine speed	(rpm)	650	1,000	1,200	1,200	1,500	2,000
		Load 716 mm	(kg)	0	40	90	140	210	170
	BD155	895 mm	(kg)	0	32	72	112	168	176
		1,023 mm	(kg)	0	28	63	98	147	119
		Horsepower	(HP)	0	39.4	106.4	165.6	310.6	335.2
BS6D170-1	BD355	Running time	(min)	3	6	3	3	10	5
		Engine speed	(rpm)	650	1,000	1,200	1,200	1,500	2,000
		Load 716 mm	(kg)	0	40	90	140	210	220
		895 mm	(kg)	0	32	72	112	168	176
		1,023 mm	(kg)	0	28	63	98	147	154
		Horsepower	(HP)	0	39.4	106.4	165.6	310.6	433.8
		Running time	(min)	3	6	3	3	10	5
		Engine speed	(rpm)	650 ± 25	1,000	1,200	1,200	1,500	1,700
BSA6D170-1	BE1000-1	Load 716 mm	(kg)	0	40	90	140	210	330
		895 mm	(kg)	0	-	-	-	-	-
		1,023 mm	(kg)	0	-	-	-	-	-
		Horsepower	(HP)	0	39.4	106.5	165.6	310.6	553.1

 \star The values given for the output is the fan removed.

★ The load (dynamometer) is given for the case of the arm length is 17.6 mm, 895 mm or 1,023 mm.

RUN-IN STANDARD

- ★ Loads are given for the case of dynamometer with 716mm arm length.
- ★ The values shown below are at standard condition and without fan.

Engine model	Applicable	Test paramete	r			C	Order		
	machine			1	2	3	4	5	6
		Running time	(min.)	5	10	10	10	20	5
		Engine speed	(rpm)	LI	1050	1300	1600	1900	2100
		Load 716 mm	(kg)	-	43	84	169	253	327
	BH60	Out put	(kW)	-	33	80	199	354	506
		Running time	(min.)	5	10	10	10	20	5
BSA6D170A-1	BH70	Engine speed	(rpm)	LI	1050	1300	1600	1900	2100
	DII/O	Load 716 mm	(kg)	-	44	90	178	268	346
		Out put	(kW)	-	34	86	209	374	534
		Running time	(min.)	5	10	10	10	20	5
	210M	Engine speed	(rpm)	LI	1050	1300	1600	1900	2100
	210101	Load 716 mm	(kg)	-	43	81	162	242	313
		Out put	(kW)	-	33	78	191	338	484
		Running time	(min.)	5	5	10	10	15	15
	BDG500	Engine speed	(rpm)	1000	1100	1200	1300	1400	1500
	DD0000	Load 716 mm	(kg)	-	78	155	233	310	388
BSA6D170AG-1		Out put	(kW)	-	63	137	222	319	428
D3A0D1/0AC-1		Running time	(min.)	5	5	10	10	15	15
	BDG550	Engine speed	(rpm)	1000	1100	1200	1300	1400	1500
		Load 716 mm	(kg)	-	86	172	258	344	430
		Out put	(kW)	-	70	152	246	354	474

PERFORMANCE TEST CRITERIA

Engine	Applicable	Test item	Specified value	Engine speed	Dy	namometer (kg	g)
model	machine		(fully equipped)	(rpm)	Arm length	Arm length	Arm length
					716 mm	895 mm	1,023 mm
		Flywheel horsepower	320 HP/ 2,000 rpm	$2,000 \pm 5$	168.0 - 178.0	134.4 - 142.4	117.6 - 124.6
	BD155	Max. torque	144 kgm/ 1,400 rpm	1,400±100	205.3 - 217.8	164.2 - 174.2	143.7 - 152.5
		High idling speed	$2,\!200\pm\!50\mathrm{rpm}$	2,150-2,250	0	0	0
BS6D170-1		Low idling speed	$650\pm50\mathrm{rpm}$	600 - 700	0	0	0
DS0D170-1	BD355	Flywheel horsepower	410 HP/ 2,000 rpm	$2,000 \pm 5$	220.0 - 232.0	176.0 - 185.6	154.0 - 162.4
		Max. torque	176 kgm/ 1,400 rpm	1,400±100	252.8 - 267.5	202.2 - 214.0	177.0 - 189.2
		High idling speed	$2,\!200\pm50\mathrm{rpm}$	2,150-2,250	0	0	0
		Low idling speed	650 ± 50 rpm	600 - 700	0	0	0
		Flywheel horsepower	542 HP/ 1,700 rpm	$1,700 \pm 5$	329.0 - 348.0	263.2 - 278.4	230.3 - 243.6
8540110 ¹	BE1000	Max. torque	260 kgm/ 1,300 rpm	$1,300 \pm 100$	361.0 - 382.0	288.8 - 305.6	252.7 - 267.4
		High idling speed	$1,850\pm50\mathrm{rpm}$	$1,850 \pm 50$	0	0	0
		Low idling speed	675 ± 25 rpm	675 ± 25	0	0	0

- ★ The values in the table are indicated at standard conditions (Atmospheric temperature 25°C, atmospheric pressure 750 mm Hg).
- ★ The values given for dynamometer loads the output and torque are with the fan removed, so they differ from those of the specification.
- ★ Values are standardized under the following conditions: Muffler; air cleaner installed; alternator idling; and air compressor (if installed) open.
- ★ Dynamometer loads are given for the case of the arm length is 716 mm.
- ★ Fuel used: ASTM D975 No. 1 or No. 2 diesel fuel.
- ★ Lubrication oil used: CLASS CO SAE30.
- ★ Exhaust temperature column t: (Suction temperature 25°C)

Output	Torque	Fuel	Coolant	Lubrication	Lubrication	Exhaust temperature
(HP)	(kgm)	consumtion	temperature	oil temperature	oil pressure	(°C)
		(sec /500 cc)	(°C)	(°C)	(kg/cm ²)	t = Intake temp 20° C
331.3 - 351.0	-	Min. 23.3	70 - 90	80 - 110	3.0 - 5.0	600 + 3t
-	147.0 - 156.0	-	70 - 90	80 - 110	-	650 + 3t
0	0	0	70 - 90	80 - 110	-	-
0	0	0	70 - 90	80 - 110	-	-
433.8 - 457.5	-	Min. 19.2	70 - 90	80 - 110	3.0 - 5.0	600 + 3t
-	181.0 - 191.5	-	70-90	80 - 110	-	650 + 3t
0	0	0	70 - 90	80 - 110	-	-
0	0	0	70 - 90	80 - 110	-	-
559.0 - 592.0	-	Min. 16.3	70 - 90	80 - 110	3.5 - 5.0	Max. 700 + 3t
_	258.4-273.5	-	70-90	80 - 110	2.0 - 4.0	Max. 700 + 3t
0	0	0	70 - 90	80 - 110	3.5 - 5.0	-
0	0	0	70 - 90	Min. 80	Min. 1.5	-

PERFORMANCE TEST CRITERIA


Engine model	Applicable machine	Test item	Specified value (with fan)	Engine speed (rpm)	Dynamometer (Kg)
		Flywheel horsepower	504 kW/2100 rpm	2095 ~ 2105	328 ~ 348
		Max. torque	2750 Nm/1400/rpm	1300 ~ 1500	348~409
	BH60	High idling speed	$2365 \pm 35 \mathrm{rpm}$	2330~2400	0
		Low idling speed	$925\pm25\mathrm{rpm}$	900 - 950	0
)A-1		Flywheel horsepower	533 kW/2100 rpm	2095 ~ 2105	346 ~ 368
BSA6D170A-1	BH70	Max. torque	2975 Nm/1400/rpm	1300 ~ 1500	416~442
BSA	BII/0	High idling speed	$2365 \pm 35 \mathrm{rpm}$	2330 ~ 2400	0
		Low idling speed	$925 \pm 25 \mathrm{rpm}$	900 - 950	0
		Flywheel horsepower	483 kW/2100 rpm	2095 ~ 2105	315 ~ 334
	210M	Max. torque	2618 Nm/1400/rpm	1300 ~ 1500	366 ~ 389
	21011	High idling speed	$2365 \pm 35 \text{ rpm}$	2330 ~ 2400	0
		Low idling speed	$925 \pm 25 \mathrm{rpm}$	900 - 950	0
		Flywheel horsepower	426kW/1500 rpm	1500	315 ~ 334
-	BDG500	High idling speed	$1560 \pm 15 \text{ rpm}$	1555 ~ 1565	0
70AG		Low idling speed	$1000\pm25\mathrm{rpm}$	975 - 1025	0
BSA6D170AG-1		Flywheel horsepower	468kW/1500 rpm	1500	315 ~ 334
BS	BDG550	High idling speed	$1560 \pm 15 \text{ rpm}$	1555 ~ 1565	0
		Low idling speed	$1000\pm25\mathrm{rpm}$	975 - 1025	0

- ★ The values in the table are indicated at standard conditions (Atmospheric temperature 25°C, atmospheric pressure 743 mm Hg).
- ★ The values given for the dynamometer loads, output and torque are with the fan removed, so they differ from those of the specification.
- ★ Values are standardized under the following conditions: Muffler and air cleaner installed; alternator and compressor (if installed) under no load.
- * Dynamometer loads are given for the case of the arm length is 716 mm.
- * Fuel used: ASTM D975 No. 2 diesel fuel.
- ★ Lubrication oil used: CLASS CD SAE30.


Output	Torque	Fuel	Coolant	Lubrication	Lubrication	Exhaust temperature
(kW)	(Nm)	consumtion	temperature	oil temperature	oil pressure	(turbo inlet)
		(sec /500 cc)	(°C)	(°C)	(kg/cm ²)	(°C)
506~538	-	Min. 12	75-90	80 - 110	3.0 ~ 5.0	Max. 680
-	2700~2870	-	75 - 90	80 - 110	-	Max. 700
0	0	-	75 - 90	80 - 110	-	-
0	0	-	75 - 90	80 - 110	Min 1.5	-
534 ~ 538	-	Min. 11	75 - 90	80 - 110	3.0 ~ 5.0	Max. 680
-	2920~3100	-	75 - 90	80 - 110	-	Max. 700
0	0	-	75 - 90	80 - 110	-	-
0	0	-	75 - 90	80 - 110	Min 1.5	-
486~516	-	Min. 13	75 - 90	80 - 110	3.0 ~ 5.0	Max. 680
-	2573~2733	-	75 - 90	80 - 110	-	Max. 700
0	0	-	75 - 90	80 - 110	-	-
0	0	-	75 - 90	80 - 110	Min 1.5	-
486~516	-	Min. 13	75 - 90	80 - 110	3.0 ~ 5.0	Max. 680
0	0	-	75 - 90	80 - 110	-	-
0	0	-	75 - 90	80 - 110	Min 1.5	-
486~516	-	Min. 13	75 - 90	80 - 110	3.0 ~ 5.0	Max. 680
0	0	-	75 - 90	80 - 110	-	-
0	0	-	75-90	80 - 110	Min 1.5	-

PRECAUTIONS WHEN OPERATING THE ENGINE INDEPENDENTLY


- ★ If the engine is operated independently on a bench with a double lip seal fitted, the lubricating conditions will differ from actual running conditions, resulting in possible damage to the seal lip.
 - 1. When running-in the engine or subjecting it to a bench test, use the rear seal shown in the diagram at right on all models for the duration of testing.



2. After completing running-in or bench testing, fit the correct rear seal.



- 1) A new rear seal is coated with grease. In the event that it becomes soiled, however, wipe it clean with a cloth and coat it with about 1.2 to 1.6 cc of G2-L1 (lithium grease).
- 2) Be careful not to damage the rear seal when fitting it.



TESTING AND ADJUSTING

TESTING AND ADJUSTING TOOL LIST

No.	Inspection and measuring item	Fault finding tool	Part No.	Remarks
1	Engine speed	Multi-tachometer	799-203-8000	Digital reading, pressure sensing
				type 60 to 20,000 rpm
2	Battery S.G			1,100 to 1,300
3	Freezing temperature of	Battery, coolant tester	795-500-1001	
	cooling water			-5° C to -50° C
4	Water temperature, oil temperature,	Thermistor temperature		0 to 200° C
	air intake temperature	gauge	790-101-6000	
5	Exhaust temperature			0 to 1,000° C
6	Lubrication oil pressure			0 to 10 kg/cm ²
7	Fuel pressure	Engine pressure		0 to 20 kg/cm ²
8	Intake pressure, exhaust pressure	measuring kit	799-203-2002	0 to 1,500 mmHg
9	Blow-by pressure			0 to 1,000 mmH ₂ O
10	Air intake resistance			- 1,000 to 0 mmH ₂ O
11	Compression pressure	Compression gauge kit	795-502-1203	0 to 70 kg/cm ²
12	Blow-by pressure	Blow-by checker	799-201-1503	0 to 500 mmH ₂ O
13	Valve clearance	Feeler gauge	795-125-1340	0.4, 1.0 mm
14	Exhaust gas color	Handy smoke checker	799-201-9000	Dirtiness 0 to 70% with
				standard color
				(Dirtiness $\% \times 1/10 = Bosch$
				scale)
15	Water and fuel content in oil	Engine oil checker	799-201-6000	Provided with 0.1 and 0.2%
				water content standard
				samples.
16	Fuel injection pressure	Nozzle tester	Commercially	0 to 300 kg/cm ²
17	Fuel injection nozzle spray condition		available	
18	Coolant quality	Water quality tester	799-202-7001	pH, nitrite ion concentration
19	Pressure valve performance	Radiator cap tester	799-202-9001	$0 \text{ to } 2 \text{ kg/cm}^2$
20	Leakage in cooling water system			
21	Radiator blockage (wind speed)	Anemometer	799-202-2001	1 to 40 m/s
		(Air speed gauge)		
22	Engine cranking	Cranking kit	795-610-1000	DC24V with starting engine
		Barring device	6162-23-4820	For B6D170-1 series engine
23	Electrical circuits	Tester	Commercially	Current, voltage, resistance
			available	

TESTING AND ADJUSTING DATA

Engine model BS6D170-1 Applicable machine model BD155 BD355 Class- ffica tion Item Condition,etc Unit Standard Tolerance Standard Tolerance													
		•		BD	0155	BD	355						
Class- ifica tion			Unit			i							
mance	Engine speed	Highidling speed Low idling speed	rpm rpm	2,150 - 2,250 600-700	2,150 - 2,250 600 - 700	2,150 - 2,250 600 - 700	2,150 - 2,250 600 - 700						
Performance	Necessary Starting speed	0° C - 20° C (with starting aid)	rpm	Min. 100 Min. 100	-	Min. 100 Min. 100	-						
g	Intake resistance Intake pressure Exhaust pressure	At all speed At rated output	mmH ₂ O mmHg	Max. 300	762	Max. 200	762						
Intake and exhaust system	(Turbine inlet pressure) Exhaust temperature	At rated output	mmHg										
sha	(Turbine inlet temp.)	(intake air temp.: 20° C) Quick acceleration	°C	Max. 650 Max. 6.0	Max. 650 8.0	Max. 650 Max. 6.0	Max. 650 8.0						
take and	Exhaust gas color	(Low idling→High idling) At rated output At high idling	Bosch Scale	Max. 2.0	3.0	Max. 2.0	3.0						
II	Valve clearance (when engine is	Intake valve	mm	0.4	-	0.4	-						
	hot or cold.)	Exhaust valve	mm	1.0	-	1.0	-						
Engine body	Compression Pressure (SAE30 oil)	Oil temperature: 40° C to 60° C (Engine speed)	Kg/cm ² (rpm)	Min. 29 (210 - 250)	20 (210 - 250)	Min. 29 (210-250)	20 (210-250)						
Engin	Blow-by pressure (SAE30 oil)	re At rated output Water temperature: Min. 70° C		Max. 150	300	Max. 150	300						
Lubrication system	Oil Pressure (Oil temperature:	At rated output SAE30 oil SAE10W oil At low idling	Kg/cm² Kg/cm²	3.0-5.0	2.1	3.0 - 5.0	2.1						
cation	Min. 80° C)	SAE30 oil	Kg/cm ² Kg/cm ²	Min. 1.5 Min. 1.0	0.7 0.7	Min. 1.5 Min. 1.0	0.7 0.7						
ubri	Oil temperature	All speed (oil in oil pan)	°C	80 - 110	120	80 - 110	120						
	Oil consumption ratio	At continuous rated output (Ratio of fuel consumption)		Max. 0.5	1.0	Max. 0.5	1.0						
Fuel system	Fuel injection pressure	Nozzle tester	Kg/cm ²	$^{+13}_{255}$	230	+13 255 + 5	230						
	Fuel injection timing	B.T.D.C	degree 42 ± 1 42 ± 1			$37^{\circ} \pm 1$ (w/timer 8°)	$37^{\circ} \pm 1$ (w/timer 8°)						
system	Radiator pressure valve	Opening pressure (Differential pressure)	Kg/cm ²	0.75±0.1	0.75±0.1	0.75±0.1	0.75±0.1						
Cooling system	Fan speed Fan belt tension	At rated engine speed Deflects when pushed with a force of 6 kg	rpm mm	1,000 ± 25 See page	$1,000\pm25$ = 12 - 011	1,100±25 See page	$1,100\pm 25$ 12-011						

★ The values given in the Testing and Adjusting data are NOT for adjustment of the output.
 Do not use these values as a guide to change the setting of the fuel injection pump.

Engine modelBSA6D170-1Applicable machine modelBE1000Class-Image: Class-													
Applicable machine model BE1000													
ifica	Item	Condition,etc	Unit	Standard	Tolerance								
Performance	Engine speed	Highidling speed Low idling speed	rpm rpm	$\begin{array}{c} 1,850\pm50\\ 675\pm25\end{array}$	$1,850 \pm 50$ 675 ± 25								
rfon	Necessary	0°C	rpm	Min. 130	-								
Pe	Starting speed	- 20° C (with starting aid)	rpm	Min. 100	-								
	Intake resistance	At all speed	mmH_2O	Max. 300	762								
-	Intake pressure Exhaust pressure	At rated output	mmHg	Min. 1,000	900								
Intake and exhaust system	(Turbine inlet pressure)	At rated output	mmHg	Min. 900	810								
ust	Exhaust temperature	All speed											
khai	(Turbine inlet temp.)	(intake air temp.: 20° C)	°C	Max. 650	Max. 700								
d e)		Quick acceleration		Max. 4.0	6.0								
an	Exhaust gas color	(Low idling→High idling)											
ake		At rated output	Scale	Max. 2.0	3.5								
Int	× 1 1	At high idling		Max. 2.0	3.0								
	Valve clearance (when engine is	Intake valve	mm	0.4	-								
	hot or cold.)	Exhaust valve	mm	1.0	-								
~	Compression	Oil temperature:			10								
Engine body	Pressure	$40^{\circ} \mathrm{C} \mathrm{to} 60^{\circ} \mathrm{C}$	Kg/cm ²	Min. 26	18								
le b	(SAE30 oil)	(Engine speed)	(rpm)	(210 - 250)	(210 - 250)								
ngi	Blow-by pressure	At rated output		M. 400	800								
Ē	(SAE30 oil)	Water temperature: Min. 70° C	mmH ₂ O	Max. 400	800								
		At rated output											
		SAE30 oil	Kg/cm ²	3.5 - 5.0	2.5								
ation system	Oil Pressure	SAE10W oil	Kg/cm ²	3.0-4.5	2.1								
sys	(Oil temperature:	At low idling	ng/em	5.0 1.5	2.1								
ion	Min. 80° C)	SAE30 oil	Kg/cm ²	Min. 1.5	0.7								
cat		SAE10W oil	Kg/cm ²	Min. 1.0	0.7								
Lubric	Oil temperature	All speed (oil in oil pan)	°C	80 - 110	120								
Ĺ	Oil consumption	At continuous rated output	%	Max. 0.5	1.0								
	ratio	(Ratio of fuel consumption)											
em	Fuel injection			+13									
yst	pressure	Nozzle tester	Kg/cm ²	265+5	239								
els	Fuel injection	B.T.D.C	degree	38 ± 1	38 ± 1								
Fu	timing												
em	Radiator pressure	Opening pressure	Kg/cm ²	0.75 ± 0.1	0.75 ± 0.1								
syst	valve	(Differential pressure)											
s gu	Fan speed	At rated engine speed	rpm	950±25	950 ± 25								
Cooling system Fuel system	Fan belt tension	Deflects when pushed	mm	See page	12-011								
Ŭ		with a force of 6 kg											

★ The values given in the Testing and Adjusting data are NOT for adjustment of the output.
 Do not use these values as a guide to change the setting of the fuel injection pump.

	En	gine model			BSA6	D170A-1	
	Applicab	le machine model		BH60	/BH70	210)M
Class- ifica tion	Paramete	Condition,etc	Unit	Standard	Tolerance	Standard	Tolerance
nance	Engine speed	Highidling speed Low idling speed	rpm rpm	2365 ± 35 925 ± 25	-	2365 ± 35 925 ± 25	-
Performance	Necessary Starting speed	0° C - 20° C (with starting aid)	rpm	Min. 80 Min. 80	-	Min. 80 Min. 80	
stem	Intake resistance Allowable Ex. back	At all speed At rated output	mmH ₂ O mmHg	Max. 300 Max. 75	Max. 635 -	Max. 300 Max. 75	Max. 635 -
Intake and exhaust system	pressure Exhaust temperature (Turbine inlet temp.)	All speed	°C	Max. 680	Max. 700	Max. 680	Max. 700
and ex	Exhaust gas color	At rated output At high idling	Bosch Unit	Max. 3.0 Max.2.5	Max. 5.0 Max. 3.5	Max. 3.0 Max.2.5	Max. 5.0 Max. 3.5
Intake	Valve clearance (when engine is	Intake valve	mm	0.4	-	0.4	-
	hot or cold.)	Exhaust valve	mm	1.0	-	1.0	-
Engine body	Compression Pressure (SAE30 oil)	Oil temperature: 40° C to 60° C (Engine speed)	Kg/cm ² (rpm)	Min. 26 (200 - 250)	18 (200 - 250)	Min. 26 (200 - 250)	18 (200-250)
Engine	Blow-by pressure (SAE30 oil)	At rated output Water temperature: Min. 70° C	mmH ₂ O	Max. 400	Max. 700	Max. 400	Max. 700
Lubrication system	Oil Pressure (Oil temperature: Min. 80° C)	At rated output SAE30 oil SAE10W oil At low idling SAE30 oil SAE10W oil	Kg/cm ² Kg/cm ² Kg/cm ² Kg/cm ²	3.0 - 5.0 2.5 - 4.5 Min. 1.5 Min. 1.0	Min. 2.0 Min. 2.0 Min. 0.7 Min. 0.7	3.0 - 5.0 2.5 - 4.5 Min. 1.5 Min. 1.0	Min. 2.0 Min. 2.0 Min. 0.7 Min. 0.7
Lubri	Oil temperature Oil consumption ratio	All speed (oil in oil pan) At continuous rated output (Ratio of fuel consumption)	°C %	80 - 110 Max. 0.5	Max. 120 Max. 1.0	80 - 110 Max. 0.5	Max. 120 Max. 1.0
Fuel system	Fuel injection pressure Fuel injection timing	Nozzle tester B.T.D.C Without timer With timer	Kg/cm ² degree	300 ± 10 39 ± 1 36 ± 1	Min. 240 39 ± 1 36 ± 1	300 ± 10 39 ± 1 36 ± 1	$Min. 240$ 39 ± 1 36 ± 1
	Radiator pressure valve	Opening pressure (Differential pressure)	Kg/cm ²	30 ± 1 0.75 ± 0.1	0.65 - 0.85	50 ± 1 0.75 ± 0.1	0.65 - 0.85
Cooling system	Fan speed Fan belt tension	At rated engine speed Deflects when pushed with a force of 6 kg	rpm mm	1260±40 13	1220 - 1300 10 - 16	1260±40 13	1220 - 1300 10 - 16

 The values given in the TESTING AND ADJUSTING DATA are NOT for adjustment of the output.
 Do not use these values as a guide to change the setting of the fuel injection pump.

	En	gine model		BSA6D1	70AG-1
	Applicab	le machine model		BDG500	/BDG550
Class- ifica tion	Paramete	Condition,etc	Unit	Standard	Tolerance
Performance	Engine speed	Highidling speed Low idling speed	rpm rpm	$\begin{array}{c} 1545\pm15\\ 1000\pm25 \end{array}$	1545 ± 15 1000 ± 25
Perfor	Necessary Starting speed	0° C - 20° C (with starting aid)	rpm rpm	Min. 80 Min. 80	-
Intake and exhaust system	Intake resistance Intake pressure pressure	At all speed At rated output	mmH ₂ O mmHg	Max. 450 -	635
xhaust	Exhaust temperature (Turbine inlet temp.)	All speed	°C	Max. 650	Max. 650
and e	Exhaust gas color	At rated output At high idling	Bosch Unit	Max. 9.8 Max. 2.0	- 2.5
Intake	Valve clearance (when engine is	Intake valve	mm	0.4	-
	hot or cold.) Compression	Exhaust valve Oil temperature:	mm	1.0	-
Engine body	Pressure (SAE30 oil)	40° C to 60° C (Engine speed)	Kg/cm ² (rpm)	Min. 26 (210 - 250)	18 (210 - 250)
Engin	Blow-by pressure (SAE30 oil)	At rated output Water temperature: Min. 70° C	mmH ₂ O	Max. 280	400
stem	Oil Pressure	At rated output SAE30 oil SAE10W oil	Kg/cm² Kg/cm²	2.5 - 4.0	2.5 - 4.0
Lubrication system	(Oil temperature: Min. 80° C)	At low idling SAE30 oil SAE10W oil	Kg/cm² Kg/cm²	Min. 1.5 Min. 1.0	Min. 0.7 Min. 0.7
Lubr	Oil temperature Oil consumption ratio	All speed (oil in oil pan) At continuous rated output (Ratio of fuel consumption)	°C %	80 - 110 Max. 0.5	Max. 120 Max. 1.0
Fuel system	Fuel injection pressure	Nozzle tester	Kg/cm ²	300 ± 10	Min. 240
Fuel	Fuel injection timing	B.T.D.C	degree	39 ± 1	39±1
ystem	Radiator pressure valve	Opening pressure (Differential pressure)	Kg/cm ²	0.75 ± 0.1	0.75 - 0.1
Cooling system	Fan speedFan belt tension	At rated engine speed Deflects when pushed	rpm mm	1024 ± 25 -	-
CO		with a force of 6 kg			

 The values given in the TESTING AND ADJUSTING DATA are NOT for adjustment of the output.
 Do not use these values as a guide to change the setting of the fuel injection pump.

TROUBLESHOOTING

CONTENTS

Points	to remember when troubleshooting	12-023
Metho	d of using troubleshooting chart	12-024
S-1	Starting performance is poor	
	(Starting always takes time)	12-028
S-2	Engine does not start	12-029
	① Engine does not turn	12-029
	^② Engine turns but no exhaust comes out	
	(Fuel is not being injected)	12-030
	③ Exhaust gas comes out but engine does not start	
	(Fuel is being injected)	12-031
S-3	Engine does not pick up smoothly	
	(Follow-up is poor)12-032	
S-4	Engine stop during operations	12-033
S-5	Engine does not rotate smoothly (hunting)	12-034
S-6	Engine lacks output (no power)	12-035
S-7	Exhaust gas is black (incomplete combustion)	12-036
S-8	Oil consumption is excessive (or exhaust gas is blue)	12-037
S-9	Oil becomes contaminated quickly	12-038
S-10	Fuel consumption is excessive	12-039
S-11	Oil is in cooling water, or water spurts back, or water level goes down	12-040
S-12	Oil pressure lamp lights up (drop in oil pressure)	12-041
S-13	Oil level rises	12-042
S-14	Water temperature becomes to high (overheating)	12-043
S-15	Abnormal noise is made	12-044
S-16	Vibration is excessive	12-045

POINTS TO REMEMBER WHEN TROUBLESHOOTING

Troubleshooting means locating the basic cause of the failure, and carrying out swift repairs, and ensuring that the failure does not occur again.

When carrying out troubleshooting, it is of course important to understand the structure and function. But to carry out the troubleshooting effectively, a quick method is to carry out troubleshooting using the problems mentioned by the operator as a guide in locating the cause.

1. Do not disassemble the machine simply because there is a failure.

If the machine is disassembled immediately just because there is a failure:

- Unrelated or unnecessary places are also disas sembled
- It becomes difficult to locate the cause of the failure

This means that there is not only a waste of time and money on replacement parts, oil, and grease, but this action will also lose the confidence of the user and operator.

For this reason also, it is important to carry out troubleshooting based on full investigation before starting and troubleshooting following the correct order.

2. Questions to ask the user and operator

- 1) Are there any problems other than those already reported ?
- 2) Did anything unusual happen before the failure occurred ?
- 3) Did the failure occur suddenly, or had the condition of the machine been poor before the failure occurred ?
- 4) What were the conditions when the failure occurred?
- 5) Had any repairs been carried out before the failure occurred ?
- 6) Had any similar failure occurred before ?

3. Checks before troubleshooting

- 1) Check the oil level
- 2) Check for any external leakage of oil from the piping and hydraulic equipment.
- 3) Check the travel of the control levers.
- Other maintenance items can also be carried out visually, so carry out any check that is considered necessary.

4. Confirming failure

Check the degree of the problem to judge for yourself if it is really a failure, or if there is some problem in the handling or operation of the machine.

★ When driving the machine and re-enacting the failure, be sure that the investigation or measurement does not make the failure worse.

5. Troubleshooting

Narrow down the causes of the failure from the results of the questions and checks in the above Items 2 - 4, then follow the troubleshooting flow chart to locate the failure.

- ★ Basic procedure for troubleshooting
 - 1) Start from the simple places.
 - 2) Start from the most probable places.
 - 3) Investigate related parts also.

6. Basic action to remedy cause of failure

Even if the failure is repaired, if the root cause of the failure is not repaired, the same failure will occur again. To prevent this, it is necessary to investigate why the failure occurred, and to remove the root cause of the failure.

METHOD OF USING TROUBLESHOOTING CHART

This troubleshooting chart is divided into three sections: **questions, check items, and troubleshooting.** The questions and check items are used to pinpoint high probability causes that can be located from the failure symptoms or simple inspection without using troubleshooting tools.

Next, troubleshooting tools or direct inspection without using to check the high probability causes to make final confirmation.

[Questions]

Section $\mathbf{A} + \mathbf{B}$ in the chart on the right corresponds to the items where answers can be obtained from the user. The items in \mathbf{B} are items that can be obtained from the user, depending on the user's level.


[Check items]

The serviceman carries out simple inspection to narrow down the causes. The items under C in the chart on the right correspond to this.

The serviceman narrows down the causes from information \mathbf{A} that he has obtained from the user and the results of \mathbf{C} that he has obtained from his own inspection.

[Troubleshooting]

Troubleshooting is carried out in the order of probability, starting with the causes that have been marked as having the highest probability from information gained from [**Questions**] and [**Check items**].



Causes

(1) (2) (3)

Causes

1, seized injection nozzle

er injection timing

urbocharger, interference

d air cleaner element

ston ring, cylinder

ve injection pump (excessive injection)

The basic method of using the troubleshooting chart is as follows.

Items listed for [**Questions**] and [**Check items**] that have a relationship with the cause items are marked with \bigcirc , and of these, causes that have a high probability are marked with \bigcirc .

Check each of the [**Questions**] and [**Check items**] in turn, and marked the \bigcirc or \bigcirc in the chart for items where the problem appeared. The vertical column (Causes) that has the highest number of points is the most probable cause, so start troubleshooting for that item to make final confirmation of the cause.

- ◆1. For [Confirm recent repair history] in the [Questions] Section, ask the user, and mark thecause column with ∆ to use as reference for locating thecause of the failure. However, do not use this when making calculations to narrow down thecauses.
- *2. Use the Δ in the cause column as reference for **[Degree of use(Operated for long period)]** in the **[Questions]** Section as reference. As a rule, do not use it when calculating the points for locating the cause, but it can be included if necessary to deter mine the order for troubleshooting.

			Seized t	Clogge	Worn p	Clogge	Improp	Defecti	
☆ 1	Confirm recent repair histo	ory							
* 2	Degree of use	Operated for long period	Δ	Δ	Δ				


TESTING AND ADJUSTING

Example of troubleshooting when exhaust gas is black

Let us assume [Clogged air cleaner] is taken to be the cause of black exhaust gas. Three symptoms have causal relationship with this problem: [Exhaust gas slowly become black.], [Power slowly become weaker], and [Dust indicator is red].

If we look from these three symptoms to find the causes, we find that there is a relationship with five causes. Let us explain here the method of using this causal relationship to pinpoint the most probable cause.

S-7	Exaust gas is black (incomplete	combustion)				Γ									
0-7	General causes why exhaust gas is black														
	. Insufficient intake air						(Cau	ses						
	 Insufficient make an Improper condition of fuel injection Excessive injection of fuel 			Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder	Clogged, seized injection nozzle	Imprper injection timing	Defective injection pump (excessive injection)	Improper valve clearance	Crushed, clogged muffler	Leakage of air between turbocharger and head	Defective contact of valve, valve seat	Defective injection pump (rack, plunger seized)	
	Confirm recent repair history			•1	-	-	_	_	_	_	-	-	_	_	
	Degree of use	Operated for long				Δ	Δ						Δ		
JS		Suddenly become		0			0							0	
Questions	Color of exhaust gas	Gradually becom													
lest	Engine oil must be added more frequently	Blue under light	load			0									
õ	Power was lost	Suddenly		0	_	•	0				0			0	
		Gradually				_	0				-	_		-	
	Non-specified fuel has been used						0							0	
	Noise of interference is heard from around tu	rbocharger		0											
	Dust indicator is red														
γ	Blow-by gas is excessive	1				0	_			_	-				
	Engine pickup is poor and combustion is irre When exhaust manifold is touched immediat	gular	ino	0			0			0	0	0		0	
ms	temperature of some cylinder is low	ly after starting eng	gine.				0							0	
ite	Match marks on fuel injection pump are out	of alignment			_	_		0				_			
ck	Seal on injection pump has come off					_			0						
Check items	Clanging sound is heard from around cylinder	r head								0					
	Exhaust noise is abnormal			0			0				0				
	Muffler is crushed	11 1									0				
	Leakage of air between turbocharger and head	a loose clamp										0			
	When turbocharger is rotated by hand, it is	found by heavy													
	When air cleaner is inspected directly, it is for	ound to be clogged													
60	When compression pressure is measured, it	is found to be low													
tin	Speed of some cylinders does not change when	hen operating on re	educed				•								
loc	cylinders When check is made using delivery method,	injection timing is	found	$\left - \right $						_					
es	to be incorrect	injection timing is	Tound					\bullet							
qn	Injection pump test shows that injection am								•						
Troubleshooting	When valve clearance is checked directly it		ide						_						
	standard value									•					
	When muffler is removed, exhaust gas color When control rack is pushed, it is found to		ot roturn								•				
	when control rack is pushed, it is found to	be neavy or does n		0		6)	6)				0		0		
			Remedy	Replace	я	Replace	Replace	Adjust	Adjust	Adjust	Replace	air	Replace	Replace	
			litencuy	sep	Clean	Sep	Sep	∕dj	\dj	<u>\dj</u>	Sep	Repair	Sep	lep	
				Ľ	\cup	Ł	Ł	4	Ł	4	Ľ	ų	Ł	F	



TESTING AND ADJUSTING

S-1 Starting performance is poor (Starting always takestime)

	General causes why exha	aust gas co	mes o	out but e	engine	does					Cau	ses									
	not start						-														
	. Defective electrical sy																$\overline{\mathbf{O}}$				
	. Insufficient supply of																stuck)				
	. Insufficient intake of		1.			c											r st			è	
	. Improper selection of				ature o	T		t									lge			/al/	
	-10° C or below, use A		5 INO.	1)				sea									lur	En	e	Ä	
	★ Battery charging 1	rate						lve						ery			k, I	yste	lol	flo	
	Charging rate							val						atte			rac	els	ler	vei	ligh
	Ambient	100 %	90 %	80 %	75 %	70 %	ler	ve,	ent	ner	ine			d b	zle	പ്പ) di	fu	eath	ıp c	2
	temperature						lin	val	lem	rai	e la			ate	ZO	iii	un	LI.	bre	un	is to
	20° C	i	1.26	1.24	1.23	1.22	cy	of	er el	r, st	du	to !	or	rioi	u n	nti	d uo		air	d uo	Ę.
	0° C		1.27	1.25	1.24	1.23	ng,	tact	ane	ilte	und	ala	rnat	lete	ctic	ctio	ctic	in	ank	ctic	COSI
	-10° C		1.28	1.26	1.25	1.24	Worn piston ring, cylinder	Defective contact of valve, valve seat	Clogged air cleaner element	Clogged fuel filter, strainer	Clogged feed pump strainer Defective ADS device	Defective regualator	Defective alternator	Defective or deteriorated battery	Defective injection nozzle	Defective injection timing	Defective injection pump (rack, plunger	Leakage, clogging, air in fuel system	Clogged fuel tank air breather hole	Defective injection pump overflow valve	Engine oil viscosity is too high
	. The specific gravity s		or the	e chargir	ng rate	of 70%	sto	/e c	lair	1E	I fe	e n	/e a	/e (/e i	'e ii	/e i	, cl	1Eu	/e i	5
	or more in the above						iq	ctiv	ged	gec	gec	cti	ctiv	ctiv	ctiv	ctiv	ctiv	age	ge.	ctiv	ne
	. In cold weather the sp				or the	charging	lio'	efe	log	log	log efe	efe	efe	efe	efe	efe	efe	eak	log	efe	ng.
	rate of at least 75% in		table	e.			≤	D	U U	0				Ω	Ω	Δ		Ĺ	0	Δ	Ш
	Confirm recent repair history	/		> (1	<u>c</u> 1	· 1			_		_										
	Degree of use Ease of staritng			Operated Gradually	for long	g period		0	Δ	$\frac{\Delta}{0}$	$\frac{\Delta}{2}$	_		Δ							
	Lase of starting			Start whe			0	O		0				0					$ \rightarrow$		0
IS	Indicator lamp does not light	up			ii waiii	1					6	_									-
Questions	Engine oil must be added more		v				0														
est	Replacement of filters has no	t been carrie	ed out	accordin	g to ope	eration										_					
Su	manual							0	0	0				0		0					
Ŭ	Dust indicator is red							0													
	Non-specified fuel has been u	used							0	0				0		0					
	Type of oil is not used accord	ling to opera	ation i	manual						_											0
	Battery charge lamp is ON Starting motor cranks engine	clowly										0	0	0					\rightarrow		
	When exhaust manifold is tou		diatly	after star	tingeng	ine				_	_	-		0					$ \rightarrow$		0
V	temperature of some cylinder		anatry	urter stur	ung eng	,iiie.									0						
	Engine does not pick up smo	othly, and co	ombus	stion is in	regular			0							0						
s	Blow-by gas is excessive																				
Check items	Match marks on fuel injection	n pump are	out of	alignme	nt											0					
k it	Mud is stuck to fuel tank cap																		0		
lec	When engine is cranked with					- 1											0				
D D	 Little fuel comes out even Little fuel comes out even 	when injec	$\frac{1}{1}$ filter	ump siee	ve nut i	s loosened	1			0		-							\rightarrow		
	Leakage from fuel piping		i inter	all blee	a piug i	s iooseneu				0		-				_	0 0	0	\rightarrow		_
	Ther is hunting from engine (rotation is ir	regula	ar)						0	0	-							0	0	
	When compression pressure	• 1		<u>c</u> 1 .	be low					-	<u> </u>							-	_		
	When air cleaner element is in																				
	When fuel filter, strainer are in									\bullet								\bullet			
	When feed pump strainer is in				o be clo	gged					•										
50	APS combustion portion does				minel E	Vac					•	+									_
Troubleshooting	Voltage is 26 - 30V between a with engine at low idling	iternator teri	mmai i	B and terr	mnai E	Yes No				_		•	•				_				
00	Either specific gravity of elect	trolvte or vo	ltage o	of battery	is low	110															
she	Some cylinder does not change					duced								-							
ble	cylinder	0 1		1	0																
no.	When check is made using de	elivery metho	od, inj	ection tin	ning is f	found to be	-														
T ₁	incorrect															-					
	When control rack is pushed,																				
	(when blind plug at rear of pur		ed, it c	can be see	n that p	lunger															
	control sleeve does not move When fuel cap is inspected dire		und to	ba alogg	ad					_		-					_				_
	When overflow valve is inspected difference when overflow valve is inspected when overflow valve is					stays open					_	-				_					-
	_				. urways			-	\square			-	-			_		_	\rightarrow	-	-
		lastions and	Charl	k itama)		L.	Replace	ir.	_		1	Replace	Replace	Replace	Replace	st	Replace	.н		ace	Replace
	ossible cause (judging from Qu lost probable causes (judging f				items)	Remedy	žpl(Repair	Clean	Clean	Clean	i ĝ	zpl	žplí	3pl	Adjust	žpli	Repair	Clean	Replace	<u>spl;</u>
	ossible causes due to length of						R	R	บิ	U	U N N	- Z	R	R	R	Ý	Ř	Ř	U	R	R
	are confirm the cause		4 10																		

S-2 Engine does not start

General causes why does not turn

Causes Internal parts of engine seized ★ If internal parts of the engine are seized, carry out trouble-Defective adjustment of engine stop motor wire shooting for "Engine stops during operations" Failure in power train Defective electrical system Defective saftey relay or safety switch Defective battery terminal connection Defective wiring of starting circuit Defective or deteriorated battery Defective engine stop motor Defective starting motor Defective battery relay Broken ring gear Confirm recent repair history Degree of use Operated for long period Ouestions Δ Δ Condition of horn when starting Horn does not sound 0 0 switch is turned ON Horn sound level is low 0 Rotating speed is slow 0 When starting switch is turned to Makes grating noise 00 START, pinion moves out,but Soon disengages again Makes rattling noise and does not turn 00 0 When starting switch is turned to START, pinion does not move out Check items 0 0 When starting switch is turned to ON, there is no clicking spund 0 0 Battery terminal is loose 0 out troubleshooting for defective When starting switch is turned to ON, linkage does not move 0 0 When battery is checked, battery electrolyte is found to be low 0 Specification gravity of electrolyte, voltage of battery is low For the following conditions 1) - 5), turn the starting switch OFF, connect the cord, and carry out troubleshooting at ON 1) When terminal B and terminal C of starting switch are connected, Troubleshooting engine starts wiring of starting circuit 2) When terminal B and terminal C of starting motor are connected, engine starts 3) When terminal B and terminal C of safety relay are connected, engine starts 4) When terminal of safety switch and terminal B of starting motor are connected, engine starts 5) There is no 24V voltage between terminal B and terminal E of battery Carry . • relay When ring gear is inspected directly, tooth surface is found to be chipped Does not move even when engine stop motor linkage is disconnected . Legend Replace Replace Replace Replace Replace Replace Replace Adjust O: Possible cause (judging from Questions and Check items) Remedy Most probable causes (judging from Questions and Check items)

 Δ : Possible causes due to length of use (used for a long period)

•: Items confirm the cause

starting switch

Defective

0

0

Replace

(2) Engine turns but no exhaust gas comes out (Fuel is not being injected)

General causes why engine turns but no exhaust gas comes out

- Supply of fuel impossible .
- Supply of fuel is extremely small
- Improper selection of fuel (particularly in winter)

	Standards for	or use of fuel							Bloken, injection pump drive shaft, k	, plung	uc					ole		
	KINDOF	AN	BIEN	ГТЕМР	ERAT	URE			ive s	Defective injection pump (rack,	Seized, broken feed pump piston	<u> </u>	er		50	Clogged fuel tank air breather hole	or	
	FLUID	14	32	50	6	8	86	°F	G-	du	l III	ine	aine		ipin	reat	mol	
		10	0	10	2	20	30°	°C	l III	Ind	l pu	Clogged fuel filter, strainer	Clogged feed pump strainer		Clogged, leaking fuel piping	ir bı	stop motor	
				STM D	075 N	0.2			d	ion	fee	er,	lmp		gfu	ıka		ъ
					973 IN	0.2			[ii]	ect	en	filt	lpu		Ś	tar	gij.	use
	Diesel fuel	ASTM D975 N	lo. 1].je	:E	ok	uel	eec	lel	leal	uel	en	[e]
									.= 	ive	, p	ed f	ed f	f fu	с,	ed f	ive	r fu
		•							ker	ect	zed	80 80	80	ko	200	33	ect	ope
									Blo	Def	Sei	Clo	Clo	Lack of fuel	Clo	6	Defective engine	Iproper fuel used
	Confirm recen	t repair histor	y						<u> </u>			-	-		-	-	÷	<u> </u>
	Degree of use			perated f	or long	period						Δ	Δ			Δ		
ls	Exhaust gas su	uddenly (when	starting	again) si	topped	coming	g out		0	0	0					0		
ior	Replacement of	of filters has no	ot been o	carried ou	it accoi	rding to	oper	ation				0	0					
Questions	manual																	
5 n	Fuel tank is for	ound to be emp	oty											0				
	There is leakage			ushed pip	oing										0			
	Mud is stuck t															0		
	When starting					move											0	
l a	When fuel filte				e out													0
ite		s cranked with omes out even			in blog	d mlut i	1000	anad	0			0	0					0
ck		purts out even							0	0	0							
Check items	Rust and water	r are found wh	en fuel	is drained	$\frac{1}{4}$	eve nut	15 100	Jseneu				0	0					
00	Inspect injecti			is dramed	4							<u> </u>	<u> </u>				-	
tin	When control	rack is pushed	. it is fo	und to be	e heavy	or doe	s not	return									-	
00	Inspect feed p		,														-	
Troubleshooting	When fuel filte		nspected	directly,	they ar	e found	to be	e clogged			-	•					-	
ble	When feed put	mp strainer is i	nspecte	d directly	y, it is f	ound to	be cl											_
no	When fuel cap	is inspected d	irectly, i	it is found	d to be	clogged	1											
$\mathbf{T}_{\mathbf{r}}$	Does not move	e even when er	ngine sto	op motor	linkage	e is disc	onne	cted										
Leger	nd																	
	ossible cause (ju	dging from Q	uestions	and Che	ck item	ns)	<u> </u>		ace	ace	ace	L	u		.ц	.н	ace	ace
©: M	lost probable ca	uses (judging	from Qu	lestions a	and Che	eck iten	ns)	Remedy	Replace	Replace	Replace	Clean	Clean	Add	Repair	Repair	Replace	Replace
Δ : Po	ossible causes d	lue to length of	use (us	ed for a l	ong pe	riod)			R	R	R	Ο	Ο	A	R	Ř	Ř	Ř

•: Items confirm the cause

Causes

ger seized)

key

Causes

ion nozzle, defective spray ing, air in fuel system

eteriorated battery

nk air breather hole

ontrol lever linkage

cen valve system (vlave,rocker lever,etc.)

tion pump (rack, plunger stuck)

ng, cylinder liner

ump strainer aner element

lter, strainer

3 Exhaust gas comes out but engine does not start (Fuel is being injected)

General causes why exhaust gas comes out but engine does not start

- Lack of rotating force due to defective electrical system •
- Insufficient supply of fuel
- Insufficient intake of air
- Improper selection of fuel and oil .

			Defective, broken valve s	Defective injection pump	Worn piston ring, cylinde	Clogged fuel filter, straine	Clogged feed pump strair	Clogged air cleaner eleme	Defective APS device	Defective or deteriorated	Leakage, clogging, air in f	Clogged injection nozzle,	Clogged fuel tank air brea	Improper fuel, oil used	Defetive fuel control leve
	Confirm recent repair history														
	Degree of use Operated for long period	ł			Δ	Δ	Δ					Δ	$ \rightarrow $		
	Suddenly failed to start		0	0											
	When engine is cranked, abnormal noise is heard from around cylinder	head	0												
Questions	Engine oil must be added more frequently				0										
Ei	Non-specified fuel had been used			0								0			
es	Replacement of filter has not been carried out according to operation n	nanual				\odot	0	\odot							
l õ	Type of oil is not used according to operation manual													\odot	
	Rust is found when fuel is drained					0	0								
	Dust indicator is red							0							
	Indicator lamp does not light up								$^{\odot}$						
	Starting motor cranks engine slowly									0				0	
	Mud is stuck to fuel tank cap												0		
	When fuel lever is placed at FULL position, it does not contact stopp	er		0											0
Y	When engine is cranked with starting motor,			0											0
JS	1) Little fuel comes out even when injection pump sleeve nut is loose														\sim
Check items	2) Little fuel comes out even when fuel filter air bleed plug is loosened	1				0	0							0	
k i	There is leakage, from fuel piping										0				
ec	When exhaust manifold is touched immediately after starting engine,											0			
5	temperature of some cylinder is low											0			
	When fuel filter is drained, no fuel comes out													0	
	Even when fuel control lever is moved, fuel injection pump lever does	not move													\odot
	Remove head cover and inspect directly														
	When control rack is pushed, it is found to be heavy or does not return	n													
	When compression pressure is measured, it is found to be low														
മാ	When fuel filter, strainer are inspected directly, they are found to be clog	ged													
tin l	When feed pump strainer is inspected directly, it is found to be clogged														
Troubleshooting	When air cleaner element is inspected directly, it is found to be clogged														
she	APS combustion portion does not become warm even when starting switch	ch is													
le	turned to HEAT								•						
l du	Either specific gravity of electrolyte or voltage of battery is low														
L L	When feed pump is opaerated, there is no response or pump is heavy														
	Speed of some cylinder does not change when operating on reduced cylin	der													
	When fuel cap is inspected directly, it is found to be clogged														
	Pay, stiffness in fuel control lever linkage														
Legend	-		a)	0	0					0			\neg	0	
	ssible cause (judging from Questions and Check items)	Domoder	Replace	Replace	Replace				ür	Replace	μi		с	Replace	ا <u>ل</u> ا.
	ost probable causes (judging from Questions and Check items)	Remedy	g	<u>id</u>	lď	Clean	Clean	Clean	Repair	ď	Repair	Clean	Clean	lď	Repair
	ssible causes due to length of use (used for a long period)		R	R	R	U	U	U	R	Ř	R	U	U	R	Ъ
Δ. ΓΟ	ssible causes due to length of use (used for a long period)														_

Causes

S-3 Exhaust does not pick up smoothly (Follow-up is poor)

General causes why engine does not pick up smoothly

- Insufficient intake of air •
- Insufficient supply of fuel •
- Improper condition of fuel injection •
- Use of improper fuel •

	 Use of improper fuel Defective fuel injection pump 		Clogged all cleaner element	Clogged tuct fillet, suaffict Clogged feed minn strainer	Clogged injection nozzle, defective spray	Defective feed pump	Worn piston ring, cylinder	Seized turbocharger, interference	Improper valve clearance	Clogged fuel tank air breather hole	Clogged, leaking fuel piping	Defective contact of valve, valve seat	Improper adjustment of injection pump stop lever	Broken injection pump boost compensator diaphragm broken air pump
	Confirm recent repair history		1	+	1	<u> </u>	-			<u> </u>	Ť	_		
	Degree of use Operated for long period			1	Δ	Δ					Δ			
Questions	Replacement of filter has not been carried out according to operation manual		0 0	3										
stic	Non-specified fuel has been used	(0											
nes	Engine oil must be added more frequently			C	>									
ō [Dust indicator is red		(2							0			
	Noise of interference is heard from around turbocharger				0	0	0						\square	
	Engine pick-up suddenly poor												\odot	
	Color of exhaust gas Blue under light load				0	0								
	Black			_	_		0						\vdash	
ŕ -	Clanging sound is heard from around cylinder head	_	_	_	_			0						
s	Mud is stuck to fuel tank cap	_	_	_	_				0				0	
en	There is leakage, from fuel piping High idling speed under no load is normal, but speed suddenly drops when loa	d		+	-							0	\vdash	
kit	is applied	iu												0
Check items	There is hunting from engine (rotation is irregular)		-(>⊢	+									\sim
5 F	When exhaust manifold is touched immediatly after starting engine, temperature	re	-	+	0	0							0	
	of some cylinder is low									0				
	Blow-by gas is excessive			1							_			
	When air cleaner element is inspected directly, it is found to be clogged			-							•			
	When fuel filter, strainer are inspected directly, they are found to be clogged												0	
	When feed pump strainer is inspected directly, it is found to be clogged													0
ac	Some cylinders does not change engine speed when operating on reduced cylinder	•												
ting	Inspect feed pump													
00	When compression pressure is measured, it is found to be low													
l sh	When turbocharger is rotated by hand, it is found to be heavy				•									
Troubleshoo	When valve clearance is checked directly, it is found to be outside standard value			_	_	•	_						\square	
luo	When fuel cap is inspected directly, it is found to be clogged			_	_		•						\vdash	
Tr	When feed pump is opaerated, operation is too light or too heavy When starting switch is turned ON, there is a clearance between stop lver and stopp													
-	bolt		_	_									\vdash	
	When boost compensator diaphram is inspected it is found to be broken, or pipe	ic	-	+	-	-	-		-				\vdash	
	crushed	. 13		+	-					-	•		\vdash	-
				+		e	e	e			-	e		ه
Legend			3 9	3 5	Repair	Replace	Replace	Replace	Adjust	ŋ	Repair	Replace	Adjust	Replace
		У [Clean	Clean	de	ep	ep	ep	dj	Clean	eb	ep	<u>i</u>	ep
©: MIC	st probable causes (judging from Questions and Check items)	C			2 P	R	R	R	A	\circ	R	R	\triangleleft	R

 Δ : Possible causes due to length of use (used for a long period)

S-4 Enigne stops during operations

General causes why engine stops during operations

		of engine seized								Ca	use	s					٦
	troublesh Failure in pov ★ If the eng	overheating and the engin poting for overheating.	re in the power trai	n,	Broken, seized piston, connecting rod	Broken, seized crankshaft bearing	Broken valve system (valve, rocker lever, etc.)	Broken, seized gear train Broken mum auviliere aminment	Broken fuel pump drive shaft, key	Lack of fuel	Clogged fuel filter, strainer	Clogged feed pump strainer	Broken, seized feed pump piston	Clogged leaking fuel piping	Clogged fuel tank air breather hole	Defective injection pump (rack, plunger stuck)	Failure in chassis power train
	Confirm recent rep	air history				_			+-			<u> </u>	_	-	-	—	7
	Degree of use	Operated for long period								1	Δ	Δ				\neg	
	U	Abnormal noise was heard a	nd engine stopped su	ddenly	0	0	0	0 0	0				0			0	0
	Condition when	Engine overheated and stopp		2	0	0	-	(_				-			-	-
us l	engine stooped	Engine stopped slowly								0	0	0				-	
tio	engine stooped	There was hunting and engin	ne stopped						-	0	0	0			0	-	\neg
es	Fuel gauge lamp lig		ne stopped						-	-						-	-
Questions	Fuel tank is found								-	0					_	\rightarrow	_
			acording to empretion	monual					_	0					_	\rightarrow	-
		ters has not been carried out a	cording to operation	manuai					_	_	0	0				_	-
	Non specified fuel		• • • •						_		0	0	0	_		0	
		s operated, there is no respon	se or it is heavy						_	-	0	0		0	_	\rightarrow	-
	Mud is stuck to fue								_						0	\rightarrow	
	Engine turns, but s	tops when transmission contr							_								0
ns			Does not turn at all		0	0			_								le
ter	Try to turn by han	d	Turns in opposite of				0		_	1							lur
ki	using barring tool		Moves amount of b	acklash				00	_								S V
Check items			Shaft does not turn						0	-							chassis volume
- G		found when fuel is drained								-	0	0					chi
		e found when oil is drained			0	0					0	0					troubleshooting in
20	Remove oil pan an									1							ting
oting		r and inspect directly								1							00
J d	When gear train is	inspected, it does not turn															lesł
yu		auxiliary equipment is remov															qn
le		ainer are inspected directly, the		ged							\bullet						ĬĔ
du		rainer is inspected directly, it is	found to be clogged														out
Troubleshoo	Inspect feed pump												ullet				Carry
L	When control rack i	is pushed, it is found to be hear	vy or does not return														Ca
Legend	1				e	e	ချ	ė jė	<u>y</u> <u>v</u>				ရု	. 1	T	ю	
		g from Questions and Check it	ems)	Remedy	lac	Ыac	lac	190	lac	-	an	an	olac	air	an	lac	
		judging from Questions and (Replace	Replace	Replace	Replace	Replace	Add	Clean	Clean	Replace	Repair	Clean	Replace	
		length of use (used for a long			Å	Ц	rr le				\cup	\cup	Ч	Ц	\cup	Ч	

du

Causes

S-5 Enigne does not rotate smoothly (hunting)

General causes why engine does not rotate smoothly

. Air in fuel system

	. All fill fuel sys . Defective gov	ernor mechanism		Defective operation of governor	Defective adjustment of governor	Defective operation of control rack	Low speed is too low	Lack of fuel	Clogged feed pump strainer	Clogged fuel filter, strainer	Clogged, air in circuit between fuel tank and feed pur	Clogged, air in circuit between feed pump and zozzle	Clogged fuel tank air breather hole	Defective fuel feed pump
	Confirm recent rep													
	Degree of use	Operated for long period				_	_		Δ	Δ			$ \rightarrow$	
s		Occurs at fixed speed range		0	0	0	0		_		_	_	_	_
Questions	Condition of	Occurs at low idling		0			0		0	0	0	0	$ \rightarrow $	_
sti	hunting	Occurs even when speed is raised		0	0	0		_					0	_
ne		Ocuurs on slops				_		0					\rightarrow	_
\circ	Fuel tank is found		1					0	-	-		_	\rightarrow	
		ters has not been carried out according to operation m	nanual			_			0	0			_	_
	Rust is found wher					_			0	0	~		\rightarrow	_
	Leakage from fuel					_					0	0	_	_
IS	When feed pump i	ght, return is quick									0	0		
en		ght, return is normal				-				_	0	_	+	-
kit		times changes grealty		0	0	-	_			_	0	_	+	0
Check items	Sometimes difficul			0		0						-+	+	-
G	Seal on injection p			•	0	-	0			_		_	+	-
മാ	When governor lev	ver is moved it is found to be stiff		•								-	\neg	\neg
tin		mp is tested, governor is found to be improperly adju	usted			-							-	
00		is pushed, it is found to be heavy or does not return			-	•							-	
sh		spected directly, it is found to be clogged					•					\neg	•	
ble	When feed pump st	rainer is inspected directly, it is found to be clogged												
no		ainer are inspected directly, they are found to be clogg	ed											
Troubleshooting	Check fuel feed pun	np												\bullet
Legend														e
		from Questions and Check items)	Remedy	sn	sn	sn	sn	<u></u>	щ	Я	air	air	딟	lac
		judging from Questions and Check items)	uy	Adjust	Adjust	Adjust	Adjust	Add	Clean	Clean	Repair	Repair	Clean	Replace
		ength of use (used for a long period)		4	4	٩,	4	4	\cup	\cup	Å	Å	\cup	Ъ

Causes

S-6 Engine lacks output (no power)

Carry out troubleshooting to decide if the cause is in the engine or in the machine. (Measure engine stall speed)

	engine or in the machine. (Measure engi															_	
		(r)														Broken injection pump boost compensator diaphragm Incorrect mosition of ston lever	
	General causes why engine lacks output														-	Indu	
													ent		-	lä	
	. Insufficient intake of air								ay				Bent tuel lever linkage, Detective adjustment			ato	
	. Insufficient supply of fuel								spray			at	snfr			ens	
	. Improper condition of fuel injection								Ive			se	eac	_	<u>e</u>	du l	
	• Use of improper fuel				nce				ect	5	-	- ¥	211V	-	q	Pr CO	5
	(If non-specified fuel is used, output	drops)		ıt	fere	_		er.	det	50			etec	20 -	the	let	
	. Lack of output due to overheating			ner	terf	ide!	ine	ain,	zle,	bId	- Ice		ă :	Idi	reat		
	\star If there is overheating and lack o	f output, carry out		elei	r, in	ylir	stra	str	IOZ	d l	arar f		age	el b	Irb	t lini	
	troublshooting for overheating.			ner	rgei	ပ ဆိ	er,		u l	nd -	cle	0 มี .	ink ink	al-	lka		í La l
				lea	cha	ц.	Ē	g .	cti cti	5	ve	- nta	er l	ij,	tar		hig
				ur c	poq	uo	nel,	ee.	inje	5 '	Val	S	lev	[leal	ine i	bec	20
				ed å	1 tu	pist	ed i	eq	ed	Ξ.	. ber		inel	eď,	ed .	II II	vel 1
				Clogged air cleaner element	Seized turbocharger, interference	Worn piston ring, cylinder	Clogged fuel filter, strainer	Clogged feed pump strainer	Clogged injection nozzle, defective	Seizea injection purity plunger	Improper valve clearance	Defective contact of valve, valve seat	ntt	Clogged, leaking tuel piping	Clogged fuel tank air breather hole	Broken injection pump boost co Incorrect position of ston lever	Oil level too high
				Ũ	Se	Š	บี่ไ	5	55	NG -	E A	ă la	Be 0	บี่เป	<u></u>	<u>r</u> Br	i Ö
	Confirm recent repair history		· 1							_			-		_		+
	Degree of use Power was use	Operated for long pe Suddenly	rıod	Δ	0	Δ	Δ	Δ		_		Δ			_		
Questions	I Ower was use	Gradually		0	0	0	0	$\overline{\mathbf{o}}$	0	+		5			-	-	
sti	Engine oil must be added more frequently	Gradually				0											0
J ne	Replacement of filter has not been carried out	according to operation	on manual	0				0									
	Non-specified fuel has been used						0	0	0	0							
	Dust indicator is red	D11-		0			_								_		
	Color of exhaust gas	Black Blue under light load		0	0	0	\rightarrow	_		_	_	_	_		+		_
Y	Noise of interference is heard from around tur				0	0	-								-		
	Blow-by gas is excessive				-	0											
	Engine pick-up is poor and combustion is irre	gular			0				0					0	0	00)
s	High idling speed under no load is normal, b	ut speed suddenly dro	ps when				0	0							0		
em	load is applied When exhaust manifold is touched immediatl	y ofter starting anging					-	-		_					-		_
k it	temperature of some cylinder is low	y after starting engine.	,						0	C							
Check items	There is hunting from engine (rotation is irreg	ular)					0	0						0	$\overline{\mathbf{o}}$		
10	Clanging sound is heard from around cylinder						-			-	0			-	-		
	High idling speed of engine is low								(D			0				
	Leakage from fuel piping	4 . 1 4												0	_		
	When injection pipe is held between fingers, cylinder with a weak pulse	there is no pulse, or tr	iere are						(0							
	When air cleaner element is inspected directly	v. it is found to be close	ged	•			-	-		+					-		
	When turbocharger is rotated by hand, it is for			-	•											dn	
	When compression pressure is measured, it i										(ĸ	
ы В Ц	When fuel filter, strainer are inspected direct						•									pi	
Troubleshooting	When feed pump strainer is inspected directl Some cylinders does not change engine spe						_	•							_	lot	
po l	cylinder	ed when operating of	i reduced						•							SL	
les	When control rack is pushed, it is found to b	e heavy or does not re	turn				-								-	loe	
qn	When valve clearance is checked directly, it									-						e	
L _I	value															gin	
	When lever is placed at FULL position, it do		r				_						•	_	_	Engine does not pick up	
	When feed pump is opaerated, operation is too When fuel cap is inspected directly, it is found						_	_		_				•			
Ļ					0	0		+			+	0	-		-	Go to S-3	smoothly
Lege		k itoms)	Domoder	u	act	ace	u	д -	air.		ust	act	ust	ar	ц	to	oot
	ossible cause (judging from Questions and Chec fost probable causes (judging from Questions a		Remedy	Clean	Replace	Replace	Clean	Clean	Repair	Keplace	Adjust	Keplace	Adjust	Kepair	Clean	ß	sm
$\Delta : \mathbf{F}$	ossible causes due to length of use (used for a lo	ong period)		\cup	R	R			2	4 -	< r	¥		× (\cup	-	
	ems confirm the cause	01															

TESTING AND ADJUSTING

S-7	Exhaust gas is black (incomplete														
	General causes why exhaust gas is black							С	aus	ses					
	 Insufficient intake of air Improper condition of fuel injection Excessive injection of fuel 			Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder	Clogged, seized injection nozzle	Improper injection timing	Defective injection pump (excessive injection)	Improper valve clearance	Crushed, clogged muffler	Leakage of air between turbocharger and cylinder head	Defective contact of valve, valve seat	Defective injection pump (rack, plunger seized)	Defective APS nozzle
	Confirm recent repair history														
	Degree of use	Operated for long per	riod		Δ	Δ	Δ						Δ		
su	Color of exhaust gas	Suddenly became bla Gradually became bl	ack	O	0		0					0		0	-
Questions		Blue under light load				0									
nes	Engine oil must be added more frequently Power was lost	Suddenly		0		0								_	-
$ \circ$	rower was lost	Gradually		0	0	0	0				0	0	0	0	-
	Non-specified fuel has been used	Graddanly					0						0	0	
/	Noise of interference is heard from around tur	bocharger		0											1
	Dust indicator is red	-			0										
\boldsymbol{V}	Blow-by gas is excessive					0									
	Engine pick-up is poor and combustion is irre	egular		0			0			0	0	0		0	
Sm	When exhaust manifold is touched immediatl temperature of some cylinder is low	y after starting engine.	,				0							0	
k ite	Match marks on fuel injection pump are out of	of alignment					-	0							\neg
Check items	Seal on injection pump has come off	6						-	0						-
Ð	Clanging sound is heard from around cylinder	head								0					
	Exhaust noise is abnormal			0			0				0				0
1	Muffler is crushed Leakage of air between turbocharger and hea	d loose clamp					_				0	0			-
	When turbocharger is rotated by hand, it is for	ound to be heavy		•	<u> </u>		+			-		9			\neg
1	When air cleaner is inspected directly, it is for			-	•										\neg
50	When compression pressure is measured, it i	s found to be low													
tin	Some cylinders does not change engine spe	ed when operating of	n reduced				•							Ī	
100	cylinder When check is made using delivery method, i	niection timing is four	nd to be				-								-
est	incorrect	njeedon diffing is four						•							
ldu	Injection pump test shows that injection amo	ount is incorrect					-								\neg
Troubleshooting	When valve clearance is checked directly, it		e standard							•					
	value										_				
	When muffler is removed, exhaust gas color to When control rack is pushed, it is found to b	eturns to normal	turp				_				•				-
	<u>^</u>	c neavy of does not re	uIII	¢۵.		0	0			-	0		0	•	
Legend		k itoms)	Remedy	Replace	n	Replace	Replace	Adjust	ust	Adjust	Replace	air	Replace	Replace	Replace
O: P0: ⊚: Ma	ssible cause (judging from Questions and Chec ost probable causes (judging from Questions a	nd Check items)	_ control y	Sep.	Clean	Sep	Sep	<u>{dj</u>	Adjust	Adj	Sep	Repair	sep.	Sep	(ep
	ssible causes due to length of use (used for a lo			Å	\cup	Å	Ľ	4	4	4	R	ч	R	Ł	Ч

phragm

Causes

S-8 Oil consumption is excessive (or exhaust gas blue)

 \bigstar To prevent oil from leaking up or down, do not run the engine at idling for more than 20 minutes continuously. (Both low and high idling)

General causes why oil consumption is excessive

Abnormal combustion of oil

	 Abnormal combustion of off External leakage of oil Wear of lubrication system 				r liner	her hose	cooler		a	inder head, etc.		Тигьосћагоег	Ιμιυυνιμαιζωι	al surface	ke system	broken seal	post compensator dia	
				Broken piston ring	Worn piston ring, cylinder liner	Clogged, breather or breather hose	Leakage from oil filter, oil cooler	Leakage from oil piping	Leakage from oil drain plug	Leakage from oil pan, cylinder head, etc.	Broken oil cooler	Worn seal at turbine end	Worn seal at blower end	Worn, broken rear seal, seal surface	Dust sucked in from intake system	Worn valve (stem, guide), broken seal	Broken injection pump boost compensator dia	Oil level too high
	Confirm recent repair history																	
Questions	Degree of use	Operated for long pe	eriod		Δ							Δ	Δ			Δ		
šti	Oil consumption suddenly increased			0							0						0	0
nes	Engine oil must be added more frequently				0						0							
Θ,	Engine oil becomes contaminated quickly			0	0	0												
	Exhaust gas is blue under light load	A 1 11 .		0	0													
	Amount of blow-by gas	Abnormally excessiv	ve	0	0								0		\vdash	0		
Y I	A 1 ' ' 1' / '/1 '1	None				0		_	_	_			\mid		\square			
	Area around engine is dirty with oil						0	0	0	0	_				\square			
S	There is oil in engine cooling water	1 4 1 1 4 41 41									0				\vdash			
en	When exhaust pipe is removed, inside is fou											0			\vdash	0	0	
k it	Inside of turbocharger intake pipe is dirty wi	ith oil											0		\square			
ec	Oil level in clutch or TORQFLOW transmiss												\vdash	0	\square			
Check items	When oil level is checked with dipstick, it is Clamps for intake system are loose	Tound to be above H I	nark										\vdash					0
	If engine is run at low idling, oil leaks from jo	oint of turboahargar an	darhaaut		-								\vdash		0	-		
	mainfold	-																
50	Inside of joint bolt of injection pump and bo with oil		is wet														•	
ing	When compression pressure is measured, it i																	
Troubleshooting	When breather element is inspected, it is four	nd to be clogged with	dirty oil															
shc	There is external leakage of oil from engine						\bullet	\bullet	\bullet									
le	Pressure-tightness test of oil cooler shows the	ere is leakage																
qno	Excessive play of turbocharger shaft											\bullet						
Lrc	Check rear seal directly																	
	When intake manifold is removed, dust is fou																	
	When intake manifold is removed, inside is f	tound to be dirty with	011											\square	\square			
©: Mo	d ssible cause (judging from Questions and Cheo ost probable causes (judging from Questions a spible causes due to leagth of use (used for a leagth)	and Check items)	Remedy	Replace	Replace	Clean	Repair	Repair	Repair	Repair	Replace	Replace	Replace	Repair	Repair	Repair	Replace	Adjust

 Δ : Possible causes due to length of use (used for a long period)

TESTING AND ADJUSTING

Causes

S-9 Oil becomes contaminated quickly

General causes why oil becomes contaminated quickly

- Intake of exhaust gas due to internal wear •
- Clogging of lubrication passage •
- Improper combustion •
- Use of improper oil •
- Operation under excessive load .

Story Confirm recent repair history Operated for long period A A A Degree of use Operated for long period A A A Confirm recent repair history Non-specified fuel has been used O O O O O O Non-specified fuel has been used O O O O O O Amount of blow-by gas Abnormally excessive O O O O O Oil filter caution lamp stays on even when oil pressure rises O O O O O O O When oil filter is inspected, metal particles are found O <th></th> <th>. Interval between oil change is too lo</th> <th>ng</th> <th></th> <th>Worn piston ring, cylinder</th> <th>Clogged, breather, breather tube</th> <th>Clogged oil filter</th> <th>Worn valve, valve guide</th> <th>Clogged oil cooler</th> <th>Clogged turbocharger drain pipe</th> <th>Defective seal at turbocharger turbine end</th> <th>Defective safety vavle</th> <th>Exhaust gas is black</th> <th>Oil level too high</th>		. Interval between oil change is too lo	ng		Worn piston ring, cylinder	Clogged, breather, breather tube	Clogged oil filter	Worn valve, valve guide	Clogged oil cooler	Clogged turbocharger drain pipe	Defective seal at turbocharger turbine end	Defective safety vavle	Exhaust gas is black	Oil level too high
Control Chinast gas Different fight fold Image: State and the fight fold Image: State and the fight fold Black Amount of blow-by gas Abnormally excessive Image: State and the fight fold Image: State and the fight fold Image: State and the fight fold Oil filter caution lamp stays on even when oil pressure rises Image: State and the fight fold Oil filter caution lamp stays on even when oil pressure rises Image: State and the fight fold When oil filter is inspected, metal particles are found Image: State and the fight fold Image: State and the fight fold <t< td=""><td>JS</td><td>Confirm recent repair history</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>	JS	Confirm recent repair history												
Control Chinast gas Different fight fold Image: State and the fight fold Image: State and the fight fold Black Amount of blow-by gas Abnormally excessive Image: State and the fight fold Image: State and the fight fold Image: State and the fight fold Oil filter caution lamp stays on even when oil pressure rises Image: State and the fight fold Oil filter caution lamp stays on even when oil pressure rises Image: State and the fight fold When oil filter is inspected, metal particles are found Image: State and the fight fold Image: State and the fight fold <t< td=""><td>101</td><td></td><td>Operated for long pe</td><td>riod</td><td></td><td></td><td></td><td>Δ</td><td></td><td>_</td><td>Δ</td><td></td><td></td><td></td></t<>	101		Operated for long pe	riod				Δ		_	Δ			
Control Chinast gas Different fight fold Image: State and the fight fold Image: State and the fight fold Black Amount of blow-by gas Abnormally excessive Image: State and the fight fold Image: State and the fight fold Image: State and the fight fold Oil filter caution lamp stays on even when oil pressure rises Image: State and the fight fold Oil filter caution lamp stays on even when oil pressure rises Image: State and the fight fold When oil filter is inspected, metal particles are found Image: State and the fight fold Image: State and the fight fold <t< td=""><td>est</td><td></td><td></td><td></td><td>0</td><td></td><td>_</td><td></td><td></td><td></td><td></td><td></td><td></td><td>0</td></t<>	est				0		_							0
Control Chinast gas Different fight fold Image: State and the fight fold Image: State and the fight fold Black Amount of blow-by gas Abnormally excessive Image: State and the fight fold Image: State and the fight fold Image: State and the fight fold Oil filter caution lamp stays on even when oil pressure rises Image: State and the fight fold Oil filter caution lamp stays on even when oil pressure rises Image: State and the fight fold When oil filter is inspected, metal particles are found Image: State and the fight fold Image: State and the fight fold <t< td=""><td>5 n</td><td></td><td></td><td></td><td></td><td></td><td>0</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>	5 n						0							
Amount of blow-by gas Amount of blow-by gas Abnormally excessive Image: Constraint of the second secon		Color of exhaust gas			0									
State None Image: State Image: State </td <td></td> <td>0</td> <td></td>													0	
Image: Structure of the product of	1	Amount of blow-by gas		ve	0			0		0	0			
Image: Structure of the product of	ms					0							L	
Image: Structure of the product of	ite						0					0	foi	
Image: Structure of the product of	ĸ				0		0						80	
Image: Structure of the product of	he		nd to be dirty with oil					0					al	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)	U U								0				ng	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)				nark									oti	0
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)													ho	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)	ng		, it is found to be clo	gged with									bla	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)	oti		1. 1. 1. 1			-							ldu is	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)	ho									_			rol as	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)	es]		nd to be clogged							_			it g	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)	ldt									•	_		or	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)	LOI		1. 1	< 1 ·						_	•		th	
Legend O: Possible cause (judging from Questions and Check items) ©: Most probable causes (judging from Questions and Check items)	L		ing is found to be ca	atcning or									E G	
Legend \bigcirc : Possible cause (judging from Questions and Check items) \bigcirc : Most probable causes (judging from Questions and Check items) \land : Possible causes (judging from Questions and Check items) \land : Possible causes (judging from Questions and Check items)					0		0	0			0			$\left \right $
(1 - 1) = 1 = 1 = 1 = 1 = 1 = 1 = 1 = 1 = 1			le itoma)	D	ac		act	act		_	act	ace		lst
$ \vec{x} \vec{v} \vec{x} \vec{v} \vec{v} $				кетеау	lqs	ea	<u>Id</u>	lqe	ea	ea	<u>lq</u>	lqe	Π	iş
	\bigcirc . IVIO	ssible causes due to length of use (used for a lo	nu Check items)		Ř	<u></u>	Щ,	Ř	<u></u>	U	Ř	R		Ā

Causes

S-10 Fuel consumption is excessive

General causes why fuel consumption is excessive

- . Leakage of fuel
- Impoper condition of fuel injection •
- Excessive injection of fuel

	• Excessive injection of fuel										
				Defective injection pump (excessive injection)	Defective injection nozzle spray	Defective injection pump plunger	Improper fuel injection timing	External leakage from fuel piping, fuel filter	Defective oil seal inside feed pump (piston)	Defective adjustment of fuel lever linkage	Defective injection nozzle (loose retaining cap)
	Confirm recent repair history										
Questions	Degree of use	Operated for long period			Δ	Δ	-		Δ		_
sti	Condition of fool commution	More than for other machines of sam	e model	0	0		0				
ne	Condition of fuel consumption	Gradually increased			0	0		_			_
$ \circ\rangle$	Exhaust and color	Suddenly increased		0	0			0		_	_
	Exhaust gas color	Black White		0	0		0			0	_
	Seel on injection nume has some off	white									_
	Seal on injection pump has come off			0	0						_
s	There is irregular combustion When exhaust manifold is touched imm	adjately ofter starting angine tempera	tura of		0						_
me	some cylinder is low	equatery after starting engine, tempera	ture or		0	0					
ćit	Match mark on injection pump is missa	ligned					0				_
ect	There is external leakage of fuel from en							0	_		_
Check items	Engine oil level rises and smells of diese			0				-	0		0
	Engine low idling speed in high			0					-		Ť
ac	Injection pump test shows that injection	n amount is too high									-
Troubleshooting	Some cylinder does not change engine s		der								\neg
00	When control rack is pushed, it is found										
sh	When check is made using delivery met		correct								
ble	Remove nozzle holder and inspect dire										
no	Remove feed pump and inspect directly										
T_{r}	When engine speed is measured, low id	ling speed is found to be high									
Legend				t.	Se	g	t.			ţ	
	ssible cause (judging from Questions and		Remedy	Adjust	Replace	Replace	Adjust	Repair	Repair	Adjust	Repair
	ost probable causes (judging from Questi			<u>Ad</u>	Set	Set	∱d,	Set	Set	∱d,	l 🥵
Δ : Po	ssible causes due to length of use (used f	for a long period)		4	ł	1	4	Ч	Ľ	ł	<u> </u>

TESTING AND ADJUSTING

Causes

pitting

(pag

S-11 Oil is in cooling water, or water spurts back, or water level goes down

General causes	why oil	is in	cooling water
----------------	---------	-------	---------------

- Internal leakage in lubrication system .
- Internal leakage in cooling system .

	Confirm roomt romain history			Broken oil cooler core, O-ring	Broken cylinder head, cylinder head gasket	Insufficient protrusion of cylinder liner	Broken oil cooler for power train	Brocken cylinder liner O-ring holes caused by I	Internal cracks in cylinder block	Broken seal on water pump (breather hole clogg
Questions	Confirm recent repair history Degree of use	Operated for long period						Δ	_	
stic	Increase in oil level	Suddenly increased		$\overline{0}$	0		0			
nes		Gradually increased		Ĕ				0	0	_
$ \bar{O}/$	Hard water is being used as cooling wat			0				0	-	-
	Engine oil level risen, oil is cloudy, whit	te		0				0	0	0
×.	Excessive air bubbles inside radiator, w	vater spurts back			0	0				
ms	Hydraulic oil, torque converter, transmi	ission oil is cloudy white					0			
Check items	When hydraulic oil, torque converter, tr		es out				0			
	Pressure-tightness test of oil cooler sho									
3 G	Pressure-tightness test of cylinder head									
1 bl	Remove cylinder head and inspect direct	ctly								
Trouble shooting	Remove oil pan and inspect directly									
T ₁	Inspect water pump									
©: M	d ssible cause (judging from Questions and ost probable causes (judging from Quest ssible causes due to length of use (used i	tions and Check items)	Remedy	Replace	Replace	Replace	Replace	Replace	Replace	Replace

Causes

pan

S-12 Oil pressure lamp lights up (drop in oil pres-

sure)

General causes why oil pressure lamp lights up

- Leakage, clogged, wear of lubricating system
- Defective oil pressure control •
- Use of improper oil (improper viscosity) •
- Deterioration of oil due to overheating .

	★ Standar	ds for e	engin	e oil se	lection						_	e oil J	Broken suction pipe brazing portio					ping				
	KIND OF		AN	IBIEN	ТТЕМРЕ	RATURE	C				Clogged strainer inside oil pan	Clogged, broken oil pipe inside	ing]		Insufficient oil level in oil pan	0		Leakage, crushed hydraulic piping		sensor		
	FLUID	1	4	32	50	68	86 °F	1			e oi	ipe	oraz		i oi	alve		raul	sor	Sei		
		-1	10	0	10	20	30° C			nal	nsid	il pi	pe t	e.	'el ii	Defective regualator valve	lve	hydi	Defective oil level sensor	Defective oil pressure		
					SAF	E 30	I	-	ter	Worn bearing journal	ler i	en c	id u	Defective oil pump	1 lev	ıalat	Defective relief valve	hed	eve	pres	oil	Clogged oil cooler
	Enigne oil	SEA	10W	,					Clogged oil filter	ing	trair	prok	Ictio	<u>[]</u>	nt oi	regu	relie	crus	oil l	oil	Water, fuel in oil	il co
			1 10 11						ed o	oear	ed s	ed, l	n su	live	iciei	ive	live	ge, c	tive	ive	fue	o pe
		I							0860	orn l	089	089	oke	fect	glins	fect	fect	aka	fect	fect	ater,	0990
									Ū	Ň	Ũ	Ũ	Br	ă	In	ă	ă	Ľ	ă	ă	ž	Ū
	Confirm recent rep	pair histo	ory		0 10									_	_		_			$ \rightarrow$		
Questions	Degree of use	. 1	. 1		Operated f			1	Δ	Δ				Δ	_					$ \rightarrow$		_
ŝti	Replacement of fil		not be	een carr	ied out acco	ording to o	peration i	manual	0					_	_		_	_				_
ne	Caution lamp light Non-specified fuel		n 1100	d					0		_		_	-	-	_	0	_		\rightarrow		_
Ο,	Non-specified fuel	lias bee	II use	u i	Lights up a	t low idlir	20		0	0	_		-	_	-	_		_	_	\rightarrow		_
/	Condition when oi	1 process	ro	ŀ	Lights up a				-	0	0	0	0	0	0		0	-		\rightarrow		
	lamp lights up	i pressu	ic.		Lights-up		Tuning		-				•		0		-	_		—		0
/	lump ingins up				Sometimes								_	-	-	0	0	-	0	0		-
/ മ	Crushed piping, lea	akage fro	om hv											+	-			0	\neg	\rightarrow		-
en	Oil level sensor la	mp light	s up	araano	piping (ent	(11111)								-	0				0			
Check items	When oil level in c			ked. it i	s found to b	e low								-	0							
ec	Metal particles are									0				+	-					-		
5	Metal particles are									0				0						-		
	Oil is cloudy white	e or smel	lls of	diesel o	il																0	
1g	When oil filter is in	nspected	l direc	ctly, it is	found to b	e clogged															8 ng	
ti.	Remove oil pan an																				I roubleshooting il level rises"	
ğ	Oil pump rotation																				rise	
est	There is catching o							is broken												:	ldu	
Troubleshooting	When oil level sen																			F	Carry Troubleshoot for "Oil level rises"	
no	When oil pressure	is measu	ured,	it is fou	nd to be wi	thin standa	ard value													\bullet	È,	
Ţ	Check oil cooler																			(for Ca	
Legen	ıd													ရှ		-	ا ب		e l	e		e
	ossible cause (judgii	ng from	Ques	tions an	d Check ite	ms)		Remedy	l l	gu	n l	gu	air	ы Ца	_	sn	sn	air	lac	lac		lac
	lost probable causes						5)		Clean	Clean	Clean	Clean	Repair	Keplace	Add	Adjust	Adjust	Repair	Replace	Replace	н	Replace
Δ : Po	ossible causes due te	o length	of us	e (used	for a long p	eriod)	l		$\overline{\mathbf{U}}$					Ύ ·	4	<	<.	14		R		К

L

e by pitting

Causes

S-13 Oil level rises

★ If there is oil in the cooling water, carry out troubleshooting for "Oil is in cooling water"

General causes why oil level rises

	 General causes why oil level rises Water in oil (cloudy white) Fuel in oil (diluted, and smother common structure) Entry of oil from other common structure 			Broken oil cooler core, O-ring	Defective nozzle holder sleeve	Broken cylinder head, head gasket (including	precomputation champer) Clogged water pump breather hole, defective seal	Worn, damaged rear seal surface	Defective seal of pump or auxiliary equipment	Leakage of fuel from zozzle holder retaining cap	Defective inside injection pump	Defective thermostat seat	Damaged cylinder liner O-ring, holes made by pitt	Cracks inside cylinder block	Broken after-cooler core
su	Confirm recent repair history														
Questions	Degree of use	Operated for long period			Δ		Δ	Δ	Δ				Δ		
es	There is oil in radistor cooling water			0	0	0							0	0	
1 7/	Exhaust gas is white				0					0		0			
17	When engine is first started, drops of w				0										0
V	Leave radiator cap open. when engine i					0							0		
	number of bubbles appear, or water sp														
l m	Water pump breather hole is clogged w						0								
ite	When water pump breather hole is clea	ned, water comes out					0								
X	Oil level does down in TORQFLOW th	ansmission, or damper case						0							
Check items	Oil level does down in hydraulic tank	· •							0						
D D	Engine oil smells of diesel fuel									0	0	0		-	
	Fuel is added more frequently									0	0	0			
	Pressure-tightness test of oil cooler sho	ws there is leakage												-	
	Pressure-tightness test of cylinder head			-											
0.0	When compression pressure is measure				-									-	
tin	Remove water pump and inspect direc													-	
8	Inspect rear seal directly	5					—							-	\neg
sh	When pump auxiliary equipment is ren	noved, seal is found to be broke	n						•					-	
le	Remove nozzle holder and inspect dire								-					-	-
Troubleshooting	Remove injection pump and inspect di							1					\rightarrow	+	\neg
Γī	There is improper contact of thermosta										-			-	
L .	Remove oil pan and inspect directly												•	•	
	Pressure-tightness test of after-cooler c	ore shows there is leakage						1					-	-	
	, e				0		-	+	0			\vdash			_
Leger				JCe	3Ce	ace	Ce	l.1	ace	н.	sce	.ы	S	ace	gc
	ossible cause (judging from Questions ar		Remedy	Replace	Replace	Replace	Replace	Repair	Replace	Repair	Replace	Repair	Replace	Replace	Replace
	lost probable causes (judging from Ques			Re	Re	Re	Re	Re	Re	Re	Re	Re	Re	Re	Re
$\Lambda : \mathbf{P}$	ossible causes due to length of use (used	for a long period)		<u> </u>	Ľ	P 1	1	1, 1	Ľ, ,	Ľ	- · ·	<u> </u>			<u> </u>

 Δ : Possible causes due to length of use (used for a long period)

S-14 Water temperature becomes too high (overheating)

General causes why water temperature becomes too high

- . Lack of cooling wind (deformation, damage of fan)
- Drop in heat dissipation efficiency •
- Defective cooling circulation system Rise in oil temperature of power train •

	 Rise in oil temperature of powe ★ Carry out trubleshooting for Confirm recent repair history 			Broken water pump	Clogged, crushed radiator fin	Clogged radiator core, leakage	Defective thermostat (does not open)	Defective water temperature gauge	Insufficient cooling water	Fan belt slipping, worn fan pulley	Clogged, broken oil cooler	Defective pressure valve	Broken cylinder head, head gasket	Damaged cylinder liner O-ring, holes made b	Rise in torque converter oil temperature	Crack in cylinder block	Defective fan pump motor (BD457A-1)
	Degree of use	Operated for long period			Δ	Δ				_			Δ	Δ			
Questions	Condition of overheating	Suddenly overhated		0					0	0							
tic		Always tends to overheat			0	0	0			0							\odot
nes	Water temperature gauge	Rises quickly					0	-	0								
Ō		Does not go down from red rat	nge					0	-						\square		
	Radiator water level sensor lights up								0	_							
	Fan belt whines under sudden load Cloudy white oil is floating on cooling									0					\vdash	\vdash	
	Cooling water flows out from overflow			<u> </u>							0	_			\vdash	\vdash	
	Excessive air bubbles inside radiator, w			-						_		0	0		\vdash	\vdash	
/	Engine oil level has risen, oil is cloudy										0			0	\vdash	0	for chassis
ms	Radiator shroud, inside of underguard a	wille			0					_	0			0	\vdash	\mathbb{H}	has
ite	When light bulb is held behind radiator.	re light passes through			0					0					\vdash	\vdash	L L
ck.	Water is leaking because of cracks in ho			-	0				0						\vdash	\vdash	fo
Check items	Belt tension is found to be slack	se of foose clamps		-					•	0					\vdash	\vdash	out troubleshooting
D	Power train oil temperature enters red r	anga hafara angina watar tamp	aratura	-						0					0	\vdash	l of
	Temperature difference between top an	d bottom radiator tanks is exce	sive							_					-	\vdash	esh
	Temperature difference between top an				•					_					issi	\vdash	lbl
	When radiator is inspected through wat				-										chassis	\vdash	Ĩ
-	clogged	ter filler port, the core is found	10 00			\bullet									for		Ħ
ng	When a function test is carried out on t	he thermostat it does not open	at the												50		5
oti	cracking temperature	ne mermostat, n does not open	at the												otir		Carry
Troubleshooting	When water temperature is measured, i	t is found to be normal						•		_					troubleshooting	\square	
les	When oil cooler is inspected directly, it							-		_	•				les		
qn	When measurement is made with radia		und to be								-				out		
LO LO	low	· · · · · · · · · · · · · · · · · · ·													tt		
	When compression pressure is measure	ed, it is found to be low													out		
	Remove oil pan and inspect directly														Carry		
	Pressure-tightness test of cylinder head	shows there is leakage													Ca		
Legen	d			မ			e	ė			e	e	e	e		e	
	ssible cause (judging from Questions an	d Check items)	Remedy	lac	air	air	lac	lac		air	lac	lac	lac	lac		lac	
	ost probable causes (judging from Ques		litencuy	Replace	Repair	Repair	Replace	Replace	Add	Repair	Replace	Replace	Replace	Replace		Replace	
	ossible causes due to length of use (used			ЫК	R	R	R	R	\triangleleft	Я	R	Ч	R	R		Ч	

•: Items confirm the cause

bitting

Causes

cylinder head of position)

Causes

, etc.)

seized) ction)

S-15 Abnormal noise is made

★ Judge if the noise is an internal noise or an external noise

General causes why abnormal noise is made

- Abnormal due to defective parts
- Abnormal combustion noise

	 Abnormal combustion noise Air sucked in from intake system 			Worn piston ring, cylinder liner	Seized turbocharger, interference	Missing, seized bushing	Clogged, seized injection nozzle	Defective injection pump (rack, plunger se	Defective injection pump (excessive inject	Deformed fan, interference of fan belt	Improper adjustment of valve clearance	Broken valve system (valve, rocker lever,	Improper gear train backlash	Leakage of air between turbocharger and c	Defect inside muffler (dividing board out	Leakage from air compressor piping	Seized crankshaft, bearing
	Confirm recent repair history	1													\square		
	Degree of use	Operated for long p	eriod	Δ													
ns	Condition of abnormal noise	Gradually occurred		0						0							
tio		Suddenly occurred			0	0						0					
Questions	Non-specified fuel has been used						0	0									_
Ιð	Engine oil must be added more frequently			0													
—	Color of exhaust gas	Blue under light load	1	0													
	Black				\odot						0			0			
	Metal particales are found in oil filter			0		0											0
	Blow-by gas is excessive			0	-										\rightarrow	$ \rightarrow$	
	Noise of interference is heard from around turbocharger				0		_										_
/	Engine pickup is poor and combustion is irregular						0								$ \rightarrow $	_	_
l SI	When exhaust manifold is touched immediately a	after starting engine,					0	0									
te	temperature of some cylinder is low			<u> </u>											\rightarrow		_
Check items	Seal on injection pump has come off						_	_	0				_			_	_
Jec	Abnormal noise is loud when accelerating engine			<u> </u>			0	0	0	0	0	_	0			0	_
D	Clanging sound is heard from around cylinder hea			<u> </u>							0	0		_			_
	Leakage of air between turbocharger and cylinder	rhead		┣─										0			_
<u> </u>	Vibrating noise is heard from around muffler	····													0		_
	When compression pressure is measured, it is fo When turbocharger is rotated by hand, it is found															_	_
					•	•	_									_	_
	Remove gear cover and inspect directly, (flywheel housing top cover) Some cylinder does not change engine speed when operating on reduced					-							•		\rightarrow	-+	_
50	cylinders	in operating on reduce	u				ullet										
ti.	When control rack is pushed, it is found to be he	eavy or does not retur	n										_	_	\rightarrow	-	-
l õ	Injection pump test shows that injection amount								•						\rightarrow	-	-
Troubleshooting	Fan is deformed, or belt is loose								-	•						-	
ld.	When valve clearance is checked directly, it is found to be outside standard									-							
no.	value																
Ē	Remove cylinder head cover and inspect directly When muffler is removed, abnormal noise disappears											•					-
												-					
	Check for leakage from air compressor piping																
	Remove oil pan and inspect																
Legend					e	0	e)	e				e			e	0	a
O: Possible cause (judging from Questions and Check items) Remedy				Replace	Replace	Replace	Replace	Replace	Adjust	air	Adjust	Replace	١Ħ	Repair	Replace	Replace	Replace
©: Most probable causes (judging from Questions and Check items)					ep	ep	ep	epi	[i]	Repair	id;	ep	Repair	epi	ep	eb	eb
Δ : Possible causes due to length of use (used for a long period)					R	R	R	R	A	R	\triangleleft	R	R	R	2	2	Я

S-16 Vibration is excessive

	\star If there is abnormal noise together with the vibration, carry out					Causes								
troubleshooting for "Abnormal noise is made"												ed)		
												seiz		
General causes why vibration is excessive												ger		
	 Defective parts (abnormal wear, breakag Improper alignment Abnormal combustion 	ge)		Worn, seized connecting rod, main bearing	Worn cam bushing	Worn support pilot	Loose engine mounting bolts, broken cushion	Broken part inside output shaft (damper)	Misalignment between engine and power train	Improper gear train backlash	Valve system (valve, rocker lever, etc.) stuck	Defective injection pump (excessive injection, plunger seized)	Defective vibration damper	Clogged injection nozzle
	Confirm recent repair history			>	>	>		E	4	<u> </u>	~			4
Questions	Degree of use	Operated for long pe	eriod	Δ	Δ	Δ	Δ							
tio	Condition of vibration	Suddenly increased						0			0		0	
es		Gradually increased		0	0	0	0							0
Ιð	Non-specified fuel has been used				0									
- /	Metal particales are found in oil filter				0									
	Metal particales are found when oil is drained				0									
l/st	Dil pressure is low at low idling				0									
te	Vibration occurs at mid-range speed						0	0						
ι.Υ	Vibration follows engine speed					0	0	0	0	0			0	
Oil pressure is low at low idling Vibration occurs at mid-range speed Vibration follows engine speed Exhaust gas is black Osel on injection pump has come off											0	0		0
• Bear on injection pump has come on												\odot		
	Remove oil pan and inspect directly													
0.0	Remove side cover and inspect directly													
E	Check directly for worn support pilot, play													
00	Inspect directly for loose engine mounting bolts, broken cushion													
she	Check inside of output shaft (damper) directly													
le	When radial runout, face runout are measured, they are found to be outside								•					
l du	standard								_					_
Troubleshooting	Remove front cover, and inspect directly.													
	Remove head cover and inspect directly													
	Injection pump test shows that injection amount	is incorrect										•		
Legend						e	g	ce	5	2	ce	<u>,</u>	e	e
O: Possible cause (judging from Questions and Check items) Remedy						ola	ola	ola	Dai	Dai	ola	juŝ	ola	pla
◎: Most probable causes (judging from Questions and Check items)					Replace	Replace	Replace	Replace	Repair	Repair	Replace	Adjust	Replace	Replace
Δ : Possible causes due to length of use (used for a long period)				Replace	H	H	H	ł	ł	I	ł	7	ł	<u>-</u>

•: Items confirm the cause

ENGINE 14 DISASSEMBLY AND ASSEMBLY



DISASSEMBLY	14-002
Washing	14-019
Washing cylinder block	14-019
Washing crankshaft	14-020
Measuring parts	14-021
ASSEMBLY	14-027

- ★ The explanation for disassembly and assembly of the engine given in this section describes the procedure for the BSA6D170-1 engine when using the repair stand.
- * If a different engine or engine repair stand is used, or if the engine is not equipped with an aftercooler, the procedure may be different in places, but the operation is basically the same.

DISASSEMBLY


Special tools


No.	Part No.	Part Name	Qty
А	790-501-2000	Engine repair stand	1
A1	790-901-1170	 Repair stand bracket 	1
В	790-476-1140	Lifting tool	1
С	795-601-1110	push tool	1
D	795-102-2102	Spring pusher	1
Е	795-100-1181	Timer remover	1
F	795-100-1191	Piston ring tool	1
G	795-102-1300	Liner puller	1

• Preparatory work

1. Washing

- Before disassembling the engine, check all parts for any cracks of damage, then clean the whole engine carefully with steam so that the disassembly work can be carried out swiftly.
 - 1) Before washing, remove starting motor assembly (1), alternator assembly (2), and electric wiring.
 - 2) Cover all the openings of the engine with tape.
 - 3) Using a washing machine, clean engine.






2. Setting engine stand

• Prepare a stable engine stand that will prevent the engine from falling over, then set the engine assembly on the stand and secure it in position.

3. Engine oil

Drain engine oil



GENERAL DISASSEMBLY

1. Water pump assembly

- 1) Remove water tube (1).
- 2) Remove plate, then remove water tube (2).
- 3) Remove water pump assembly (3).
- ★ After removing the water pump, remove the drive shaft.

2. Turbocharger drain tube


Disconnect drain tube (1).


3. Oil cooler


- 1) Remove water tube (1).
- 2) Remove oil cooler (2).


4. Placing engine on the stand

- Install bracket A1 for the engine repair stand A using the threads for the oil cooler.
- 2) Raise engine assembly (1) and set it to the engine repair stand **A**.
 - ★ Tighten the bolts on the engine repair stand securely.










GENERAL DISASSEMBLY

5. Air cleaner

Remove air cleaner (1).



6. Intake connector Remove bracket (1) and intake connector (2).

7. Connector pipe

- 1) Remove boost compensator tube (1).
- Remove plate, then remove connector pipe (2).

8. Fuel filter


- 1) Disconnect fuel hose for APS.
- 2) Disconnect fuel hoses and remove fuel filter.


9. After-cooler tube, lubrication tube

- 1) Disconnect after-cooler tube.
- 2) Disconnect turbocharger lubrication tube.

10. Fuel injection tube

Remove lamp, and disconnect fuel injection tube (1).





11. Oil filter


Remove oil filter (1), then remove bracket.


12. Oil filler, oil level gauge


- 1) Remove oil filler (2).
- 2) Remove oil level gauge (3).

10. Tension spring, tension pulley

- Loosen locknut (1), loosen bolt (2) to allow spring to expand, then remove tension spring (3).
- ⚠
- Be careful not to get your fingers caught in the bracket.
- 2) Remove tension pulley assembly (4) and bracket as one unit.
 - Disassemble tension pulley assembly.
 - i) Remove snap ring (5), then remove cover (6).
 - ii) Remove lock plate (7), then remove holder (8).
 - iii) Remove pulley assembly (9) from shaft.
 - iv) Remove bearing (10), then remove snap ring (11), and take out spacer (12) and bearing (13).
 - v) Remove oil seal (15) from pulley (14).
 - vi) Remove plate (16), then remove seal (17), bearing (18), inner race (19), and seal (20).








GENERAL DISASSEMBLY

14. Corrosion resistor


Using filter wrench, remove corrosion resistors (1).




15. Thermostat housing

Remove thermostat housing (1).

• Disassembly thermostat housing.



- i) Remove outlet pipe (2) and cover (3).
- ii) Remvoe thermostat (4).
- iii) Remove thermostat seal (5) from housing (6).




16. Turbocharger, exhaust manifold assembly


- 1) Sling turbocharger and exhaustmanifold assembly (1), remove mounting bolts.
- 2) Remove turbocharger and exhaust manifold.


17. Aftercooler, intake manifold assembly

- 1) Sling aftercooler and intake manifold assembly (1), remove mounting bolts.
- 2) Remove aftercooler and intake manifold assembly.

- Disassembly aftercooler and intake manifold.
 - i) Remove joint (2) and connector (3).
 - ii) Remove cover (4).
 - iii) Remove core assembly (5) from intake maniflod (6).










GENERAL DISASSEMBLY


18. Fuel injection pump assembly

- 1) Remove lubrication tube between injection pump and cylinder block.
- 2) Screw lifting tool **B** into delivery valve thread, and sling assembly.
- 3) Pull out fuel injection pump assembly (1) to rear and remove.




Fuel injection pump assembly. BSA6D170 : 48 Kg BS6D170 : 30 Kg





19. Spill tube, head cover


- 1) Disconnect spill tube (1).
- 2) Disconnect turbocharger lubrication tube (2).
- 3) Disconnect connection (3) and remove head cover (4).
 - ★ Screw forcing screws (Thread dia. = 14 mm, Pitch = 1.5 mm) into the places marked, and remvoe the head cover.
 - ★ After removing the head cover, remove the nozzle seal from the head cover.




20. Rocker arm

Remove rocker arm (1).

★ To prevent pressure on the push rod when installing, loosen the locknut and turn the adjustment screw (2) back 2 to 3 turns before removing the rocker arm assembly.



- Disassembly rocker arm assembly.
 - i) Remove locknut (1), then remove adjustment screw (2) from reocker arm (3).
 - ii) Using push tool, remove bushing (4).




21. Crosshead

1) Remove crosshead (1).


22. Push rod

Remove push rod (2).




23. Injection nozzle holder

Remove mounting bolts (1), then remove injection nozzle holder assembly (2).



24. Rocker arm housing

1) Remove snap ring (1), then using push tool **C**, remove water manifold (2).



${\bf DISASSEMBLY} {\bf AND} {\bf ASSEMBLY}$

GENERAL DISASSEMBLY


2) Remove rocker arm housing (3)

25. Cylinder head assembly


Using eyebolt \bigcirc Dia. = 12 mm, Pitch = 1.75 mm), remove cylinder head assembly (2).




Cylinder head: 40 kg



- Disassembly the cylinder head
- i) Using spring pusher **D**, compress spring then remove valve cotter (3).
- ii) Remove retainer (4).
- iii) Remove outer spring (5), inner spring and valve lower seat.
- iv) Remove exhaust valves (6) and intake valves (7).






26. Crankshaft pulley


- 1) Remove mechanical pump tubes (1).
- 2) Remove crankshaft pulley (2).
 - ★ If an impact wrench is used to loosen thebolts, there is danger of damage to the thread, so loosen the bolts with a hand tool.





27. Vibration dampre

- 1) Remove spacer (3).
- 2) Sling vibration damper (4), then screw in forcing screw 1 and remove vibration damper (4).
 - ★ While tightening the forcing screw, take care not to drop the vibration damper.




28. Front support

Lift out front support (1).



29. Cover

Remove cover (2).



30. Trunnion

Tighten the forcing screw to remove trunnion (1).

 \star When replacing the front seal, remove oil seal.

31. Timer

Using tool \mathbf{E} , remove timer (3).


 ★ Timer (3) is press fitted with a taper, so hit the end face of reamer bar E with a hammer to remove it.


32. Accessory drive pulley

- 1) Remove accessory drive pulley (4).
- 2) Remove pulley (5) for alternator drive.

33. Mechanical pump assembly

Remove mechanical pump assembly.






GENERAL DISASSEMBLY

34. Injection pump drive case


Remove coupling (1), then remove injection pump drive case (2).

GENERAL DISASSEMBLY



35. Cam follower

- 1) Remove cover (1).
- 2) Remove cam follower (2).




36. Gear case cover

Remove gear case cover (1).



Gear case cover : 48 kg




37. Camshaft assembly

Remove mounting bolt from hole in cam gear, then pull out camshaft assembly (1).

 When removing the camshaft, rotate it while pulling it out to prevent damage to the cam bushing.



Camshaft assembly : 32 kg



38. Main idler gear

Remove mounting bolt (1), then remove main idler gear (2).

39. Idler gear for water pump gear

Remove mounting blot (3), then remove idler gear (4) for water pump.

40. Idler gear for oil pump gear


Remove mounting bolt (5), then remove idler gear (6) for oil pump

41. Flywheel


Using the sling bolts (thread dia. = 12 mm, pitch = 1.5), lift out flywheel (1).

kg

Flywheel : See Weight Table



GENERAL DISASSEMBLY





 ★ If an impact wrench is used to loosen the bolts, there is danger of damage to the thread, so loosen the bolts with a hand tool.



42. PTO drive gear


- 1) Remove steering pump drive gear (1).
- 2) Remove the six set bolts, and remove PTO drive gear (2).






BS(A)6D170-1

- Disassemble PTO driving gear as follows:
 - i) Remove bearing retainer (3) and shim(4).




ii) Remove drive gear (5) and bearing (6).iii) Remove bearing (7) from shaft (8).






Remove rear seal cover (1).



44. Oil pan

- 1) Turn over repair stand to set oil pan at top.
- 2) Remove oil pan (1).



45. Oil strainer

47. Gear case

kg


Remove bracket, then remove oil strainer (1).

46. Oil pump assembly

1) Remove tube (2).

Remove gear case (1).

2) Remove oil pump assembly (3).




48. Flywheel housing

Lift out flywheel housing assembly (1).

Gear case : 30 kg

-	-	-
	40	1
	ĸg	


Flywheel housing: 95 kg



49. Piston cooling nozzle

Remove piston cooling nozzle (1).

★ To avoid hitting the piston, rotate 90° to remove.




GENERAL DISASSEMBLY

GENERAL DISASSEMBLY


50. Piston and connecting rod assembly

- 1) Using dial gauge ① measure connecting rod side clearance to act as a guide when assembling.
 - Check the stamped number on the connecting rod cap.
 - i) The cap number and cylinder number must match.
 - ii) The number is stamped on the cam side.
 - ★ If there is no stamped mark, mark the cylinder No. with an electric pen before removing. Do not stamp a mark.
- 2) Rotate the crankshaft so that the piston to be removed is at bottom dead center.
- 3) Loosen connecting rod bolt 5 6 turns.
 - ★ If an impact wrench is used to loosen the bolts, there is danger of damage to the thread, so loosen the bolts with a hand tool.





- 4) Tap head of connecting rod bolt with a plastic hammer, then disassemble connecting rod cap and connecting rod.
- 5) Remove carbon from top wall of liner with fine sandpaper.
- 6) Rotate crankshaft, and align with top dead center, then remove connecting rod cap (2).
- 7) Push in piston and connecting rod from oil pan end.





GENERAL DISASSEMBLY


- 8) Support piston at cylinder head end, and remove piston and connecting rod assembly.
 - ★ Be careful not to damage the inside surface of the liner with the corner of the connecting rod when removing it.
- 9) Remove other piston and connecting rods in the same way.
 - ★ Keep in a safe place and be careful not to damage the piston sliding surface and the bearing.
 - ★ Assemble the connecting rod and cap temporarily and keep together with the bearing to prevent mistakes when reassembling.
 - Disassemble the piston and connecting rod assembly.
 - i) Remove snap ring (4).
 - ii) Support connecting rod (5) with hand, then pull out piston pin (6), and disassemble piston (7) and connecting rod.
 - ★ If the piston pin is stiff and cannot be removed, heat it in hot water (100°C [212°F], 5 min.) before removing it.
 - iii) Remove snap ring on the opposite side.
 - iv) Using piston ring tool **F**, remove piston ring (8).
 - v) Remove oil ring expander (9).
 - ★ Keep the piston, connecting rod, connecting rod bearing, piston ring, and piston pin is sets for each cylinder.


51. Crankshaft

- 1) Before removing the crankshaft, using dial gauge 1) to measure end play of crankshaft, and use it as a guide when assembling.
- 2) Measure starting torque of crankshaft and use as a guide when assembling.











GENERAL DISASSEMBLY

- 3) Remove mounting bolts(2) of main cap(1).
- 4) Insert bolt in hole of main cap, and move the main cap from side to side to remove it.
 - ★ Thrust bearing is installed to the No. 6 cap, so after removing it, mark the assembly position.






kg Crankshaft assembly : 260 kg

5) Using nylon sling, lift off crankshaft (3).


6) Remove upper main bearing.

52. Cylinder liner

★ Before removing cylinder liner, using dial indicator (2) to measure protrusion of cylinder liner.




Using liner puller \mathbf{G} , pull out cylinder liner (1).



WASHING

- When washing, divide the parts into small parts and large parts, and wash the small parts in a bath like the one shown on the right.
 - ★ Before washing disassembled parts, remove the gasket carbon with a wire brush.
 - After washing, dry the washing fluid off completely with compressed air. (Be particularly careful that there is no washing fluid remaining in the bolt holes.)




WASHING CYLINDER BLOCK

- 1) Before washing the cylinder block, remove the plugs from the oil line and cooling systems.
- 2) Use a washing machine such as shown on the right, and use the nozzle of a jet cleaner to wash the oil line and cooling systems thoroughly.
- 3) Clean with a stiff wire brush to prevent any metal particles from remaining in the oil line.
- 4) Use sandpaper to polish the O-ring contact surface smooth at the bottom of the liner bore and to remove the burrs and flashes from the liner bore.
- 5) Dry off the cleaning fluid completely with compressed air.
 - Be particularily careful not to leave any cleaning fluid in the bolt holes.
- 6) Completely press fit the plugs in the oil line and cooling systems.




Outside diameter of plug : Thread tightener (LT-2)




${\bf DISASSEMBLY} {\bf AND} {\bf ASSEMBLY}$

WASHING CRANKSHAFT

- If the engine is disassembled, wash the crankshaft before inspecting.
- 1) Clean the crankshaft with a steam cleaner, then use a wire brush like the one shown in the diagram on the right to clean all the oil holes.
- 2) After washing, dry the cleaning fluid off thorougly with compressed air.
- 3) Use a small magnet to completely remove all the metal particles from the oil holes.





MEASURING PARTS


- Before reassembling disassembled parts, check visually that there are no cracks, damage, or abnormal wear.
- If no abnormalities are found during the visual inspection, use an accurate measuring device to measure the specified position precisely.
- Action and judgement on whether the parts can be reused shall be in accordance with the maintenace standard.


MEASURING CURVATURE OF CRANKSHFT


- 1) Spport the center of both ends of the crankshaft with lathes, put the indicator of the dial gauge perpendicularly in contact with the journal at the center, and set it to 0.
- 2) Rotate the crankshaft one turn, and measure the difference between the maximum reading and minimum reading of the dial gauge.
 - ★ Do not measure with both ends of thecrankshaft supported on V blocks. This method produces an error because of the eccentric wear of the journal.

MEASURING OUTSIDE DIAMETER OF JOURNAL

1) Using a micrometer, measure the outside diameter of the main journal and pin journal in the X and Y directions.








GENERAL DISASSEMBLY


MEASURING DEPTH OF CYLINDER LINER COUNTERBORE


- 1) Set deapth gauge 2 on gauge block 1, then set the gauge indicator to 0.
- 2) Set the gauge block parallel with the top surface of the cylinder block, and measure the depth of the counterbore.
 - ★ Clean the counterbore and top surface of the cylinder block before measuring.

MEASURING MAIN BEARING BORE

- 1) Install the main bearing cap to the cylinder block, and tighten to the specified torque.
- 2) Using a dial bore gauge or inside micrometer, measure the main bearing bore.
 - ★ When measuring the bore, measure in two directions (X and Y).









MEASURING CURVATURE OF CAMSHAFT

- 1) Support the center of both ends of the camshaft with lathes, put the indicator of the dial gauge perpendicularly in contact with the journal at the center and set it to 0.
- 2) Rotate the camshaft one turn, and measure the difference between the maximum reading and minimum reading of the dial gauge.
 - ★ Do not measure with both ends of the camshaft supported on V blocks. This method produces an error because of the eccentric wear of the journal.




MEASURING OUTSIDE DIAMETER OF JOURNAL

1) Using a micrometer, measure the outside diameter of the journal.



MEASURING HEIGHT OF CAM

1) Using a micrometer, measure cam height **H** for the intake and exhaust.



GENERAL DISASSEMBLY

MEASURING PISTON RING GROOVE

Special tool


No.	Part No.	Part Name	Qty
А	795-901-1120	Wear gauge	1


• Measuring keystone ring groove

- 1) Push piston ring wear gauge A lightly into the ring grooves of the top ring and second ring, and measure the wear of the ring groove.
 - If the shoulder of the wear gauge con

tacts the piston, replace the piston.


- ★ Carry out the measurement at several places.
- Measuring straight ring groove
 - 1) Assemble a new ring in the oil ring groove, and measure the clearance at the top and bottom with a feeler gauge.
 - ★ If the clearance is greater than the permissible limit, replace the piston.





MEASURING PISTON RING END GAP

- Assemble the piston ring to the cylinder liner, push the piston ring into the area of the cylinder where there is least wear, then measure the piston ring end gap with a feeler gauge.
 - ★ Insert the piston ring so that it is at right angles to the sliding portion of the liner.



MEASURING LENGTH OF CONNECTING ROD


- 1) Tighten the mounting bolts of the connecting rod cap to the specified torque.
 - ★ Do not assemble the connecting rod bearing.
- 2) Assemble a new piston pin in the hole at the small end of the connecting rod.
 - ★ Coat the piston pin with grease (G2-LI) before installing.
- Support both ends of the piston pin on V blocks, and support both ends of the connecting rod on square blocks.
- 4) Measure distance **A** between the big end and small end with a height gauge.
- 5) Measure the inside diameter of the big end and small end.
- Calculate the value for the length **B** of the connecting rod as follows.


= -

Connecting rod dimension **B** ID of big end + ID of small end



 $+\mathbf{A}$






MEASURING CURVATURE, TWISTING OF CONNECTING ROD

• Method for measuring curvature

- 1) Tighten the mounting bolts of the connecting rod cap to the specified torque.
 - \star Do not assemble the connecting rod bearing.
- Assemble a new piston pin in the hole at the small end of the connecting rod, place V blocks on a flat surface, then set both endof the piston pin on the V block.
 - ★ Coat the piston pin with grease (G2-LI) before installing.
- 3) Stand the connecting rod perpendicularly, and support both sides of the big end with square blocks.
- 4) Set the indicator of height gauge 1 at the front of the hole at big end, set it in contact with the bottom, then set the gauge to 0.
- 5) Move the height gauge to the opposite side by a distance equal to the width of the big end, and read the measurement of the gauge.

• Method of measuring twisting

- From the condition described above, remove the square blocks, lay the connecting rod down, and support the big end on the tip of a conical jack.
- 2) Measure the big end in the same way as when measuring the curvature.
 - Calcualte the value for the curvature and twisting as follows. Curvature, twisting





Actual measured


Value

Dimension A

= -








ASSEMBLY

TIGHTENING BOLTS BY PLASTIC RANGE TURNING ANGLE METHOD

• The imported bolts on the 170 Series engine use the plastic range turning angle method for tightening.

This method uses special bolts, and by tightening the bolts to the load where the bolt starts to deform permanently (plastic range), it is possible to get an accurate, high tightening force. (Of the methods used for tightening bolts,the method using checking of the torque is the most common, but because of the influence of friction factors, it is difficult to control the tightening force accurately.)

• The tightening method using the plastic range tuning angle method uses the initial tightening torque and the turning angle to tighten the bolts.



- Bolts tightened with the plastic range turning angle method on the 170 Series engine.
 - 1) Crankshaft pulley mounting bolts(Only HD465)
 - 2) Idler gear mouning bolts.
 - 3) Flywheel mounting bolts BHD465 only)
- With the plastic range turning angle mehtod, there is a permanent deformation remaining after tightening.

Therefore, there is a limit to the number of times that the bolt can be used, so please observe the following.

- 1) After tightening, make one punch marks, If any bolts has more than 5 punch marks, do not use it again; replace it with a new bolt.
- 2) When tightening to an angle greater than the specified angle, loosen completely before tightening again. (In this case, make two punch marks.)
- 3) The target for the tightening angle should be the satandard value \pm tolereance.


Specia	al tools

Part No.	Part Name	Qty.
790-501-2000	Engine repair stand	1
790-901-1170	. Repair stand bracket	1
790-476-1140	Lifting tool	1
795-601-1110	Push tool	1
795-102-2102	Spring pusher	1
		1
795-250-1210	Liner driver	1
795-225-1700	Piston holder	1
790-331-1110	Wrench	1
	790-501-2000 790-901-1170 790-476-1140 795-601-1110 795-102-2102 795-100-1191 795-250-1210 795-225-1700	Part No. Part Name 790-501-2000 Engine repair stand 790-901-1170 . Repair stand bracket 790-476-1140 Lifting tool 795-601-1110 Push tool 795-102-2102 Spring pusher 795-100-1191 Piston ring tool 795-250-1210 Liner driver 795-225-1700 Piston holder 790-331-1110 Wrench

- Wash all parts clean, and check that there are no dents, scratches, or casting defects. Check also that all oil or water passages are clear before as sembling.
- Before inserting the cylinder liner, take the following action with the cylinder block.
 - 1) Remove the rust and scale from surfaces (A) and (B) with sandpaper unit the machining surface appears.
 - 2) Polish portions (R) and (r) with #240 sandpaper so that the (R) surface is smooth.
 - Polish portions (B), (R) and (r) with #240 sandpaper so that they become smooth. If the corner of the (R) portion is sharp or there are burrs, polish with a scraper or sandpaper.

Be sure to finish this surface particularly smoothly so that it does not scratch the Oring.

- 4) If surface (R) is pitted and rough, and cannot be corrected, replace the cylinder block.
- 5) If surface (A) and portions (R) and (r) are pitted and rough, finish them smoothly.
- 6) Inspect the counterbore, and remove any burrs or flashes. If there are any metal particles or dirt on surface \bigcirc , the liner will not fit properly in close contact, and this may cause problems such as leakage of water or protrusion of liner.
- ★ If there is any drooping, corrosion, or pitting left in the counterbore, carry out additional machining.




1. Cylinder liner

- Replace the liner O-ring and clevis seal with new parts immediately before assembling the liner.
- Method of installing liner O-ring and clevis seat
 - 1) Check the cylinder liner O-ring groove and outside circumference of the liner to confirm that there is no rust or pitting.
 - If the surface is rough and pitted, it may cause, leakage of water, so replace the liner.
 - 2) Coat the liner O-ring and clevis seal with clean engine oil (SAE #30).
 - ★ Oil causes the clevis seal and O-ring swell and deteriorate, so do not leave them soaking in oil.


Use a brush and coat them with a small amount of oil immediatly before assembly.

- 3) Assemble the liner O-ring and clevis seal to the liner as shown in the diagram on the right.
- 4) After installing the liner O-ring, check for twisting. If any twisting is found, use a smooth bar (approx. Ø10) to remove the twisting.







- To prevent the clevis seal from twisting when it is installed, press it around the whole circumference so that it fits into the seal groove.
- ★ Assemble the clevis seal with the chamfered sidee facing down.




GENERALASSEMBLY

- 5) Method of inserting cylinder liner
 - i) Using a cloth, wipe off all the dirt and oil from the contact surface of the liner lip and the cylinder block counterbore.
 - ii) Coat the mating surface of the cylinder block and cylinder liner counterbore with silicon-based gasket sealant (LG-6).






 ★ Make an overlap of 6 ± 6 mm at the begin ning and end when coating with gasket sealant LG-6.



- When machining the bottom contact surface of the counterbore liner lip and using a shim.
 - i) Coat the bottom of the shim thinly with gasket sealant LG-6, then assemble the shim.
 - ii) Next, coat with gasket sealant LG-6 in the same way as when not using a shim.





GENERALASSEMBLY


- 6) Coat the liner O-ring, clevis seal, and cylinder block contact surface with a small amount of engine oil (SAE #30) immediately before press fitting the liner.
- ★ Coat the contact surface of the cylinder block uniformly around the whole circumference by hand
- 7) Insert liner (1) into cylinder block, taking care not to damage O-ring.
- 8) Use your weight and push the liner in with both hands.
 - ★ If the liner does not go in smoothly when you apply your weight, there is danger that the O-ring may be damaged, so check the cylinder block for burrs of flashes.
- 9) Using a liner driver **I**, press fit cylinder liner (1) into the cylinder block.
- ★ Using the following procedure, squeeze out the gasket sealant coated on the counterbore
 - i) Tighten the cylinder head temporarily with a used head gasket.


Mounting bolt: 26 ± 1 kgm

- Remove the cylinder head, and wipe off the gasket sealant that has been squeezed out from between the cylinder liner and cylinder block.
- ★ If gasket sealant sticks to the grommet in the head gasket, the grommet will change shape and cause leakage of water, so be sure to wipe off all the gasket sealant.












- 10) After press fitting cylinder liner, use dial gauge (1) to measure protrusion of cylinder liner.
 - ★ When measuring the protrusion of the liner, hold the liner down with a plate to prevent the liner from coming up on the O-ring when measuring.
 - ★ Protrusion of cylinder liner : 0.07-0.15mm
- ★ If it is not within the standard value, take the action given in the maintenance standard.

2. Crankshaft

- 1) Align protrusion of upper main bearing (1) with notch of cylinder block, then assemble in cylinder block.
 - ★ Check that there is no dirt at the rear face of the bearing before tightening. Coat the inside surface of the bearing with engine oil (SAE #30).
 - ★ Do not coat the rear surface of the bearing bearing with oil.
 - ★ Upper bearing: With oil hole
- 2) Check for the following before assembling the crankshaft.
 - i) Abnormality int the front, rear side threaaded portion (The bolt must go in smoothly when turned by hand).
 - ii) Scratches or dents on the pin or main journal portion.
 - iii) Dirt stuck to the inside of the oil hole.
- 3) Raise crankshaft (2), and assemble to mounting position, taking care not to hit the cylinder block.









GENERALASSEMBLY


4) Move crankshaft to one side. then coat upper thrust bearing (3) with engine oil (SAE #30), and install to No.6 bearing so that side with oil griive is faing crankshaft end.

- 5) Align Protrusion of lower bearing (4) with notch of main cap and install.
 - ★ Check that there is no dirt at the rear face of the bearing before tightening. Coat the inside surface of the bearing with engine oil (SAE #30).
 - ★ Do not coat the rear surface of the bearibearing with oil.
 - ★ Lower bearing: No oil hole
- 6) For No. 6 main cap, knock in dowel pin so that protrusion from end face of cap is 3.0 3.5 mm, then install lower thrust bearing (5) on both sides.
 - ★ Install the thrust bearing with the side with the groove on the crankshaft side.





- 7) Coat journal surface of crankshaft with, engine oil (SAE #30), check that stamped number on main cap (6) matches number on cylinder block, then install main cap.
- 8) Coat mounting bolt thread and washer of main cap with engine oil (SAE #30), then screw in bolts, and insert main cap completely.



GENERALASSEMBLY


- 9) Tighten main cap mounting bolts as follows.
 - ★ When tightening, start from the center and work in order to the outside. Tighten the bolts to the specified tightening torque using the following steps.


Unit kom

Main cap mounting bolt

		Unit. Kgin
Step	Target	Range
1st	56	51 to 61
2nd	113	107 to 118
3rd	0	Loosen completely
4th	38	33 to 43
5th	75	70 to 80
6th	113	107 to 118


- 10) After tightening main cap bolts. screw bolt into center bolt hole and measure starting torque of crankshaft.
 - Standard value: Max. 2.8 kgm
- 11) Measure end play of crankshaft with dial gauge(1).
 - End play : 0.140 0.32 mm
 - ★ If it is within the standard value, take the action given in the maintenance standard.






3. Piston, connecting rod assembly

- Assemble piston and connecting rod.
 - i) Fit oil ring expander (1) in oil ring groove.
 - ii) Using piston ring tool **H**, assemble oil ring, second ring, and top ring in order.
- * Set each ring with the stamped mark facing up and install to the piston.
- ★ Place the end of the expander coil at 180°to the end gap of the oil ring.





GENERALASSEMBLY

- ★ Assemble each piston ring as shown in the diagram.
- Top ring Second ring Oil ring
- iii) Install snap ring (2) on the side,
- iv) Heat piston (3) at 100°C [212°F] for 5 minutes in a heating furnace.
- ★ If no heating furnace is available, heat in hot water at 100°C [212°F] for 5 minutes.
- ★ When heating with hot water, clean the piston completely after setting it in position.



- v) Coat piston boss with engine oil (SEA #30), set front embossed casting letters on piston facing in same direction as part number casting letters on connecting rod, then insert piston pin (4).
- vi) Install snap ring (5) on opposite side.
 - Rotate the left and right snaprings to check that the snap rings ar completely fitted into the ring groove.
- vii) Align protrusion of connecting rod upper bearing (6) with notch of connecting rod, then install.
 - ★ Check that there is no dirt the rear face of the bearing before assembling.
 - ★ Do not coat the rear surface of the bearing with oil.
 - ★ Check that the hole in the bearing and the oil hole in the connecting rod are aligned.







GENERALASSEMBLY

- viii) Align protrusion of connecting rod lower bearing (7) with notch of connecting rod cap,then install.
 - Check that there is no dirt at the rear face of the bearing before assembling.
 - ★ Do not coat the rear surface of the bearing with oil
- Method of inserting piston and connceting rod assembly.
 - Coat cylinder liner with engine oil (SAE #30).
 - ★ Coat uniformly with engine oil around the whole circumference by hand.
 - 2) Rotate crankshaft and set pin journal at top dead center for cylinder where piston is to be inserted.
 - Set embossed letters on conncted rod facing front of engine (stamped number is on camshaft side), then insert piston and connecting rod assembly into cylinder from head end.

A CONTRACTOR





4) Align all piston rings as shown in diagram.





- 5) Coat piston ring uniformly with engine oil (SAE #30).
- 6) Tighten piston ring with piston ring holder **J**, then push in piston head with wooden bar.

- 7) Using connecting rod pulling tool shown in the diagram on the right, pull connecting rod, and fit it in close contact with crank pin journal.
- ★ Check that the connecting rod bearing is correctly in position.
- ★ To make a connecting rod pulling tool, weld a bar to an old connecting rod bolt.
- 8) Coat crankshaft pin journal with engine oil (SAE #30).
- 9) Rotate crankshaft 180° while pulling conecting rod.
- 10) Coat connecting rod lower bearing with engine oil (SAE #30), check cap number, then align with dowel pin, and install connecting rod cap (8).
 - ★ When coating with engine oil, spread the oil with a finger over the whole part.
 - ★ When assembling a new connecting rod, mark the cylinder number with an electric pen. Do not make a stamped mark.












- 11) Coat thread and washer of connecting rod bolt with engine oil (SAE #30).
- 12) Tighten connecting rod bolts in turn until connecting rod cap is in tight contact.
 - ★ If an impact wrench is used to loosen the bolts, there is danger of damage to the thread, so loosen the bolts with a hand tool.





- 13) Rotate crankshaft 180° and repeat Steps (1 to 12) to insert pistons in all cylinders.
- 14) Tighten the connecting rod bolts as follows.
 - i) 1st step : Tighten 20 ± 1 kgm
 - ii) 2nd step : Using wrench **K** turn $90^{\circ^{+15^{\circ}}_{0}}$ to tighten.
- When not using wrench **K** tighten as follows.
 - i) 1st step : Tighten 20 ± 1 kgm
 - ii) 2nd step : Put a mark on the bolt and cap with a felt pen, then turn the bolt a further 90° $^{+15^{\circ}}_{0}$
- ★ After tightening, make one punch mark on the bolt head. If the bolt head has five punch marks, do not reuse it. Replace the bolt with a new bolt.
- ★ After assembling the connecting rod, check that the crankshaft rotates smoothly.






GENERALASSEMBLY

- 15)Using dial gauge (1). measure side clearance of connecting rod.
- ★ Standard for side clearance : 0.200 0.375 mm
- ★ If the connected rod does not move, remove the connectingrod cap and check that there is no mistake in assembly, and that there are no burrs, or dirt caught anywhere.
- 4. Piston cooling nozzle Fit O-ring to cooling nozzle (1) and install.

✓ O-ring : Engine oil (SAE #30)

- ★ Before installing, check the curvature (angle) of the nozzle, and check that there is no clogging inside the nozzle.
- ★ Face the tip of the nozzle to the side with the mounting hole at the side, insert into the piston, taking care that it does not hit the piston, then turn 90°



5. Flywheel housing

 Fit gasket to mounting surface of cylinder block, then using eyebolts (Thread dia. = 16 mm, Pitch = 2.0 mm), raise flywheel housing (1) and install to cylinder block.


Mounting bolt:


1st step : Tighten to 36 - 40 kgm


2nd step : Loosen completely 3rd step : Tighten to 40 - 44 kgm


- ★ Tighten the mounting bolts of the flywheel housing as follows, in the order shown in the diagram.
- ★ The bolts are of different legths, so be careful when installing them.
- 2) After installing flywheel housing, using dial gauge to measure face runout and radial runout.
- ★ Face runout : Max. 0.20 mm
 - Radial runout : Max. 0.20 mm
- 3) Inspect stepped difference between cylinder block and flywheel housing.
- * Stepped difference at bottom surface :

Max. 0.15









GENERALASSEMBLY

6. Gear case

- 1) Fit gasket to mounting surface of gear case.
- 2) Install gear case (1).

7. Main idler gear

Install main idler gear (1).

- ★ Assemble with the oil groove of the thrust bearing on the gear side.
- Press fit the thrust plate to the shaft.

Coat the bolt thread and seat with engine oil (SAE #30), then tighten.

 ★ When installing the mounting bolts, screw in first at least 2-3 turns by hand, then tighten as follows. (All models)


Idler gear mounting bolt:

(Thread size) x (Pitch)	Tightening method
M16 x 1.5	30 - 35 kgm
	(Tighten by torque)
M18 x 2.5	$_{+30^{\circ}}$ 5 ± 0.5 kgm
	90 ^{°°} Tighten an additional
M18 x 1.5	$_{+30^{\circ}}$ 31 ± 4 kgm
	90 ^{°°} Tighten an additional


- ★ After tightening, make one punch mark on the bolt head to indicate the number of times that the bolt has been used. If any bolt has four punch marks, do not reuse it. Replace it with a new bolt.
- ★ Align carefully with the match marks on the gear when installing.


8. Camshaft


Coat surface of camshaft journal with engine oil (SAE #30) and install camshaft (2).



- ★ When inserting the cam shaft, rotate it while inserting it in order to prevent damage to the cam bushing.
- ★ Align carefully with the match marks on the gear when installing.







9. Idler gear for oil pump

Install idler gear (2) for oil pump.

Idler gear mounting bolt:

(Thread size) x (Pitch)	Tightening method
M16 x 1.5	30 - 35 kgm
	(Tighten by torque)
M18 x 2.5	$5 \pm 0.5 \text{ kgm}$
	$90^{+30^{\circ}}$ Tighten an additional
M18 x 1.5	$_{\pm 30^{\circ}}$ 31 ± 4 kgm
	$90^{+30^{\circ}}_{0}$ Tighten an additional

- Be sure to install the thrust bearing with the oil groove facing in the correct direction.
- Coat the bolt thread and seat with oil.
- When installing the mounting bolts, screw in first at least 2 3 turns by hand, then tighten fully.
- After tightening, make one punch mark on the bolt head to indicate the number of times that the bolt has been used.
- ★ Align carefully with the match marks on the gear when installing.

10. Idler gear for water pump


Install idler gear(1) for water pump.


★ Align carefully with the match marks on the gear when installing

Idler gear mounting bolt for water pump : Same as in item 9 above

11. Injection pump drive case

- 1) Fit O-ring and install injection pump drive case (2).
- 2) Install coupling (1).






GENERALASSEMBLY

12. Timer

Install timer (2) aligning it with the gear, then tighten nut (1).

Timer nut : 1.75 ± 2.5 kgm


- ★ Align the match marks on the timer and the gear surely.
- * Measure the backlash and end play of each gear with dial gauge (1).
- \star Standard value of backlash and end play :




Without a timer

	Backlash		End play
А	0.140 - 0.460	1	0.075 - 0.21
В	0.130 - 0.470	2	0.10 - 0.32
С	0.130 - 0.470	3	* 0.145 - 0.395
D	0.100 - 0.500	4	0.10 - 0.32
а		5	
b	0.095 - 0.460	6	0.14 - 0.32
с	0.120 - 0.425	7	0.10 - 0.32
d	0.100 - 0.445	8	0.085 - 0.125

* End play (3) for machines with a timer (HD465 twin turbo, WA700 only) is 0.09 - 0.45 mm.
 For other machines the backlash and end play are as in the talble above.





13. Gear case cover

- 1) Stick gasket to mounting surface for gear case cover.
- 2) Install gear case cover (1).
 - Check the difference in level between the gear case, gear cover, and the bottom face of the cylinder block.
 - ★ Difference in level of bottom face : Max. 0.15 mm

14. Oil pump assembly

1) Install oil pump assembly (3).

Mounting bolt : 11.0 ± 1.5 kgm

2) Fit gasket, O-ring and install tube (2).

15. Oil strainer

Fit gasket, then install oil strainer (1) and secure with bracket.

16. Oil pan

★ Before installing the oil pan, cut off the gaskets of the flywheel housing, gear case, and gear cover so that they are the same level as the cylinder block.

Apply liquid gasket to the face of the oil pan, and install oil pan (1).


Face of oil pan : Liquid gasket (LG-7)


★ Diameter of gasket sealant: \u03c6 1.6 - 2.0mm


17. Rear seal cover


Fit O-ring and install rear seal cover (1).

★ Take care that the lip is not rolled up









GENERALASSEMBLY


GENERALASSEMBLY


18. PTO drive gear

- ★ Assemble PTO drive gear as follows:
 - i) Install bearing (7) to shaft (8).
 - ii) Install the snap ring to gear (5), then install bearing (6).
- ★ Coat the bearing portion with engine oil (SAE #30).



- \star Bend the lock plate securely.
- ★ Confirm that the gear can rotate smoothly. If not, adjust the thickness of the shim.







- 1) Install PTO drive gear (2), and then tighten six bolts.
 - ★ After installing PTO drive gear, confirm that there is backlash between it and the PTO gear,
 - ★ Backlash: 0.15 to 0.52 mm
- 2) Install steering pump drive gear (1).
 - \star Bend the lock plate securely.

19. Flywheel

- Using eyebolts (Thread dia.= 12 mm, Pitch= 1.75 mm), raise flywheel (1), mesh train gear and idler gear, then install flywheel and tighten bolts.
 - ★ For engine with a PTO: When measuring the engine capacity, the inside of the PTO case cannot be lubricated, so remove the PTO drive gear and install the flywheel.






GENERALASSEMBLY

- 2) Coat bolt thread and washer with engine oil (SAE #30) or anti-friction compound (LM-P).
- 3) Tighten bolts in turn unit flywheel is in tight contact.
 - ★ If impact wrench is used to loosen the bolts, there is danger of damage to the thread, so loosen the bolts with a hand tool.



- 4) Secure flywheel and housing with stopper ① and tighten bolts.
 - ★ Order of tightening




5 kgm	Flywheel mounting bolt (BHD465)						
	1st step :	Tighten to 20 ± 2 kgm					
	1st step : 2nd step :	Tighten to 47 ± 2 kgm					
	3rd step :	Make marks on bolts					
		and flywheel with felt					
		pen, then tighten bolt					
		an additional 90 $^{+30^{\circ}}_{0}$					


Flywheel mounting bolt (machines except HD465): 1st step : 8 - 12 kg

2nd step : 28 - 32 kgm 3rd step : 53 - 57 kgm

- 5) Measure radial runout and face runout of flywheel.
 - ★ Radial runout and face runout of flywheel

Item	Except BHD465	BHD465 only
Radial runout	Max. 0.15 mm	0.10 mm
(pilot bearing		
hole)		
Face runout	Max. 0.20 mm	0.20 mm





20. Cam follower

1) Install cam follower assembly (2), aligning it with the pin

Cam follower mounting bolt :

9.2 - 10.6 kgm

- ★ Before installing the cam follower, wash the oil hole of the mounting bolt.
- 2) Install cover (1).

✓ Face of cover : Liquid gasket (LG-7)

★ Diameter of gasket sealant: Ø1.6 - 2.0

21. Mechanical pump assembly

Fit O-ring to mechanical pump assembly (6), then align with slit at tip of camshaft, and intall.

22. Accessory drive pulley

- 1) Fit O-ring and install drive pulley (5) for alternator.
- Fit O-ring and install accessory drive pulley (4).

23. Trunnion

- 1) When press fitting front seal, use a tool.
 - ★ After press fitting, check that the spring has not come cut of position.

Lip of oil seal : Grease (G2-LI)


- 2) Fit O-ring and install trunnion (1).
 - ★ Before installing the trunnion, clean off all dirt from the outside circumference of the crankshaft, then coat the whole circumference thinly with engine oil (SAE #30).
 - ★ Take care that the lip is not rolled up.


24. Cover

Install cover (2).

Face of cover : Liquid gasket (LG_-7)

★ Diameter of gasket sealant : Ø1.6-2.0 mm





GENERALASSEMBLY

25. Front support

Raise front support (1) and install to trunnion portion.

Front support grease groove : Grease (G2-LI)

26. Vibration damper

- 1) Sling vibration damper (4), align with dowel pin, and install,
- 2) Install spacer (3).

27. Crankshaft pulley


- 1) Install crankshaft pulley (2) and tighten with mounting bolts
- Coat bolt thread and seat surface with engine oil (SAE #30), then tighten bolts.
 - ★ When installing the mounting bolts, screw in first at least 2 - 3 turns by hand, then tighten as follows.


Crankshaft pulley mounting bolt :


		Unit: kgm
Order	BHD465 only	Except BHD465
1st step	40± 3	7.5 ± 2
2nd step	78±3	25±2
3rd step	Make marks on bolt	65±2
	and pulley with felt	
	pen, then tighten	
	bolt an additional	
	$90^{+30^{\circ}}_{0}$	


★ If an impact wrench is used to loosen the bolts, there is danger of damage to the thread, so loosen the bolts with a hand tool.












GENERALASSEMBLY

GENERALASSEMBLY

Fit gasket and install mechanical pump tubes (1).





28. Cylinder head assembly


- Assemble cylinder head as follows.
 - i) Align with casting mark on cylinder head and assemble intake valve (7) and exhaust valve (6).

Valve stem : Engine oil (SAE #30) (Inside face of valve guide)

- ★ The intake valve has the mark **IN** and the exhaust valve has the mark **E** on the bottom.
- ii) Assemble valve blower seat to cylinder head, then assemble inner spring and outer spring (5).
 - ★ The spring with the unequal pitch (WA600, WD600, WA700, HD465) is assembled with the narrow pitch at the head end.
- iii) Install retainer (4).
- iv) Using spring compressor **D**, compress spring, and fit valve cotter (3) in grrove of valve stem.
- v) Tap valve stem with plastic hammer and check that, valve cotter is completely fitted.
- vi) When nozzle valve has been replaced, install nozzle holder to cylinder head, then use depth gauge to measure protrusion of nozzle.
 - ★ Protrusion of nozzle: 4.9 5.7 mm









GENERALASSEMBLY


28. Cylinder head assembly

- Check that there is no dirt on cylinder head mounting surface or inside cylinder, then install gasket (9).
 - ★ When installing the gasket, check that grommet (10) has been properly installed and has not peeled off.
- Note: There is danger that the head gasket grommet may swell and change shape, so do not coat it with gasket sealant.
- 2) Coat thread of head bolt and washer with antifriction compound (LM-P).






- 3) Using eyebolts 1 (Thread dia. = 12 mm, pitch = 1.75 mm), install cylinder head assembly (2).
- 4) Screw in head bolts (1) at least 2 3 turns by hand, then tighten in order shown in diagram below.



Cylinder head mounting bolt:

		Unit: kgm
Step	Target	Range
1st	7.9	6.4 to 9.4
2nd	23.5	22 to 25
3rd	39	37.5 to 40.5
4th	50.5	49 to 52



GENERALASSEMBLY


29. Crosshead


Install crosshead (1).

- ✓ Guide pin : Engine oil (SAE #30)
- ★ Adjust the crosshead as follows.
- i) Loosen locknu, and turn back adjustment screw.
- ii) Hold top surfaces of crosshead lightly, and screw in adjustment screw.
- iii) After adjustment screw contacts valve stem, screw in a further 20°.
- iv) Tighten locknut to hold in position.

 $5 \text{ Locknut } 4.0 \pm 0.6 \text{ kgm}$


★ Install the crosshead so that theadjustment nut is at the exhaust end.





30. Rocker housing


- 1) Fit gasket, align tab of grommet with groove in gasket, then install.
 - ★ The grommet has a top and bottom, so be sure to install it facing the righ way up.



2) Fit O-ring, then insert water manifold (3) in rocker housing.


✓ O-ring: Engine oil (SAE #30)

- ★ If the O-ring is coated with engine oil and left for a long time, it will swell, os coat it with oil immediately before assembling it.
- ★ Insert the snap ring groove end into the rocker housing.



GENERALASSEMBLY

- 3) Install rocker housing (3),
- 5 kgm Mounting bolt : 10 ± 0.5 kgm
- 4) Using push tool **C**, insert water manifold (2).
- 5) Secure water manifold with snap ring (1).



31. Injection nozzle assembly

- Check that there is no dirt or dust inside the nozzle holder sleeve. (Mark it with a rubber cap.)
- 1) Align line on nozzle body with line on plate, then set with lines facing front of engine, and install injection nozzle assembly (1).
- 2) When tightening 2 mounting bolts (2), tighten each in turn to a low torque, then gradually increase torque of each bolt in turn (approx. 0.5 kgm each time) to tighten to specified torque.
 - ★ Do not reuse nylock bolts. Always replace them with new parts.


Mounting bolt: 2.75 ± 0.25 kgm

★ Keep the difference in torque between the two bolts to a maximum of 0.5 kgm.


32. Push rod

Install push rod (1).

★ Check that the push rod is fitted properly into the socket of the cam follower.




Line




33. Rocker arm assembly

Assemble rocker arm.

- i) Using push tool, align oil hole of bushing (4) and knock in rocker arm (3).
- ii) Assemble adjustment screw (2) and locknut (1) to rocker arm.



- iii) Coat rocker shaft with engine oil (SAE #30), then set so that portion with plug is at exhaust end.
- iv) Set exhaust rocker arm (long arm on left and intake rocker arm (short arm) on right, insert collar at center, then insert onto rocker shaft.




- 1) Install rocker arm assembly (1) and tighten mounting bolts.
 - ★ Check that the ball of adjustment screw
 (2) is fitted properly into the socket of the push rod
 - ★ Assemble a spacer (length: 15 mm) to the short bolt and a washer to the long bolt.

Mounting bolt: 10 ± 0.5 kgm

34. Adjusting valve clearance

Adjust valve clearance. For details, see TESTING AND ADJUSTING, Adjusting valve clearance.



GENERALASSEMBLY

35. Head cover, spill tube

- 1) Fit gasket, install head cover (4), then tighten bolts temporarily.
- 2) Install nozzle seal and press fit with push tool.
 - Nozzle seal surface:

Engine oil (SAE #30)


3) Tighten head cover mounting bolts in orders hown in diagram.


Mounting bolt: 3.25 ± 0.25 kgm


- 4) Install connection (3).
- 5) Install turbocharger lubrication tube (2).
- 6) Install spill tube (1).


36. Fuel injection pump assembly

- Laminated coupling type
- 1) Knock key into drive shaft.
- 2) Screw lifting tool **B** into delivery valve thread, raise fuel injection pump assembly (1), then align key groove of pump coupling (2), and connect pump.
- 3) Tighten drive shaft mounting bolts (3) of coupling.
- 4) Align lines on coupling and bearing cover of injection pump, then tighten bolt (4).
 - ★ If the mounting bolts are not tightened uniformly, the pump will be at an angle and will rotate against the drive shaft, and this will result in a change in the injection timing.
 - ★ If there are no lines marked, or if the injection pump has been replaced, adjust the injection timing. For details, see TESTING AND ADJUSTING.









GENERALASSEMBLY

GENERALASSEMBLY

- Flange type
 - ★ When installing the flange type injection pump, align line "a" on the flange with line "b" on the injection pump flanges.
 - ★ If there are no lines marked, or if the injection pump has been replaced, adjust the injection timing. For details, see TESTING AND ADJUSTING.
- 1) Fit gasket, then install lubrication tube between injection pump and cylinder block.


37. Aftercooler, intake manifold assembly


- Assemble aftercooler and intake manifold assembly.
 - i) Fit gasket, then assemble core assembly (5) to intake manifold (6).
 - ii) Fit gasket, then install cover (4).

Mounting bolt: 30 ± 0.5 kgm

iii) Fit gasket and O-ring, then align connector (3) and joint (2) with joint of cooler core, and install.

✓ O-ring: Engine oil (SAE #30)






1) Fit gasket, then install aftercooler and intake manifold assembly (1).




Mounting bolt : 6.5 ± 1.0 kgm




38. Turbocharger, exhaust manifold assembly


Fit gasket, then install turbocharger and exhaust manifold assembly (1).

- Mounting bolt thread: Anti-friction compound (LM-P)
- Mounting bolt: 11.25 ± 1.25 kgm
- BD375A,BE1000,WA700,BD465-5 2 bolts (length: 50 mm):8.5 ± 0.5 kgm
- ★ If the turbocharger has been replaced, the tightening torque for the turbocharger mounting bolts is as follows.





 BE1000 : 60 - 7.5 kgm (Serial No. up to 12887)
 : 4.5 - 5.5 kgm (Serial No. 12888 & up)




39. Thermostat case

Assemble thermostat case.

- i) Using push tool ①, press fit thermostat seal(5) to housing (6).
 - ★ Be careful that the seal is not at an angle when press fitting.
- ii) Assemble thermostat (4).
- iii) Fit gasket, then install cover (3) and outlet pipe (2).


Install thermostat case (1).



40. Corrosion resistor

Install corrosion resistor (1).

- ★ Coat the seal and thread with engine oil (SAE #30).
- ★ After the seal surface comes into contact with the fitter head, tighten a further 2/3 turns.




GENERALASSEMBLY

41. Tension spring, tension pulley

- Assemble tension pulley.
 - i) Press fit shaft (21) to bracket (22).
 - ii) Install seal (20) to bracket (23), then assemble inner race (19), bearing (18),

and seal (17), and install plate (16).

- ★ Coat the bearing and seal portion with grease (G2-LI).
- iii) Install oil seal (15) to pulley (14).
- iv) Assemble pulley to bracket (23), then assemble bearing (13) and spacer (12), and install snap ring (11).
- v) Install braring (10).
- vi) Fit holder (8), and tighten lock plate (7) with bolts.
 - ★ Bend the lock plate securely.
- vii)Fit cover (6), then secure with snap ring (5).



GENERALASSEMBLY

- 1) Insert spacer, then install tension pulley assembly (4) and bracket as one unit.
- 2) Install tension spring (3) and tighten bolt (2), then secure them with locknut (1).
 - ★ The tension spring will be adjusted according to the tension of the fan belt after the engine assembly is mounted.

42. Oil filter, oil level gauge

- 1) Fit gasket and install oil level gauge (3).
- 2) Fit gasket and install oil filter (2).

43. Oil filter

Fit O-ring and install bracket, then install oil filter (1).

- ★ Coat the seal and thread with engine oil (SAE #30).
- ★ After the seal surface comes into contract with the filter head, tighten by hand a further 3/4 1turn.

44. Fuel injection tube

Install fuel injection tube (1) and secure it with the clamp.


Sleeve nut: 2.25 ± 0.25 kgm (both pump and nozzle ends)


45. After-cooler tube and oil filter tube


- 1) Install lubrication tube for the turbocharger.
- 2) Install O-ring and after-cooler tube, then secure them with the lockbolt.


46. Fuel filter

- 1) Install fuel filter (1).
- 2) Fit gasket and connect fuel hoses (2).
- 3) Connect fuel hose (3) for APS.










47. Connector pipe

1) Install O-ring and gasket, install connector pipe (2), then secure it with the plate.




- ★ When connecting the piping to the turbocharger, center the piping so that the turbocharger is not twisted, then tighten.
- 2) Fit gasket and install tube (1) for boost compensator.

48. Intake connector

Fit O-ring and install intake connector (2). Align the hole on it with the one on bracket (1).


✓ O-ring : Grease (G2-LI)


★ Insert a plain washer between the connector and the bracket.



49. Air cleaner assembly


Fit gasket and install air cleaner assembly (1) and secure it with the band.





50. Setting off engine from engine stand

- 1) Lift the engine assembly (1) and remove the mounting bolts to separate the engine assembly from engine repair stand **A**.
- 2) Remove the bracket for the engine repair stand **A1**.
 - ★ Prepare an engine stand, then place the engine on the stand and secure it in position.



GENERALASSEMBLY

51. Oil cooler

1) Fit gasket and install oil cooler (2).

Oil cooler mounting bolt :


52. Drain tube of turbocharger

tube (1) for the turbocharger.

 $6.75\pm0.75~kgm$


Fit gasket to both end faces, then install drain

2) Fit gasket and install water pipe (1).




53. Water pump assembly

- 1) Install drive shaft
- 2) Fit gasket and install water pump assembly (3), aligning it with the drive shaft.
- 3) Fit O-rings to both end faces. Install water pipe (2) and secure it with the plate.
- 4) Fit O-rings and gaskets to both end surfaces, then install water pipe (1).



54. Alternator assembly


- 1) Install bracket (5).
- 2) Install alternator (4) and temporarily tighten nut (3).



GENERALASSEMBLY


GENERALASSEMBLY

- 3) Fit belt (2) to the pulley, and tighten the mounting bolts for adjustment plate (1).
- 4) Raise the alternator assembly with a bar, and adjust so that the deflection of the belt is approx. 15 mm when pressing its center with 6 kg of force. Then tighten the bolt securely.




55. Starting motor assembly

1) Fit gasket and install starting motor (1).




ENGINE 15 MAINTENANCE STANDARD




INTAKE AND EXHAUST SYSTEM

Turbocharger	15-002
ENGINE BODY	
Cylinder head	15-003
Valves and valve guide	15-004
Crosshead and crosshead guide	15-005
Push rod and cam follower	15-006
Cylinder block	15-007
Cylinder liner	15-009
Crankshaft	15-010
Camshaft	15-011
Timing gear	15-012
Piston, piston ring and piston pin	15-013
Connecting rod	15-014
LUBRICATION SYSTEM	
Oil pump	15-015
Oil pump relief valve, piston cooling	
valve and oil cooler by-pass valve	15-016
COOLING SYSTEM	
Water pump	15-017

TURBOCHARGER KTR110







Unit: kgm

Check	item	Crite	aria	Remedy
				Replace parts
	nation)		•	related to thrust
	lection)			
1		0.25	- 0.60	Replace parts
				related to bearing
Outside diamete	er of journal	Permiss	ible range	
bearing inside d	iameter of	Shaft	Hole	
center housing		22.92 - 22.96	23.00 - 23.03	
Inside diameter	ofjournal			
bearing, outside	e diameter of	14.95 - 14.97	15.00 - 15.04	
thrust collar				
		Permiss	ible range	Replace
Thickness of thi	rust	Width	Groove	
bearing		4.86 - 4.92	5.00 - 5.04	
Thickness of	Turbine end	1.85 - 1.92	1.46 - 2.05	_
seal ring	Blower	1.45 - 1.52	1.56 - 1.65	_
Clearance betw	een blower	Clearance lim	it: (Min.) 0.20	Replaces parts
housing and imp	beller			related to bearing
Tightening torq	ue of blower	2.9 ± 0	.3 kgm	
impeller locknut	t	C C		Tighten
Tightening torq	ue of V-band	0.9 ± 0	.1 kgm	
locknut			2	
	End play (Play in axial din Radial play (Play in radial d Outside diameter bearing inside d center housing Inside diameter bearing, outside thrust collar Thickness of the bearing Thickness of seal ring Clearance betw housing and imp Tightening torqu impeller locknut	$\begin{array}{l} (\mbox{Play in axial direction}) \\ \mbox{Radial play} \\ (\mbox{Play in radial direction}) \\ (\m$	End playPermiss(Play in axial direction)0.08Radial play0.25(Play in radial direction)0.025(Play in radial direction)0.025Outside diameter of journal bearing inside diameter of center housingPermissbearing inside diameter of journal bearing, outside diameter of thrust collarShaft 22.92 - 22.96Inside diameter of journal bearing, outside diameter of thrust collar14.95 - 14.97Permiss: Thickness of thrust bearingThickness of thrust bearingWidth 4.86 - 4.92Thickness of seal ringTurbine end Blower1.85 - 1.92Clearance between blower housing and impellerClearance lim housing and impellerTightening torque of blower impeller locknut2.9 \pm 0Tightening torque of V-band0.9 \pm 0	End play (Play in axial direction)Permissible range $0.08 - 0.18$ Radial play (Play in radial direction) $0.25 - 0.60$ Outside diameter of journal


CYLINDER HEAD



Tightening order of head mounting bolt




Tightening order of head cover mounting bolt




No.	Check item	Criteria				Remedy
1	Distortion of cylinder head	Tolerance		Repair limit		Repir by grinding
	mounting surface	Max.0.	05		0.1	or replace
2	Protrusions of nozzles	5	Standard	l: 4.9 to	5.7	Replace nozzle
						sleeves
3	Tightening torque of cylinder	Order	Targe	t valve	Range	
	head mounting bolts		(kg	m)	(kgm)	
	(Coat bolt threads and	1st	8.	0	6.5 to 9.5	Tighten in sequence
	washer with anti-friction	2nd	23	.5	22.0 to 25.0	as indicated above.
	Compound (LM-P))	3rd	39	.0 37.5 to 40.5		
		4th	50	.5	49.0 to 52	
		Target value ((kgm)	Ra	nge (kgm)	
4	Tightening torque of nozzle	2.75		2	2.5 to 3.0	
	holder mounting bolt					
5	Tightening torque of cylinder	3.25		3.0 to 3.5		Retighten
	head cover					
6	Tightening torque of rocker	10		9.5 - 10.5		
	arm housing mounting bolt					

ALVES AND VALVE GUIDE




					•				unit: mm
No.	Check item	1		Criteria					Remedy
					Standar	andard Repair limit		pair limit	Replace
1	Amount of valve sin	king	Intake valve	e	0.9 - 1	.5		2.1	valve or
			Exhaust valv	/e					seat
					Standard siz	e Tolera	ance	Repair limit	
2	Valve head thicknes	SS	Intake valve	e	3.4			2.9	Replace
			Exhaust valv	/e	3.5			3.1	valve
					Standar	rd	To	olerance	
3	Valve seat angle		Intake vlav	e	60°		=	±0°10'	
			Exhaust vlav	/e	45°		=	±0°10'	
			Standard siz	ze	Tolerance		Repair limit		
	Outside dianeter of				-0.060		11.90		1
	valve stem	Intake	12		-0.080				Replace
4		Exhaust			-0.092	2		11.80	
					-0.107	7			
	Inside diameter of v	alve guide	12		-0.001	1	12.10		
					-0.019				
5	Protrusion of valve	guide	23.7		+0.2			-	
					-0.3				
	Val	ve	Free length	Ins	stalled length	Installe	d load	d Load limit	
	Close	Inner	59.3		47.0	19.07	±1 k	g 17.4 kg	
		Outer	64.8		52.0	43.78	$\pm 2 k_{z}$	g 39.9 kg	
6	Open	Inner	59.3		32.5	41.55	$\pm 2 k_{z}$	g 37.8 kg	Replace
		Outer	64.8		37.5	93.23 ±	4.7 k	g 84.8 kg	
	Squareness of valve	e spring	Inner spring		Re	pair limi	ts: 2°		
	Outer spring			1					
	I		I	1					I

CROSSHEAD AND CROSSHEAD GUIDE



No.	Chec	k item		Crite	eria		Remedy
		Except	Standard size	Tolera	ance	Repair limit	
1	Depth of	BD465-5	3.0	+0.	3	-	-
	cross head			0			
	stem	BD465-5 only	7.5	+0.	3	-	
				0			
2	Inside diamete	er of crosshead	15	+0.	10	15.21	Replace
				+0.	05		
	Outside diame	eter of	15	+0.	039	15.00	
	crosshead guid	de		+0.	028		
3	Clearance bet	ween crosshead	Standard cle	arance	Clearance	e limit Adjust	
	guide and cros	sshead	0.011 to 0	.072		0.02	
			Standard s	size	Tolerance	e Repair limit	
4	Protrusion of c	crossgead guide	54		0	-	
					-0.3		Replace
5	Valve clearance	ce (at cold)	Intake valve		Exhaust valve		
			0.4			1.0	
6	Tightening tor	que of cross-	Except BHD465-5		4.0±	0.6 kgm	Tighten
	head lock nut		BHD465-5	only	6.0±	0.6 kgm	
			(Serial No. 1420)3 and up)			

PUSH ROD AND CAM FOLLOWER



					unit: mm		
No.	Check item		Criteria				
1	Outside diameter of cam	Standard size	Tolerance	Repair limit			
	follower shaft	25.0	-0.040	24.9			
			-0.055				
2	Inside diameter of cam	25.0	-0.020	25.0			
	follower lever		0				
	Inside diameter of cam	19.0	+0.175	19.2			
	follower roller		+0.150		Replace		
3	Outside diameter of cam	19.0	+0.075	19.0			
	follower roller pin		+0.065				
4	Outside diameter of cam	41.0	+0.050	41.0			
	follower roller		+0.025	-			
5	Diameter of push rod tip ball	15.85	±0.03	-	7		
6	Inside diameter of push rod	12.7	±0.20	-	7		
	socket						


CYLINDER BLOCK 5 3 6

No.	Check item			Remedy			
			Tol	erance			
1	Clearance between cylinder	Standard size	Inside	Outside	Standard	Clearance	Replace
	block and liner		diameter	diameter	clearance	limit	cylinder
			of block	ofliner			liner or
		190			0.050 to		block
					0.160		
	Inside diameter of main	Standard si	ze	Tolerance		Repair limit	
	bearing hole	148		-0.025		-	
				0			Repair or
2	Thickness of main bearing	4		-0.040		3.90	
				-0.050			
	Inside diameter of main	140		+0.125	1	40.20	
	bearing			+0.075			

						unit: mm	
No.	Check item		Criteria				
3	Clearance between main	Standard cle	earance	Cle	earance limit		
	bearing and crankshaft journal	0.075 to (0.150		0.32		
4	Interference between main	Standard inte	erference	Inte	erferencelimit		
	bearing cap and cylinder block	0.080 to 0	.1.60		0.05		
	Inside diameter of camshaft	Standard size	Toler	rance	Repair limit	Repair or	
	bushing	72	+0.	070	72.10	replace	
5			0				
	Clearance between camshaft	Standard cle	arance	Cle	earance limit		
	and journal	0.080 to (0.180		0.24		
6	Distortion of cylinder head	Tolerand	ce	Repair limit		1	
	face	0.09			0.15		
		Order	Target valu	ie (kgm)	Range (kgm)		
		1st	5	6	51 to 61		
7	Tightening torque of main2nd113		3	107 to 118			
	bearing cap bolt	3rd	Loosen co		mpletely	Tighten	
	(Coat bolt threads with	4th 38		8	33 to 43		
	engine oil)	5th	7	5	70 to 80		
		6th	11	3	107 to 118		


CYI				P	Cylinder liner Deteil F	Cylinder block
No.	Check item		Crite	eria		Remedy
1	Protrusion of cyliner liner	Permissible renge: 0.07 to 0.15 Difference among cylinder: 0.05 max.				Replace inder liner or block
2	Inside diameter of cylinder	Standard size	Toler	ance	Repair limit	
	liner	170	+0 0	.04	170.24	
	Roundness		Repair lir	nit: 0.020)	
	Cylindricity		Repair lir			
	Outside diameter of cylinder	Standard s	ize		Tolerance	1
3	liner (Counter bore lower part) Interference of cylinder liner	194.59		194.5	565 - 194.615	_
	and block (Counter bore lower part)	Standard	interferer	ice: 0.02	5 to 0.135	Replace cylinder
	Outside diameter of cylinder	Standard s	ize	,	Tolerance	liner
	liner	205.99		205.	965 - 206.015	
4	(Counter bore part)					
	Clearance between cylinder	Ir	terferenc	e: 0.085	to	
	liner and block		Clearanc	e: 0.025		
	(Counter bore part)					
	Outside diameter of cylinder	Standard s	ize		Tolerance	_
	liner	190.4		190	0.34 - 190.40	
5	(O-ring part)					_
	Clearance between cylinder liner and block (O-ring part)	Standar	d clearan	ce: 0.050	0 to 0.210	
6	Unevenness of counter bore	Toleranc	e	R	epair limit	Repair by
-	depth	-			0.03	grinding
	1 *	1				

CRNAKSHAFT




No.	Check item			Crit	eria			Remedy	
		Size	Stan	dard size	Tolerar	nce	Repair limit		
		S.T.D.	S.T.D. 140.00				139.91		
1	Outside diameter of main	0.25US	1	39.75	0		139.66		
	journal	0.50US	1	39.50	-0.02	5	139.41		
		0.75US	1	39.25			139.16		
		1.00US	1	39.00			138.91	Repair or	
		S.T.D.	1	08.00			107.91	replace	
2	Outside diameter of crank	0.25US	1	07.75	0		107.66		
	pin journal	0.50US	1	07.50	-0.02	0	107.41		
		0.75US	1	07.25			107.16		
		1.00US	1	07.00			106.91		
				Stan	dard]	Repair limit		
3	Journal roundness	Main jourr	nal	max. (0.010		0.085		
		Pin journa	al	max. (0.010		0.065		
		Tole	erance	e]	Repai	irlimit		
4	End play	0.140	to 0.1	320		0.6	59		
		Standard siz	ze	Toleranc	e Sta	ndar	d interference	Replace	
5	Main bearing thickness(Center)	4		-0.040		,	3.90		
				-0.050					
6	Outside diameter of rear flange	170		±0.020			-		
7	Bend of crankshaft	To	oleran	ice]	Repai	irlimit		
	(by indicator)		0.09			0.2	20		
8	Tightening torque of crank			See page	14-047			Tighten	
	pulley mounting bolt								

CAMSHAFT



No.	Che	eck item		Crite	eria		Remedy
			Standard size	Tole	rance	Repair limit	
		Intake side	62	+0.4	440	61.37	Repair or
1	Cam height			+0.2	240		replace
		Exhaust side	61	-0.3	310	59.64	
				-0.5	510		
2	Outside diame	eter of journal	72.00	-0.0	080	71.86	
				-0.1	10		Replace
3	Thrust plate th	nickness	10.00	-0.0)25	6.85	
			-0.06)60		
4	Camshaft end	play	Standard clearance		ance Clearance lin		Replace
			0.075 to 0.240			0.40	thrust plate
5	Bend of cams	haft	Repair limit: 0.20 (by indicate			ator)	Replace


TIMING GEAR



				9		13	τ	Jnit : mm
No.	Check item				Cr	iteria		Remedy
		Posi- tion	Me	easuring	ooint	Standard	Repair limit	
		A	Crank g	gear and i	dler gea	ur 0.14 to 0.46		
		В	Main id idler gea	ler gear (ar	large) aı	nd 0.013 to 0.47	,	
		С	Main id cam gea	ler gear (s ar	small) a	nd 0.13 to 0.47		
		D		ler gear (s n pump g	,	nd 10 to 0.50		Replace
		a	Cam ge drive ge	ear and co	mpress	or		
		b	-	ump idle rive gear	r gear a	nd 0.095 to 0.46		
		с	Crank g	gear and c ar	oil pump	0.12 to 0.425		
		d		np idler ge p drive ge		0.10 to 0.445		
		Stand	lard size	Tole	ance	Stadard	Clearan-	
7	Clearance between main idler			Shaft	Hole	Clearance	ce limit	
	gear bushing and shaft		47	+0.600	+0.695	5 0.045 to 0.095		
				+0.585	+0.630)		Replace
8	Clearance between idler gear		47	+0.600	+0.695	5 0.045 to 0.095		bushing
	bushing and shaft			+0.585	+0.630			4
9	Clarance between oil pump		47	+0.600		5 0.045 to 0.095		
	idler gear bushing and sahft			+0.585	+0.630			
10	End play of main idler gear			clearance	2	Clearance lin	mit	Replace
				to 0.32				thrust
11	End play of idler gear			to 0.32				bearing
12	End play of oil pump idler gear		0.101	to 0.32	1	0.15		
13	Difference of timing gear case and cylinder block lower step			10	olerance	: 0.15		Replair or replace


PISTON, PISTON RING AND PISTON PIN

ALUMINIUM PISTON TYPE




								unit: mm	
No.	Check item		Criteria						
1	Outside diameter of piston	Standa	Standard size		Tolerance		Repair limit		
	(3.0 mm from bottom and	1	170		-0.25	7	169.62		
	at 20° C)				-0.28	7			
					Tolerace				
			Standard s	ize	Ring	Ring	Clearance limit		
					groove	thickne	ss		
2	Piston ring groove	Top ring	Keyston	e	Check w	ith pisto	n 0.15		
		2nd ring	Keyston	stone groove wear gaug		ge Clearance			
							with new ring		
		Oilring	4.80		±0.010	-0.50	0.3	Replace	
						-0.07	5		
				Standard clearance		learance	Clearance limit		
3	Piston ring gap	Тор	ring		0.50 -	0.65			
		2nd	ring		0.45 -	0.60	1.8		
		Oil	ring		0.50 -	0.70			
4	Inside diameter of piston	Standa	Standard size		Tolera	ince	Repair limit		
	pin boss		68		+0.0	14	68.04		
					+0.00)4			
5	Outside diameter of piston		68		0		67.98		
	pin				-0.00	6			

CONNECTING ROD




No.	Check item			Cri	teria			Remedy
1	Clearance betwen conne-	Standard	Tole	rance	Star	dard	Clearance	Replace (the
	cting rod bushing and	size	Shaft	Hole	Clea	rance	limit	bushing is
	piston pin	68	0	+0.070	0.050	- 0.075	0.11	supplied as a
			-0.060	+0.050				semi-finished
								Product)
2	Inside diameter of conne-	Sta	andard siz	e	,	Tolerand	ce	
	cting rod big end		115			+0.023	5	
						0		
3	Clearance between inside	Stand	ard cleara	ince	Cle	earance	limit	
	diameter of connecting	0.0)60 - 0.13	30	0.34			
	rod big end and crankshaft							
	journal							
		Size	Stan	dard size	Toleran	ice 1	Repair limit	
		S.T.D.	3.	500			3.41	
4	Connecting rod bearing	0.125U	S 3.	625	-0.04	-0	3.54	
	thickness (Center)	0.250U	S 3.	750	-0.03	0	3.66	
		0.375U	S 3.	875			3.79	
		0.500U	S 4.	000			3.90	
5	Bend or twist of connec-		-	air limit o				
	cting rod		Repair limit of twist: 0.25					
6	Connecting rod weight			10.15 ± 0	0.03 kg			
7	Tightening torque of	Ord	ler	Target	(kgm)		ge (kgm)	
	connecting rod cap	1st	t		0		9 - 21	Tighten
	(Coat bolt and nut threads	2n	d	9	0°	90	° -105	
	with engine oil)							

OIL PUMP




No.	Check item		Criteria						
10.	Check Item		Criteria						
		Standard	Tole	rance	Standard	Clearance			
1	Clearance between drive	size	Shaft	Hole	Clearance	limit			
	shaft and bushing	32	-0.025	+0.035	0.040 to 0.075	-			
			-0.040	+0.015					
2	Clearance between driven	30	-0.020	+0.030	0.030 to 0.070				
	shaft and driven gear		-0.035	+0.010			Replace		
	bushing								
3	Clearance between outside	71.95	0	+0.170	0.085 to 0.125				
	diameter of gear and body		-0.030	+0.120					
4	Main pump gear and body	66	-0.095	+0.035	0.095 to 0.15]		
	end play		-0.115						
5	Tightening torque of	69 ± 1.0 kgm				Tighten			
	mounting bolt								

OIL PUMP RELIEF VALVE, PISTON COOLING VALVE AND OIL COOLER BY-PASS VALVE



No.	Check item			Criteria			Remedy	
		S	Standard size Repair limit					
1	Main relief valve spring	Free	Installed	Installed	Free	Installed		
		length	length	load	length	load		
		73.77	72.0	2.37 kg				
2	Regulator valve spring	21.5	17.6	2.97 kg				
3	Piston cooling valve	128.31	102.12	7.1 kg			Replace	
	spring (Check valve)							
4	Oil cooler by-pass valve	75.0	72.0	6.0 kg				
	spring							
5	Main relief valve operating		Standard	l: 3.3 ± 0.3 k	g/cm ²			
	pressure							
6	Regulator valve operating		Standard	l: 8.0 ± 0.8 k	g/cm ²		Repair or	
	pressure						replace	
7	Piston cooling valve oper-		Standard: $1.3 + 0.3$ kg/cm ²					
	ating pressure			-0.1				
8	Oil cooler by-pass vavle		Standard: 4.5 ± 0.5 kg/cm ²					
	operating pressure							

WATER PUMP



unit: mm

No.	Check item		Criteria					
		Standard size	Toler	rance	Standard			
1	Interference between front	Shaft	Hole	interference				
	shaft and bearing	30	+0.015	0	0 to 0.025			
			0	-0.010				
2	Interference between rear	25	+0.010	0	0 to 0.020			
	shaft and bearing		0	-0.010		Replace		
3	Interference between rear	19.9	+0.020	-0.025	0.030 to 0.070			
	shaft and ompeller		+0.005	-0.05				
4	Clearance between impe-	Standard clearance		Clearance limit]		
	ller and connection	0.23 to 0.66		-		1		

BS(A)6D170-1


ENGINE 16 REPAIR AND REPLACEMENT OF PARTS



CYLINDER HEAD SECTION

Cylinder head	16-002
Testing and inspecting	16-003
Repairing mounting face of	
cylinder head by grinding	16-005
Replacing valve seat inserts	16-006
Replacing nozzle holder sleeve	16-010
Replacing vavle guide	16-014
Replacing cross head guide	16-015
Grinding the valve	16-016
CYLINDER BLOCK SECTION	
Grinding the top surface of	
cylinder block	16-017
Replacing main metal cap	16-018
Replacing the crankshaft	16-019
Replacing cam bushing	16-023
Replacing crankshaft gear	16-025
Replacing cam gear	16-026
Replacing flywheel ring gear	16-026

CYLINDER HEAD



- 1. Valve guide
- 2. Cross head guide
- 3. Fuel injection nozzle sleeve
- 4. O-ring
- 5. Cylinder head
- 6. O-ring
- 7. Pushrod tube
- 8. Valve sea insert

TESTING AND INSPECTING

(1) Cylinder head

Unit:mm

		Unit:mm
Inspection item	Judgement standards	Remedy
A.Cracks, leakage from cylinder head	 Check for cracks (external color check) Check for air leakage with air pressure test (3.0 - 3.5 kg/cm², 30sec.) Water pressure test (3.5 - 4.0 kg/cm², 10 min.) 	Repair by welding or replace
B. Distortion of top bottom surface of cylinder head	ToleranceRepair limitMax. 0.050.1	Grind to correct
C.Damage to injection nozzle sleeve seat surface, contact width		Machine to repair or replace sleeve
D.Protrusion of injection nozzle	Permissible range: 4.9 - 5.7	Replace sleeve
E. Damage to valve seat surface or loosening of seat	 Pitting of seat surface Check contact between valve and seat surface Airtighteness test Tap cylinder head and check for looseness 	Correct se- at surface or replace valve seat
F. Sinking of valve (both intake and exhaust)	sinking Standard value Repair limit 0.9 - 1.5 2.1	Replace valve or valve seat
G Thickness of valve head	Angle of seat surface Thickness of valve head . Thickness of valve head . Standard value Intake valve 3.4 2.9 Exhaust vavle 3.5 3.1 . Angle of seat surface Intake valve : 30° Exhaust valve : 45°	Replace

CYLINDER HEAD SECTION

Unit	:	mm

Inspection item	Judgement standards	Remedy
H.Abnormality in valve	 Check if head has becomes flat, check or pitting of seat surface Airtightness test Check for play in cotter pin when new cotter pin is inserted in cotter groove 	Replace
	. Check for eccentric wear or curvature of stem.	Correct
I. Outside diameter of vavle stem	Outside diameterStandard sizeStandard valueRepair limit1211.908 - 11.89311.80	Replace
J. Inside diameter of vavle guide	Standard sizeStandard valueRepair limit1211.981 - 11.99912.10	
K.Protrution of valve guide	Protrusion Permissible renge : 23.4 - 23.9	Replace
L. Outside diameter of crosshead guide	Standard sizeStandard valueRepair limit1515.028 - 15.03915.00	
M. Protrusion of crosshead guide	Crosshead guide Cylinder head	Correct

REPAIRING MOUNTING FACE OF CYLINDER HEAD BY GRINDER


Grinding

- 1) Remove the valve seat inserts. For details, see REPLACING VALVE SEAT INSERTS.
- Remove the nozzle holder sleeves. For details, see REPLACING NOZZLE HOLDER SLEEVS.
- 3) Grind the cylinder head to remove the strained or corroded portion within the limit of the height of the cylinder head (H).
 - ★ Repair limit of cylinder head height (H): 139.55 mm
 - Amount to remove per grinding:
 0.10 to 0.1 mm
 - * Surface roughness of grinding surface: within 6S
 - ★ Flatness (deformation): 0.05 mm max.
 - ★ Grinding limit: 0.3 mm
 - ***** Difference in head height per unit:
 - 0.15 max.
- 4) Press-fit the one-size-larger inserts. For details, see REPLACING VALVE SEAT INSERTS.
- 5) Press-fit the nozzle holder sleeves. For details, see REPLACING NOZZLE HOLDER SLEEVES.

Check after grinding

Check the sinking of the valves and the protrusion of the nozzles are within the standard valves.

- ***** Standard sinking of valves : 0.9 to 1.5 mm
- * Allowable protrusion of nozzle : 4.9 to 5.7 mm




REPLACING VALVE SEAT INSERTS

Special tools required


Symbol	Part No.	PartName	Qty.
А	795-100-4800	Valve seat puller	1
В	795-100-3002	Valve seat cutter	1
С	795-600-2510	Push tool	1
		(for intake valve)	
С	795-600-2520	Push tool	1
		(for exhaust valve)	
D	795-600-2530	Calking tool	1
		(for exhaust valve)	
D	795-600-2540	Calking tool	1
		(for exhaust valve)	
D	795-602-2510	Body	1

When repairing the cylinder head without removing the valve seat inserts, see the following figures.

• Intake valve




• Intake valve



1. Pulling out the valve seat insert


- 1) Using the grinder of valve seat puller A, make grooves on the inserts to pull them out according to the following procedure.
 - ★ Set the air pressure to 5 to 6 kg/cm².
 - When replacing the grindstone of the grinder, shut off the compressed air.
- Before using the grinder, run it for a minute to set test it.
 - After replacing the grindstone, run the grinder for three minutes to test it.
- Confirm that the grindstone is not damaged, then install it to the shaft of the grinder without applying excessive force. Confirm that there is no play between the grindstone and shaft.
- When using the grinder, wear safety goggles.
 - i) Install grindstone (5) to grinder (1).
 - ii) Install the sleeve and grinder after align ing the groove of sleeve(3) with holder
 (2). Adjust th position of the grinder with set screw (4).





- iii) Adjust the position of the grinder so that the center of grindstone (5) will be at the center of seat insert (1), then tighten the set screw to secure the grinder.
- iv) Fully open the throttle of the grinder to rotate the grinderstone and slowly move it until it contacts insert (1).
- v) Press the grindstone against the inside of the insert, move it in a circuar pattern, and make a groove about 1 mm deep.


- 2) Pull out the insert with the puller head of valve seat puller **A** according to the following procedure.
 - i) Push three claws (a) of puller head (6) inward by hand and put them in insert(1).
 - ii) Tighten screw (8 to press the three claws against the groove on the inside surface of the insert.
 - ★ If the screw is tigtened too strongly, the insert will break and it will be difficult to pull itout. Therefore, stop tightening the screw when the claws completely contact the groove.
 - iii) Place birdge 9 over the puller head, then place plates 10 and 11 on the bridge. Tighte nut 12 to pull out the insert.

CYLINDER HEAD SECTION











2. Machining valve seat insert mounting hole to oversize

- 1) Using valve seat cutter B, machine the mounting hole to install a one-size-lager insert.
- Dimensions of insert and monting hole





• Intake valve side

Unit: mm

Stamp on insert	inser O.D. (d ₁)	t Hight(h ₁)	Mounting h I.D. (d_2)	ole for insert Depth(h ₂)
S.T.D.	63.00 ^{+0.100} +0.080	8.5 ⁰ _{-0.1}	63.00 ^{+0.020} -0.010	12.5 ± 0.1
0.25 O.S	63.25 ^{+0.100} _{+0.080}	8.5 ⁰ _{-0.1}	63.25 ^{+0.020} -0.010	12.5 ± 0.1
0.50 O.S	63.50 ^{+0.100} +0.080	8.62_0.1	63.50 ^{+0.020} - 0.010	12.62 ± 0.1
0.75 O.S	63.75 ^{+0.100} +0.080	8.75 ⁰ _{-0.1}	63.75 ^{+0.020} - 0.010	12.75 ± 0.1
1.00 O.S	64.00 ^{+0.100} +0.080	8.88 ⁰ _{-0.1}	64.00 ^{+0.020} -0.010	12.88 ± 0.1

• Exhaust valve side


Unit: mm

Stamp	insei	t	Mounting hole for inser	
insert	O.D. (d_1)	$Hight(h_1)$	I.D. (d ₂)	$Depth(h_2)$
S.T.D.	61.00 ^{+0.100} _{+0.080}	8.5 ⁰ _{-0.1}	61.00 ^{+0.020} - 0.010	12.5 ± 0.1
0.25 O.S	61.25 ^{+0.100} _{+0.080}	8.5 ⁰ _{-0.1}	+0.020 61.25-0.010	12.5 ± 0.1
0.50 O.S	61.50 ^{+0.100} _{+0.080}	8.62 ⁰ _{-0.1}	+0.020 61.50 - 0.010	12.62 ± 0.1
0.75 O.S	$61.75 \begin{array}{c} +0.100 \\ +0.080 \end{array}$	8.75 ⁰ _{-0.1}	61.75 ^{+0.020} - 0.010	12.75 ± 0.1
1.00 O.S	62.00 ^{+0.100} +0.080	8.88 ⁰ _{-0.1}	62.00 ^{+0.020} - 0.010	12.88 ± 0.1

- ★ Inside surface roughness: 12.5S max.
- ★ Mounting hole bottom roughness: 12.5S max.
- ★ Concentricity of inside diameter of valve guide and inside diameter of insert hole: 0.05 mm (T.I.R) max.
- ★ Rectangularity of inside diameter of valve guide and bottom of insert hole :

:0.03 mm (T.I.R) max.


CYLINDER HEAD SECTION




2) If the calked portion of the mounting hole, is damaged remove it within the range of 1.00mm oversize. If the damage portion cannot be removed within the range of 1.00 mm oversize, replace the cylinder head.

3. Press fitting the insert

1) Using insert push tool **C**, Press-fit the insert (1).



- 2) Check the sinking distance of the insert from the mounting, surface of the cylinder head.
- Standard sinking distance of insert:
 3.9 to 4.2 mm.



4. Finishing seat surface


- 1) Using valve seat cutter B, finish the seat surface to the dimensions shown in the diagram.
 - ★ Seat surface angle Intake : 30° Exhaust : 45°
 - ★ Seat finishing width Intake : 3.69 mm
 - Exhaust : 3.79 mm
 - ★ Concentricity of valve guide and insert Within 0.07 mm (T.I.R.)
- 2) Rub the seat surface with compound.
 - ★ Standard sinking of valve (new part):
 - 0.9 1.5 mm
 - Checking width of contact with valve New part (reference value)
 - Intake : 2.5 ± 0.2 mm
 - Exhaust : $2.8 \pm 0.2 \text{ mm}$


Final inspection


- Coat the seat surface of the new valve thinly with red lead (minimum), insert it inthe valve guide, push lightly against the valve insert surface, and rotate 10°. Check the valve insert contact surface, and confirm that the contact is uniform without any breaks.
- Another way is to make marks with a pencil on the seat surface of the new valve as shown in the diagram below, insert it in the valve guide, push lightly against the valve insert surface, and rotate10°. Check that the pencil marks have been erased uniformly around the whole circumference.
- When carrying out an airtighteness test wih a vacuum tester, test as follows.
 - 1) Wipe off all the dirt, dust and oil from the valve and valve seat surface with a cloth.
 - 2) Assemble the cylinder head as specified, then tap the tip of the valve stem with a plastic hammer 2 or 3 times directly fom above to bring it into tight contact with the seat surface.
 - Fit a vacuum cup that matches the size of the valve in tight contact with the head surface.
 When doing this, to improve the airtightness of the vacuum cup, coat grease on the O-ring

fitted to the vacum cup, and fit it in tight contact with the flat surface of the head.

- ★ Be careful not to get any grease on the seat surface.
- Set the vacum gauge, and check that the pressure drops less than 10 mmHg in 3 seconds. If it drops more than 10 mmHg in 3 seconds, check for any dirt on the seat surface, or rub the surface to correct it.







REPLACEING NOZZLE HOLDER SLEEVE

Special tools required

No.	Part No.	Part Name	Qty.
А	795-600-2110	Push bar	1
В	795-600-1191	Push bar	1
С	795-600-2120	Sleeve driver	1
G	795-600-2140	Sleeve expander	1
Н	795-600-2150	Sleeve expander	1
Ι	795-600-2160	Sleeve cutter	1
J	795-600-2170	Guide bushing	1
Κ	795-600-1151	Sleeve expander	1

1. Cutting hoel at bottom of sleeve

• Insert drill (Ø12 mm) (1) into the hole at the bottom of the sleeve, and drill the hole diameter.


2. Removing sleeve


- 1) Insert push bar A inside the sleeve.
- Apply oil and use sleeve removal tap⁽²⁾ to make a tap to approx. 25 mm from the end face at the top of the sleeve.
 - ★ Removal tap: M32, P=2.0
- 3) Insert push bar B from the bottom surface of the head, and tap with a hammer to remove the sleeve.
- 4) Remove all the remaining sleeve material stuck in the tap of portion.
- 5) Remove O-ring (2).


3. Press fitting sleeve


- 1) Insert O-ring (2) in the O-ring groove.
- 2) Insert sleeve (1) in the cylinder head, then use sleeve driver **C** and tap in until the sleeve
 - ★ Clean the sleeve and seat completely.
 - ★ Coat the seat portion on the otside circumference of the sleeve with adhesive.

Adhesive: LT-2









CYLINDER HEAD SECTION

4. Rolling sleeve taper portion


- Using sleeve expande **H**, roll the sleeve taper portion.
 - ★ Install sleeve expander H to a radial drilling machine or upright drilling machine, push the roller portion at the top strongly against the sleeve taper portion, and roll for approx. 20-25 sec. Check that the rolling surface is being rolled, and repeat the operation 2 - 3 times.
 - ★ Rotating speed : 200 300 rmp
- Compressing hole at bottom of sleeve
 Using sleeve expander G, roll the hole (portion (P)) at the bottom of sleeve (1).
 - ★ With the shank of sleeve expander G pulled up and the roller portion at the tip coming out slightly from the bottom hole, adjust the mounting position with bearing collar ④ of the tool.
 - ★ Install sleeve expander G to a redial drilling machine or upright drilling machine, push in a a little at a time, and roll to the standard dimension.


Note: Install sleeve sxpander **G** to the drilling machie with the shank pulled up.


- ★ Rotating speed : 200 300 rmp
- * Diameter of bottom hole after rolling : $\emptyset 9.7 + 0.015 \text{ mm}$
- 6 Repeat the procedure in Stop 4 and roll the sleeve taper portion again.

7. Rolling hole at top of sleeve

- Using sleeve expander **K**, roll the (portion **Q**) at the top of sleeve (1).
 - ★ With the shank of sleeve expander K pulled up, push in the roller portion at the tip to a depth where the whole of portion (②) can be rolled, and adjust the mounting position with bearing collar (⑥) of the tool.







- ★ Allow the shank to sink under its own weight, and note the position (measure dimension *l*).
- ★ Install sleeve expander K to a radial drilling machine or upight drilling machine, and after allowing the shank to sink under its own weight, push it lightly and carry out rolling to a position 4 - 6 mm lower.

Note: Install sleeve expander **K** to the drilling machine with the shank pulled up.


★ Rotating Speed : 100 - 200 rpm

8. Spot facing seat portion inside sleeve

- 1) Using guide bushing **J** as a guide, carry out spot facing of the seat portion with sleeve cutter **I**.
- ★ When cutting the seat surface, use a holder and dial gauge to measure the protrusio of the nozzle, cut and check a little at a time so that the protrusion of the nozzle comes within the standard value.
- ★ Rotating speed : 500 600 rpm
- ★ Protrusion of nozzle : 4.9 5.7 mm
- 2) Remove all dirt and metal particles from the finished surface.

9 Checking for leakage from seat surface

- Carry out an air pressure test (or wate pressure test) to check for leakage from the sleeve seat surface.
- When using the air pressre test, apply air pressure (4 ± 0.3 kg/cm²) for 30 seconds. There must be no leakage.
 - ★ When checking for leakage from the seat surface, install a used nozzle holder.



Water pressure testing method

• If the area around the head has been corrected, test as follows.

Special tools required

Symbol	Part No.	Part Name	Qty.
Α	790-553-1700	Coolant tester kit	1
В	79A-471-1050	Pump assy.	1

1. Checking for leakage from seat surface

- 1) Tighten the nozzle holder assembly to the specified torque.
- 2) Assemble tool **A** and tool **B**, and connect a hose to flange (1).
- 3) Apply water pressure (3.5 4.0 kg/cm²) for appox. 10 minutes, and check for any leakage from around the head.
- ★ It is preferable to warm the whole cylinder head and carry out the test with hot water (82 - 93° C).

2. Air pressure test

- 1) Tighten the nozzle holder assembly to the specified torque.
- 2) Connect the pump hose to flange (1).
- Place the head in a water bath, appl air pressre (3.0 - 3.5 kg/cm²) for approx. 30 seconds, and check for any air leakage in the water.
- ★ It the above test shows that there are cracks around the nozzle holder and plugs, replace the cylinder head.

в


REPLACING VALVE GUIDE

Special tools required

Symbol	Part No.	Part Name	Qty.
А	795-600-2550	Valve guide remover	1
В	795-600-2560	Valve guide driver	1


1. Removing the valve guide

• Remove the guide with valve guide remover A.



2. Press-fitting the valve guide

- 1) Press-fit the valve guide until the tip of valve guide driver **B** contacts the cylinder head.
- 2) Confirm that the protrusion of the valve guide is within specification.
 - * Protrusion of valve guide: $23.7^{+0.2}_{-0.3}$ mm
 - ★ Cylinder head valve guide inside diameter:19 + 0.021 mm 0



REPLACING CROSS HEAD GUIDE

Special tools required


Symbol	Part No.	Part Name	Qty.
А	795-140-6410	Cross head guide puller	1

1. Removing the cross head guide

- Using cross head guide puller **A**, pull out the cross head guide.
 - 1) As shown in the figure, hold the cross head guide with collet (5) of the puller.
 - 2) Tighten the collet with bolt ① to lock sleeve ②
 - 3) Rotate nut(3) and pull out the cross head guide.
 - 4) Remove burrs, fins, etc. from the mounting place of the cross head guide and clean it.

2. Press-fitting the cross head guide

- Insert the cross head guide in the cylinder head, then hit it into the cylinder head with a copper bar or plastic hammer until its protrusion is within specification.
 - ★ Protrusion of cross head guide Tolerance: 54 ⁰/_{-0.3} mm
 - Inside diameter of crosshead guide hole:15 + 0.018 mm 0



GRINDING THE VALVE


Special tools required

Symbol	Part No.	Part Name	Qty.
А	- (Purchase)	Valve refacer	1

1. Grinding the seat surface

- Grind the seat surface with valve refacer A.
 - ★ Angle of valve seat :

Intake valve : 30° Exhaust valve : 45°



2. Checking after grinding


• Confirm that the thickness of the valve head, protrusion of the valve, and the contact surface of the valve seat are within specification.

*	Thickness of valve head		
	Repair limit		
	Intake valve	:	Min. 2.9 mm
			(Standard size 3.4 mm)
	Exhaust valve	:	Min. 3.1 mm
			(Standard size 3.5 mm)

- ★ Sinking of valve Standard : 0.9 1.5 mm Repair limit : 2.1 mm
- ★ Check the contact of the valve with the seat surface using one of the following methods.
 - Coat the seat surface of the ground valve thinly with red lead (minimum), insert it in the valve guide, push lightly against the valve insert surface, and confirm that the contact is uniform without any breaks.
 - Make marks with a pencil on the seat surface of the ground valve a sshown in the diagram, insert it in the valve guide, push lightly against the valve insert surface, and rotate 10°. check that the pencil marks have been erased uniformly around the whole circumference.







GRINDING THE TOP SURFACE OF CYLINDER BLOCK

1. Grinding


- Grind off the strained and corroded portions of the cylinder block within the allowable height (H) of the cylinder block.
 - ★ Allowable height (H) of cylinder block:
 - 509.84 mm
 - * Grinding depth/time: 0.03 to 0.08 mm
 - * Roughness of ground surface:
 - * Flatness (deformation): 0.09 mm max.

If grinding with a grindstone(for reference)

- * Speed of grindstone: 1,650 to 1,90m/min.
- * Speed of table: 15 to 30 m/min.
- * Grinding depth/time: 0.025 mm
- * Cross feed/time: 1 to 2 mm
- ★ Grindstone: A46IV
- * Grinding lubricant: Water-soluble grinding lubricant

2. Checking after grinding

- Check the protrusion of the cylinder liner. If it is out of specification, repair the counterbore. For details, see REPAIRING THE COUNTERBORE.
 - ★ Protrusion of cylinder liner Allowable range: 0.07 to 0.15 mm Difference among cylinders: 0.05 mm max.



REPLACING MAIN METAL CAP

 When replacing the main metal cap, machine the semi-finished part according to the following procedre.


1. Machining the bore of main metal cap

- 1) Remove the cylinder liner.
- 2) Install the replacement metal cap to the cylinder block and tighten it to specification.

		Unit: kgm
Step	Target	Range
1st	56	51 - 61
2nd	113	107 - 118
3rd	0	Completely loosen
4th	38	33 - 43
5th	75	70 - 80
6th	113	07 - 118


Mounting bolt for main metal cap:

- ★ Align the notches on the cylinder block and cap.
- 3) Set the jig for mounting the cylinder the cylinder block to the table of a horizontal boring machine. Install the cylinder block by mounting its hole for the liner to the datum plug of the jig.




 Center the arbor of the boring machine by applying a dial gauge to the inside wall of the two metal caps which have the largest pitch in the metal caps to be used again.

- 5) Cut the inside of metal cap (1) little by little while checking its inside diameter.
- Cut until the cutting tool contacts the inside wall of cylinder block (2).
- * Inside diameter of main cap:148 $^+$ 0.025
- * Surface roughness: 3.3S max.
- ★ Never cut the inside wall of the cylider block.



2. Correcting the width of the main metal cap

- Insert cast iron bushing (6), and pass arbor (7) through.
- 2) Install facing tool (8) to the arbor.
- 3) Cut cap (9) until the cutting tool contacts the cylinder block.
- 4) Cut the opposite side in the same way.
 - * Width of main cap: $56 \frac{0}{-0.030}$ mm
 - * Roughness of surface facing thrust metal: 12.5S max.
 - \star Never cut the cylinder block.




REPAIRING THE CRANKSHAFT

• If the crankshaft is worn or slightly seized or damaged, cut it to any one of the following thicknesses.

Undersize dimensions : 0.25, 0.50, 0.75, 1.00 mm


- If the crankshaft is bent or worn unevenly, replace it instead of repairing it. (A lot of skill is required to repair it.)
- Only the following sections can be repaired by plating.
 - 1. Rear seal journal
 - 2. Section to which crank gear is installed
- Carefully finish section **R** of the fillet of the crankshaft, section **r** on the shoulder, and section **R** facing the hole.
- Dimension of fillet



• Dimension of oil hole on journal




Pin journal



The width of the connecting section of the oil holes must be at least 2.0, and the surface roughness must be 1.6S at maximum. Other surface of the round section must be finished within 6S.

- Tolls and jigs required for cutting
 - 1) Magnetic flaw detector
 - 2) Shore hardness tester
 - 3) Etching kit
 - 4) Crankshaft cutting machne
 - 5) Crankshaft grinding machine
 - 6) Roughness gauge
 - 7) Ball gauge for measuring radii of fillets For minimum value : 795-500-1140 For maximum value: 795-500-1150
- 1. Check before cutting
 - Visual check
 Check for cracks, damage, seizure, discoloration, wear, etc. to see if it can be repaired.
 - 2) Hardness test of journal
 - Hardness of journal (Shore hardness)Allowable range : 60 to 67 HsLimit : 60 HsIf the hardness is below the limit, dispose ofthe crankshaft.
 - 3) Torsion test



Throw of eccentric: $85_{-0.15}^{0}$ mm


Limit of horizontal displacement (Difference in throw of eccentric between No. 1 cylinder and the rearmost cylinder): **0.94 mm**

Dispersion of throws of eccentric among cylinders : 0.20 max.

If the above values are out of specification dispose of the crankshaft.


2. Check during and after cutting

- 1) Checking the round sections of fillets
 - i) Confirm that the round sections of fillets are smoothly connected to the shoulders of journals.
 - ii) Using ball gauges for measuring the radii of the fillets, cofirm that each radii is between the minimum and maximum limits.



Minimum radius of fillet : 6.00 mm Maximum radius of fillet : 6.50 mm

- 2) Checking the seized surfaces by etching
- After cutting the journals, confirm that no parts were seized in the cutting pocedure by the etching test.
- If any seized part is found, cut the journal another 0.02 mm to apply the next undersize.
- After etching the journals, neutralize and wash the checked surface, then apply oil.
- 3) Magnetic flaw detecting
- Before sin the repaired crankshaft, confirm that there are no cracks on it by magnetic flaw detection.
- Check the fillets of journals which are put in the critical area of each web of the crank shaft especially carefully.



- 4) Measuring the bend (Alignment)
- Measure the bend of the repaired crankshaft.

CYLINDER BLOCK SECTION

- Measure the bend (alignment) at the following four places.
 - i) Overall length alignment:

	0.09mm max.		
ii) Adjoining alignment:	0.05 mm max.		
iii) Forward end alignment:			
	0.04mm max.		

- iv) Rear end alignment: 0.03 mm max.
- 3. Cutting the main journals

•

- ★ Cut all the main jornals to the same under size.
- ★ When cutting the main journals, count in the finishing allowance for grinding 0.007 to 0.008mm

Unit: mm Allowable error Size **Basic dimension** S.T.D 140.00 0.25 US 139.75 0 0.50 US 139.50 -0.025 0.75 US 139.25 1.00 US 139.00

Undersized of main journal

• Out of roundness and cylindricality of main journals (T.I.R)

Limit	:	0.015 mm
Allowable error	:	0.010 mm max.

BS(A)6D170-1

4. Grinding the thrust bearing surface

- ★ It is not always required to grind the front and rear thrust bearing surfaces to the same undersize.
- ★ If the thrust bearing surfaces have been ground, confirm that the end play of the crankshaft is within the allowable range (For details, see DISASSEMBLY AND ASSEMBLY).

Undersizes of thrust bearing surfaces

- 0	- Chacibizes of the use searing surfaces			
				Unit: mm
			Rear thrust bearing	
		surface		
		S.T.D	0.25 O.S	
Front thrust bearing surface	S.T.D	Basic Dimension	64 ^{+0.050} ₀	64.25 ^{+0.050} ₀
		Limit	64.060	64.310
	0.25 O.S	Basic dimension	64.25 ^{+0.050} ₀	64.50 ^{+0.050} ₀
	0.5	Limit	64.310	64.560

Squareness of thrust bearing surface (T.I.R) Limit: 0.04 mm Allowable error: 0.035 mm max.

CYLINDER BLOCK SECTION

5. Grinding pin journals

- ★ Grind all the pin journals to the same undersize.
- ★ When grinding, count in finishing allowance for grinding 0.007 to 0.008 mm.

• Undersizes of pin journal


		Unit: mm
Size	Basic dimension	Allowable error
S.T.D	108.00	
0.25 US	107.75	0
0.50 US	107.50	-0.020
0.75 US	107.25	
1.00 US	107.00	

 Out of roundness and cylindricality of pin journal (T.I.R)
 Limit: 0.015 mm


 Allowable error: 0.010 mm max

Correcting the width of th	na main jaurnal and

- 6. Correcting the width of the main journal and pin journal by grinding
- When correcting the worn surfaces of the main journals ansd pin journals. limit the grinding thickness to the minimum.
- Width of crank pin journal If cutting one side only: Standard: 72 0 mm Limit: 74.500 mm
 - Squareness of thrust bearing surface (T.I.R) Limit: 0.04 mm



- 7. Correcting the grindstone
- Dress the grindstone each time one journal is ground.
- Grindstone dressor Tip angl: 75°±1° Radius of edge: 0.38±0.25 mm At the edges of the dresser, a diamond for industrial use must be embedded.



- Adjust the machine for correcting the grindstone, and correct the edge of the grindstone to the radius of the fillet.
- When checking and correcting the grindstone edge, grind a wood bar for trial and use ball gauges.

8. Preventing seizure caused by grinding

- 1) Use the plunge grinding method.
- 2) Use the overall width of the grindstone Do not grind the bosses if possible.
- 3) Apply sufficient cooling oil.
- 4) Set the circuferential speed of the grindstone to 2,000 m/min when the speed of crankshaft is 50 rpm.

9. Surface finishing

- Standard surface roughness Journal, thrust bearing, fillet: 1.6S max. Tapered end, boss of pin and main journal:3.2S max.
- Finishing allowance for grinding: 0.007 to 0.008 mm.

10. Treatment after grinding

- Confirm that each dimension is within specification.
- Carefully wash each section and apply oil to it.
- When storing the crankshaft for a long time, support it at three points or hang it vertically.

11. Balancing (for reference)

(Do not perform any repair which will have an adverse effect on the balance of the crankshaft).

- Limit of unbalance: 110 g.cm
 - Limits of reading the balance correctly Bend of crankshaft: 0.05 mm (T.I.R) Speed of crankshaft: 325 rpm max.
- Balance the crankshaft with the crank gear installed or install a weight equivalent to the weight of the gear fixing key to the keyway.
- To balance the crankshaft, make a hole on the counter weight with a drill or cut it.
 Limit of amount of counterweight to be removed: 56 g.
 Number of holes: 5 max.
 Diameter of hole: 19mm max.

Depth of hole: 50 mm max. Distance between hole and side face: 5 mm min.

Distance among holes: 15° of central angle min.

REPLACING CAM BUSHING


Special tools required

N	0.	Part No.	Part Name	Qty.
Ā	Ι	795-250-1301 Push tool		1
	1	795-250-1310	Push bar	1
	2	795-250-1320	Push bar	1
А	3	795-250-1330	Push tool	1
	4	795-250-1360	Collar	1
	5	795-250-1350	Guide	1
	6	792-103-0400	Grip	1

★ When replacing the cam bushing, first remove the blind plug at the rear of the cylinder block.


1. Removal of No. 1, 7 bushings

As shown in the diagram, assemble push tool A3, collar A4, and grip A6, then hit the push bar to knock bushing (2) out from cylinder block (1).




2. Removal of No. 2, 6 bushings


Assemble push bar A2, push tool A3, collar A4, and guide A5, then hit the push bar to knock bush ing (3) out from cylinder block (1).



3. Removal of No. 3, 4, 5, bushings Assemble push bar A1, push tool A3, collar A4, and guide A5, then hit the push bar to knock bushing (4) out from cylinder block (1).



- After removing the bushing, remove any burrs or dirt, and clean the mounting hole of the bushing.
- ★ Cam bushing assembly drawing



1. Press fitting No. 3, 4, 5 bushings Assemble bushing (4) to tool A, and press fit the bushing until the oil hole of cylinder block (1) matches the oil hole of the bushing.


2. Press fitting No. 2, 6 bushing

Assemble bushing (3) to tool \mathbf{A} , and press fit the bushing unit the oil hole of cylinder block (1) matches the oil hole of the bushing.

3. Press fitting No. 1, 7 bushings

Assemble bushing (2) to tool **A**, and press fit the bushing until the oil hole of cylinder block (1) matches the oil hole of the bushing.

- Using inside gauge (1), measure the inside diam eter of the bushing.
- Check the clearance between the bushing and shaft, and if the clearance is not within the specified range, or the shaft does not move smoothly, correct the inside diameter of the bushing with reamer.
- When the inside diameter of the bushing has been corrected with a reamer, clean all the metal particles from the oil hole and oil groove.
- ★ Inside diameter cam bushing : see MAINTE-NANCE STANDARDS.



REPLACING CRANKSHAFT GEAR

Special tools required (or equivalent parts)

No.	Part No.	Part Name	Qty.
	790-101-2800	Bearing puller	1
2	790-101-2300	Bearing puller	1


1. Removal of gear


Make a scratch in the surface at the root of the teeth with a grinder, then assemble pullers①and ② and turn the nut to remove the gear.

- ★ If the gear cannot be removed in this way, make a scratch in the surface at the root of the teeth with a grinder, then heat the gear with a burner and knock the gear out with a copper rod.
 - ★ Be careful not to damage the shaft.

2. Press fitting gear

- 1) Check the gear mounting surface, key groove, and flange surface, and if there are any scratches, correct them with an oilstone.
- 2) Knock a new key into the key groove of the shaft.
- 3) Heat the gear for the specified time at the specified shink-fitting temperature.
 - ★ Crankshaft gear shink-fitting temperature: 200° C Heating time: Min. 30 minutes
- 4) Put the timing mark on the outside, then use a hitting tool to press fit until the side face of the gear is in close contact with the shaft flange.
 - Knock in quickly before the gear becomes cool.





REPLACING CAM GEAR

1 Removal of gear

Set the camshaft assembly on the press stand, then push the camshaft to remove the gear.



When setting the camshaft assembly on the press stand, be careful not to get your fingers caught between the press stand and the gear.

2 Press fitting gear

- 1) Check the gear mounting surface, key groove, and flange surface, and if there are any scratches, correct them with an oilstone.
- 2) Knock a new key into the key groove of the shaft.
- 3) Assemble the thrust plate.
- 4) Heat the gear for the specified time at the specified shrink-fitting temperature.
 - ★ Cam gear shring-fitting temperature: 200°C Heating time: Min.30 minutes
- 5) Put the timing mark on the outside, then use a hitting tool to press fit until the side face of the gear is in close contact with the shaft flange.
 - Knock in quickly before the gear becomes cool.

REPLACING FLYWHEEL RING GEAR



 \bigwedge Take care not to let the flywheel fall.

1. Removing the ring gear

Make a groove on the tooth bottom surface of the ring gear with a grinder, then crack the gear with a chisel.



2. Press-fitting the ring gear

- 1) Check the fitting surface of the ring gear. If any flaw is found, repair it with an oilstone.
- 2) Heat the ring gear at the specified temperature for the specified time for shrinkage fitting.
 - ★ Heating temperature for ring gear: Max. 200°C

Heating time: Min. 50 minutes

3) With the chamfered side of rin gear facing the flywheel, fit it until is side contact the flywheel.

