



SHOP MANUAL



BS6D125G1 DIESEL GENERATOR

**BEML LIMITED
MYSORE, INDIA.**

CONTENTS

00 SAFETY AND FORWARD 00-001

11 GENERAL 11-001

12 STRUCTURE AND FUNCTION 12-001

13 TESTING AND ADJUSTING 13-001



14 DISASSEMBLY AND ASSEMBLY 14-001

15 MAINTENANCE STANDARD 15-001



IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended by **beml** and described in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed by **beml** for the purpose.

To prevent injury to workers, the symbols  and  are used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.



SAFETY

GENERAL PRECAUTIONS

Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully BEFORE operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions given on the decals which are fixed to the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the opera

tion. Before starting work, hang UNDER REPAIR signs on the controls in the operator's compartment.

5. Keep all tools in good condition and learn the correct way to use them.
6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.

PREPARATIONS FOR WORK

7. Before adding oil or making any repairs, park the machine on hard, level ground, and block the wheels or tracks to prevent the machine from moving.
8. Before starting work, lower blade, ripper, bucket or any other work equipment to the ground. If this is not possible, insert the safety pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.

-
9. When disassembling or assembling, support machine with blocks, jacks or stands before starting work.
 10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.
 16. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.
 17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips on to the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.
 18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out. Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned. Wait for the oil and water to cool before carrying out any work on the oil or water circuits.
13. Before starting work, remove the leads from the battery. Always remove the lead from the oil or water circuits. negative (-) terminal first.
14. When raising heavy components, use a hoist or crane. Check that the wire rope, chains and hooks are free from damage. Always use lifting equipment which has ample capacity. Install the lifting equipment at the correct places. Use a hoist or crane and operate slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.
19. Be sure to assemble all parts again in their original places. Replace any damaged parts with new parts.
 - When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also, check that connecting parts are correctly installed.
21. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
22. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.
24. Take care when removing or installing the tracks of track-type machines. When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

FOREWORD

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into chapters for each main group of components; these chapters are further divided into the following sections.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating “Problems” to “Causes” are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your **beml** Regional Office for the latest information.

HOW TO READ THE SHOP MANUAL

VOLUMES

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

Chassis volume : Issued for every machine model

Engine volume : Issued for each engine series.

Electrical volume : } Each issued as one volume to cover all models

Attachments volume : }

These various volumes are designed to avoid duplicating the same information. Therefore to deal with all repairs for any model, it is necessary that chassis, engine, electrical and attachment volumes are ready.

DISTRIBUTION AND UPDATING

Any additions, amendments or other changes will be sent to **beml** Regional office. Get the most upto-date information before you start any work.

FILING METHOD

1. See the page number on the bottom of the page. File the pages in correct order.
2. Following examples show how to read the page number.

Example.

1 3 - 1 0

Unit number (1. Engine)
Item number (2. Testing and Function)
Consecutive page number

3. Additional pages: Additional pages are indicated by a hyphen (-) and number after the page number. File as in the example.

Example:

REVISED EDITION MARK (① ② ③ ...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

REVISIONS


Revised pages are shown at the LIST OF REVISED PAGES on the between the title page and SAFETY page.


SYMBOLES

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

| Symbol | Item | Remarks |
|--------|-------------------|--|
| | Safety | Special safety precautions are necessary when performing the work. |
| | | Extra special safety precautions are necessary when performing the work because it is under internal pressure. |
| | Caution | Special technical precautions or other precautions for preserving standards are necessary when performing the work. |
| | Weight | Weight of parts or systems. Caution necessary when selecting hoisting wire, or when working posture is important, etc. |
| | Tightening torque | Places that require special attention for the tightening torque during assembly. |
| | Coat | Places to be coated with adhesives and lubricants etc. |
| | Oil, water | Places where oil, water or fuel must be added, and the capacity. |
| | Drain | Places where oil or water must be drained, and quantity to be drained. |

HOISTING INSTRUCTIONS



Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is indicated clearly with the symbol 

1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:

- Check for removal of all bolts fastening the part to the relative parts.
- Check for existence of another part causing interference with the part to be removed.


2. Wire ropes

- 1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:


| Wire ropes (Standard "Z" or "S" twist ropes without galvanizing) | |
|--|-----------------------|
| Rope diameter (mm) | Allowable load (tons) |
| 10 | 1.0 |
| 11.2 | 1.4 |
| 12.5 | 1.6 |
| 14 | 2.2 |
| 16 | 2.8 |
| 18 | 3.6 |
| 20 | 4.4 |
| 22.4 | 5.6 |
| 30 | 10.0 |
| 40 | 18.0 |
| 50 | 28.0 |
| 60 | 40.0 |

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

- 2) Sling wire ropes from the middle portion of the hook.
Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result.



Hooks have maximum strength at the middle portion.



- 3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.




Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.

When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.





STANDARD TIGHTENING TORQUE



STANDARD TIGHTENING TORQUE

1. STANDARD TIGHTENING TORQUE OF BOLTS AND NUTS

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in section of “Disassembly and Assembly

| Thread diameter of bolt (mm) | width across flat (mm) |  |  |
|------------------------------------|------------------------------|---|---|
| | | kgm | Nm |
| 6 | 10 | 1.35±0.15 | 13.2±1.4 |
| 8 | 13 | 3.2±0.3 | 31.4±2.9 |
| 10 | 17 | 6.7±0.7 | 65.7±6.8 |
| 12 | 19 | 11.5±1.0 | 112±9.8 |
| 14 | 22 | 18.0±2.0 | 177±1.9 |
| 16 | 24 | 28.5±3 | 279±29 |
| 18 | 27 | 39±4 | 383±39 |
| 20 | 30 | 56±6 | 549±58 |
| 22 | 32 | 76±8 | 745±78 |
| 24 | 36 | 94.5±10 | 927±98 |
| 27 | 41 | 135±15 | 1320±140 |
| 30 | 46 | 175±20 | 1720±190 |
| 33 | 50 | 225±25 | 2210±240 |
| 36 | 55 | 280±30 | 2750±290 |
| 39 | 60 | 335±35 | 3280±340 |

This torque table does not apply to the bolts with which nylon packings or other non-ferrous metals washers are to be used, or which require tightening to otherwise specified torque.

★ Nm (newton meter): 1 Nm = 0.1 kgm


2. TIGHTENING TORQUE OF SPLIT FLANGE BOLTS

Use these torques for split flange bolts.

| Thread diameter of bolt (mm) | Width across flats (mm) | Tightening torque | |
|------------------------------------|-------------------------------|-------------------|----------|
| | | kgm | Nm |
| 10 | 14 | 6.7±0.7 | 65.7±6.8 |
| 12 | 17 | 11.5±1 | 112±9.8 |
| 16 | 22 | 28.5±3 | 279±29 |

STANDARD TIGHTENING TORQUE


3. TIGHTENING TORQUE FOR NUTS OF FLARED



Use these torques for nut part of flared.

| Thread diameter of nut part (mm) | width across flats of nut part (mm) | Tightening torque | |
|----------------------------------|-------------------------------------|-------------------|------------|
| | | kgm | Nm |
| 14 | 19 | 2.5±0.5 | 24.5±4.9 |
| 18 | 24 | 5±2 | 49±19.6 |
| 22 | 27 | 8±2 | 78.5±19.6 |
| 24 | 32 | 14±3 | 137.3±29.4 |
| 30 | 36 | 18±3 | 176.5±29.4 |
| 33 | 41 | 20±5 | 196.1±49 |
| 36 | 46 | 25±5 | 245.2±49 |
| 42 | 55 | 30±5 | 294.2±49 |

COATING MATERIALS



The recommended coating materials prescribed in **beml** Shop Manuals are listed below.

| Nomenclature | BEML code | Applications |
|--|-----------|---|
| Adhesives | LT-1A | Used to apply rubber pads, rubber gaskets, and cork plugs |
| | LT-1B | Used to apply resin, rubber, metallic and non-metallic parts when a fast, strong seal is needed |
| | LT-2* | Preventing bolts, nuts and plugs from loosening and leaking oil. |
| | LT-3 | Provides an airtight, electrically insulating seal. Used for aluminum surfaces. |
| | LT-4 | Used to coat plugs (plate shaped, bowl shaped) and holes, and mating portion of shaft. |
| Sealant gasket | LG-1 | Used with gaskets and packings to increase sealing effect. |
| | LG-3 | Heat-resistant gasket for precombustion chambers and exhaust piping. |
| | LG-4 | Used by itself on mounting surfaces on the final drive and transmission cases. (Thickness after tightening: 0.07 - 0.08 mm) |
| | LG-5 | Used by itself to seal grease fittings, tapered screw fittings and tapered screw fittings in hydraulic circuits of less than 50 mm in diameter. |
| | LG-6 | Silicon base type used in combination with LG-1 and LG-4. |
| | LG-7 | Has a shorter curing time than LG-6, and is easier to peel off. |
| Antifriction compound (Lubricant including molybdenum disulfide) | LM-P | Applied to bearings and taper shafts to facilitate press-fittings and to prevent sticking, burning or rusting. |
| Grease (Lithium grease) | G2-L1 | Applied to bearings, sliding parts and oil seals for lubrication, rust prevention and facilitation of assembling work. |
| Vaseline | | Used for protecting battery electrode terminals from corrosion. |

*LT-2 is also called LOCTITE in the shop manuals.

ELECTRIC**ELECTRIC WIRE CODE**

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires. This wire code table will help you understand WIRING DIAGRAMS.

Example: 5WB indicates a cable having a nominal number 05 and white coating with black stripe.

CLASSIFICATION BY THICKNESS


| Nominal number strands | Copper Wire | | | Cable O.D (A) | Current rating | Applicable circuit |
|------------------------|-------------|-----------------------------------|--------------------|---------------|----------------|---------------------------------|
| | Number (mm) | Dia.of strands (mm ²) | Cross section (mm) | | | |
| 01 | 11 | 0.32 | 0.88 | 2.4 | 12 | Starting, lighting, signal etc. |
| 02 | 26 | 0.32 | 2.09 | 3.1 | 20 | Lighting, signal etc. |
| 05 | 65 | 0.32 | 5.23 | 4.6 | 37 | Charging and signal |
| 15 | 84 | 0.45 | 13.36 | 7.0 | 59 | Starting (Glow plug) |
| 40 | 85 | 0.80 | 42.73 | 11.4 | 135 | Starting |
| 60 | 127 | 0.80 | 63.84 | 13.6 | 178 | Starting |
| 100 | 217 | 0.80 | 109.1 | 17.6 | 230 | Starting |

CLASSIFICATION BY COLOR AND CODE

| Priority | Circuits | | Charging | Ground | Starting | Lighting | Instrument | Signal | Other |
|----------|---------------------|-------|---------------|--------|----------------|--------------|----------------|-----------------|----------------|
| | Classi- fication | | | | | | | | |
| 1 | Pri- mary | Code | W | B | B | R | Y | G | L |
| | | Color | White | Black | Black | Red | Yellow | Green | Blue |
| 2 | Aux- iliary | Code | WR | - | BW | RW | YR | GW | LW |
| | | Color | White & red | - | Black & White | Red & White | Yellow &Red | Green & White | Blue & White |
| 3 | | Code | WB | - | BY | RB | YB | GR | LR |
| | | Color | White & Black | - | Black & Yellow | Red & Black | Yellow & Black | Green & Red | Blue & Red |
| 4 | | Code | WL | - | BR | RY | YG | GY | LY |
| | | Color | White & Blue | - | Black & Red | Red & Yellow | Yellow & Green | Green & Yellow | Blue & Yellow |
| 5 | | Code | WG | - | - | RG | YL | (GB) | (LB) |
| | | Color | White & Green | - | - | Red & Green | Yellow & Blue | (Green & Black) | (Blue & Black) |
| 6 | | Code | - | - | - | RL | YW | (GL) | - |
| | | Color | - | - | - | Red & Blue | Yellow & White | (Green & Blue) | - |


ENGINE

11 GENRAL




| | |
|--------------------------------|--------|
| General View | 11-002 |
| Specification | 11-004 |
| General assembly drawing | 11-010 |
| Engine performance curve | 11-017 |
| Weight table | 11-016 |

GENERAL VIEW BS6D125G1




1. Fan pulley
2. Dipstick
3. Fuel filter
4. Adapter
5. Fuel injection pump
6. Oil filter
7. Crankshaft pulley
8. Vibration damper



10. Turbocharger
11. Alternator
12. Oil cooler
13. Starting motor

GENERAL VIEW


BS6D125G1 (PES100 GENSET)





1. Fan pulley
2. Fuel filter
3. Oil filter
4. Fuel injection pump
5. Automatic timer


SPECIFICATION

| | | | | |
|--|---|---|---|---|
| Engine model | | BS6D125G1 | | |
| Applicable machine | | PES100 | | |
| Number of cylinder - Bore x Stroke mm | | 6 - 125 x 150 | | |
| Total piston displacement cc | | 11,040 | | |
| Firing order | | 1 - 5 - 3 - 6 - 2 - 4 | | |
| Dimensions | Overall length mm | 1,722 | | |
| | Overall width mm | 1,024 | | |
| | Overall height mm | 1,175 | | |
| | (Excluding exhaust pipe) | | | |
| | Overall height mm (Including exhaust pipe) | 1,430 | | |
| Performance | Flywheel horsepower Rated kW/r/min | 118/1,500 | | |
| | 10% Over Load kW/r/min | 130 | | |
| | 25% Over Load kW/r/min | 147 | | |
| | High idling r/min | Max. 1545 | | |
| | Low idling r/min | 700-750 | | |
| | Minimum fuel consumption ratio g/kW.h | 215 | | |
| Dry weight kg | | 1,050±30 | | |
| Fuel pump Governor | | Bosch PE-NB type Bosch RSV centrifugal, all-speed type | | |
| Lubricating oil amount (refill capacity) | | 32 (26) | | |
| Coolant amount (engine only) | | 78.5 | | |
| Aternator | | 24V,30A | | |
| Starting motor | | 24V, 7.5 kw | | |
| Battery | | 12V, 200Ah x 2 | | |
| Turbocharger | | KKK(KEL) | - | |
| Air compressor | | - | - | - |
| Other | | - | - | - |

BS6D125G1 LEFT SIDE VIEW


BS6D125G1 RIGHT SIDE VIEW

BS6D125G1 FRONT VIEW

BS6D125G REAR VIEW

BS6D125G (FOR PES100)

Flywheel horsepower : 118 kW / 1,500 rpm
Minimum fuel consumption ratio : 215 g / kW.h



WEIGHT TABLE

This weight table is a guide for use when transporting or handling components.

Unit:Kg

| No. | ITEM | COMPONENT | BS6D 125G1 |
|-----|---|---|--|
| 1 | Turbocharger | GARRET CO. TV77- 05 GARRET CO. TV77- 05 GARRET CO. TV77- 05 | 17 7 15 |
| 2 | Cylinder head assembly | Cylinder head, valve and valve spring | 16 x 6 |
| 3 | Cylinder block assembly | Cylinder block, Main bearing cap , Cylinder liner | 223 : Except D60F - 8,8F 264 : HD205-3/280 D60F- 8, 8A |
| 4 | Front cover | | 19: Except D60F - 8,8A 21 : D60F- 8,8A |
| 5 | Oil pan | | -- |
| 6 | Flywheel assembly | Flywheel , Ring gear | 35 : Except PC300-3, PC300LC-3 |
| 7 | Flywheel housing | | 25 : Except PC300-3 PC300LC-3 50 : Except PC300-3 PC300LC-3 |
| 8 | Crankshaft assembly | Crankshaft, Crankshaft gear | 104 |
| 9 | Camshaft assembly | Camshaft, camshaft gear and thrust plate | |
| 10. | Piston and connecting rod assembly . | Piston, piston ring, piston pin and connecting rod. | 7.8x 6 |
| 11. | Oil pump | | 5 |
| 12. | Fuel injection pump | | 26:PC300-3,PC300LC-3 |

| No. | ITEM | COMPONENT | BS6D 125G1 |
|-----|----------------|--------------------------------|------------|
| 13. | Water pump | | 9.5 |
| 14. | Alternator | Without vacuum pump (24V, 13A) | 7.5 |
| | | With vacuum pump (24V, 25A) | 11 |
| | | 24V, 35A | 10.5 |
| 15. | Starting motor | | 18 |
| 16. | Air compressor | | 10 |


ENGINE

12 STUCTURE AND FUNCTION



| | |
|--|---------------|
| GENERAL STRUCTURE | 12-002 |
| INTAKE AND EXHAUST SYSTEM | |
| Intake and exhaust system | 12-004 |
| Turbocharger | 12-006 |
| ENGINE BODY | |
| Cylinder head | 12-007 |
| Valve system | 12-009 |
| Cylinder block | 12-011 |
| Main circulation part | 12-013 |
| Timing gear | 12-015 |
| Flywheel and flywheel housing | 12-017 |
| LUBRICATION SYSTEM | |
| Lubrication system chart | 12-021 |
| Oil pump | 12-022 |
| Regulator valve | 12-023 |
| Oil filter | 12-024 |
| Oil cooler | 12-026 |
| FUEL SYSTEM | |
| Fuel system chart | 12-027 |
| Fuel injection pump | 12-029 |
| Fuel injection nozzle | 12-030 |
| Fuel filter | 12-031 |
| Magnetic switch (fuel cut solenoid) | 12-032 |
| COOLING SYSTEM | |
| Cooling system chart | 12-033 |
| Water pump | 12-034 |
| Thermostat | 12-036 |
| Corrosion resistor | 12-037 |
| ELECTRICAL SYSTEM | |
| Alternator | 12-038 |
| Starter Motor | 12-040 |
| Wiring Diagram | 12-040 |
| Electrial intake air heater..... | 12-041 |
| ACCESSORY | |
| Air compressor | 12-042 |
| Exhaust brake | 12-045 |

GENERAL STRUCTURE



1. Cylinder block

2. Cylinder liner

3. Piston

4. Connecting rod

5. Piston pin

6. Intake valve

7. Cross head

8. Exhaust valve

9. Rocker arm shaft

10. Fuel injection nozzle

11. Cylinder head cover

12. Camshaft

13. Ring gear

14. Flywheel

15. Rear seal

16. Flywheel housing

17. Oil pan

18. Crankshaft

19. Main bearing cap

20. Oil strainer


21. Crankshaft gear

22. Front cover

23. Front seal

24. Crankshaft pulley

25. Vibration damper



26. Cylinder head

27. Thermostat

28. Rocker arm

29. Push rod

30. Cam follower

31. Connecting rod cap

32. Oil pump

Engine: . B6D 125-1


. BS6D 125-1 (With turbocharger)

. BSA6D 125-1 (With turbocharger and after- cooler)


Type:

. In-line, 6-cylinders, water-cooled, direct fuel injection,
4 -cycle diesel engine.

INTAKE AND EXHAUST SYSTEM

BS6D125G1

1. Dust cap
2. Outer element
3. Inner element
4. Air cleaner body
5. Electrical intake air heater
6. Evacuator valve



7. Air cleaner cover

8. Muffler

9. Turbocharger

10. Exhaust manifold (Front)

11. Exhaust manifold (Center)


12. Exhaust manifold (Rear)

A. Air intake

B. Gas exhaust

a. Intake air pressure pick-up
for dust indicator

TURBOCHARGER




- | | |
|---------------------|----------------------|
| 1. Lock nut | 11. Shroud |
| 2. Blower housing | 12. Turbine housing |
| 3. Blower impeller | 13. Piston ring |
| 4. Thrust collar | 14. Turbine impeller |
| 5. Back plate | |
| 6. Thrust bearing | A. Air inlet |
| 7. Seal ring | B. Air outlet |
| 8. Center housing | C. Gas inlet |
| 9. Retaining ring | D. Gas outlet |
| 10. Journal bearing | E. Oil inlet |
| | F. Oil outlet |

TURBOCHARGER

| | |
|-------------------------|--------------------------------------|
| Type | GARRETT CO T04B NV |
| Overall length | 229 mm. |
| Overall width | 222 mm. |
| Overall height | 185 mm. |
| Weight | 7 kg. |
| Continous speed | 125,000 rpm. |
| Applicable exhaust temp | 700° C max. |
| Direction of rotation | Clockwise (see from the blower side) |

ENGINE BODY

CYLINDER HEAD



1. Cylinder head bolt

5. Valve spring


2. Nozzle holder

6. Intake valve

3. Cylinder head

7. Exhaust valve

4. Cylinder head cover

**CYLINDERHEAD**

- . Direct fuel injection.
- . 4 valve
- . Injection nozzle assembled in cylinder head.
- . Divided type
(1-cylinder head for 1-cylinder)

VALVE SEAT

- . Press fitted insert for intake and exhaust .

CYLINDER HEAD COVER

- . Floating type seal

VALVE ROTATOR

- . Installed BS6D125G1

8. Valve spring seat

12. Valve guide

a. Water temperature pick-up

9. Valve cotter

13. Valve seat insert

b. Outlet for heater

10. Cross head


14. Push rod

c. Outlet for corrosion resistor


11. Rocker arm

d. Inlet for corrosion resistor

VALVE SYSTEM



- | | | |
|--|--|-------------------------------|
| 1. Rocker arm shaft | 9. Cross head | 15. Adjustment screw |
| 2. Camshaft gear (No. of teeth: 44) | 10. Upper valve spring seat | 16. Locknut |
| 3. Camshaft | 11. Intake valve | 17. Rocker arm |
| 4. Air compressor drive gear (No. of teeth: 14) | 12. Valve spring | 18. Push rod |
| 5. Cam roller | 13. Lower valve spring seat B6D125-1 : Intake and exhaust BS6D125-1 : Exhaust only | 19. Cam follower |
| 6. Cam roller pin | | 20. Exhaust valve |
| 7. Adjustment screw | 14. Valve rotator (BS6D 125-1: Intake only) (BSA6D125-1 : Intake only) | 21. Valve seal (Exhaust only) |
| 8. Locknut | | |



a. Oil


VALVE TIMING

CAMSHAFT

- Stamp forging
- Journal portion, cam portic



CYLINDER BLOCK



1. Cylinder block

2. Cylinder liner

3. Clevis seal

4. Liner seal (Ethylene propylene rubber)

5. Liner seal (Silicon rubber)

6. Front seal

7. Front cover



8. Main bearing cap bolt

9. Main bearing cap

10. Main bearing

11. Thrust bearing

12. Piston cooling nozzle (BS6D 125-1)

**CYLINDER BLOCK:**

- . Crankshaft : 7 bearings
- . Camshaft : 7 bearings

FRONT SEAL:

- . Single lip with dust seal

PISTON COOLING:

- . With piston cooling nozzle (BS6D125G1)


CYLINDER LINER:

- . Wet type
- . Treatment : Plateau honing finish
Tufftride treated (BS6D125G1)

LINER SEAL:

- . Top : Clevis seal
- . Middle : O-ring (Ethylene propylene rubber)
- . Bottom : O-ring (Silicon rubber)

MAIN CIRCULATION PART



1-A. Piston (BS6D 125-1)

1-B. Piston (B6D 125-1)

2. Connecting rod bushing

3. Piston pin

4. Top ring

5. Second ring

6. Oil ring

7. Connecting rod

8. Crankshaft


9. Crankshaft gear

10. Connecting rod cap

11. Connecting rod bearing

12. Connecting rod cap bolt

* The above is a composite sectional drawing for BS6D125G1



CRANKSHAFT : Stamp forging




. BS6D 125-1 : Induction hardening on journal and fillet portions.

PISTON :

Material :
B S6D125G1 (No.1) : Ductile cast iron (FCD)/
ALUMINIUM.

Type : Elliptical taper profile thermal flow,
MTCC combustion chamber.


PISTON RING

| Topring | Second ring | oil ring |
|--|---|---|
|  |  |  |
| Both faces keystone barrel face Hard chrome plating | keystone inner cuttapped face Hard chrome plating | Hard chrome plating |

CONNECTING ROD :

BS6D125-1: With lubrication hole


TIMING GEAR



Section F - F


Section E - E


- | | |
|--|--|
| 1. Cylinder block | 7. Injection pump drive gear (No. of teeth : 44) |
| 2. Water pump drive gear (No. of teeth : 22) | 8. Timing gear cover |
| 3. Main idler gear (No. of teeth : 57) | 9. Camshaft gear (No. of teeth : 44) |
| 4. Main idler gear (No. of teeth : 38) | 10. Crankshaft gear (No. of teeth : 33) |
| 5. Oil pump drive gear (No. of teeth : 21) | 11. Crankshaft |
| 6. Idler gear for oil pump (No. of teeth : 25) | |
- A, B, C : Match marks for timing gears.**




FLYWHEEL AND FLYWHEEL HOUSING

With PTO type






Section A - A



Section B - B

1. Bearing case
2. Ball bearing
3. Pump drive shaft
4. Pump drive gear (No. of teeth: 61)
5. Spacer
6. Ball bearing
7. Bearing case
8. Bearing case
9. Roller bearing
10. Pump drive shaft
11. Pump drive gear (No. of teeth : 35)
12. Spacer
13. Ball bearing
14. Bearing case

- a. PTO for steering pump
- b. PTO for torque converter pump
- c. PTO for work equipment pump



Section C - C






FLEXIBLE COUPLING (HOLESET)

Machine The Hub (Inner Member) Bore And Key Way To Suit Alternator (Driven Machine) Shaft (Fig A)

Insert Cover If Single Piece Press Fit The Hub (Inner Member) Onto The Shaft (Fig B)

Place Outer Member In Position Resting On Inner Member (Fig C)

Assemble Two Halves Of Cover And Torque Bolts (See Table)



Insert Rubber Blocks For
Easy Assembly And To Avoid Damages
To The Rubber Blocks Use Lubricant

Silicone Fluid Of Viscosity Between 300 And 1000 Centistokes Or Jelly Soap.

Do Not Use Petroleum Base Lubricants
Like Grease

Apply Lubricants To Rubber Blocks And Cavities

Insert Blocks In Pairs Using A Non Metallic Hammer.

Use Sequence Shown In The Fig(D)

Fasten Outer Member To Flywheel And Torque As Per Table,

Check Alignment

NOTE:

A flexible coupling operating in correctly assembled system requires no maintenance.

It is recommended that the rubber blocks are inspected every 5000 hours.


A small amount of rubber dust is normal. In initial running large quantity of dust requires inspection-on use of sufficient lubricants, damages during assembly and improper torques.

| RB COUPLING SIZE | FLANGE BOLTS | | COVER SETSCREW | |
|------------------|--------------|-----------------------|----------------|-----------------------|
| | GRADE | TIGHTENING TORQUE N-m | GRADE | TIGHTENING TORQUE N-m |
| 0.12 | M 8 | 23 | M 8 | 23 |
| 0.20 | M 8 | 23 | M 8 | 23 |
| 0.24 | M 10 | 45 | M 8 | 23 |
| 0.37 | M 10 | 45 | M 10 | 45 |
| 0.73 | M 12 | 85 | M 10 | 45 |
| 1.15 | M 12 | 85 | M 12 | 85 |
| 2.15 | M 12 | 85 | M 12 | 85 |

Data : **Assembly instructions for RB series flywheel mounted couplings**
(Manufactured by : Poona Couplings Pvt. Ltd.)

LUBRICATION SYSTEM

LUBRICATION SYSTEM CHART




1. Oil strainer
2. Oil pump
3. Oil cooler
4. Oil filter
5. Main relief valve
6. Thermostat
7. Regulator valve

8. Safety valve
9. Crankshaft
10. Camshaft
11. Piston
12. Piston cooling nozzle (BS6D 125- 1)
13. Rocker arm
14. Intake and exhaust valve

15. Fuel injection pump
 16. Turbocharger (BS6D125G1)
 17. Timing gear
 18. Adapter
- W : Cooling water

OIL PUMP

BS6D125G1



1. Pump drive gear (No. of teeth : 21)
2. Bushing
3. Pump cover
4. Drive gear
5. Pump body
6. Drive shaft
7. Main relief valve
8. Valve spring
9. Retainer
10. Driven shaft
11. Bushing
12. Driven gear


OIL PUMP:

- * Type : Gear type
- * Pump speed : Engine speed x 1.571

MAIN RELIEF VALVE:

- * Set pressure : $7 \begin{smallmatrix} +0.1 \\ 0 \end{smallmatrix} \text{ kg/cm}^2$

REGULATOR VALVE




Section A - A

- 1. Adapter
- 2. Regulator valve

- B. From oil filter
- C. To engine each part
- D. To oil filter
- E. From oil pump
- F. To oil pan
- G. To piston cooling nozzle


REGULATOR VALVE :

* Set pressure : $3.75 \pm 0.15 \text{ kg / cm}^2$
(BS6D125G1)

BS6D125G1**Remote mounting type**

- 1. Bracket
- 2. Safety valve
- 3. Cartridge

- A. Oil inlet
- B. Oil outlet

Direct mounting type**OIL FILTER :**


* Filtration area : 0.84 m²

SAFETY VALVE :

* Set pressure : 2.0 ± 0.2 kg / cm²

OIL FILTER

BS6D125G1



- 1.Bracket
- 2. Safety Valve
- 3.Cartridge

A Oil inlet
B Oil Outlet


Oil Filter

* Filtration Area : 0.84 m²

Safety Valve

* Set Pressure : 2.0 ± 0.2 kg/cm²

OIL COOLER



Section-AA

1. Thermostat housing
2. Thermostat
3. Cooler cover
4. Cooler Element

BS6D125G1 : 7 Cores

- A. Water drain port
 B. Water inlet
 C. Oil inlet
 D. To engine each part

THERMOSTAT FUNCTION :


- * Valve cracking temperature : $104 \pm 1.5^{\circ}\text{C}$
- * Full opening temperature : 115°C
- * Full opening lift : Min. 8 mm

OIL COOLER :


BS6D125G 1 : 0.504 m^2

FUEL SYSTEM

FUEL SYSTEM CHART




1. Fuel tank
2. Feed pump
3. Fuel injection pump
4. Fuel filter
5. Fuel injection nozzle
6. Governor

BS6D125G1

- | | |
|--|---------------------------------|
| 1. Fuel injection pipe (No. 3) | 9. Feed pump |
| 2. Fuel injection pipe (No. 2) | 10. Fuel injection pump |
| 3. Fuel injection pipe (No. 1) | 12. Oil tube (outlet) |
| 4. Fuel injection pump drive gear (No. of teeth : 44) | 13. Fuel injection pipe (No. 4) |
| 5. Drive shaft | 14. Fuel injection pipe (No. 5) |
| 6. Drive case | 15. Fuel injection pipe (No. 6) |
| 7. Coupling | |
| 8. Oil tube (inlet) | |

FUEL INJECTION PUMP



- a. Fuel inlet
- b. To fuel filter
- c. From fuel filter
- d. To fuel injection nozzle
- e. To oil pan (oil)


FUEL INJECTION PUMP :

- * Maker : DIESEL KIKI NIPPON DENSO
- * Type : Bosch PE - P NB (EP9)
- * Lubrication method : Forced lubrication with engine oil.

GOVERNOR :

- * Type : RSV Centrifugal, all - speed type.

FUEL INJECTION NOZZLE



1. Inlet connector

2. Nozzle holder

3. Nozzle spring

4. Nozzle

5. Frange

FUEL INJECTION NOZZLE

* Type :

Multi - hole type

BS6D125G1 :

Made by NIPPON DENSO

Multi - hole type

* Adjustment injection pressure :

Shim adjusting type

* Adjusting value (per shim thickness 0.1 mm)

BS6D125G1 : Approx. 14 kg / cm²

* Adjusting shims (at intervals of 0.025 mm)

BS6D 125-1 : 0.5 to 1.975 mm

a. From injection pump


b. Nozzle hole

c. to fuel tank

* Injection pressure

BS6D125G1 : 250 kg / cm²

FUEL FILTER



- 1. Air bleed plug
- 2. Bracket
- 3. Cartridge
- 4. Water drain plug
- A. Fuel inlet
- B. Fuel outlet




FUEL FILTER :

* Filtration area : 0.3 m²

MAGENTIC SWITCH AND FUEL SOLENOID

MAGENTIC SWITCH

B contact (electricity flows in ordinary operations) method



Inner wiring

C1. Pull - in coil
C2. Holding coil

- | | |
|-----------|-----------------------|
| 1. Shaft | 5. Stop lever |
| 2. Case | 6. Return spring |
| 3. Piston | 7. Solenoid |
| 4. Coil | 8. Fuel control lever |

MAGNETIC SWITCH :

- | | |
|---------------------|---|
| * Maker | : NIKKO DENKI |
| * Type | : Sealed |
| * Rated voltage | : DC 24V |
| * Operating current | : Maximum : 35 A max. Continuity : 0.5 A max |
| * Stroke | : 12 ± 0.3 mm |
| * Weight | : 3.3 kg |

FUNCTION :

* Starting engine :


When the starting key is turned on, the solenoid is energized.
Solenoid shaft (1) is electrically attracted, pulling injection pump stop lever (5) and fixing it in the RUN position.

* Stopping engine :

When the starting key is turned off, the solenoid is de - energized.
Injection pump stop lever (5) is returned to STOP position (non - injection position) by return spring (6).


* During operation, the amount of fuel injection is controlled by fuel control lever (8).

* When installing the fuel solenoid, adjust clearance A referring to TESTING AND ADJUSTING.




COOLING SYSTEM

COOLING SYSTEM CHART



- | | |
|---------------------------------------|--------------------|
| 1. Radiator | 8. Cylinder liner |
| 2. Thermostat | 9. Piston |
| 3. Water pump | 10. Cylinder block |
| 4. Water temperature gauge | 11. Oil cooler |
| 5. Water manifold | |
| 6. Corrosion resistor (if equipped) | |
| 7. Cylinder head | A. Lubrication oil |



WATER PUMP MOUNTING



1. Thermostat
2. Housing cover
3. Corrosion resistor
4. Thermostat housing
5. Water pump
6. Oil cooler

- A. To radiator (coolant)
- B. From engine each part (coolant)
- C. To engine each part thru oil cooler (coolant)
- D. From radiator (coolant)
- E. From oil pump (oil)
- F. To engine each part (oil)
- a. Outlet for heater
- b. Water temperature gauge pick - up
- c. Coolant drain plug
- d. Outlet for air bleed tube

WATER PUMP




1. Water pump drive gear
(No. of teeth : 22)
2. Pump shaft
3. Ball bearing
4. Pump body
5. Water seal
6. Impeller
7. Pump cover

- A. From thermostat
B. From radiator
C. To engine each part

WATER PUMP:

- * Type : Centrifugal gear drive.
- * Pump speed : Engine speed x 1.5

THERMOSTAT



1. Housing cover
2. Thermostat
3. Gasket
4. Thermostat housing


THERMOSTAT :

- * Valve cracking temperature : 74.5 - 78.5° C
- * Full open temperature : 90° C
- * Full open lift : Min. 10 mm

A. To radiator

B. To corrosion resistor (BS6D125G1)

CORROSION RESISTOR (If equipped)



1. Head
2. Cartridge
3. Element (Paper)
4. Element (Chemicals)
5. Spring

CORROSION RESISTOR :


* Filtration area : 0.5 m²

- A. Water inlet
B. Water outlet

ELECTRICAL SYSTEM

ALTERNATOR

MOUNTING




* Pulley O.D


- 1. Adjustment plate
- 2. Alternator
- 3. Fan belt
- 4. Fan
- 5. Crankshaft pulley
- a. Fan pulley O.D
- b. Alternator pulley O.D
- c. Crankshaft pulley O.D

| Engine model | Applicable machine | Pulley O.D (mm) | | |
|--------------|--------------------|-----------------|----|-----|
| | | a | b | c |
| BS6D125G1 | PES100 | 189 | 95 | 182 |
| | | | | |

ALTERNATOR , PES100 GENSET




| TERMINAL | SIZE | TIGHTENING TORQUE |
|--|-----------------|-------------------|
| +VE | M8x1.25 | 45kg.cm~55kg.cm |
| -VE | M6x1 | 25kg.cm~30kg.cm |
| WL | LUCAR 6.35x0.8t | — |
| W | — | — |
| W= A.C PHASE TAP TERMINAL (UNREGULATED VOLTAGE TERMINAL) | | |



| ENGINE MODEL | APPLICABLE MODEL | TYPE | SPECIFICATION | PULLEY O.D (mm) | WEIGHT (kg) |
|--------------|------------------|-----------------------|---------------|-----------------|-------------|
| BS6D125G1 | PES100 GENSET | LUCAS TVS (SM 130 PE) | 24V , 30A | 90 | 5.5 |

STARTING MOTOR, PES100 GENSET




- 1. MAGNETIC SWITCH
- 2. PINION GEAR
- 3. STARTING MOTOR
- B,C,E : TERMINALS

| ENGINE MODEL | APPLICABLE MODEL | TYPE | SPECIFICATION | NUMBER OF TEETH | WEIGHT (kg) |
|--------------|------------------|-----------------------|---------------|-----------------|-------------|
| BS6D125G1 | PES100 GENSET | LUCAS TVS (SM 130 PE) | 24V ,7.5 kW | 12 | 32 |

ELECTRICAL INTAKE AIR HEATER


RIBBON TYPE

1. Body
2. Heater coil



ELECTRICAL INTAKE AIR HEATER


- * Rated voltage : DC24V
- * Rated current : 111A




Inner wiring

ACCESSORY

AIR COMPRESSOR



- | | | |
|-------------------|-----------------------|-------------------------|
| 1. Cylinder head | 7. Crank case | a. Air intake |
| 2. Unloader valve | 8. Crankshaft | b. Air exhaust |
| 3. Piston ring | 9. Connecting rod cap | c. Unloader |
| 4. Piston | 10. Bearing cover | d. Cooling water inlet |
| 5. Cylinder block | 11. Piston pin | e. Cooling water outlet |
| 6. Connecting rod | | f. Oil inlet |

**AIR COMPRESSOR**

- * Maker : DIESEL KIKI
- * Type : Single cylinder, double acting
- * Discharge volume : 340 cc / rev.
- * Air pressure : 8.5 kg / cm² (at full load)
- * Weight : 11 kg

UNLOADER VALVE


- * Valve opening pressure : 6.3 kg / cm²
- * Valve shutting pressure : 5.4 kg / cm²

OUTLINE :


The air compressor is installed between the engine timing gear and fuel injection pump, and is driven by the timing gear. It is connected directly to the engine, so the air compressor always rotates when the engine is rotating.

ACTION OF UNLOADER VALVE :

1) The intake valve and delivery valve automatically open and close according to the pressure inside the cylinder. During the piston up-stroke, the air inside the cylinder is compressed, the intake valve is closed, and the delivery valve opens to discharge the compressed air. On the down-stroke, the delivery valve closes and the intake valve opens to suck in air from the air cleaner.


**When intake valve is actuated**

2) An air governor is installed to control the amount of air inside the air tank. When the air pressure inside the air tank reaches the specified pressure, the compressed air inside the tank passes through the air governor, and pushes down the rod of the unloader valve to keep the intake valve open. As a result, while the unloader valve is being actuated, the intake air is not compressed.

**When intake valve is kept open**

EXHAUST BRAKE

For HD200D- 3, HD205- 3



- | | |
|------------------|------------------------|
| 1. Pipe | 8. Piston |
| 2. Poppet | 9. Piston packing |
| 3. Valve housing | 10. Retainer |
| 4. Gate valve | 11. Head cover |
| 5. Guide bushing | |
| 6. Cylinder | A. From solenoid valve |
| 7. Spring | B. Exhaust gas exist |

OUTLINE :

- * Exhaust brake mounting between engine turbo-charger and muffler works due to air pressure from solenoid valve.
The exhaust brake throttles exhaust passage between turbocharger and muffler, and reduces engine speed.
The exhaust brake consists of valve mechanism and air cylinder which operates a valve.

ENGINE

13 TESTING AND ADJUSTING



ENGINE BODY

| | |
|--------------------------------------|--------|
| Adjusting valve clearance | 13-002 |
| Measuring compression pressure | 13-003 |

FUEL SYSTEM

| | |
|---|--------|
| Checking and adjusting fuel injection timing | 13-004 |
| Testing and adjusting fuel cut solenoid | 13-006 |
| Fuel injection pump calibration data | 13-016 |

PERFORMANCE TEST

| | |
|----------------------------------|--------|
| Run-in standard | 13-027 |
| Performance test criteria | 13-031 |
| Testing and adjusting data | 13-041 |

ENGINE BODY

ADJUSTING VALVE CLEARANCE

ADJUSTEMENT PROCEDURE

1. Remove the cylinder head cover.
2. Rotate the crankshaft in the normal direction, while watching the movement of the intake valve of the No.6 cylinder, bring the No.1 cylinder into the top dead center position of the compression stroke and align the "1.6 TOP" mark on vibration damper (2) with pointer (3).

- ★ When the No. 1 cylinder comes near the top dead center of the compression stroke, the No.6 intake valve will start to move (open).

3. Adjust the clearance for valves ● marked in the valve arrangement chart.
4. Rotate the crankshaft in the normal direction by one revolution and adjust the valve clearance for the remaining valves ○ marked.


- ★ To adjust the valve clearance, loosen locknut (8) on adjustment screw (7), insert Feeler gauge A corresponding to the specified clearance between crosshead (6) and rocker arm (5), and adjust the clearance with the adjustment screw until the thickness gauge can slide lightly.

5. After the clearance is properly adjusted, tighten the locknut to secure the adjustment screw.





Locknut: 7 ± 0.5 kgm

- ★ The engine firing order: 1-5-3-6-2-4
- ★ Intake and exhaust valve clearances may be adjusted for each cylinder in firing order by rotating the crankshaft 120° at a time in the normal direction.
- ★ For details about valve clearance, see TESTING AND ADJUSTING DATA.




● Valve arrangement chart

| Cylinder No. | 1 | 2 | 3 | 4 | 5 | 6 |
|---------------|---|---|---|---|---|---|
| Exhaust valve | ● | ○ | ● | ○ | ● | ○ |
| Intake valve | ○ | ● | ○ | ● | ○ | ○ |




MEASURING COMPRESSION PRESSURE


MEASUREMENT PROCEDURE

 While measuring the compression pressure, take care not to burn yourself on the exhaust manifold or muffler, and be careful not to get caught in any revolving part of the engine.



* Measure the compression pressure while the engine is warm.

(Oil temperature : 40-60°C)

1. Adjust valve clearance properly.
For details, see ADJUSTING VALVE CLEARANCE.
 2. Remove spill tube (1) and disconnect fuel injection pipe(2).
 3. Remove the nozzle holder assembly (3) for each cylinder.
 - ★ Remove the nozzle holder assembly by prying it with two mounting bolts.
 - ★ Take care not to let any dirt or foreign matter get into the cylinder.
 4. Install adapter **A** the nozzle holder mounting section of the cylinder to be measured, and tighten the adapter to the specified torque.
-  Torque: 2.2 ± 0.3 kgm
5. Connect compression gauge **B** to the adapter.
 6. Place the fuel control lever in NO INJECTION position. Crank the engine with the starting motor and read the gauge when the pointer is stabilized.

 If you do not put the fuel control lever in NO INJECTION position fuel will blow out.

- ★ Most compression leakage can be prevented by applying a small amount of oil to the mounting section of the adapter.
- ★ For the reference values of the compression pressure, see TESTING AND ADJUSTING DATA.





FUEL SYSTEM

CHECKING AND ADJUSTING FUEL INJECTION TIMING

There are two methods for checking and adjusting the fuel injection timing of an injection pump.

- The “MATCH MARK ALIGNMENT” method, which is used when the injection pump is installed to the original engine and the pump is not being repaired.
- The “DELIVERY VALVE” method, which is used when a repaired or replaced injection pump is installed to the engine.
- When using the “DELIVERY VALVE” method, make preparations to replace the delivery valve copper gasket and O-ring with new parts.
- ★ Before inspecting and adjusting the fuel injection timing bring the No. 1 cylinder piston to the top dead center of the compression stroke.
For details, see 12 ADJUSTING VALVE CLEARANCE.




- **CHECKING AND ADJUSTING BY THE MATCH MARK ALIGNMENT METHOD.**
 1. With No. 1 cylinder piston at TOP position, rotate the crankshaft 30° to 40° in the reverse direction.
 2. Align the injection timing stamp line on crankshaft damper (1) with pointer (2) by slowly rotating the crankshaft in the normal direction.
 3. Confirm that stamp line **a** on the injection pump is aligned with stamp line **b** on the coupling.

- ★ If the stamp line are out of alignment, loosen nut (3) align the stamp lines by shifting the coupling and tighten the nut.



Nut: 6.2 ± 0.2 kgm



- **CHECKING AND ADJUSTING BY THE DELIVERY VALVE METHOD.**

1. Disconnect fuel injection pipe (4) for the No.1 cylinder
2. Remove delivery valve holder (5).

3. Remove spring (6) and delivery valve (7) from the delivery valve holder, and reassemble the delivery valve holder.

4. With No.1 cylinder piston at TOP position, rotate the crankshaft 30° to 40° in the reverse direction.

5. Place the fuel control lever in FULL position, slowly rotate the crankshaft in the normal direction while operating the priming pump, and observe the position when the fuel stops flowing out of the delivery valve holder.

6. In the position where the outflow of fuel stops, check the injection timing stamp line on the crankshaft damper to see if it is aligned with the pointer.




- If the injection timing stamp line passed through the pointer : The injection timing is late.
- If the injection timing stamp line did not reach the pointer : The injection timing is advanced.

★ If the inspection shows that the injection timing is out of adjustment, adjust the fuel injection timing in the following manner.

- 1) Rotate the crankshaft 30° to 40° in the reverse direction, starting from TOP position in No. 1 cylinder.
- 2) Align the injection timing stamp line on damper (1) with pointer (2) by slowly rotating the crankshaft in the normal direction.
- 3) Loosen nut (3) on the injection pump mounting flange slot, and rotate the flange on the pump side little by little by operating the priming pump until no fuel flows out of the delivery valve holder.
- 4) Tighten the nut on the injection pump mounting flange slot.
 - ★ Recheck the injection timing to see if it is properly adjusted.
- 5) Align match mark **a** with mark **b** and stamp the marks.


★ After the checking and adjusting, be sure to reassemble the spring and the delivery valve.

★ Always replace the delivery valve copper gasket and O-ring with new parts.



TESTING AND ADJUSTING FUEL CUT SOLENOID

1. Adjust rod (2) so that there is clearance of 0.4 ± 0.1 mm between stop lever (4) and stopper (5), while pulling rod (2) to the running direction.
2. Turn on the engine starting key and confirm that the solenoid has a stroke of 12 mm and the clearance of 0.4 ± 0.1 mm.
3. After turning on and off the key two or three times, reconfirm that solenoid works smoothly and engine runs or stops completely.
 - ★ If the solenoid does not work smoothly, solenoid coil burns in the cause of excessive current or flywheel horsepower downs in the cause of dropping fuel injection volume.



BS6D125- 1, BSA6D125- 1 :

1. A rod forms a link between the solenoid and injection pump. At this time, when the stop lever returns 0.5 - 1.0 mm from the stop pin on the RUN side and the solenoid shaft is pushed by hand, the stop lever of the pump will be set in a position in which it has returned 0.5 - 1.0 mm from the stop pin.
2. Next, energize the solenoid and see if its movement is smooth. Turn the starting switch ON and OFF two to three times and confirm that the operation condition does not change. If the operation is not smooth, adjust the linkage and carefully observe the movement.
3. Confirmation of Functions
After confirming that the operation is smooth, start the engine and confirm that the rated output can be obtained. Next, energize the solenoid and confirm that the engine stops. (The engine should stop within 10 sec.)

1. Solenoid valve
2. Rod
3. Fuel injection pump
4. Stop lever
5. Stopper


★ Failures caused by faulty adjustment of solenoid :

| | |
|---|---|
| If the clearance between the stop bolt and lever is 0 when the solenoid is energized. | ★ Burning of the solenoid core (when solenoid is only partially pulled). ★ Breakage or scuffing of the injection pump governor (an undue force will be applied to the lever) |
| When there is a large clearance between the stop lever and RUN side bolt when the lever is free (faulty linkage). | ★ Engine power will be generated because of a decline in amount of fuel injection |

.....Continue

PROCEDURE FOR ADJUSTING MOTOR CABLE

When the cable is pulled and stop lever (4) of the fuel injection pump is aligned with the STOP position, the cable will be fastened to bracket (1) with clamp (3). To give some play to the cable, remove the ball joint, turn the ball joint one revolution in the opposite (extension) direction, then reinstall it to the stop lever of the fuel injection pump.
(Note that it is also acceptable to install the ball joint from the beginning after estimating how much play the cable needs.)



1. Bracket
2. Wire
3. Clamp
4. Fuel injection pump stop lever

.....Continue

1. Stop the engine.
2. Install a ball joint to the injection pump stop lever, then temporarily fit the cable connecting the wiper motor and injection pumps.
3. Pull the injection pump stop lever by hand to the NO INJECTION position, and temporarily fix the cable to the bracket.
When doing this, temporarily fit the cable to the bracket using the holding nut with the stop lever contacting the ENGINE STOP stopper.
 - * The engine stop motor is delivered with the cable pulled (engine stopped).
 - * The stop lever of the fuel injection pump is at the RUN position when the lever is free. (It is pulled to the RUN position by a spring).
4. When the wiper motor is installed (engine stopped), adjust so that the clearance between the stop lever of the fuel injection pump and the STOP stopper is 0.5 - 2.5 mm. Carry out the adjustment with the nut holding the cable to the bracket, or make fine adjustments by changing the amount the ball joint is screwed in.
5. Tighten all bolts and nuts.
6. Turn the engine starting switch ON and OFF repeatedly, and check that the engine stop motor and cable move smoothly. Then check the following points again.
 - (1) When the engine is running, check visually that there is slack in the engine stop motor cable, and that the stop lever of the fuel injection pump is fully returned to the **RUN** position.
 - (2) Check again that the clearance between the stop lever and STOP stopper is 0.5 - 2.5 mm when the engine is stopped.

- * The engine stop motor has limit switches built in on both sides of the cable stroke.
- * Engine stop motor stroke : 35 mm
Fuel injection pump stop lever stroke : 30 mm
- * When the engine is running, there is slack in the engine stop motor cable, and the **RUN** position is maintained by the action of a spring (this is frequently built in the fuel injection pump).
- * There is a loose spring inside the engine stop motor, and this absorbs the tolerance of the stop, motor when the engine is stopped. However, if it is absorbed by the loose spring of the engine stop motor, force is applied to the injection pump, so depending on the model, this may be impossible. With such models, if the clearance between the stop lever and STOP stopper is made zero when the engine is stopped, there is a risk that problems may occur with the injection pump.
- * Problems caused by defective adjustment of the engine stop motor cable.

| | |
|--|---|
| ★ When the clearance between the stop lever and STOP stopper is excessive with the engine stop motor cable pulled. | ★ Engine does not stop. |
| ★ When the clearance between the stop lever and the RUN stopper is excessive at the free position. | ★ Fuel injection amount drops, causing loss of engine output power. |

FUEL INJECTION PUMP CALIBRATION DATA

PES100 GENSET (NIPPON DENSO)

PUMP ASSEMBLY NUMBER

31Z 710 1682

| | |
|---------------------|-------------------|
| Injection Pump Type | Pump Manufacturer |
| PE-6P | DIESEL KIKI |

| | |
|--------------------|-------------------|
| Applicable machine | Applicable engine |
| PES100 | BS6D125G1 |
| | |

| | |
|--|---|
| Rotating direction | : Counter Clockwise viewed from Drive End |
| Injection Order | : 1 - 5 - 3 - 6 - 2 - 4 |
| Injection Interval | : $60^{\circ} \pm 30'$ |
| Plunger pre stroke mm | : 3.8 ± 0.05 |
| Delivery valve Retraction volume mm ³ /st | : 80 |

ENGINE SPECIFICATION WITH FAN : (Reference Only)

| | | |
|--------------------|------------|----------------|
| Rated power | kW @ r/min | : 123 / 1500 |
| Maximum torque N-m | @ r/min | : -- |
| High idling | r/min | : 1545 \pm 5 |
| Low idling | r/min | : 700 ~ 750 |

CALIBRATION STANDARD

| | | | | | | | | | |
|--|---------------------------------|--------------------|--------------------|-----------------------------|-----------|-----------------------------------|------------------|-----------|-----------------------------------|
| Condition | Manufacturer Standard | | | | | | Service Standard | | |
| Service standard indicates data using calibration test parts | Nozzle part no. | | | -- | | | -- | | |
| | Nozzle holder part no. | | | -- | | | -- | | |
| | Injection pipe (OD x ID x L) mm | | | φ6 x 2.2 x 650 | | | -- | | |
| | Test oil | | | ASTM D975 No. 2 Diesel fuel | | | | | |
| Manufacturer standard is data for factory test. | Oil temperature °C | | | 40 to 45 | | | 40 to 45 | | |
| | Nozzle opening pressure Kgf/cm² | | | 250 | | | 250 | | |
| | Transfer pump pressure Kgf/cm² | | | 1.6 | | | 1.6 | | |
| Injection Volume Rack position are the reference when adjusting the injection volume arks * are average volumes. | Manufacturer Standard | | | | | | Service Standard | | |
| | mm³/st | | | | | | mm³/st | | |
| | | Rack position (mm) | Pump speed (r/min) | Basis | allowance | Maximum variance between cylinder | Basis | allowance | Maximum variance between cylinder |
| | -- | -- | 750 | 121 | 111~124 | ≤6 | -- | -- | -- |
| | -- | -- | 360 | 16 | 14~18 | ≤4 | -- | -- | -- |
| | -- | -- | | | | | | | |
| | -- | -- | | | | | | | |
| | -- | -- | | | | | | | |

PERFORMANCE TEST

RUN-IN STANDARD ★ Load are given for the case of the dynamometer arm length is 716 mm.
This list shows the standard on condition that the fan is removed.

| Engine model | Applicable machine | Item | Order | | | | | | |
|--------------|--------------------|----------------------|-------|-------|-------|-------|-------|----|---|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| BS6D125G1 | PES100 | Running time (min) | 5 | 10 | 15 | 15 | 15 | -- | |
| | | Engine speed (r/min) | 700 | 1,000 | 1,200 | 1,400 | 1,500 | -- | |
| | | Load (Nm) | - | 235 | 392 | 588 | 784 | -- | |
| | | Output (kW) | - | 24 | 67 | 86 | 123 | -- | |
| | | Running time (min) | | | | | | | |
| | | Engine speed (r/min) | | | | | | | |
| | | Load (Nm) | | | | | | | |
| | | Output (kW) | | | | | | | |
| | | Running time (min) | | | | | | | |
| | | Engine speed (r/min) | | | | | | | |
| | | Load (Nm) | | | | | | | |
| | | Output (Kw) | | | | | | | |
| | | Running time (min) | | | | | | | |
| | | Engine speed (r/min) | | | | | | | |
| | | Load (Nm) | | | | | | | |
| | | Output (kW) | | | | | | | |
| | | Running time (min) | | | | | | | |
| | | Engine speed (r/min) | | | | | | | |
| | | Load (Nm) | | | | | | | |
| | | Output (kW) | | | | | | | |
| | | Running time (min) | | | | | | | |
| | | Engine speed (rpm) | | | | | | | |
| | | Load (kg) | | | | | | | |
| | | Output (hp) | | | | | | | |
| | | Running time (min) | | | | | | | |
| | | Engine speed (r/min) | | | | | | | |
| | | Load (kg) | | | | | | | |
| | | Output (hp) | | | | | | | |

PERFORMANCE TEST CRITIREA

| Engine model | Applicable machine | Test item | Specified value (fully equipped) | Engine speed (r/min) | Dynamometer (N.m) |
|--------------|---------------------|---------------------|----------------------------------|----------------------|-------------------|
| B(S)6D125-1 | PES100 BS6D125G1 | Flywheel horsepower | 118 kW / 1500 r/min | 1,500 | 750-810 |
| | | High idling speed | 1,545 r/min | 1,540~1550 | 0 |
| | | Low idling speed | 725±25 r/min | 700~750 | 0 |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

- ★ The values in the table are indicated at standard conditions (Atmospheric temperature 25°C, atmospheric pressure 750 mm Hg).
- ★ The values given for dynamometer loads output and torque are with the fan removed, so they differ from those of the specification.
- ★ Values are standardized under the following conditions: Muffler; air cleaner installed; alternator idling; and air compressor (if installed) open.
- ★ Dynamometer loads are given for the case of the arm length is 716 mm.
- ★ Fuel used: ASTM D975 No. 1 or No. 2 diesel fuel.
- ★ Lubrication oil used: CLASS - CD SAE30.
- ★ Exhaust temperature column t : (Intake temperature - 25°C)

NOTE “*”: IF THE ENGINE OPERATES AT HIGH ALTITUDE, THE FUEL DELIVERY HAS TO BE REDUCED AS PER THE **FIP** CALIBRATION CHART

| Output (Hp) / (kW) | Torque (kgm) / (Nm) | Fuel consumption (sec /200 cc) | Coolant temperature (°C) | Lubrication oil temperature (°C) | Lubrication oil pressure (kg/cm ²) | Exhaust temperature (°C) (t = Intake temp.25°C) |
|--------------------------|---------------------------|--------------------------------------|--------------------------------|--|--|---|
| Rated 118 | -- | Min. 14 | 70 - 95 | 80-110 | 3.0-5.0 | Max. 700 |
| 10% 130 | 860 | Min. 12 | 70 - 95 | 80-110 | 3.0-5.0 | Max. 700 |
| 25% 147 | 980 | Min. 10 | 70 - 95 | 80min | min 1.5 | Max. 700 |
| Hi 0 | 0 | -- | 70 - 95 | 80-110 | 3.0-5.0 | Max. 700 |
| Li 0 | 0 | -- | 70 - 95 | 80min | Min 1.5 | Max. 700 |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

TESTING AND ADJUSTING DATA :

PES100 GENERATOR SET

| Engine model | | | | BS6D125G1 | | | |
|---------------------------|--|--|-------------------------------|---|-------------------|----------|-----------|
| Applicable machine model | | | | PES100 | | | |
| Class-ification | Item | Condition,etc | Unit | Standard | Permissible Value | Standard | Tolerance |
| Performance | Engine speed | High idling speed | r/min | 1,545 \pm 50 | -- | | |
| | | Low idling speed | r/min | 725 $\begin{smallmatrix} +50 \\ +0 \end{smallmatrix}$ | -- | | |
| | Necessary Starting speed | 0° C - 20° C (with starting aid) | r/min r/min | Min. 100 Min. 85 | - - | | |
| Intake and exhaust system | Intake resistance | At all speed | mmH ₂ O | Max. 300 | 650 | | |
| | Intake pressure | At rated output | mmHg | Max. 75 | -- | | |
| | Exhaust pressure | All speed | ° C | Max. 700 | Max. 700 | | |
| | Exhaust temperature (Turbine inlet temp.) | | | | | | |
| | Exhaust gas colour | At rated output | Bosch Unit | Max.7.0 | Max 8.0 | | |
| | At high idling | | | Max. 4.0 | Max 5.0 | | |
| | Valve clearance (when engine is hot or cold.) | Intake valve | mm | 0.33 | -- | | |
| Engine body | | Exhaust valve | mm | 0.71 | - | | |
| | Compression Pressure (SAE30 oil) | Oil temperature: 40° C to 60° C (Engine speed) | Kg/cm ² (r/min) | Min. 32 (200 - 250) | 22 (200 - 250) | | |
| | Blow-by pressure (SAE30 oil) | At rated output Water temperature: Min. 70° C | mmH ₂ O | Max. 150 | Max. 300 | | |
| Lubrication system | Oil Pressure (Oil temperature: Min. 80° C) | SAE30 oil | Kg/cm ² | 2.7 - 5.0 | Min 1.9 | | |
| | | At rated output | | | | | |
| | | SAE10W oil | Kg/cm ² | 2.5 - 4.5 | Min 1.8 | | |
| | | At low idling | | | | | |
| | Oil temperature | All speed (oil in oil pan) | ° C | 80 - 110 | Max 120 | | |
| Fuel system | Fuel injection Pressure | Nozzle tester | Kg/cm ² | 250 $\begin{smallmatrix} +10 \\ +3 \end{smallmatrix}$ | Min 225 | | |
| | Fuel injection timing | B.T.D.C | degree | 18 \pm 1 | 18 \pm 1 | | |
| | | | | | | | |
| Cooling system | Radiator pressure valve | Opening pressure (Differential pressure) | Kg/cm ² | 0.75 \pm 0.1 | 0.7.5 \pm 0.1 | | |
| | Fan speed | At rated engine speed | r/min | 1,395 \pm 42 | -- | | |
| | Fan belt tension | Deflects when pushed with a force of 6 kg | mm | 6.5 | 5-8.5 | | |

★ The values given in the Testing and Adjusting data are NOT for adjustment of the output.

Do not use these values as a guide to change the setting of the fuel injection pump.

ENGINE

TROUBLESHOOTING



| | |
|--|------------|
| Points to remember when troubleshooting. | 13.015 |
| method of using troubleshooting chart | 13.018 |
| S-1 Starting performance is poor (Starting always takes time) | 13.022 |
| S-2 Engine does not start | |
| ① Engine does not turn | 13.023 |
| ② Engine turns but no exhaust gas comes out (Fuel is not being injected) | 13.024 |
| ③ Exhaust gas comes out but engine does not start (Fuel is being injected) | 13.025 |
| S-3 Engine does not pick up smoothly (Follow-up is poor) | 13.026 |
| S-4 Engine stops during operation | 13.027 |
| S-5 Engine does not rotate smoothly | 13.028 |
| S-6 Engine lacks output (no power) | 13.029 |
| S-7 Exhaust gas is black (Incomplete combustion) | 13.030 |
| S-8 Oil consumption is excessive (or exhaust gas is blue) | 13.031 |
| S-9 Oil becomes contaminated quickly | 13.032 |
| S-10 Fuel consumption is excessive | 13.033 |
| S-11 Oil is in cooling water , or water spurts back , or water level goes down | 13.034 |
| S-12 Oil pressure lamp lights up (drop in oil pressure) | 13.035 |
| S-13 Oil level rises | 13.036 |
| S-14 water temperature becomes too high(overheating) | 13.037 |
| S-15 Abnormal noise is made | 13.038 |
| S-16 Vibration is excessive | 13.039 |



When carrying out testing and adjusting , or troubleshooting , stop the machine on level ground , fit Safety pins, block the wheels , and apply the parking brake.



When carrying out operation with two or more workers , always use signals , and do not allow any unauthorized person near the machine.



When checking the water level , if the radiator cap is removed when the engine is hot , boiling water will spurt out and may cause burns , so always wait for the engine to cool down before checking the water level

* When using the standard values table for judgement in testing , adjusting , or troubleshooting , it is necessary to be careful of the following points.

1. The standard values for the new machines in the standard values table are values given as reference from the standards for new machines and machines shipped from the factory. They should be used as values for estimating wear during operation or as target values when carrying out repairs.
2. The failure judgement standard values in the standard value table are values using estimated values based on the results of various tests and standard values for machines shipped from the factory. Use these values for reference together with the repair and operation history of the machine when judgement failures.
3. Do not use this standard values table as a standard for judgement claims

POINTS TO REMEMBER WHEN TROUBLESHOOTING

Troubleshooting means locating the basic cause of the failure, and carrying out swift repairs, and ensuring that the failure does not occur again.

When carrying out troubleshooting, it is of course important to understand the structure and function. But to carry out the troubleshooting effectively, a quick method is to carry out troubleshooting using the problems mentioned by the operator as a guide in locating the cause.

1. Do not disassemble the machine simply because there is a failure.

If the machine is disassembled immediately just because there is a failure:

- Unrelated or unnecessary places are also disassembled
- It becomes difficult to locate the cause of the failure

This means that there is not only a waste of time and money on replacement parts, oil, and grease, but this action will also lose the confidence of the user and operator.

For this reason also, it is important to carry out troubleshooting based on full investigation before starting and troubleshooting following the correct order.

2. Questions to ask the user and operator

- 1) Are there any problems other than those already reported ?
- 2) Did anything unusual happen before the failure occurred ?
- 3) Did the failure occur suddenly, or had the condition of the machine been poor before the failure occurred ?
- 4) What were the conditions when the failure occurred?
- 5) Had any repairs been carried out before the failure occurred ?
- 6) Had any similar failure occurred before ?

3. Checks before troubleshooting

- 1) Check the oil level
- 2) Check for any external leakage of oil from the piping and hydraulic equipment.
- 3) Check the travel of the control levers.
- 4) Other maintenance items can also be carried out visually, so carry out any check that is considered necessary.

4. Confirming failure

Check the degree of the problem to judge for yourself if it is really a failure, or if there is some problem in the handling or operation of the machine.

- ★ When driving the machine and re-enacting the failure, be sure that the investigation or measurement does not make the failure worse.

5. Troubleshooting

Narrow down the causes of the failure from the results of the questions and checks in the above Items 2 - 4, then follow the troubleshooting flow chart to locate the failure.

- ★ Basic procedure for troubleshooting
 - 1) Start from the simple places.
 - 2) Start from the most probable places.
 - 3) Investigate related parts also.

6. Basic action to remedy cause of failure

Even if the failure is repaired, if the root cause of the failure is not repaired, the same failure will occur again. To prevent this, it is necessary to investigate why the failure occurred, and to remove the root cause of the failure.

METHOD OF USING TROUBLESHOOTING CHART

This troubleshooting chart is divided into three sections:

questions, check items, and troubleshooting.

The questions and check items are used to pinpoint high probability causes that can be located from the failure symptoms or simple inspection without using troubleshooting tools.

Next, troubleshooting tools or direct inspection are used to check the high probability causes to make final confirmation.

[Questions]

Section **A + B** in the chart on the right corresponds to the items where answers can be obtained from the user. The items in **B** are items that can be obtained from the user, depending on the user's level.

[Check items]

The serviceman carries out simple inspection to narrow down the causes. The items under **C** in the chart on the right correspond to this.

The serviceman narrows down the causes from information **A** that he has obtained from the user and the results of **C** that he has obtained from his own inspection.

[Troubleshooting]

Troubleshooting is carried out in the order of probability, starting with the causes that have been marked as having the highest probability from information gained from [Questions] and [Check items].

| | | Causes | | |
|--|------------------|--------|-----|-----|
| | | (1) | (2) | (3) |
| <div style="display: flex; align-items: center;"> <div style="margin-right: 5px;"> <div style="border-left: 1px solid black; height: 100px; position: relative;"> <div style="position: absolute; top: 0; left: -5px;">A</div> <div style="position: absolute; bottom: 0; left: -5px;">B</div> <div style="position: absolute; top: 50%; left: -5px;">C</div> </div> </div> </div> | Questions | (a) | ◎ | |
| | | (b) | | ◎ |
| | | (c) | ◎ | |
| | | (d) | ○ | |
| | | (e) | | ○ |
| | Check items | ● | | |
| | | | | |
| | | | | |
| | Trouble-shooting | i | ● | |
| | | ii | | ● |
| | | iii | | ● |
| | | | | |

The basic method of using the troubleshooting chart is as follows.

Items listed for **[Questions]** and **[Check items]** that have a relationship with the cause items are marked with ○ , and of these, causes that have a high probability are marked with ⊙

Check each of the **[Questions]** and **[Check items]** in turn, and marked the○ or ⊙ in the chart for items where the problem appeared. The vertical column (Causes) that has the highest number of points is the most probable cause, so start troubleshooting for that item to make final confirmation of the cause.

- ❖1. For **[Confirm recent repair history]** in the **[Questions]** Section, ask the user, and mark the cause column with Δ to use as reference for locating the cause of the failure. However, do not use this when making calculations to narrow down the causes.
- ❖2. Use the Δ in the cause column as reference for **[Degree of use (Operated for long period)]** in the **[Questions]** Section as reference. As a rule, do not use it when calculating the points for locating the cause, but it can be included if necessary to determine the order for troubleshooting.

| | | | Causes | | | | | |
|-----|-------------------------------|--------------------------|-----------------------------------|-----------------------------|----------------------------|----------------------------------|---------------------------|--|
| | | | Seized turbocharger, interference | Clogged air cleaner element | Worn piston ring, cylinder | Clogged, seized injection nozzle | Improper injection timing | Defective injection pump (excessive injection) |
| ❖ 1 | Confirm recent repair history | | | | | | | |
| ❖ 2 | Degree of use | Operated for long period | | Δ | Δ | Δ | | |
| | | | | | | | | |
| | | | | | | | | |

Example of troubleshooting when exhaust gas is black :

Let us assume that [Clogged air cleaner] is taken to be the cause of black exhaust gas. Three symptoms have causal relationship with this problem: [Exhaust gas slowly become black.], [Power slowly become weaker], and [Dust indicator is red].

If we look from these three symptoms to find the causes, we find that there is a relationship with five causes. Let us explain here the method of using this causal relationship to pinpoint the most probable cause.


S-7 Exhaust gas is black (incomplete combustion)

General causes why exhaust gas is black

- Insufficient intake air
- Improper condition of fuel injection
- Excessive injection of fuel

Gradually became black

| | | | Causes | | | | | | | | | | |
|------------------------|--|--------------------------|-----------------------------------|-----------------------------|----------------------------|----------------------------------|---------------------------|--|--------------------------|--------------------------|--|--|---|
| | | | Seized turbocharger, interference | Clogged air cleaner element | Worn piston ring, cylinder | Clogged, seized injection nozzle | Improper injection timing | Defective injection pump (excessive injection) | Improper valve clearance | Crushed, clogged muffler | Leakage of air between turbocharger and head | Defective contact of valve, valve seat | Defective injection pump (rack, plunger seized) |
| Gradually became black | | | | | | | | | | | | | |
| Questions | Confirm recent repair history | | | | | | | | | | | | |
| | Degree of use | Operated for long period | Δ | Δ | Δ | | | | | | | Δ | |
| | Color of exhaust gas | Suddenly became black | | | ○ | | | | | | | | ○ |
| | | Gradually became black | | ◎ | ○ | | | | | | ○ | | |
| | | Blue under light load | | | ◎ | | | | | | | | |
| Check items | Engine oil must be added more frequently | | | | ◎ | | | | | | | | |
| | Power was lost | Suddenly | ◎ | | ○ | | | | | ○ | | | ○ |
| | | Gradually | | ○ | ○ | | | | | | ○ | ○ | |
| | Non-specified fuel has been used | | | | | ○ | | | | | | | ○ |
| | Noise of interference is heard from around turbocharger | | ◎ | | | | | | | | | | |
| | Dust indicator is red | | | ◎ | | | | | | | | | |
| | Blow-by gas is excessive | | | | ◎ | | | | | | | | |
| | Engine pickup is poor and combustion is irregular | | ○ | | | ◎ | | ○ | ○ | ○ | | ○ | |
| | When exhaust manifold is touched immediatly after starting engine, temperature of some cylinder is low | | | | | | ◎ | | | | | | ○ |
| | Match marks on fuel injection pump are out of alignment | | | | | | | ◎ | | | | | |
| | Seal on injection pump has come off | | | | | | | | ◎ | | | | |
| | Clanging sound is heard from around cylinder head | | | | | | | | | ◎ | | | |
| | Exhaust noise is abnormal | | ○ | | | ○ | | | | | ◎ | | |
| | Muffler is crushed | | | | | | | | | | ◎ | | |
| | Leakage of air between turbocharger and head, loose clamp | | | | | | | | | | | ◎ | |
| Troubleshooting | When turbocharger is rotated by hand, it is found by heavy | | ● | | | | | | | | | | |
| | When air cleaner is inspected directly, it is found to be clogged | | | ● | | | | | | | | | |
| | When compression pressure is measured, it is found to be low | | | | | | | | | | | ● | |
| | Speed of some cylinders does not change when operating on reduced cylinders | | | | | ● | | | | | | | |
| | When check is made using delivery method, injection timing is found to be incorrect | | | | | | ● | | | | | | |
| | Injection pump test shows that injection amount is incorrect | | | | | | | ● | | | | | |
| | When valve clearance is checked directly it is found to be outside standard value | | | | | | | | ● | | | | |
| | When muffler is removed, exhaust gas color returns to normal | | | | | | | | | ● | | | |
| | When control rack is pushed, it is found to be heavy or does not return | | | | | | | | | | | | ● |
| | | Remedy | Replace | Clean | Replace | Replace | Adjust | Adjust | Adjust | Replace | Repair | Replace | Replace |



S-1 Starting performance is poor (Starting always takes time)

General causes why starting performance is poor

- Defective electrical system
- Insufficient supply of fuel
- Insufficient intake of air
- Improper selection of fuel (At ambient temperature of -10° C use ASTM D 975 No.1 ,and -10° C or above , use ASTM D975 No. 2 diesel fuel)
- ★ Battery charging rate

| Charging rate Ambient temperature | 100 % | 90 % | 80 % | 75 % | 70 % |
|--------------------------------------|-------|------|------|------|------|
| 20° C | 1.28 | 1.26 | 1.24 | 1.23 | 1.22 |
| 0° C | 1.29 | 1.27 | 1.25 | 1.24 | 1.23 |
| -10° C | 1.30 | 1.28 | 1.26 | 1.25 | 1.24 |

- The specific gravity should exceed the value for the charging rate of 70 % in the above table
- In cold weather the specific gravity must exceed the value for the charging rate of 75% in the above table

| Causes | | | | | | | | | | | |
|----------------------------|--|-----------------------------|-------------------------------|----------------------------|----------------------|---------------------|----------------------|-----------------------------------|----------------------------|----------------------------|--|
| Worn piston ring, cylinder | Defective contact of valve, valve seat | Clogged air cleaner element | Clogged fuel filter, strainer | Clogged feed pump strainer | Defective APS device | Defective regulator | Defective alternator | Defective or deteriorated battery | Defective injection nozzle | Defective injection timing | Defective injection pump (rack, plunger stuck) |
| | | | | | | | | | | | Leakage, clogging, air in fuel system |
| | | | | | | | | | | | Clogged fuel tank air breather hole |

| | | | | | | | | | | | | |
|-----------------|---|---------|--------|-------|-------|-------|---------|---------|---------|---------|--------|---------|
| Questions | Confirm recent repair history | | | | | | | | | | | |
| | Degree of use | | | | | | | △ | | | | |
| | Ease of starting | | | | | | | | | | | |
| | | | | | | | | | | | | |
| | Indicator lamp does not light up | | | | | | | | | | | |
| | Engine oil must be added more frequently | ◎ | | | | | | | | | | |
| | Replacement of filters has not been carried out according to operation manual | | | ◎ | ◎ | ◎ | | | | ○ | ○ | |
| | Dust indicator is red | | | ◎ | | | | | | | | |
| Check items | Non-specified fuel has been used | | | | ○ | ○ | | | | ○ | ○ | |
| | Battery charge lamp is ON | | | | | | ◎ | ◎ | | | | |
| | Starting motor cranks engine slowly | | | | | | | ◎ | | | | |
| | When exhaust manifold is touched immediately after starting engine, temperature of some cylinder is low | | | | | | | | ◎ | | | |
| | Engine does not pick up smoothly, and combustion is irregular | ○ | ○ | | | | | | ◎ | | | |
| | Blow-by gas is excessive | ◎ | | | | | | | | | | |
| | Match marks on fuel injection pump are out of alignment | | | | | | | | | ◎ | | |
| | Mud is stuck to fuel tank cap | | | | | | | | | | | ○ |
| | When engine is cranked with starting motor, 1) Little fuel comes out even when injection pump sleeve nut is loosened | | | | | | | | | | ◎ | |
| | 2) Little fuel comes out even when fuel filter air bleed plug is loosened | | | | ◎ | ◎ | | | | | ◎ | |
| Troubleshooting | Leakage from fuel piping | | | | | | | | | | ○ | ◎ |
| | There is hunting from engine (rotation is irregular) | | | | ○ | ○ | | | | | ◎ | ○ |
| | When compression pressure is measured, it is found to be low | ● | ● | | | | | | | | | |
| | When air cleaner element is inspected directly, it is found to be clogged | | | ● | | | | | | | | |
| | When fuel filter, strainer are inspected directly, they are found to be clogged | | | | ● | | | | | | | ● |
| | When feed pump strainer is inspected directly, it is found to be clogged | | | | | ● | | | | | | |
| | APS combustion portion does not become warm | | | | | ● | | | | | | |
| | Voltage is 26 - 30V between alternator terminal B and terminal E with engine at low idling | | | | | | ● | | | | | |
| | Either specific gravity of electrolyte or voltage of battery is low | | | | | | | ● | | | | |
| | Speed of some cylinders does not change when operating on reduced cylinder | | | | | | | | ● | | | |
| | when check is made using delivery method , injection timing is found to be incorrect | | | | | | | | | ● | | |
| | When control rack is pushed , it is found to be heavy or does not return (when blind plug at rear of pump is removed, it can be seen that plunger control sleeve does not move) | | | | | | | | | | ● | |
| | When fuel cap is inspected directly , it is found to be clogged | | | | | | | | | | | ● |
| | Legend | | | | | | | | | | | |
| | ● : Possible cause (judging from Questions and Check items) | | | | | | | | | | | |
| | ○ : Most probable causes (judging from Questions and Check items) | | | | | | | | | | | |
| | ◎ : Possible causes due to length of use (used for a long period) | | | | | | | | | | | |
| | △ : Items confirm the cause | | | | | | | | | | | |
| | Remedy | Replace | Repair | Clean | Clean | Clean | Replace | Replace | Replace | Replace | Adjust | Replace |
| | | | | | | | | | | | | Repair |
| | | | | | | | | | | | | Clean |

S-2 Engine does not start

① Engine does not turn

General causes why does not turn

- Internal parts of engine seized
 - ★ If internal parts of the engine are seized, carry out trouble-shooting for “Engine stops during operations”
- Failure in power train
- Defective electrical system

| | | | Causes | | | | | | | | | | |
|---|---|--|--------------------------------------|-----------------------------------|--------------------------|------------------|---|-------------------------|---------------------------------------|-----------------------------------|--|-----------------------------|---------------------------|
| | | | Defective wiring of starting circuit | Defective or deteriorated battery | Defective starting motor | Broken ring gear | Defective safety relay or safety switch | Defective battery relay | Defective battery terminal connection | Defective fuel cut solenoid valve | Defective adjustment of engine stop motor wire | Defective engine stop motor | Defective starting switch |
| <div>Questions</div> <div>Check items</div> <div>Troubleshooting</div> | Confirm recent repair history | | | | | | | | | | | | |
| | Degree of use | Operated for long period | | Δ | Δ | | | | | | | | |
| | Condition of horn when starting switch is turned ON | Horn does not sound | ⊙ | | | | | ○ | | | | | ○ |
| | | Horn sound level is low | | ⊙ | | | | | | | | | |
| | | Rotating speed is slow | | ⊙ | | | | | | | | | |
| | When starting switch is turned to START, pinion moves out,but | Makes grating noise | | | ⊙ | ⊙ | | | | | | | |
| | | Soon disengages again | | | | | ⊙ | | | | | | |
| | | Makes rattling noise and does not turn | | | | | | | | | | | |
| | When starting switch is turned to START, pinion does not move out | | ⊙ | ○ | ○ | | ○ | | | | | | ○ |
| | When starting switch is turned to ON, there is no clicking sound | | | ○ | | | ⊙ | | | | | | |
| | Battery terminal is loose | | | | | | | ⊙ | | | | | |
| | When starting switch is turned to ON, linkage does not move | | | | | | | | ⊙ | ⊙ | ⊙ | | |
| | When battery is checked, battery electrolyte is found to be low | | | ○ | | | | | | | | | |
| | Specific gravity of electrolyte, voltage of battery is low | | | ● | | | | | | | | | |
| | For the following conditions 1) - 5), turn the starting switch OFF, connect the cord, and carry out troubleshooting at ON | | | | | | | | | | | | |
| 1) When terminal B and terminal C of starting switch are connected, engine starts | | | | | | | | | | | | ● | |
| 2) When terminal B and terminal C of starting motor are connected, engine starts | | | | ● | | | | | | | | | |
| 3) When terminal B and terminal C of safety relay are connected, engine starts | | | | | | ● | | | | | | | |
| 4) When terminal of safety switch and terminal B of starting motor are connected, engine starts | | | | | | | ● | | | | | | |
| 5) There is no 24V voltage between battery relay terminal B and terminal E of battery | | | | | | | | ● | | | | | |
| When ring gear is inspected directly, tooth surface is found to be chipped | | | | | ● | | | | | | | | |
| Does not move even when fuel cut solenoid linkage is disconnected | | | | | | | | | ● | | | | |
| Does not move even when engine stop motor linkage is disconnected | | | | | | | | | | | ● | ● | |
| Remedy | | | - | Replace | Replace | Replace | Replace | Replace | Replace | Replace | Adjust | Replace | Replace |

Legend

- : Possible cause (judging from Questions and Check items)
 ⊙ : Most probable causes (judging from Questions and Check items)
 Δ : Possible causes due to length of use (used for a long period)
 ● : Items confirm the cause

② Engine turns but no exhaust gas comes out (Fuel is not being injected)

General causes why engine turns but no exhaust gas comes out

- Supply of fuel impossible
- Supply of fuel is extremely small
- Improper selection of fuel (particularly in winter)

Standards for use of fuel

| TYPE OF FUEL | AMBIENT TEMPERATURE | | | | | | | | | |
|--------------|---------------------|-----|-----|----|----|----|----|-----|-------|--|
| | -22 | -4 | 14 | 32 | 50 | 68 | 86 | 104 | 122°F | |
| | -30 | -20 | -10 | 0 | 10 | 20 | 30 | 40 | 50°C | |
| Diesel fuel | ASTM D975 No.2 | | | | | | | | | |
| | ASTM D975 No.1 | | | | | | | | | |

| | | | Causes | | | | | | | | | |
|-----------------|---|--------------------------|--|---|---------------------------------|-------------------------------|----------------------------|--------------|------------------------------|-------------------------------------|-----------------------------|-----------------------------|
| | | | Blocked, injection pump drive shaft, key | Defective injection pump (rack, plunger seized) | Seized, broken feed pump piston | Clogged fuel filter, strainer | Clogged feed pump strainer | Lack of fuel | Clogged, leaking fuel piping | Clogged fuel tank air breather hole | Defective fuel cut solenoid | Defective engine stop motor |
| | | | Improper fuel used | | | | | | | | | |
| Questions | Confirm recent repair history | | | | | | | | | | | |
| | Degree of use | Operated for long period | | | Δ | Δ | | | Δ | | | |
| | Exhaust gas suddenly (when starting again) stopped coming out | | ⊙ | ⊙ | ⊙ | | | | | | | |
| | Replacement of filters has not been carried out according to operation manual | | | | ⊙ | ⊙ | | | | | | |
| | Fuel tank is found to be empty | | | | | | ⊙ | | | | | |
| | There is leakage from fuel piping, | | | | | | | ⊙ | | | | |
| | Mud is stuck to fuel tank cap | | | | | | | | ⊙ | | | |
| | When starting switch is turned ON, linkage does not move | | | | | | | | | ⊙ | ⊙ | |
| | When fuel filter is drained, fuel does not come out | | | | | | | | | | | ⊙ |
| | When engine is cranked with starting motor, | | ⊙ | | | | | | | | | |
| Check items | 1) Injection pump coupling does not rotate | | ⊙ | | | | | | | | | |
| | 2) No fuel comes out even when fuel filter air bleed plug is loosened | | ⊙ | | ○ | ○ | | | | | | |
| | 3) No fuel spurts out even when injection pipe sleeve nut is loosened | | ⊙ | ⊙ | ⊙ | | | | | | | |
| | Check injection pump directly | | ● | | | | | | | | | |
| | When control rack is pushed, it is found to be heavy or does not return | | | ● | | | | | | | | |
| | Check feed pump directly | | | | ● | | | | | | | |
| | When fuel filter, strainer are inspected directly, they are found to be clogged | | | | | ● | | | | | | ● |
| | When feed pump strainer is inspected directly, it is found to be clogged | | | | | | ● | | | | | |
| | When fuel cap is inspected directly, it is found to be clogged | | | | | | | | ● | | | |
| | Does not move even when fuel cut solenoid linkage is disconnected | | | | | | | | | ● | | |
| Troubleshooting | Does not move even when engine stop motor linkage is disconnected | | | | | | | | | | ● | |
| | Remedy | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |
| | | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |
| | | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |
| | | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |
| | | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |
| | | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |
| | | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |
| | | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |
| | | | Replace | Replace | Replace | Clean | Clean | Add | Repair | Repair | Replace | Replace |

Legend

- : Possible cause (judging from Questions and Check items)
- ⊙: Most probable causes (judging from Questions and Check items)
- Δ: Possible causes due to length of use (used for a long period)
- : Items confirm the cause

③ Exhaust gas comes out but engine does not start (Fuel is being injected)

General causes why exhaust gas comes out but engine does not start

- Lack of rotating force due to defective electrical system
- Insufficient supply of fuel
- Insufficient intake of air
- Improper selection of fuel and oil

| | | Causes | | | | | | | | | | |
|--|---|--|--|----------------------------------|-------------------------------|----------------------------|-----------------------------|-------------------------------------|-----------------------------------|---------------------------------------|---|-------------------------------------|
| | | Defective, broken valve system (valve, rocker lever, etc.) | Defective injection pump (rack, plunger stuck) | Worn piston ring, cylinder liner | Clogged fuel filter, strainer | Clogged feed pump strainer | Clogged air cleaner element | Defective intake heater (ribbo typ) | Defective or deteriorated battery | Leakage, clogging, air in fuel system | Clogged injection nozzle, defective spray | Clogged fuel tank air breather hole |
| Questions | Confirm recent repair history | | | | | | | | | | | |
| | Degree of use | | | Δ | Δ | Δ | | | | | Δ | |
| | Suddenly failed to start | ⊙ | ⊙ | | | | | | | | | |
| | When engine is cranked, abnormal noise is heard from around cylinder head | ⊙ | | | | | | | | | | |
| | Engine oil must be added more frequently | | | ⊙ | | | | | | | | |
| | Non-specified fuel had been used | | ○ | | | | | | | | ○ | |
| | Replacement of filter has not been carried out according to operation manual | | | | ⊙ | ⊙ | ⊙ | | | | | |
| | Type of oil is not used according to operation manual | | | | | | | | | | | |
| | Rust is found when fuel is drained | | | | ⊙ | ⊙ | | | | | | |
| | Dust indicator is red | | | | | | ⊙ | | | | | |
| | Indicator lamp does not light up | | | | | | | ⊙ | | | | |
| | Starting motor cranks engine slowly | | | | | | | | ⊙ | | | |
| | Mud is stuck to fuel tank cap | | | | | | | | | | | ○ |
| Check items | When fuel lever is placed at FULL position, it does not contact stopper | ○ | | | | | | | | | | |
| | When engine is cranked with starting motor, 1) Little fuel comes out even when injection pump sleeve nut is loosened | ⊙ | | | | | | | | | | |
| | 2) Little fuel comes out even when fuel filter air bleed plug is loosened | | | | ⊙ | ⊙ | | | | | | ○ |
| | There is leakage, from fuel piping | | | | | | | | | ⊙ | | |
| | When exhaust manifold is touched immediately after starting engine, temperature of some cylinder is low | | | | | | | | | | ⊙ | |
| | When fuel filter is drained, no fuel comes out | | | | | | | | | | | ⊙ |
| | | | | | | | | | | | | |
| | | | | | | | | | | | | |
| Troubleshooting | Remove head cover and inspect directly | ● | | | | | | | | | | |
| | When control rack is pushed, it is found to be heavy or does not return | | ● | | | | | | | | | |
| | When compression pressure is measured, it is found to be low | | | ● | | | | | | | | |
| | When fuel filter, strainer are inspected directly, they are found to be clogged | | | | ● | | | | | | | ● |
| | When feed pump strainer is inspected directly, it is found to be clogged | | | | | ● | | | | | | |
| | When air cleaner element is inspected directly, it is found to be clogged | | | | | | ● | | | | | |
| | Heater mout does not become warm | | | | | | | ● | | | | |
| | | | | | | | | | | | | |
| | Either specific gravity of electrolyte or voltage of battery is low | | | | | | | | ● | | | |
| | When feed pump is operated, there is no response or pump is heavy | | | | | | | | | ● | | |
| | Speed of some cylinder does not change when operating on reduced cylinder | | | | | | | | | | ● | |
| | When fuel cap is inspected directly, it is found to be clogged | | | | | | | | | | | ● |
| Legend | | Remedy | | | | | | | | | | |
| ○: Possible cause (judging from Questions and Check items) | | Replace | Replace | Replace | Clean | Clean | Clean | Repair | Replace | Repair | Clean | Clean |
| ⊙: Most probable causes (judging from Questions and Check items) | | Replace | Replace | Replace | Clean | Clean | Clean | Repair | Replace | Repair | Clean | Clean |
| Δ: Possible causes due to length of use (used for a long period) | | | | | | | | | | | | |
| ●: Items confirm the cause | | | | | | | | | | | | |

S-3 Engine does not pick up smoothly (Follow-up is poor)

General causes why engine does not pick up smoothly

- Insufficient intake of air
- Insufficient supply of fuel
- Improper condition of fuel injection
- Use of improper fuel

| | | | Causes | | | | | | | | | | | |
|---|--|--------------------------|-----------------------------|-------------------------------|----------------------------|---|-------------------------------|----------------------------|-----------------------------------|--------------------------|-------------------------------------|------------------------------|--|---------|
| | | | Clogged air cleaner element | Clogged fuel filter, strainer | Clogged feed pump strainer | Clogged injection nozzle, defective spray | Seized injection pump plunger | Worn piston ring, cylinder | Seized turbocharger, interference | Improper valve clearance | Clogged fuel tank air breather hole | Clogged, leaking fuel piping | Defective contact of valve, valve seat | |
| Questions | Confirm recent repair history | | | | | | | | | | | | | |
| | Degree of use | Operated for long period | Δ | Δ | Δ | | | Δ | | | | | Δ | |
| | Replacement of filter has not been carried out according to operation manual | | ⊙ | ⊙ | ⊙ | | | | | | | | | |
| | Non-specified fuel has been used | | | ⊙ | ⊙ | ⊙ | ⊙ | | | | | | | |
| | Engine oil must be added more frequently | | | | | | | ⊙ | | | | | | |
| | Rust and water are found when fuel is drained | | | ⊙ | ⊙ | | | | | | | | | |
| | Dust indicator is red | | ⊙ | | | | | | | | | | | |
| | Noise of interference is heard from around turbocharger | | | | | | | | ⊙ | | | | | |
| Check items | Engine pick-up suddenly poor | | | | | ○ | | ⊙ | | ○ | ○ | | | |
| | Color of exhaust gas | Blue under light load | | | | | | ⊙ | | | | | | |
| | | Black | ⊙ | | | ⊙ | | ⊙ | | | | | ○ | |
| | Clanging sound is heard from around cylinder head | | | | | | | | ⊙ | | | | | |
| | Mud is stuck to fuel tank cap | | | | | | | | | ⊙ | | | | |
| | There is leakage, from fuel piping | | | | | | | | | | ⊙ | | | |
| | High idling speed under no load is normal, but speed suddenly drops when load is applied | | | ⊙ | ⊙ | | | | | ○ | | | | |
| | There is hunting from engine (rotation is irregular) | | | ○ | ⊙ | ○ | | | | | | | | |
| | When exhaust manifold is touched immediatly after starting engine, temperature of some cylinder is low | | | | | ⊙ | ○ | | | | | | | |
| | Blow-by gas is excessive | | | | | | | ⊙ | | | | | | |
| Troubleshooting | When air cleaner element is inspected directly, it is found to be clogged | | ● | | | | | | | | | | | |
| | When fuel filter, strainer are inspected directly, they are found to be clogged | | | ● | | | | | | | | | | |
| | When feed pump strainer is inspected directly, it is found to be clogged | | | | ● | | | | | | | | | |
| | Some cylinders does not change engine speed when operating on reduced cylinder | | | | | ● | | | | | | | | |
| | When control rack is pushed, it is found to be heavy, or does not return | | | | | | ● | | | | | | | |
| | When compression pressure is measured, it is found to be low | | | | | | | ● | | | | | ● | |
| | When turbocharger is rotated by hand, it is found to be heavy | | | | | | | | ● | | | | | |
| | When valve clearance is checked directly, it is found to be outside standard value | | | | | | | | | ● | | | | |
| | When fuel cap is inspected directly, it is found to be clogged | | | | | | | | | | ● | | | |
| When feed pump is operated, operation is too light or too heavy | | | | | | | | | | | ● | | | |
| | | | Remedy | Clean | Clean | Clean | Repair | Replace | Replace | Replace | Adjust | Clean | Repair | Replace |

Legend :

○: Possible cause (judging from Questions and Check items)

⊙: Most probable causes (judging from Questions and Check items)

Δ: Possible causes due to length of use (used for a long period)

●: Items confirm the cause

S-4 Engine stops during operations

General causes why engine stops during operations

- Seized parts inside engine
- Insufficient supply of fuel
- Overheating
 - ★ If there is overheating and insufficient output carry out troubleshooting for overheating.
- Failure in power train
 - ★ If the engine stops because of a failure in the power train, carry out troubleshooting for the chassis.

| | | Causes | | | | | | | | | | | | | |
|--|---|--|-----------------------------------|---|---------------------------|---------------------------------|-----------------------------------|--------------|-------------------------------|----------------------------|---------------------------------|-----------------------------|-------------------------------------|--|--------------------------------|
| | | Broken, seized piston, connecting rod | Broken, seized crankshaft bearing | Broken valve system (valve, rocker lever, etc.) | Broken, seized gear train | Broken pump auxiliary equipment | Broken fuel pump drive shaft, key | Lack of fuel | Clogged fuel filter, strainer | Clogged feed pump strainer | Broken, seized feed pump piston | Clogged leaking fuel piping | Clogged fuel tank air breather hole | Defective injection pump (rack, plunger stuck) | Failure in chassis power train |
| Questions | Confirm recent repair history | | | | | | | | | | | | | | |
| | Degree of use | Operated for long period | | | | | | | Δ | Δ | | | | | |
| | Condition when engine stooped | Abnormal noise was heard and engine stopped suddenly | | | | | | | | | | ○ | | | |
| | | Engine overheated and stopped | | ○ | | | ○ | | | | | | | | |
| | | Engine stopped slowly | | | | | | | | ○ | ○ | | | | |
| | | There was hunting and engine stopped | | | | | | | | ○ | ○ | | | ○ | |
| | Fuel gauge lamp lights up | | | | | | | ⊙ | | | | | | | |
| | Fuel tank is found to be empty | | | | | | | ⊙ | | | | | | | |
| | Replacement of filters has not been carried out according to operation manual | | | | | | | | ⊙ | ⊙ | | | | | |
| | Non specified fuel has been used | | | | | | | | | ○ | ○ | ○ | | | ○ |
| Check items | When feed pump is operated, there is no response or it is heavy | | | | | | | | ○ | ○ | | ⊙ | | | |
| | Mud is stuck to fuel tank cap | | | | | | | | | | | | ⊙ | | |
| | Engine turns, but stops when transmission control lever is operated | | | | | | | | | | | | | | |
| | Try to turn by hand using barring tool | Does not turn at all | ⊙ | ⊙ | | | | | | | | | | | |
| | | Turns in opposite direction | | | ⊙ | | | | | | | | | | |
| | | Moves amount of backlash | | | | ⊙ | ⊙ | | | | | | | | |
| | | Shaft does not turn | | | | | | ⊙ | | | | | | | |
| | Rust and water are found when fuel is drained | | | | | | | | ⊙ | ⊙ | | | | | |
| Metal particales are found when oil is drained | | ⊙ | ⊙ | | | | | | ○ | ○ | | | | | |
| Troubleshooting | Remove oil pan and inspect directly | | ● | ● | | | | | | | | | | | |
| | Remove head cover and inspect directly | | | | ● | | | | | | | | | | |
| | When gear train is inspected, it does not turn | | | | | ● | | | | | | | | | |
| | Turns when pump auxiliary equipment is removed | | | | | | ● | | | | | | | | |
| | When fuel filter, strainer are inspected directly, they are found to be clogged | | | | | | | | ● | | | | | | |
| | When feed pump strainer is inspected directly, it is found to be clogged | | | | | | | | | | ● | | | | |
| | check feed pump directly | | | | | | | | | | | ● | | | |
| | When control rack is pushed, it is found to be heavy or does not return | | | | | | | | | | | | | | ● |
| Remedy | | Replace | Replace | Replace | Replace | Replace | Replace | Add | Clean | Clean | Replace | Repair | Clean | Replace | I |
| Legend | | ○: Possible cause (judging from Questions and Check items) | | | | | | | | | | | | | |

Legend

- : Possible cause (judging from Questions and Check items)
- ⊙: Most probable causes (judging from Questions and Check items)
- Δ: Possible causes due to length of use (used for a long period)
- : Items confirm the cause

S-5 Engine does not rotate smoothly (hunting)

General causes why engine does not rotate smoothly

- Air in fuel system
 - Defective governor mechanism
 - Defective engine throttle controller mechanism (engine throttle controller type)
- ★ If there is no hunting when the engine throttle controller rod is disconnected, carry out troubleshooting for the electrical system.

| | | Causes | | | | | | | | | |
|-----------------|---|---------------------------------|----------------------------------|-------------------------------------|----------------------|--------------|----------------------------|-------------------------------|---|--|-------------------------------------|
| | | Defective operation of governor | Defective adjustment of governor | Defective operation of control rack | Low speed is too low | Lack of fuel | Clogged feed pump strainer | Clogged fuel filter, strainer | Clogged, air in circuit between fuel tank and feed pump | Clogged, air in circuit between feed pump and nozzle | Clogged fuel tank air breather hole |
| Questions | Confirm recent repair history | | | | | | | | | | |
| | Degree of use | | | | | | | Δ | Δ | | |
| | Condition of hunting | | | | | | | | | | |
| | Occurs at certain speed range | ⊙ | ⊙ | ⊙ | ○ | | | | | | |
| | Occurs at low idling | ○ | ○ | ○ | ⊙ | | ○ | ○ | ○ | ○ | |
| | Occurs even when speed is raised | ○ | ○ | ○ | | | | | | | ○ |
| | Occurs on slopes | | | | | ⊙ | | | | | |
| | Fuel tank is found to be empty | | | | | ⊙ | | | | | |
| | Replacement of filters has not been carried out according to operation manual | | | | | | ⊙ | ⊙ | | | |
| | Rust is found when fuel is drained | | | | | | ○ | ○ | | | |
| Check items | Leakage from fuel piping | | | | | | | | ⊙ | ⊙ | |
| | When feed pump is operated, | | | | | | | | | | |
| | 1) No response, light, return is quick | | | | | | | | ⊙ | ⊙ | |
| | 2) No response, light, return is normal | | | | | | | | ⊙ | | |
| | Engine speed sometimes rises too high | ⊙ | ⊙ | | | | | | | | |
| | Engine is sometimes difficult to stop | ⊙ | | ⊙ | | | | | | | |
| | Seal on injection pump has come off | | ⊙ | ⊙ | | | | | | | |
| | When governor lever is moved it is found to be stiff | ● | | ● | | | | | | | |
| Troubleshooting | When injection pump is tested, governor is found to be improperly adjusted | | ● | | | | | | | | |
| | When control rack is pushed, it is found to be heavy or does not return | | | ● | | | | | | | |
| | When fuel cap is inspected directly, it is found to be clogged | | | | ● | | | | | | ● |
| | When feed pump strainer is inspected directly, it is found to be clogged | | | | | | ● | | | | |
| | When fuel filter, strainer are inspected directly, they are found to be clogged | | | | | | | ● | | | |
| | | | | | | | | | | | |
| Remedy | | Adjust | Adjust | Adjust | Adjust | Add | Clean | Clean | Repair | Repair | Clean |

Legend

- : Possible cause (judging from Questions and Check items)
 ⊙: Most probable causes (judging from Questions and Check items)
 Δ: Possible causes due to length of use (used for a long period)
 ●: Items confirm the cause

S-6 Engine lacks output (no power)

General causes why engine lacks output

- Insufficient intake of air
- Insufficient supply of fuel
- Improper condition of fuel injection
- Use of improper fuel
(If non-specified fuel is used, output drops)
- Lack of output due to overheating
 - ★ If there is overheating and Insufficient output, carry out troubleshooting for overheating.

| General causes why engine lacks output | | | Causes | | | | | | | | | | | | |
|---|--|--------------------------|-----------------------------|-----------------------------------|----------------------------|-------------------------------|----------------------------|---|-------------------------------|--------------------------|--|---|------------------------------|-------------------------------------|-------|
| | | | Clogged air cleaner element | Seized turbocharger, interference | Worn piston ring, cylinder | Clogged fuel filter, strainer | Clogged feed pump strainer | Clogged injection nozzle, defective spray | Seized injection pump plunger | Improper valve clearance | Defective contact of valve, valve seat | Bent fuel lever linkage, Defective adjustment | Clogged, leaking fuel piping | Clogged fuel tank air breather hole | |
| <ul style="list-style-type: none">Insufficient intake of airInsufficient supply of fuelImproper condition of fuel injectionUse of improper fuel (If non-specified fuel is used, output drops)Lack of output due to overheating<ul style="list-style-type: none">★ If there is overheating and Insufficient output, carry out troubleshooting for overheating. | | | | | | | | | | | | | | | |
| Questions | Confirm recent repair history | | | | | | | | | | | | | | |
| | Degree of use | Operated for long period | Δ | | Δ | Δ | Δ | | | | Δ | | | | |
| | Power was use | Suddenly | ⊙ | ⊙ | | | | | | | | | | | |
| | | Gradually | ○ | | ○ | ○ | ○ | ○ | | | ○ | | | | |
| | Engine oil must be added more frequently | | | | ⊙ | | | | | | | | | | |
| | Replacement of filter has not been carried out according to operation manual | | ⊙ | | | ⊙ | ⊙ | | | | | | | | |
| | Non-specified fuel has been used | | | | | | ⊙ | ⊙ | ⊙ | ⊙ | | | | | |
| | Dust indicator is red | | ⊙ | | | | | | | | | | | | |
| | Color of exhaust gas | Black | ⊙ | ⊙ | | | | | | | | | | | |
| | | Blue under light load | | | ⊙ | | | | | | | | | | |
| | Noise of interference is heard from around turbocharger | | | ⊙ | | | | | | | | | | | |
| | Blow-by gas is excessive | | | | ⊙ | | | | | | | | | | |
| | Engine pick-up is poor and combustion is irregular | | | ⊙ | | | | ○ | | | | | ○ | ○ | |
| | High idling speed under no load is normal, but speed suddenly drops when load is applied | | | | | ⊙ | ⊙ | | | | | | | ○ | |
| Check items | When exhaust manifold is touched immediatly after starting engine, temperature of some cylinder is low | | | | | | ⊙ | ○ | | | | | | | |
| | There is hunting from engine (rotation is irregular) | | | | | ○ | ○ | | | | | ○ | ○ | | |
| | Clanging sound is heard from around cylinder head | | | | | | | | ⊙ | | | | | | |
| | High idling speed of engine is low | | | | | | | ○ | | | ⊙ | | | | |
| | Leakage from fuel piping | | | | | | | | | | | ⊙ | | | |
| | | | | | | | | | | | | | | | |
| Troubleshooting | When air cleaner element is inspected directly, it is found to be clogged | | ● | | | | | | | | | | | | |
| | When turbocharger is rotated by hand, it is found to be heavy | | | ● | | | | | | | | | | | |
| | When compression pressure is measured, it is found to be low | | | | ● | | | | | ● | | | | | |
| | When fuel filter, strainer are inspected directly, they are found to be Clogged | | | | | ● | | | | | | | | | |
| | When feed pump strainer is inspected directly, it is found to be clogged | | | | | | ● | | | | | | | | |
| | Speed of some cylinders does not change when operating on reduced cylinder | | | | | | | ● | | | | | | | |
| | When control rack is pushed, it is found to be heavy or does not return | | | | | | | | ● | | | | | | |
| | When valve clearance is checked directly, it is found to be outside standard value | | | | | | | | | ● | | | | | |
| | When lever is placed at FULL position, it does not contact stopper | | | | | | | | | | | ● | | | |
| | When feed pump is opaerated, operation is too light or too heavy | | | | | | | | | | | | ● | | |
| | When fuel cap is inspected directly, it is found to be clogged | | | | | | | | | | | | | ● | |
| Legend | | Remedy | | Clean | Replace | Replace | Clean | Clean | Repair | Replace | Adjust | Replace | Adjust | Repair | Clean |
| ○: Possible cause (judging from Questions and Check items) | | | | | | | | | | | | | | | |
| ⊙: Most probable causes (judging from Questions and Check items) | | | | | | | | | | | | | | | |

S-7 Exhaust gas is black (incomplete combustion)

General causes why exhaust gas is black

- Insufficient intake of air
- Improper condition of fuel injection
- Excessive injection of fuel

| General causes why exhaust gas is black | | | Causes | | | | | | | | | | | |
|---|--|--------------------------|-----------------------------------|-----------------------------|----------------------------|----------------------------------|---------------------------|--|--------------------------|--------------------------|---|--|---|---------|
| | | | Seized turbocharger, interference | Clogged air cleaner element | Worn piston ring, cylinder | Clogged, seized injection nozzle | Improper injection timing | Defective injection pump (excessive injection) | Improper valve clearance | Crushed, clogged muffler | Leakage of air between turbocharger and cylinder head | Defective contact of valve, valve seat | Defective injection pump (rack, plunger seized) | |
| Questions | Confirm recent repair history | | | | | | | | | | | | | |
| | Degree of use | Operated for long period | | Δ | Δ | Δ | | | | | | Δ | | |
| | Color of exhaust gas | Suddenly became black | ⊙ | | | ○ | | | | | | | ○ | |
| | | Gradually became black | | ⊙ | | ○ | | | | | ○ | | | |
| | | Blue under light load | | | ⊙ | | | | | | | | | |
| | Engine oil must be added more frequently | | | | ⊙ | | | | | | | | | |
| | Power was lost | Suddenly | ⊙ | | | ○ | | | | ○ | | | ○ | |
| | | Gradually | | ○ | ○ | | | | | | ○ | ○ | | |
| | Non-specified fuel has been used | | | | | ○ | | | | | | | ○ | |
| | Noise of interference is heard from around turbocharger | | ⊙ | | | | | | | | | | | |
| Check items | Dust indicator is red | | | ⊙ | | | | | | | | | | |
| | Blow-by gas is excessive | | | | ⊙ | | | | | | | | | |
| | Engine pick-up is poor and combustion is irregular | | ○ | | | ⊙ | | | ○ | ○ | ○ | | ○ | |
| | When exhaust manifold is touched immediatly after starting engine, temperature of some cylinder is low | | | | | ⊙ | | | | | | | ○ | |
| | Match marks on fuel injection pump are out of alignment | | | | | | ⊙ | | | | | | | |
| | Seal on injection pump has come off | | | | | | | ⊙ | | | | | | |
| | Clanging sound is heard from around cylinder head | | | | | | | | ⊙ | | | | | |
| | Exhaust noise is abnormal | | ○ | | | ○ | | | | ⊙ | | | | |
| | Muffler is crushed | | | | | | | | | ⊙ | | | | |
| | Leakage of air between turbocharger and head, loose clamp | | | | | | | | | | ⊙ | | | |
| Troubleshooting | When turbocharger is rotated by hand, it is found to be heavy | | ● | | | | | | | | | | | |
| | When air cleaner is inspected directly, it is found to be clogged | | | ● | | | | | | | | | | |
| | When compression pressure is measured, it is found to be low | | | | ● | | | | | | | ● | | |
| | Speed of cylinders does not change when operating on reduced cylinder | | | | | ● | | | | | | | | |
| | When check is made using delivery method, injection timing is found to be incorrect | | | | | | ● | | | | | | | |
| | Injection pump test shows that injection amount is incorrect | | | | | | | ● | | | | | | |
| | When valve clearance is checked directly, it is found to be outside standard value | | | | | | | | ● | | | | | |
| | When muffler is removed, exhaust gas color returns to normal | | | | | | | | | ● | | | | |
| | When control rack is pushed, it is found to be heavy or does not return | | | | | | | | | | | | ● | |
| Legend | | Remedy | | Replace | Clean | Replace | Replace | Adjust | Adjust | Adjust | Replace | Repair | Replace | Replace |
| ○: Possible cause (judging from Questions and Check items) | | | | | | | | | | | | | | |
| ●: Most probable cause (judging from Questions and Check items) | | | | | | | | | | | | | | |

Legend

- : Possible cause (judging from Questions and Check items)
 ⊙: Most probable causes (judging from Questions and Check items)
 Δ: Possible causes due to length of use (used for a long period)
 ●: Items confirm the cause

S-8 Oil consumption is excessive (or exhaust gas is blue)

- ★ Do not run the engine at idling for more than 20 minutes continuously. (Both low and high idling)

General causes why oil consumption is excessive

- Abnormal combustion of oil
- External leakage of oil
- Wear of lubrication system

| General causes why oil consumption is excessive | | | Causes | | | | | | | | | | | | | |
|---|--|--------------------------|--------------------|----------------------------------|------------------------------------|-------------------------------------|-------------------------|-----------------------------|---|-------------------|--------------------------|-------------------------|--------------------------------------|-----------------------------------|---------------------------------------|--|
| | | | Broken piston ring | Worn piston ring, cylinder liner | Clogged, breather or breather hose | Leakage from oil filter, oil cooler | Leakage from oil piping | Leakage from oil drain plug | Leakage from oil pan, cylinder head, etc. | Broken oil cooler | Turbocharger | | Worn, broken rear seal, seal surface | Dust sucked in from intake system | Worn valve (stem, guide), broken seal | |
| | | | | | | | | | | | Worm seal at turbine end | Worm seal at blower end | | | | |
| | | | | | | | | | | | | | | | | |
| Questions | Confirm recent repair history | | | | | | | | | | | | | | | |
| | Degree of use | Operated for long period | | Δ | | | | | | | Δ | Δ | | | Δ | |
| | Oil consumption suddenly increased | | ⊙ | | | | | | ○ | | | | | | | |
| | Engine oil must be added more frequently | | | ⊙ | | | | | ○ | | | | | | | |
| | Engine oil becomes contaminated quickly | | ○ | ⊙ | ○ | | | | | | | | | | | |
| | Exhaust gas is blue under light load | | ⊙ | ⊙ | | | | | | | | | | | | |
| | Amount of blow-by gas | Abnormally excessive | ⊙ | ⊙ | | | | | | | | ○ | | | ○ | |
| | | None | | | ⊙ | | | | | | | | | | | |
| | Area around engine is dirty with oil | | | | | ⊙ | ⊙ | ⊙ | ⊙ | | | | | | | |
| | There is oil in engine cooling water | | | | | | | | | ⊙ | | | | | | |
| Check items | When exhaust pipe is removed, inside is found to be dirty with oil | | | | | | | | | | ⊙ | | | | ○ | |
| | Inside of turbocharger intake pipe is dirty with oil | | | | | | | | | | | ⊙ | | | | |
| | Oil level in clutch or TORQFLOW transmission damper case rises | | | | | | | | | | | | ⊙ | | | |
| | Clamps for intake system are loose | | | | | | | | | | | | | ⊙ | | |
| | | | | | | | | | | | | | | | | |
| Troubleshooting | When compression pressure is measured, it is found to be low | | ● | ● | | | | | | | | | | | | |
| | When breather element is inspected, it is found to be clogged with dirty oil | | | | ● | | | | | | | | | | | |
| | There is external leakage of oil from engine | | | | | ● | ● | ● | ● | | | | | | | |
| | Pressure-tightness test of oil cooler shows there is leakage | | | | | | | | | ● | | | | | | |
| | Excessive play of turbocharger shaft | | | | | | | | | | ● | ● | | | | |
| | Check rear seal directly | | | | | | | | | | | | ● | | | |
| | When intake manifold is removed, dust is found inside | | | | | | | | | | | | | ● | | |
| | When intake manifold is removed, inside is found to be dirty with oil | | | | | | | | | | | | | | ● | |
| | | | | | | | | | | | | | | | | |
| | | Remedy | Replace | Replace | Clean | Repair | Repair | Repair | Repair | Replace | Replace | Replace | Repair | Repair | Repair | |

Legend

- : Possible cause (judging from Questions and Check items)
 ⊙: Most probable causes (judging from Questions and Check items)
 Δ: Possible causes due to length of use (used for a long period)
 ●: Items confirm the cause

S-9 Oil becomes contaminated quickly

General causes why oil becomes contaminated quickly

- Intake of exhaust gas due to internal wear
- Clogging of lubrication passage
- Improper combustion
- Use of improper oil
- Operation under excessive load

| | | | Causes | | | | | | | | |
|-----------------|--|--------------------------|----------------------------|----------------------------------|--------------------|-------------------------|--------------------|---------------------------------|--|------------------------|----------------------|
| Questions | | | | | | | | | | | |
| | | | Worn piston ring, cylinder | Clogged, breather, breather tube | Clogged oil filter | Worn valve, valve guide | Clogged oil cooler | Clogged turbocharger drain pipe | Defective seal at turbocharger turbine end | Defective safety vavle | Exhaust gas is black |
| Check items | Confirm recent repair history | | | | | | | | | | |
| | Degree of use | Operated for long period | Δ | | | Δ | | | Δ | | |
| | Engine oil must be added more frequently | | ⊙ | | | | | | | | |
| | Non-specified fuel is being used | | | | ○ | | | | | | |
| | Color of exhaust gas | Blue under light load | ⊙ | | | | | | | | |
| | | Black | | | | | | | | | ⊙ |
| | Amount of blow-by gas | Abnormally excessive | ⊙ | | | ○ | | ○ | ○ | | |
| | | None | | ⊙ | | | | | | | |
| | Oil filter caution lamp stays on even when oil pressure rises | | | | ⊙ | | | | | ○ | |
| | When oil filter is inspected, metal particles are found | | ○ | | ⊙ | ○ | | | | | |
| Troubleshooting | When exhaust pipe is removed, inside is found to be dirty with oil | | | | ⊙ | | | | | | |
| | Engine oil temperature rises quickly | | | | | ⊙ | | | | | |
| | When compression pressure is measured, it is found to be low | | ● | | | ● | | | | | |
| | When breather element is inspected directly, it is found to be clogged with dirty oil, or hose is broken | | | ● | | | | | | | |
| | When oil filter is inspected directly, it is found to be clogged | | | | ● | | | | | | |
| | When oil cooler is inspected directly, it is found to be clogged | | | | | | ● | | | | |
| | Turbocharger drain tube clogged | | | | | | | ● | | | |
| Remedy | Excessive play of turbocharger shaft | | | | | | | | ● | | |
| | When safety vavle is inspected directly, spring is found to be catching or broken | | | | | | | | | ● | |
| | | | Replace | Clean | Replace | Replace | Clean | Clean | Replace | Replace | I |

Legend

- : Possible cause (judging from Questions and Check items)
- ⊙: Most probable causes (judging from Questions and Check items)
- Δ: Possible causes due to length of use (used for a long period)
- : Items confirm the cause

S-10 Fuel consumption is excessive

General causes why fuel consumption is excessive

- Leakage of fuel
- Improper condition of fuel injection
- Excessive injection of fuel

| | | | Causes | | | | | | | | |
|---|---|---|--|----------------------------------|----------------------------------|--------------------------------|--|-----------------------------------|--|--|--------|
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | Defective injection pump (excessive injection) | Defective injection nozzle spray | Defective injection pump plunger | Improper fuel injection timing | External leakage from fuel piping, fuel filter | Leakage of fuel inside head cover | Defective oil seal inside feed pump (piston) | Defective adjustment of fuel lever linkage | |
| Questions | Confirm recent repair history | | | | | | | | | | |
| | Degree of use | Operated for long period | | Δ | Δ | | | Δ | | | |
| | Condition of fuel consumption | More than for other machines of same model | ◎ | | ○ | | | | | | |
| | | Gradually increased | | ○ | ○ | | | | | | |
| Suddenly increased | | | | | | ○ | ○ | | | | |
| Exhaust gas color | Black | ◎ | ○ | | ○ | | | | | ○ | |
| | White | | | | | | ○ | | | | |
| Check items | Seal on injection pump has come off | | ◎ | | | | | | | | |
| | There is irregular combustion | | | ◎ | | | | | | | |
| | When exhaust manifold is touched immediately after starting engine, temperature of some cylinder is low | | | ◎ | ○ | | | | | | |
| | Match mark on injection pump is missaligned | | | | | ◎ | | | | | |
| | There is external leakage of fuel from engine | | | | | | ◎ | | | | |
| | Engine oil level rises and smells of diesel fuel | | ○ | | | | | ◎ | ◎ | | |
| | Engine low idling speed in high | | ○ | | | | | | | ◎ | |
| | Troubleshooting | Injection pump test shows that injection amount is too high | | ● | | | | | | | |
| Speed of some cylinder does not change when operating on reduced cylinder | | | ● | | | | | | | | |
| When control rack is pushed, it is found to be heavy or does not return | | | | ● | | | | | | | |
| When check is made using delivery method, injection timing is found to be incorrect | | | | | ● | | | | | | |
| Remove nozzle holder and check directly | | | | | | | | | | | |
| Remove feed pump and inspect directly | | | | | | | ● | | | | |
| When engine speed is measured, low idling speed is found to be high | | | | | | | | ● | ● | | |
| | | | Remedy | Adjust | Replace | Replace | Adjust | Repair | Repair | Repair | Adjust |
| Legend | | | | | | | | | | | |
| ○: Possible cause (judging from Questions and Check items) | | | | | | | | | | | |
| ◎: Most probable cause (judging from Questions and Check items) | | | | | | | | | | | |

Legend

- : Possible cause (judging from Questions and Check items)
- ◎: Most probable causes (judging from Questions and Check items)
- Δ: Possible causes due to length of use (used for a long period)
- : Items confirm the cause

S-11 Oil is in cooling water, or water spurts back, or water level goes down

General causes why oil is in cooling water

- Internal leakage in lubrication system
- Internal leakage in cooling system

| | | | Causes | | | | | |
|-----------|---|--------------------------|---------|---------|---------|---------|---------|---------|
| Questions | Check items | Trouble shooting | | | | | | |
| | | | | | | | | |
| | Confirm recent repair history | | | | | | | |
| | Degree of use | Operated for long period | Δ | | | | | Δ |
| | Increase in oil level | Suddenly increased | ○ | ○ | | ○ | | |
| | | Gradually increased | | | | | ○ | ○ |
| | Hard water is being used as cooling water | | ○ | | | | ○ | |
| | Engine oil level risen, oil is cloudy, white | | ⊙ | | | | ○ | ○ |
| | Excessive air bubbles inside radiator, water spurts back | | | ⊙ | ⊙ | | | |
| | Hydraulic oil, torque converter, transmission oil is cloudy white | | | | | ⊙ | | |
| | When hydraulic oil, torque converter, transmission oil is drained, water is found | | | | | ⊙ | | |
| | Pressure-tightness test of oil cooler shows there is leakage | | ● | | | ● | | |
| | Pressure-tightness test of cylinder head shows there is leakage | | | ● | | | | |
| | Remove cylinder head and check directly | | | | ● | | | |
| | Remove oil pan and check directly | | | | | | ● | ● |
| Remedy | | | Replace | Replace | Replace | Replace | Replace | Replace |

Legend

- : Possible cause (judging from Questions and Check items)
- ⊙: Most probable causes (judging from Questions and Check items)
- Δ: Possible causes due to length of use (used for a long period)
- : Items confirm the cause

S-12 Oil pressure lamp lights up (drop in oil pressure)

General causes why oil pressure lamp lights up

- Leakage, clogging, wear of lubricating system
- Defective oil pressure control
- Improper oil used (improper viscosity)
- Deterioration of oil due to overheating

★ Standards for use of fuel

| TYPE OF OIL | AMBIENT TEMPERATURE | | | | | | | | |
|----------------|---------------------|--------------|-----|----|--------|----|----|-----|-------|
| | -22 | -4 | 14 | 32 | 50 | 68 | 86 | 104 | 120°F |
| | -30 | -20 | -10 | 0 | 10 | 20 | 30 | 40 | 50°C |
| Engine oil | | | | | SAE 30 | | | | |
| | SAE 10W | | | | | | | | |
| | | SAE 10W - 30 | | | | | | | |
| | | SAE 15W - 40 | | | | | | | |

| | | | | | | | | | | | | | | | | | | | | | | |
|---|--|---|-----|-----|----|-------------------------------|----|----|-----|--------|-------|-------|-------|--------|---------|-----|--------|--------|--------|---------|---------|---|
| <ul style="list-style-type: none">Defective oil pressure controlImproper oil used (improper viscosity)Deterioration of oil due to overheating | | | | | | | | | | Causes | | | | | | | | | | | | |
| ★ Standards for use of fuel | | | | | | | | | | | | | | | | | | | | | | |
| TYPE OF OIL | | AMBIENT TEMPERATURE | | | | | | | | | | | | | | | | | | | | |
| | | -22 | -4 | 14 | 32 | 50 | 68 | 86 | 104 | 120°F | | | | | | | | | | | | |
| | | -30 | -20 | -10 | 0 | 10 | 20 | 30 | 40 | 50°C | | | | | | | | | | | | |
| Engine oil | | | | | | SAE 30 | | | | | | | | | | | | | | | | |
| | | SAE 10W | | | | | | | | | | | | | | | | | | | | |
| | | SAE 10W - 30 | | | | | | | | | | | | | | | | | | | | |
| | | SAE 15W - 40 | | | | | | | | | | | | | | | | | | | | |
| Questions | Confirm recent repair history | | | | | | | | | | | | | | | | | | | | | |
| | Degree of use | | | | | Operated for long period | | | | | Δ | Δ | | | | | | | | | | |
| | Replacement of filters has not been carried out according to operation manual | | | | | | | | | | ⊙ | | | | | | | | | | | |
| | Caution lamp lights up | | | | | | | | | | ⊙ | ○ | | | | | | | | | | |
| | Non-specified fuel has been used | | | | | | | | | | ⊙ | ○ | | | | | | | | | | |
| | Condition when oil pressure lamp lights up | | | | | Lights up at low, idling | | | | | | ⊙ | | | | | | | | | | |
| | | | | | | Lights up at low, high idling | | | | | | | ⊙ | ⊙ | ⊙ | ⊙ | ○ | ○ | ○ | | | |
| | | | | | | Lights-up on slopes | | | | | | | | | | ⊙ | | ⊙ | ⊙ | | | |
| | | | | | | Sometimes lights up | | | | | | | | | | | | ⊙ | ⊙ | | ○ | ○ |
| | Check items | There is clogging, leakage from hydraulic piping (external) | | | | | | | | | | | | | | | | | | | | |
| Oil level sensor lamp lights up | | | | | | | | | | | | | | | | | | | | | | |
| When oil level in oil pan is checked, it is found to be low | | | | | | | | | | | | | | | | | | | | | | |
| Metal particles are found when oil is drained | | | | | | | | | | | | | | | | | | | | | | |
| Metal particles are stuck to oil filter element | | | | | | | | | | | | | | | | | | | | | | |
| Oil is cloudy white or smells of diesel oil | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | |
| Troubleshooting | When oil filter is inspected directly, it is found to be clogged | | | | | | | | | | ● | ● | | | | | | | | | | |
| | Remove oil pan and check directly | | | | | | | | | | | | ● | ● | ● | | | | | | | |
| | Oil pump rotation is heavy, there is play | | | | | | | | | | | | | | ● | | | | | | | |
| | There is catching of relief valve or regulator valve, or spring or valve guide is broken | | | | | | | | | | | | | | | ● | ● | | | | | |
| | When oil level sensor is replaced, oil pressure sensor lamp goes out | | | | | | | | | | | | | | | | | | | | | |
| | When oil pressure is measured, it is found to be within standard value | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | Remedy | | | | | | | | | | | | |
| | | | | | | | | | | Clean | Clean | Clean | Clean | Repair | Replace | Add | Adjust | Adjust | Repair | Replace | Replace | I |
| Legend | | | | | | | | | | | | | | | | | | | | | | |

Legend

- : Possible cause (judging from Questions and Check items)
 ◎: Most probable causes (judging from Questions and Check items)
 Δ: Possible causes due to length of use (used for a long period)
 ●: Items confirm the cause

S-13 Oil level rises

- ★ If there is oil in the cooling water, carry out troubleshooting for “Oil is in cooling water”

General causes why oil level rises

- Water in oil (cloudy white)
- Fuel in oil (diluted, and smells of diesel fuel)
- Entry of oil from other component

| | | | Causes | | | | | | | | | | |
|-----------------|---|--------------------------|--------------------------------|--------------------------------|---|--|---------------------------------|---|---|---|---------------------------|--|------------------------------|
| | | | | | | | | | | | | | |
| | | | Broken oil cooler core, O-ring | Defective nozzle holder sleeve | Broken cylinder head, head gasket (including precombustion chamber) | Clogged water pump breather hole, defective seal | Worn, damaged rear seal surface | Defective seal of pump or auxiliary equipment | Leakage of fuel from piping inside head cover | Defective part inside injection pump(flange type) | Defective thermostat seat | Damaged cylinder liner O-ring, holes made by pitting | Cracks inside cylinder block |
| Questions | Confirm recent repair history | | | | | | | | | | | | |
| | Degree of use | Operated for long period | | △ | | △ | △ | | | | | △ | |
| | There is oil in radiator cooling water | | ◎ | ○ | ○ | | | | | | | ○ | |
| | Exhaust gas is white | | | ◎ | | | | | ○ | | ○ | | |
| | When engine is first started, drops of water come from muffler | | | ◎ | | | | | | | | | |
| | Leave radiator cap open. when engine is run at idling, an abnormal number of bubbles appear, or water spurts back | | | | ◎ | | | | | | | ○ | |
| | Water pump breather hole is clogged with mud | | | | | ◎ | | | | | | | |
| | When water pump breather hole is cleaned, water comes out | | | | | ◎ | | | | | | | |
| | Oil level does down in clutch , TORQFLOW transmission, or damper chamber | | | | | | ◎ | | | | | | |
| | Oil level goes down in hydraulic tank | | | | | | | ◎ | | | | | |
| | Engine oil smells of diesel fuel | | | | | | | | ◎ | ◎ | ◎ | | |
| | Fuel is added more frequently | | | | | | | | ◎ | ◎ | ◎ | | |
| Troubleshooting | Pressure-tightness test of oil cooler shows there is leakage | | ● | | | | | | | | | | |
| | Pressure-tightness test of cylinder head shows there is leakage | | | ● | | | | | | | | | |
| | When compression pressure is measured, it is found to be low | | | | ● | | | | | | | | |
| | Remove water pump and check directly | | | | | ● | | | | | | | |
| | check rear seal directly | | | | | | ● | | | | | | |
| | When pump auxiliary equipment is removed, seal is found to be broken | | | | | | | ● | | | | | |
| | Remove head cover and check directly | | | | | | | | ● | | | | |
| | Remove injection pump and check directly | | | | | | | | | ● | | | |
| | There is improper contact of thermostat seat vavle | | | | | | | | | | ● | | |
| | Remove oil pan and check directly | | | | | | | | | | | ● | ● |
| Remedy | | | Replace | Replace | Replace | Replace | Repair | Replace | Repair | Replace | Repair | Replace | Replace |

Legend

- : Possible cause (judging from Questions and Check items)
 ◎: Most probable causes (judging from Questions and Check items)
 △: Possible causes due to length of use (used for a long period)
 ●: Items confirm the cause

S-14 Water temperature becomes too high (overheating)

General causes why water temperature becomes too high

- Lack of cooling water (deformation, damage of fan)
- Drop in heat dissipation efficiency
- Defective cooling circulation system
- Rise in oil temperature of power train
- ★ Carry out troubleshooting for chassis

| General causes why water temperature becomes too high | | | Causes | | | | | | | | | | | |
|--|--|--------------------------|-------------------|-------------------------------|-----------------------|--------------------------------------|-----------------------------------|----------------------------|------------------------------------|----------------------------|--------------------------|-----------------------------------|--|--|
| | | | Broken water pump | Clogged, crushed radiator fin | Clogged radiator core | Defective thermostat (does not open) | Defective water temperature gauge | Insufficient cooling water | Fan belt slipping, worn fan pulley | Clogged, broken oil cooler | Defective pressure valve | Broken cylinder head, head gasket | Damaged cylinder liner O-ring, holes made by pitting | Rise in torque converter oil temperature |
| Questions | Confirm recent repair history | | | | | | | | | | | | | |
| | Degree of use | Operated for long period | | Δ | Δ | | | | | | Δ | Δ | | |
| | Condition of overheating | Suddenly overheated | ◎ | | | | ○ | ○ | | | | | | |
| | | Always tends to overheat | | ◎ | ◎ | ○ | | ○ | | | | | | |
| | Water temperature gauge | Rises quickly | | | | ◎ | | ○ | | | | | | |
| Check items | Does not go down from red range | | | | | | ◎ | | | | | | | |
| | Radiator water level sensor lights up | | | | | | | ◎ | | | | | | |
| | Fan belt whines under sudden load | | | | | | | | ◎ | | | | | |
| | Cloudy white oil is floating on cooling water | | | | | | | | | ◎ | | | | |
| | Cooling water flows out from overflow hose | | | | | | | | | | ◎ | | | |
| | Excessive air bubbles inside radiator, water spurts back | | | | | | | | | | | ◎ | | |
| | Engine oil level has risen, oil is cloudy white | | | | | | | | ○ | | | ◎ | | |
| | There is play when fan pulley is rotated | | ◎ | | | | | | | | | | | |
| | Radiator shroud, inside of underguard are clogged with dirt or mud | | | ◎ | | | | | ◎ | | | | | |
| | When light bulb is held behind radiator, no light passes through | | | ◎ | | | | | | | | | | |
| | Water is leaking because of cracks in hose or loose clamps | | | | | | | ◎ | | | | | | |
| | Belt tension is found to be slack | | | | | | | | ◎ | | | | | |
| | Power train oil level enters red range before engine water temperature | | | | | | | | | | | | ◎ | |
| Troubleshooting | Temperature difference between top and bottom radiator tanks is excessive | | ● | | | | | | | | | | | |
| | Temperature difference between top and bottom radiator tanks is too slight | | | ● | | | | | | | | | | |
| | When water filler port is inspected , the core is found to be clogged | | | | ● | | | | | | | | | |
| | When a function test is carried out on the thermostat, it does not open even at the cracking temperature | | | | | ● | | | | | | | | |
| | When water temperature is measured, it is found to be normal | | | | | | ● | | | | | | | |
| | When oil cooler is inspected directly, it is found to be clogged | | | | | | | | ● | | | | | |
| | When measurement is made with radiator cap tester, set pressure is found to be low | | | | | | | | | ● | | | | |
| | When compression pressure is measured, it is found to be low | | | | | | | | | | ● | | | |
| | Remove oil pan and check directly | | | | | | | | | | | ● | | |
| Legend | | | Remedy | | | | | | | | | | | |
| ○: Possible cause (judging from Questions and Check items) | | | Replace | Repair | Repair | Replace | Replace | Add | Repair | Replace | Replace | Replace | Replace | |
| ◎: Most probable causes (judging from Questions and Check items) | | | | | | | | | | | | | I | |
| Δ: Possible causes due to length of use (used for a long period) | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |

S-15 Abnormal noise is made

★ Judge if the noise is an internal noise or an external noise

General causes why abnormal noise is made

- Abnormal due to defective parts
- Abnormal combustion noise
- Air sucked in from intake system

| ★ Judge if the noise is an internal noise or an external noise | | | Causes | | | | | | | | | | | | |
|--|---|--|----------------------------------|-----------------------------------|-------------------------|----------------------------------|---|--|--|--|---|------------------------------|---|--|--|
| General causes why abnormal noise is made | | | Worn piston ring, cylinder liner | Seized turbocharger, interference | Missing, seized bushing | Clogged, seized injection nozzle | Defective injection pump (rack, plunger seized) | Defective injection pump (excessive injection) | Deformed fan, interference of fan belt | Improper adjustment of valve clearance | Broken valve system (valve, rocker lever, etc.) | Improper gear train backlash | Leakage of air between turbocharger and cylinder head | Defect inside muffler (dividing board out of position) | |
| Questions | Confirm recent repair history | | | | | | | | | | | | | | |
| | Degree of use | Operated for long period | △ | | | | | | | | | | | | |
| | Condition of abnormal noise | Gradually occurred | ○ | ○ | ○ | | | | ○ | | | | | | |
| | Non-specified fuel has been used | | | | | ○ | ○ | | | | | ○ | | | |
| | Engine oil must be added more frequently | | ◎ | | | | | | | | | | | | |
| | Color of exhaust gas | Blue under light load | ◎ | | | | | | | | | | | | |
| | | Black | | ◎ | | | | | | ○ | | | ○ | | |
| | Metal particales are found in oil filter | | ◎ | | ◎ | | | | | | ○ | | | | |
| | Blow-by gas is excessive | | ○ | | | | | | | | | | | | |
| | Noise of interference is heard from around turbocharger | | | ◎ | | | | | | | | | | | |
| Check items | Engine pickup is poor and combustion is irregular | | | | | ◎ | | | | | | | | | |
| | When exhaust manifold is touched immediately after starting engine, temperature of some cylinder is low | | | | | ◎ | ○ | | | | | | | | |
| | Seal on injection pump has come off | | | | | | | ◎ | | | | | | | |
| | Abnormal noise is loud when accelerating engine | | | | | ○ | ○ | ○ | ○ | | | | ○ | | |
| | Clanging sound is heard from around cylinder head | | | | | | | | | ◎ | ◎ | | | | |
| | Leakage of air between turbocharger and cylinder head | | | | | | | | | | | | | ◎ | |
| | Vibrating noise is heard from around muffler | | | | | | | | | | | | | ◎ | |
| | Troubleshooting | When compression pressure is measured, it is found to be low | | ● | | | | | | | | | | | |
| | | When turbocharger is rotated by hand, it is found to be heavy | | | ● | | | | | | | | | | |
| | | Remove gear cover and inspect directly, (flywheel housing top cover) | | | | ● | | | | | | | ● | | |
| Speed of some cylinder does not change when operating on reduced cylinders | | | | | ● | | | | | | | | | | |
| When control rack is pushed, it is found to be heavy or does not return | | | | | | ● | | | | | | | | | |
| Injection pump test shows that injection amount is incorrect | | | | | | | ● | | | | | | | | |
| Fan is deformed, or belt is loose | | | | | | | | ● | | | | | | | |
| When valve clearance is checked directly, it is found to be outside standard value | | | | | | | | | ● | | | | | | |
| Remove cylinder head cover and check directly | | | | | | | | | | ● | | | | | |
| When muffler is removed, abnormal noise disappears | | | | | | | | | | | | | ● | | |
| Legend | | Remedy | Replace | Replace | Replace | Replace | Replace | Adjust | Repair | Adjust | Replace | Repair | Repair | Replace | |
| ○ : Possible cause (judging from Questions and Check items) | | | | | | | | | | | | | | | |
| ◎ : Most probable causes (judging from Questions and Check items) | | | | | | | | | | | | | | | |
| △ : Possible causes due to length of use (used for a long period) | | | | | | | | | | | | | | | |
| ● : Items confirm the cause | | | | | | | | | | | | | | | |

Legend

- : Possible cause (judging from Questions and Check items)
- ◎ : Most probable causes (judging from Questions and Check items)
- Δ : Possible causes due to length of use (used for a long period)
- : Items confirm the cause

S-16 Vibration is excessive

- ★ If there is abnormal noise together with the vibration, carry out troubleshooting for “Abnormal noise is made”

General causes why vibration is excessive

- Defective parts (abnormal wear, breakage)
- Improper alignment
- Abnormal combustion

| | | Causes | | | | | | | | | |
|-----------------|---|---|----------------------------|--------------------|---|--|---|------------------------------|--|--|--------|
| | | | | | | | | | | | |
| | | Worn, seized connecting rod, main bearing | Worn balancer, cam bushing | Worn support pilot | Loose engine mounting bolts, broken cushion | Broken part inside output shaft (damper) | Misalignment between engine and power train | Improper gear train backlash | Valve system (valve, rocker lever, etc.) stuck | Defective injection pump (excessive injection, plunger seized) | |
| Questions | Confirm recent repair history | | | | | | | | | | |
| | Degree of use | Operated for long period | Δ | Δ | Δ | Δ | | | | | |
| | Condition of vibration | Suddenly increased | | | | ○ | | | ○ | | |
| | | Gradually increased | ○ | ○ | ○ | ○ | | | | | |
| | Non-specified fuel has been used | | ○ | ○ | | | | | | | |
| | Metal particles are found in oil filter | | ◎ | ◎ | | | | | | | |
| | Metal particles are found when oil is drained | | ◎ | ◎ | | | | | | | |
| | Oil pressure is low at low idling | | ○ | ○ | | | | | | | |
| | Vibration occurs at mid-range speed | | | | | ○ | ○ | | | | |
| | Vibration follows engine speed | | | | ○ | ○ | ○ | ○ | | | |
| Check items | Exhaust gas is black | | | | | | | | ◎ | ○ | |
| | Seal on injection pump has come off | | | | | | | | | ◎ | |
| | Remove oil pan and check directly | | ● | | | | | | | | |
| | Remove side cover and check directly | | | ● | | | | | | | |
| | Check directly for worn support pilot, play | | | | ● | | | | | | |
| | check directly for loose engine mounting bolts, broken cushion | | | | | ● | | | | | |
| | Check inside of output shaft (damper) directly | | | | | | ● | | | | |
| | When radial runout, face runout are measured, they are found to be outside standard value | | | | | | | ● | | | |
| | Remove front cover, and check directly. | | | | | | | | ● | | |
| | Remove head cover and check directly | | | | | | | | | ● | |
| Troubleshooting | Injection pump test shows that injection amount is incorrect | | | | | | | | | ● | |
| | | | Replace | Replace | Replace | Replace | Replace | Repair | Repair | Replace | Adjust |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |

Legend

- : Possible cause (judging from Questions and Check items)
 ◎: Most probable causes (judging from Questions and Check items)
 Δ: Possible causes due to length of use (used for a long period)
 ●: Items confirm the cause

ENGINE

14 DISASSEMBLY AND ASSEMBLY



GENERAL

| | |
|-------------------|--------|
| Disassembly | 14-002 |
| Assembly | 14-018 |


AIR COMPRESSOR


| | |
|-------------------|--------|
| Disassembly | 14-044 |
| Assembly | 14-046 |


EXHAUST BRAKE

| | |
|--------------------------------|--------|
| Disassembly and Assembly | 14-048 |
|--------------------------------|--------|

- * The description of overall engine disassembly and assembly given in this section is based on the **BS6D125-1** engine, assuming the use of an overhaul stand.
- * The work procedure may differ slightly from that given here depending upon the machine in which the engine is mounted and also the particular stand used, however it is fundamentally the same.
- * Use the correct service tools when performing disassembly and assembly.







Special tools :

| | Part No. | Part Name | QTY |
|---|--------------|-----------------------|-----|
| A | 790-901-1240 | Adapter | 1 |
| B | 790-501-2000 | Engine overhaul stand | 1 |
| C | 795-102-2102 | Spring pusher | 1 |
| D | 795-100-1191 | Piston ring tool | 1 |
| E | 795-220-1000 | Liner puller | 1 |

Preparation work :

- 1) Clean the engine by washing the mud and dirt off.
- 2) Drain the engine coolant and the engine oil.



Engine oil : approx. 30L

- 3) Mount the engine assembly on a stable engine stand so that it won't fall down.




Engine assembly: approx. 1,175kg

(The engine weight differs according to machine model.)


1. Air Cleaner :

- 1) Disconnect the connecting hose to the turbocharger.
- 2) Remove the mounting bolts, and lift off air cleaner (2) together with bracket (1).

* The air cleaner and the bracket may be disconnected depending upon the machine models.


**2. Turbocharger and exhaust manifold assembly :**

- 1) Remove turbocharger outlet tube (1) and inlet tube (2).
- 2) Disconnect the intake connector connecting hose from the turbocharger.
- 3) Suspend the turbocharger and exhaust manifold assembly (3), and dismount them after removing 18 mounting bolts (4).




3. Starting motor :


Remove starting motor (1).

**4. Body side oil cooler :**


- 1) Remove aeration pipe (1).
- 2) Remove 8 mounting bolts (2) and engine side oil cooler (3).

**5. Engine oil cooler :**

Remove 17 mounting bolts (1) and engine oil cooler (2).


**6. Mounting the engine assembly on the engine overhaul stand :**

- 1) Install adapter A to the mounting section of the engine oil cooler.
- 2) Sling the engine assembly, align engine overhaul stand B with the adapter, and secure the engine assembly to the stand.



7. Oil Filter :

- 1) Disconnect hoses (1) and (2) between the oil filter and the adapter from the oil filter.
- 2) Remove 4 mounting bolts, and dismount engine oil filter (3) together with the bracket.

**8. Fuel filter :**


- 1) Disconnect hoses (4) and (5) between the fuel filter and the injection pump from the injection pump.
- 2) Remove 4 mounting bolts, and disconnect fuel filter (6) together with the bracket.

**9. Fuel injection pipes :**


- 1) Remove clamps (1) and (2).
- 2) Remove 6 fuel injection pipes (3) and (4).

10. Intake manifold :

- 1) Remove tube (1) between the intake manifold and the air compressor.
- 2) Remove 24 mounting bolts (2) and intake manifold (3).


**11. Fuel injection pump :**

- 1) Disconnect overflow hose (1) at adapter end.
- 2) Remove lubrication tubes (2) and (3).
- 3) Remove 2 bolts (8) holding front laminated coupling (9) and cross coupling (10)
- 4) Remove 4 mounting bolts (5) remove fuel injection pump.
- 5) Move fuel injection pump assembly (6) to rear and remove. when doing this, leave flange coupling (11) and front laminated coupling (9) on drive shaft
- 6) remove bolt (4) connecting coupling and drive shaft, then remove flange shaft coupling (11) and front laminated coupling (9)
- 5) Remove bracket (7).




12. Lubrication oil valve adapter :


- 1) Remove lubricating oil valve adapter (1).
- 2) Disconnect the spill hose and remove fuel over flow adapter (2).

**13. Fan :**


- Remove fan (1).

**14. V-Belts :**

- 1) Remove belt tension adjustment bolt (2).
- 2) Loosen alternator fastening bolt (3), and remove V-belts (4) by pushing the alternator inward.

**15. Alternator :**


- 1) Remove the fastening bolts for plate (1) and alternator (4).
- 2) Remove fastening bolt (3) and alternator (4).
- 3) Remove bracket (5).

**16. Fan pulley :**

- 1) Remove 4 mounting bolts and fan pulley (1).
- 2) Remove bracket (2) and 2 spacers (3).
- 3) Remove hanger (4) and spacer (5).

17. Water pump :


- 1) Disconnect connecting hose (1) between the water pump and the thermostat housing connector, and shift the hose towards the connector.
- 2) Remove 3 mounting bolts (2) and water pump (3)

**18. Crankshaft pulley - Vibration damper :**


Remove 6 mounting bolts (1) and crankshaft pulley - vibration damper (2).

19. Front support :


Remove front support (3).

**20. Water manifold :**

- 1) Disconnect tube (1) between the air compressor and the connector.
- 2) Remove 12 mounting bolts (2), 2 bolts (3), and water manifold (4).


**21. Spill pipes :**

Remove spill pipes (1).




22. Cylinder head covers :

Remove 24 mounting bolts (10 and each head cover (2).

**23. Nozzle holders :**


Remove 12 mounting bolts (1) and each nozzle holder (2).

* Give a number to each nozzle holder before removing it and store all nozzle holders together in an appropriate place to protect them from damage.

**24. Rocker arms :**

Remove 12 mounting bolts (1) and each rocker arm (2).


* Before installing the rocker arms, loosen the lock nut and then the adjustment screw by 2 to 3 turns so that the push rod will not be subjected to undue force.

**25. Crossheads :**

Remove crossheads (1).


26. Push rods :

Remove push rods (2).




27. Rocker arm housing :

Remove 42 mounting bolts (1) and each rocker arm housing (2).


**28. Cylinder head assembly :**

- 1) Remove 42 mounting bolts (1) and each cylinder head (2).
- 2) Remove each cylinder head gasket.




- Disassemble the cylinder head assembly as follows.

- i) Compress valve spring (3) using spring pusher C and remove valve cotters (4).
- ii) Remove upper seat (5) and valve spring (3).




- iii) Remove seal (7) and lower seat (8).
- iv) Set up the cylinder head upright and remove valve (6).

* The seals are provided on the exhaust side only.




29. Oil pan :


Remove oil pan (1).

**30. Flywheel :**


- 1) Sling flywheel (1) using eye bolt ①
(Thread dia : 12 mm, pitch : 1.75 mm)
- 2) Remove the mounting bolts and flywheel.

**31. Flywheel housing :**

- 1) Sling flywheel housing (1).
- 2) Remove mounting bolts (2) and the housing.
 - * When removing the housing, take care not to damage the oil seal.


**32. Front cover :**

- 1) Remove tachometer drive assembly (1).
- 2) Remove front cover (2).
 - * When removing the front cover, take care not to damage the oil seal.




33. Fuel injection pump drive gear :


- 1) Remove nut (1) and washer (2).
* Loosen the nut while holding the gear with a screwdriver.
- 2) Pull out fuel injection pump drive gear (3) using puller (2).

**34. Air compressor**


- 1) Remove air compressor tubes (1) and (2).
- 2) Remove dipstick guide (4).
- 3) Remove 4 mounting bolts (5) and air compressor (6).

**35. Cam follower cover :**

- Remove cam follower cover (1).


**36. Cam follower :**

- Remove 12 mounting bolts (1) and each cam follower (2).



37. Camshaft :


- 1) Remove 2 mounting bolts (1).
 - 2) Remove camshaft (2).
- * When pulling out the camshaft, turn it slowly to protect the cam bushing from damage.

**38. Oil pump :**


Remove 4 mounting bolts (1) and oil pump (2).

39. Idler gears :


- 1) Remove mounting bolt (3), plate (4), and oil pump idler gears (5).
- 2) Remove shaft (6).
- 3) Remove mounting bolt (7), shaft (8), and main idler gear (9).

**40. Oil suction pipe :**


Detach bracket (1) and remove oil suction pipe (2).

**41. Piston and connecting rod assembly :**


- 1) Check stamp numbers on connecting rod caps. (Make sure the cap number coincides with the cylinder and also that the number is stamped on the cam side)
- * If there is no stamp number, stamp the number before the cap is removed.
- 2) Rotate the crankshaft so that the piston to be removed is placed in bottom dead center.
- 3) Remove the carbon from the liner wall using a fine sand paper.
- * If necessary, measure the end play of the connecting rod using dial gauge (3) before removing the piston and connecting rod assembly.




- 4) Remove bolt (1) from the connecting rod cap.
- 5) Remove connecting rod cap (2) and the connecting rod bearing as a unit by tapping the connecting rod bolt with a plastic hammer.
- * Take care not to damage the screw.




- 6) Push the piston and connecting rod assembly from the oil pan side with a wooden stick. Hold piston (3) in your hand and remove it from the cylinder head side.
- * Take care not to damage the piston cooling nozzle. (BS6D125-1, SA6D125-1)
- * During removal, take care not to damage the inner surface of the liner with the connecting rod.



- 7) Remove the remaining piston and connecting rod assemblies in the same manner.
- * When storing the piston and connecting rods, take care not to damage sliding portions of the piston and the bearing.
- * Keep the connecting rods and caps together, then store them with their corresponding bearings in order to avoid confusion during reassembly.




- Disassemble the piston and connecting rod assembly as follows.
 - i) Remove snap ring (4).
 - ii) Pull out piston pin (6) while holding connecting rod (5) in your hand, and separate connecting rod from piston (7)
 - iii) Remove the snap ring on the opposite side.
 - iv) Remove piston rings (8) using piston ring tool D.
 - * Store the piston, connecting rod, connecting rod bearings, piston rings, and piston pin for every cylinder.




42. Crankshaft :


- * If necessary, measure the crankshaft end play using dial gauge ③ before removing the crankshaft.




- 1) Remove mounting bolts (2) for main cap (1).
- 2) Insert a bolt into the hole on the main cap, and remove the main cap by shaking it.




- 3) Since lower thrust bearing (3) is installed to main cap No. 7, mark the installation position after removing the cap.



- 4) Using nylon slings, lift off crankshaft (4).
 - * When lifting the crankshaft, take care not to let it hit against the cylinder block.
 - * Store the crankshaft in an appropriate places so that its sliding portions do not get damaged.




- 5) Remove upper thrust bearing (5).




- 6) Remove upper bearing (6).

* Put identification tags on the main caps, main bearings, and thrust bearings or mark their installation position with a felt - tip pen, segregate them for each cap, and store them properly to protect them from damage.




- 43. Piston cooling nozzle (BS6D125-1, SA6D125-1) :**
Remove mounting bolts (1) and each piston cooling nozzle (2).




- 44. Cylinder liner :**


* If necessary, measure the cylinder liner protrusion using dial gauge (3) before removing the cylinder liners.


Pull out cylinder liners (1) using liner puller E.



GENERAL ASSEMBLY








TIGHTENING BOLT BY THE PLASTIC RANGE TURNING ANGLE METHOD

- Important bolts in the 125 Series engines are tightened by the plastic range turning angle method. In this method, special bolts are used. By being tightened to the load (Plastic range) at which they begin to be permanently deformed, accurate and high tightening force can be obtained. The most common method for tightening bolts is the torque control method. In this method, however, it is difficult to accurately control the tightening force because of the coefficient of friction.
- The plastic range turning angle method is based on the initial tightening torques and the turning angle.



- * Elongation exceeding the elastic range results in permanent deformation.
- Bolts to be tightened by the plastic range turning angle method in the 125 series engines.
 - 1) Cylinder head mounting bolts.
 - 2) Main cap mounting bolts.
 - 3) Connecting rod cap mounting bolts.
 - 4) Crank pulley mounting bolts (only in D60P, S-8 machines)
- * In the plastic range turning angle method, the permanent strain remains in bolts after they are tightened. Therefore, the number of times that each bolt can be reused is limited. Observe the following precautions.
 - 1) After tightening put one punch mark on the bolt. Do not reuse any bolt which has 5 or more punch marks.
 - 2) If a bolt has been tightened in excess of the specified turning angle, loosen the bolt completely and retighten it. (In this case, put two punch marks on the bolt.)
 - 3) The tightening angle should be targeted at the standard value plus or minus tolerance.

Special tools :


| | Part No. | Part Name | QTY |
|---|--------------|-----------------------|-----|
| A | 790-901-1240 | Adapter | 1 |
| B | 790-501-2000 | Engine overhaul stand | 1 |
| C | 795-102-2102 | Spring pusher | 1 |
| D | 795-100-1191 | Piston ring tool | 1 |
| F | 795-225-1520 | Liner driver | 1 |
| G | 795-102-3900 | Piston holder | 1 |
| H | 795-502-1121 | Gauge | 1 |
| I | 795-125-1360 | Feeler gauge | 1 |

- * Clean every part thoroughly and check the part for dents, flaws, and blowholes. When assembling the parts, make sure that none of the oil and water passages are blocked.

Preparation work :



- Install adapter A to the cylinder block, then raise it and place it on engine overhaul stand B.
- Repair the cylinder block as follows before inserting the cylinder liners.
 - 1) Remove rust and scale from surfaces (A) and (B) with sandpaper until the machined surface is exposed.
 - 2) Polish portion (R) with No. 60 sandpaper to make surface (R) smooth.
 - 3) Polish portions (R) and (h) with No. 60 sandpaper to make them smooth.
If portion (R) is square or burred, polish it with sandpaper or a scraper.
Finish this portion to an especially smooth surface to protect the O-ring from damage.
 - 4) If the pitting in surface (B) is so rough that it cannot be repaired, replace the cylinder block.

- 5) If surface (A) and portion (R) are roughened with pitting, finish them smooth.
- 6) Inspect the counterbore section and remove any burrs. Chips and dirt on surface (C) will cause poor contact of the liner, which will lead to water leakage or improper liner projection.
 - * Repair the counterbore section if there is any drooping, corrosion, or pitting.



1. Cylinder liner :

- * Replace the liner O-ring and clevis seal with new parts just before assembling the liner.
- Method of installing liner O-rings and clevis seal
 - 1) Confirm that the cylinder liner O-ring grooves and the circumference of the liner are free from rust and pitting.
 - * If there surfaces are roughened with pitting , replace the liner to remove the cause of water leakage
 - 2) Coat liner O-rings and clevis seals with SAE No. 30 engine oil.
 - * The clevis seal and black O-ring will become swollen and degraded because of oil. To prevent this, do not leave these parts immersed in oil.
 - * Apply a little oil with a brush just before assembling the parts.
 - 3) After fitting the O-ring on the cylinder liner, check that it is not twisted. If it is twisted, use a smooth bar (approx. 10 mm O.D.) to remove the twist from the O-ring.
 - 4) To prevent the clevis seal from twisting, continue to press the whole circumference until it is intalled properly in the groove.
 - 5) Install the liner O-ring and clevis seal as shown in the diagram.
 - * Install the clevis seal with the chamfered side down.




2) Insert the cylinder liners

- i) Coat the liner O-rings and cylinder block O-ring grooves with SAE No. 30 engine oil
- ii) Insert the liner into the cylinder block with mark A and B stamped on the liner top facing the front, taking care not to damage the O-ring.
- iii) Insert the liner by pushing with both hands and all your weight.
 - * If the liner fails to go into the cylinder block smoothly when pushed with your weight, the O-ring may get damaged. Confirm that there are no burrs on the cylinder block.

iv) Press-fit cylinder liners (1) into the cylinder block using liner driver F.


- v) Measure the cylinder liner protrusion using dial gauge ③ after press-fitting the cylinder liner.
 - * Before measuring the liner protrusion, press the liner with a plate to eliminate the raising of the liner caused by the O-ring.
 - * Cylinder liner protrusion : 0.07 - 0.15 mm




2. Piston cooling nozzle

Install each piston cooling nozzle (2) and tighten mounting bolts (1).

- * Before setting nozzles in place, put them side by side and make sure that they are free from bends and other defects.




- * After the piston and connecting rod assembly is installed, recheck the mounting position.



3. Crankshaft


- 1) Install upper main bearing (6) to the cylinder block with the projected part of the bearing aligned with the groove on the cylinder block.

* Before installing the bearing, see if any foreign matter is adhering to the back of the bearing.
Coat the inner surface of the bearing with SAE No. 30 engine oil.




- 2) Drive the roll pin until its protrusion reaches 1.5 to 1.9 mm from the end of the cylinder block, then install upper side thrust bearing (5).

* Install the thrust bearing with the grooved surface facing the crankshaft.



- 3) Lift crankshaft (4) using nylon slings. Place it in the mounting position, taking care not to let it hit the cylinder block.

* When replacing the crank gear, heat the new gear in an electric furnace at 200°C for at least 30 minutes and shrink fit it.




- 4) Install lower main bearing (7) with the projected part of the bearing aligned with the groove on the main cap.


* Before installing the bearing, make sure that no foreign matter is stuck on the back of the bearing.

- 5) Drive the roll pin into the No. 7 cap until its protrusion reaches 1.5 to 1.9 mm from the end of the cap, and install thrust bearings (3) to both sides.

* Install the thrust bearings with the grooved side facing the crankshaft.



- 6) Coat the crankshaft journal with SAE No. 30 engine oil, confirm that the stamp No. on main cap (1) coincides with the number on the cylinder block, and install the main cap.
- * Install the main cap with the cast number facing the engine front.
- 7) Coat the threads of the mounting bolts and the washers for the main cap with SAE No. 30 engine oil and secure the main cap by tightening the bolts.
- 8) Tighten main bearing cap mounting bolts (2) as follows.
- * Starting from the center to the outside, tighten the bolts to the specified tightening torque as follows.

 Unit : kgm Main bearing cap mounting bolts

| Unit : kgm | | |
|------------|--|-------------|
| Order | Target | Range |
| 1st step | 10 | 9 - 11 |
| 2nd step | 20 | 19.5 - 20.5 |
| 3rd step | Mark the bolts and the cap with a felt-tip pen, and turn the bolts with following degree | |
| | 90° | 90° - 120° |




Mark the bolt and the cap




- * After tightening the bolts, put one punch mark on the head of each bolt. do not reuse a bolt which has 5 punch marks. Replace it with a new one.
- 9) After tightening the bolts, confirm that the crankshaft rotates smoothly.
- 10) Measure the end play of the crankshaft using dial gauge ③.
- * End play : 0.14 - 0.315 mm

4. Piston and connecting rod assembly


- 1) Assemble the piston and connecting rod assembly as follows.
 - i) Install piston rings (7) to the piston using piston ring tool D.




- * Install each piston ring as shown in the drawing.
- * Install each piston ring to the piston with the stamped surface facing upward.
- * Remove the expander from the oil ring, fit the expander into the groove, then install the oil ring. Make sure that the expander fits snugly into the ring groove.



- ii) Connect the piston to the connecting rod.
 - * Align the cylinder No. on the piston top with the stamp No. on the connecting rod, and install piston (7) to connecting rod (5) by inserting piston pin (6) with the numbers facing in the same directions.
- iii) Secure the piston pin by fitting snap rings (4) on both sides.




- iv) Install the upper bearing to the connecting rod with the projected part on the bearing aligned with the notch on the rod.
 - * Make sure the back of the bearing is free from any foreign matter before installing the bearing.



- 2) Rotate the crankshaft of the cylinder to be installed to bring it to bottom dead center, and coat the inner surface of the connecting rod bearing and the inner surface of the cylinder with SAE No. 30 engine oil.
- 3) Insert piston and connecting rod assembly (3) into the cylinder with the cast number on the rod facing the engine front (the stamp No. should be on the camshaft side), and with the relative position of the piston ring openings arranged as shown in the drawing.

* For BS6D125G1


Take care not to damage the piston cooling nozzle when inserting the piston and connecting rod assembly.



- 4) Contract the piston rings using piston holder G, and push the piston head into the cylinder with a wooden stick.

* For BS6D125G1


Take care not to damage the piston cooling nozzle when inserting the piston. Make sure also that the nozzle is located in the center of the notched part on the piston.



- 5) Install the lower bearing to the connecting rod cap with the projected part on the bearing aligned with the notch on the cap, and install connecting rod cap (2) in alignment with the stamped mark on the connecting rod.

* Make sure the back of the bearing is free from any foreign matter before installing it.

* Coat the sliding surface of the connecting rod with SAE No. 30 engine oil.




- 6) Coat the threads and seating surface of connecting rod bolts (1) with SAE No. 30 engine oil and tighten them as follows.

Connecting rod cap mounting bolts



Unit : kgm

| Order | Target | Range |
|----------|--|------------|
| 1st step | 10 | 9.5 - 10.5 |
| 2nd step | Mark the bolts and the cap with a felt-tip pen, and turn the bolts with following degree | |
| | 90° | 90°-120° |




* After tightening the bolts, put one punch mark on the head of each bolt. Do not reuse a bolt which has 5 punch marks. Replace it with a new one.

- 7) After the piston and connecting rod assembly is installed, make sure the crankshaft rotates smoothly.

- 8) Measure the side clearance of the connecting rod with dial gauge ③.

* Standard side clearance : 0.20 - 0.375 mm




- 9) Measure the protrusion of piston top from cylinder block top face using gauge H.

* Protrusion of piston :


Unit : mm

| (Aluminium piston) | (FCD piston) |
|--------------------|---------------|
| 0.806 - 1.151 | 0.984 - 1.335 |



5. Oil suction pipe

- 1) Fit an O-ring and install oil suction pipe (2).
- 2) Install bracket (1) to secure the pipe.



6. Idler Gear

- 1) Align mark A on the crankshaft gear with mark A on main idler gear (9), install shaft (8), and tighten mounting bolt (7).




Mounting bolt :

16.5 ± 1.5 kgm (For M : 14 mm)

27.5 ± 2.5 kgm (For M : 16 mm)

- 2) Drive in the pin and install shaft (6).



- 3) Install oil pump idler gear (5), fit plate (4) and tighten mounting bolt (3).




Mounting bolt : 16.5 ± 1.5 kgm

7. Oil pump

- 1) Fit O-ring and install oil pump (2).
- 2) Tighten 4 mounting bolts (1).




Mounting bolt : 7 ± 0.5 kgm




8. Camshaft

- 1) Coat the camshaft journal with SAE No. 30 engine oil.
- 2) Install camshaft (2) by aligning mark B on the camshaft gear with mark B on the main idler gear.
- 3) Tighten mounting bolts (1).


 **kgm** Plate mounting bolts : 3.75 ± 0.75 kgm

- * When installing the camshaft, turn it to prevent damage to the cambushing.
- * When replacing the cam gear, heat the gear in an electric furnace at 200 - 240°C for 30 minutes and shrink fit it.


**9. Cam follower**


Install cam follower (2) in alignment with the pin, and tighten mounting bolts (1).

 **kgm** Mounting bolts : 5.25 ± 0.75 kgm


**10. Cam follower cover**

Fit an O-ring and install cam follower cover (1).

 **kgm** Mounting bolt : 1.5 ± 0.15 kgm


**11. Air compressor**


- 1) Fit an O-ring and install air compressor (6), and tighten 4 bolts (5).
- 2) Install dipstick guide (4).
- 3) Fit gasket on both sides and install air compressor tubes (3), (2), and (1).




12. Fuel injection pump drive gear

- 1) Drive the drive shaft gear, and install fuel injection pump drive gear (3) in alignment with mark C on the camshaft gear.
- 2) Fit washer (2) and tighten nut (1).
- * Tighten the nut while holding the gear with a screwdriver.

 Nut : 24.5 ± 1.5 kgm




- * Make sure match marks on each drive gear and on the idler gear are aligned with each other.



- * Measure the backlash and the end play of each gear with dial gauge ③.


- Standard value of gear backlash

| Position | Range (mm) |
|----------|---------------|
| a | 0.125 - 0.395 |
| b | 0.125 - 0.395 |
| c | 0.140 - 0.425 |
| d | 0.130 - 0.405 |
| f | 0.080 - 0.390 |







- Standard value of gear END PLAY




| Position | Range (mm) |
|----------|-------------|
| 1 | 0.09 - 0.48 |
| 2 | 0.10 - 0.25 |
| 3 | 0.05 - 0.17 |
| 4 | 0.05 - 0.21 |
| 5 | 0.03 - 0.09 |





13. Front cover



- 1) Press fit oil seal (3) into the cover using a push tool (outside diameter : 120 mm).
 * Insertion allowance (a) for oil seal : $11 +1 \text{ mm}$
 $ 0$
 Oil seal lip : G2-L1 (Coat 50 to 80% of the lip clearance)
- 2) Coat the mounting surface with liquid gasket and install front cover (2).
 * Take care not to damage the oil seal when installing the cover (2).
 Mounting surface : Liquid gasket (LG-7)
- 3) Fit an O-ring and install tachometer drive assembly (1).
- 4) Measure the difference between the cylinder block lower face and the front cover using dial gauge.
 * Difference : $0 - 0.275 \text{ mm}$

**14. Flywheel housing**


- 1) Press fit oil seal (3) into the housing using a push tool (outside diameter : 180 mm).
 Oil seal lip : Engine oil
- 2) Coat mounting surface of cylinder block with liquid gasket.
 Mounting surface : Liquid gasket (LG-7)
- 3) Sling flywheel housing (1), install the housing to cylinder block and tighten mounting bolts (2).
 * Take care not to damage the oil seal when installing the housing.
 Bolt thread and washers :
 SAE No. 30 Engine oil



*If the oil seal lip contact surface of the crank shaft is worn (enough for your fingernail to catch: 0.1 mm or more), assemble a rare seal to correct the wear (assemble it 3.5 mm to the front of the engine the lip position).

**B6D125 SERIES**


- * Tighten flywheel housing mounting bolts as follows and in the order shown in the drawing.

 Flywheel housing mounting bolts

Unit : kgm

| Order | Target | Range |
|----------|--------|-----------|
| 1st step | 19 | 15 - 24 |
| 2nd step | 28 | 25 - 31.5 |


Tightening order



- 3) After flywheel housing is installed, measure the face runout and radial runout using dial gauge ③.


* Radial runout : 0.20 mm max.

* Face runout : 0.20 mm max.



- 4) Measure the difference between the cylinder block and the flywheel housing using dial gauge ③.

* Difference : 0 - 0.35 mm




15. Flywheel

- 1) Sling flywheel (1) with eye bolt ① (Thread dia : 12 mm, pitch : 1.75 mm), install the flywheel to the crankshaft, and tighten the mounting bolts.



Bolt threads and washers :
SAE No. 30 engine oil.



- * Tighten flywheel housing mounting bolts as follows and in the order shown in the drawing.


 Flywheel housing mounting bolts

Unit : kgm

| Order | Target | Range |
|----------|--------|-------------|
| 1st step | 15 | 13 - 17 |
| 2nd step | 29.5 | 27.5 - 31.5 |


GENERAL DISASSEMBLY

Tightening order




- 2) After flywheel housing is installed, measure the face runout and radial runout using dial gauge ③.

- * Radial runout : 0.20 mm max.
- * Face runout : 0.15 mm max.



16. Oil pan

Fit a gasket and install oil pan (1).




17. Cylinder head assembly


- 1) Assemble the cylinder head assembly as follows.

- i) Fit lower seat (8) and install seal (7).
 - * The seals are provided on the exhaust side only.
- ii) Coat the valve stems and the inner surface of valve guides with SAE No. 30 engine oil and install valve (6).


- * The valve rotator is installed in BS6D125 engine, instead of the lower seat.
- * The free length of the valve springs are different between B6D125 and BS6D125.



- iii) Set the cylinder head upright, and install valve spring (3) and upper seat (5).
- iv) Contract the valve spring using spring pusher C, and install valve cotters (4).
- * Tap the valve stem lightly with a plastic hammer to make sure the cotters are securely installed in the valve stem groove.



- 2) Make sure the mounting surface of cylinder head and the inside of cylinders are free from dust and foreign matter, and place cylinder head gasket (9) in position.
- * When installing the gasket, make sure the grommet is not loose.




- 3) Install each cylinder head assembly (2) and tighten mounting bolts (1).



Coat the threads and lower side of the bolt head before tightening the mounting bolts with lubricant (LM-P).



- * First screw in the mounting bolts two or three revolutions by hand, then tighten the bolts as follows.

 Cylinder head mounting bolts


Unit : kgm

| Bolt No. | Order | Target | Range |
|-------------|----------|--|-------------|
| ① 1 ⑥ | 1st step | 10 | 9 - 11 |
| | 2nd step | 14 | 13.5 - 14.5 |
| | 3rd step | Mark the bolts and the cylinder head with a felt-tip pen, and turn the bolts with following degrees. | |
| | | 90° | 75° - 105° |
| ⑦ | - | 6.75 | 6.0-7.5 |

Put mark on the bolt and cylinder head




Tightening order




- * After tightening the bolts, put one punch mark on the head of each bolt. Do not reuse a bolt which has 5 punch marks. Replace it with a new one.

18. Rocker arm housing


Fit gaskets and install rocker arm housing (2) to the cylinder heads, then tighten 42 mounting bolts (1).

 kgm Mounting bolts : $6.75 \pm 0.75 \text{ kgm}$

**19. Push rod**


Install push rods (2).

- * Make sure the push rods are securely positioned in the cam follower lever holes.

**20. Crosshead**

Install crosshead (1).


- * Adjust the crosshead as follows.
 - i) Loosen the lock nut and the adjustment screw.
 - ii) Hold down the upper surface of the crosshead lightly with a finger, and screw the adjustment screw.
 - iii) After the adjustment screw comes into contact with the valve stem, screw the adjustment screw 20 degrees.
 - iv) Tighten the lock nut in this position.


 kgm Lock nut : $6.5 \pm 0.5 \text{ kgm}$

**21. Rocker arm**

Fit gaskets and install rocker arm (2), then tighten 12 mounting bolts (1).

- * Make sure the ball portion of the adjustment screws are securely placed in the socket portion of the push rods before tightening the bolts.
- * Clean oil holes on the bolts and tighten the bolts.

 kgm Mounting bolt : $6.75 \pm 0.75 \text{ kgm}$
- * Set a rocker arm shaft in place so that the portion having a large hole (13 mm dia.) is on the lower side and that having a blind ball plug is on the front side.




22. Adjustment of valve clearance

Adjust the valve clearance in the following procedure.

- * Adjust the valve clearance to obtain the following clearance between the crosshead and the rocker arm.
- * Valve clearance (when engine is cold)

| Intake valve | Exhaust valve |
|--------------|---------------|
| 0.33 | 0.71 |




- * With the engine cranking in firing order 1-5-3-6-2-4, adjust the valve clearance for each cylinder.


1) Rotate the crankshaft in the normal direction, while watching the movement of the valve, align stamped line "1.6 TOP" on vibration damper (1) with pointer (2).

2) Insert a feeler gauge I between rocker arm (3) and crosshead (4), and adjust the clearance with adjustment screw (5) until the gauge can slide lightly.

3) Tighten lock nut (8) to secure the adjustment screw.

 Lock nut : 6.75 ± 0.75 kgm

- * Recheck the valve clearance after tightening the lock nut. Refer 12 ADJUSTING VALVE CLEARANCE.





23. Nozzle holder

- * Make sure the inside of nozzle holder sleeve is free from dust and foreign matter.

Fit O-rings and install nozzle holders (2) to the cylinder head, then tighten mounting bolts (1).

- * Tighten the nozzle holder mounting bolts equally to achieve even tightening.


 Mounting bolt : 2.2 ± 0.3 kgm




24. Cylinder head cover

Fit O-rings and install cylinder head covers (2), then tighten 24 mounting bolts (1).


- * Apply adhesive to the O-rings so that they can be installed without causing twisting.

 Cylinder head cover mounting bolts :
1 ± 0.1 kgm


**25. Spill pipes**

Fit gaskets on both sides and install spill pipes (1).

 Joint bolt : 1.25 ± 0.25 kgm

**26. Water manifold**


- 1) Fit gaskets and install water manifold (4), then tighten 12 bolts (2) and 2 bolts (3).
- 2) Fit gaskets on both sides, and connect tube (1) between the air compressor and connector.


**27. Front support**

Install front support (3).

28. Crankshaft pulley and vibration damper


Install crankshaft pulley and vibration damper (2), then tighten 6 mounting bolts (1).

 Mounting bolts : 28 ± 3 kgm
(Threads dia. : 16 mm, Pitch :
1.5 mm)
18 ± 2 kgm
(Thread dia. : 14 mm, Pitch :
1.5 mm)



28-1. Crankshaft pulley (for D60P-8 and D60S-8)

- 1) Install crankshaft pulley.
- 2) Coat bolts with the engine oil, then tighten the bolts as follows.

 Bolt ①: 18 ± 2 kgm

Bolt ②:


1st step : 15 ± 1 kgm

2nd step : 30 ± 1 kgm

3rd step : Mark the bolts and the pulley with a felt-tip pen, and turn the bolts $90^\circ - 120^\circ$.

* Bolt ①: Thread dia. : 14 mm, Pitch : 1.5 mm

Bolt ②: Thread dia. : 16 mm, Pitch : 1.5 mm




29. Water pump

- 1) Fit O-ring and install water pump (3), then tighten 3 mounting bolts.




Mounting bolts : 6.75 ± 0.75 kgm

- 2) Connect hose (1) between the water pump and the thermostat housing.




- 3) Install spacer (5) and hanger (4).
4) Install 2 spacers (3) and bracket (2).

**30. Fan pulley**

Install fan pulley (1) and tighten the 4 mounting bolts.


31. Alternator

- 1) Install bracket (5).
2) Set alternator (4) on the bracket, and loosely tighten fastening bolt (3).
3) Install plate (1).

**32. V-belts**

- 1) Install V-belts (4) to the pulley grooves, and install the belt tension adjustment bolt (2).
2) Adjust the belt tension by raising the alternator with a bar until the belt deflects about 13 mm when the center of the belt is depressed with a force of 6 kg then tighten bolts (3) and (2).
PC300-3, PC400-3


Standard belt tension : about 6 - 7 mm

**33. Fan**

Install fan (1).

34. Lubricating oil valve adapter



- 1) Install adapter (2) for the fuel overflow, and connect the spill hose.
- 2) Fit O-ring and install lubricating oil valve adapter (1).


**35. Fuel injection pump**

- 1) Install bracket (7).
- 2) Drive in a key to the fuel injection pump drive shaft. Position fuel injection pump (6) with the key seat on the pump coupling aligned with pin section on the bracket.
- 3) Remove 2 coupling bolts (8) from fuel injection pump, then install flange coupling (11) and front laminated coupling (9) to engine drive shaft.


When doing this, do not tighten coupling connection bolt (4).

- 4) Align coupling key groove with drive shaft key, push in fuel injection pump assembly (6), align with pin portion of bracket, and set in position.
- 5) Tighten 4 mounting bolts (5) of fuel injection pump.




-  Mounting bolts :
- 3.2 ± 0.3 kgm (B6D125-1)
 - 6.75 ± 0.75 kgm (BS6D125-1)
 - 6.75 ± 0.75 kgm (BSA6D125-1)

- 6) Tighten 2 bolts (8) connecting coupling and drive shaft.

 Connecting bolts : 6.25 ± 0.25 kgm

- 7) Tighten bolts (4) connecting coupling and drive shaft.

-  Mounting bolt :
- 9 ± 0.5 kgm (B6D125-1)
 - 0
 - 8 ± 0.5 kgm (BS6D125-1)
 - 8 ± 0.5 kgm (BSA6D125-1)


8) Check the injection timing as follows.

- i) Rotate the crankshaft in the normal direction and align the injection timing stamp line on vibration damper (8) with pointer (9).

* If the stamp line on the injection pump coupling is invisible from the front, rotate the crankshaft one more revolution.


- ii) In the condition described in step i), confirm that stamp line **a** on the injection pump side is aligned with stamp line **b** on the coupling side.

* If the stamp lines are out of alignment, loosen nut (10), turn the coupling until one stamp line is aligned with the other, and tighten the nut to the specified torque.

 Nut : 6.2 ± 0.2 kgm





* When the fuel injection pump is repaired or replaced, or if the stamp line is missing, adjust the injection timing by the delivery valve method. See 12 CHECKING AND ADJUSTING FUEL INJECTION TIMING.

9) Fit gaskets to both sides and install lubrication tubes (3) and (2).

 Joint bolt for tube (2) : $2.5 + 0.5$ kgm
0

Joint bolt for tube (3) : $1.5 + 0.5$ kgm
0

10) Fit gasket to both sides and connect overflow hose (1)





36. Intake Manifold

- 1) Fit a gasket, install intake manifold (3), and tighten 24 mounting bolts (2)
- 2) Install tube (1) between the intake manifold and the air compressor.


37. Fuel injection pipe

Install fuel injection pipes (4) and (3), and secure the pipes with clamps (2) and (1).


 kgm Sleeve nut : 2.4 ± 0.1 kgm

**38. Fuel filter**


- 1) Install fuel filter (6) and the bracket as a unit.
- 2) Fit gaskets to both sides and install hoses (5) and (4) between the filter and the pump.

**39. Oil filter**


- 1) Install engine oil filter (3) and the bracket as a unit.
 - 2) Connect hoses (2) and (1) between the filter and the adapter.
- * Install the hoses without twisting or interference.


**40. Setting engine assembly on the engine stand**

- 1) Sling the engine assembly, remove the connecting bolts between adapter **A** and engine overhaul stand **B**, to separate the engine assembly from overhaul stand.
- 2) Set the engine assembly on the engine stand.
- 3) Remove adapter **A**.

**41. Engine oil cooler**


Fit a gasket and install engine oil cooler (2), then tighten 17 bolts (1).

 kgm Mounting bolt : 6.75 ± 0.75 kgm




42. Body side oil cooler


- 1) Fit a gasket and install body side oil cooler (3), then tighten 8 bolts (2).
- 2) Install aeration pipe (1).

**43. Starting motor**


- 1) Fit a gasket and install starting motor (3),

**44. Turbocharger and exhaust manifold assembly**


- 1) Sling turbocharger and exhaust manifold assembly (3), fit gaskets, and tighten 18 mounting bolts (4).
- * Fit the gasket with the marked side facing outward.

 kgm Mounting bolt : 6.75 ± 0.75 kgm

- 2) Assemble exhaust brake.
- * To prevent any excessive force from being brought to bear on the turbocharger when assembling the exhaust brake, position it first and then tighten all the bolts.
- 3) Fit gaskets and install turbocharger inlet tube (2) and outlet tube (1).
- 4) Connect the intake connector hose to the turbocharger.

**45. Air cleaner**

Install air cleaner (2) and bracket (1) as a unit, and connect the hose to the turbocharger.


**Refilling with the engine oil**

- 1) Make sure the engine drain plug is tightened.
- 2) Add engine oil through the oil filter to the specified level.



Engine oil pan : about 26ℓ

DISASSEMBLY OF AIR COMPRESSOR



OVERALL ASSEMBLY**1. Cylinder head**

- 1) Remove 4 cylinder head mounting bolts (1).
- 2) Tap with a wooden hammer from under cylinder head, and remove cylinder head (2).
- 3) Remove gasket (3) inserted between cylinder and cylinder head.

2. Cylinder, connecting rod, piston

- 1) Remove 4 cylinder mounting bolts (5), then remove cylinder (4) from crankcase (10).
- 2) Remove 2 bolts (6) holding big end of connecting rod.
- 3) Remove piston (8) and connecting rod (9) from crankcase.

3. Bearing cover

- 1) Remove 4 mounting bolts (4) of bearing cover installed to crankcase, then remove cover (15) from crankcase together with oil seal.
- 2) Remove oil seal from bearing cover (15).

4. Crankshaft

- 1) Pull out crankshaft (12) in direction of mounting surface of bearing cover (15) with 2 ball bearing (11) still installed.
- 2) Using a press, remove ball bearings (11) from crankshaft (12).

FINE DISASSEMBLY**1. Piston, connecting rod**

- 1) Remove snap ring (17), then pull out piston pin (16), and remove piston (8).
- 2) Remove piston rings (7) from piston.

2. Unloader valve assembly

- 1) Remove unloader valve body (19) installed on top of cylinder head.
- 2) Remove snap ring (30) from inside unloader valve body (19), then take out washer (31), spring (22), and rod (20).


3. Delivery valve assembly

- 1) Seat (26) is screwed in and installed to bottom of cylinder head, and thread is caulked, so remove caulking.
- 2) Remove seat (26), then remove guide (23), spring (27), valve plate (25), guide (29), and gasket (28) from inside.


4. Intake valve assembly

- 1) Guide (32) is screwed in to bottom of cylinder head, and thread is caulked, so remove caulking.
- 2) Remove guide (32), then remove spring (33), valve plate (34), seat (35), and gasket (36) at the same time.

ASSEMBLY OF AIR COMPRESSOR




FINE ASSEMBLY**1. Intake valve**

- 1) Assemble gasket (36), seat (35), valve plate (34), and spring (33) in turn to cylinder head (1), then temporarily tighten guide (32).
- 2) Check that valve plate and spring move smoothly, then tighten guide (32) to the specified torque.
 Guide : 10 kgm

* If the guide is protruding from the bottom surface of the cylinder head, it will interfere with the piston, so check the condition.

- 3) Caulk guide at three places with a punch.



2. Delivery valve

- 1) Assemble guide (23), spring (27), valve plate (25), gasket (28), guide (29), and gasket (24) in turn to cylinder head (1), then temporarily tighten seat (26).
- 2) Check that the plate moves smoothly, then tighten seat (26) to the specified torque.
 Seat : 15 kgm

* If the seat is protruding from the bottom surface of the cylinder head, it will interfere with the piston, so check the condition.

- 3) Caulk seat at three places with a punch.


3. Unloader valve

- 1) Fit O-ring (21) to rod (20), then assemble in body (19).
 O-ring : Grease (LM-G)
 - 2) Install spring (22) and washer (31) to rod (20), then install snap ring (30).
 - 3) Install gasket (18), then assemble unloader valve assembly to cylinder head (1), and tighten to the specified torque.
 Unloader valve : 5 kgm
- * Push rod (20) with a screwdriver, and check that the valve moves.


4. Piston, connecting rod

- 1) Set piston (8) to connecting rod (9), then insert piston pin (16), and install snap ring (17).
- 2) Assemble piston rings (7) to piston (8).
 * Install the top ring and second ring with the stamped mark at the top, and make sure the end gaps are not aligned.

OVERALL ASSEMBLY**1. Crankshaft**

- 1) Press fit bearings (11) to both ends of crankshaft (12).
- 2) Insert crankshaft (12) from installation side of bearing cover (15) of crankcase.
- 3) Press fit oil seal to bearing cover (15), and fit O-ring, then install to case and tighten bolts (14).
 Bolt : 2.5 kgm

2. Cylinder, connecting rod, piston


- 1) Insert connecting rod from top of crankcase, then tighten cap (13) with bolts (6).
 Connecting rod bolt : 2.5 kgm

* Check that the connecting rod match marks are aligned.

- 2) Fit O-ring to cylinder mounting surface, then compress piston ring while inserting piston in to cylinder (4), and tighten bolts (5).

 Bolt : 3 kgm

3. Cylinder head

- 1) Install gasket (3) to cylinder.
- 2) Install cylinder head (2), then tighten bolts (1) uniformly.
 Cylinder head bolt : 5 kgm

PERFORMANCE TEST AFTER ASSEMBLY

After disassembling, inspecting, and assembling, carry out an air-tightness test and performance test as follows.

1) Air tightness test

Apply an air pressure of 7 kg/cm² at the same time to the discharge port and unloader valve, and measure the amount of leakage from the intake port.

Standard for leakage : Max. 450 cc/min

2) Filling performance


With a tank capacity of 30 litres, the time taken to raise the tank pressure from 0 --> 8 kg/cm² must be as follows.

| Speed (rpm) | Filling time (sec) |
|-------------|--------------------|
| 250 | Max. 220 |
| 1,500 | Max. 40 |

3) Oil leakage up

Remove the pipe of the discharge port in the cylinder head, and check the operation. Check that there is no abnormal spray of oil from the discharge port.

DISASSEMBLY AND ASSEMBLY OF EXHAUST BRAKE



1. Exchange O-ring (30) and poppet (23)

- 1) Remove bolt (41) after fixing body.
- 2) Exchange O-ring (30) and poppet (23).

poppet (23) : Silicon grease

Bolt : 0.8 kgm

2. Exchange liner (5), gate valve (2), gasket (18) and valve housing (1).

- 1) Remove socket head cap screw (39), (40) after fixing valve housing (1).
- 2) Remove valve housing (1).
- 3) Connect air piping to PT 1/4 of poppet cover, raise air pressure to approx. 1 -- 2 kg/cm² and float T block (4).
- 4) Remove gate valve (2), liner (5), and gasket (18) in order, and install replacement parts in regular order.
- 5) Remove air piping after reducing air pressure to 0 kg/cm²
- 6) Install valve housing (1) and socket head cap screws (39) and (40).

Cap screw : Antifriction compound

Cap screw : 3 kgm

3. Exchange cylinder tube (9), piston portions (12), (13), (14), (15), (19), (21), (29) and spring (25).

- 1) Fix valve housing (1).
- 2) Remove head cover (10) after removing nut (34).
- 3) Remove socket head cap screws (39) and (40) fixing valve housing (1).
- 4) Remove valve housing (1) after pushing retainer (14).
- 5) Remove liner (5) and gasket (18).
- 6) Fix hexagonal nuts (32) holding T block.
- 7) Remove two hexagonal nuts (33) holding piston portion.
- 8) Remove retainer (14), wave washer (29), taper washer (13), washer (19), and piston packing (21).
- 9) After removing cylinder tube (9) and setting piston (12) on vice, top piston rod (17) with rubber mallet and remove piston (12).
- 10) Remove spring (25).
- 11) Apply silicon grease to one side only of the exchanged cylinder tube (9) to a surrounding width of 40 mm, install the tube turning the grease upward, into spring holder (8).

Cylinder tube : Silicon grease

- 12) Install spring (25) into spring holder (8).

- 13) Apply LOCK-TIGHT to surrounding groove of piston (12).

Piston : Adhesive (LT-2)

- 14) Place piston packing (21) on piston (12) and place the burrless side of washer (19) to the packing (21).

- 15) Apply silicon grease lightly to the edge of packing (21).

Packing : Silicon grease

- 16) Apply silicon grease to the region surrounding retainer (14) and position two web washers (29) and taper washer (13).

Retainer : Silicon grease

- 17) Place sub-assembly of piston (12), packing (21) and washer (19) into piston rod (17), while pressing packing (21) with the tapered portion of washer (13).

- 18) Push in sub-assembly of (13), (29), (14) and install them using two nuts (33).

 1st nut : 2 kgm
2nd nut : 2 kgm

- 19) Remove fixing nut (32).

- 20) Install gasket (18) and liner (5).

- 21) Install gate valve (2) while pushing in retainer (14).



- 22) Install valve housing (1) and tighten socket head cap screws (39) and (40).


Cap screw : 3 kgm

* Install head cover (10) and tighten nut (34).

Nut : 2.5 kgm

4. Exchange guide bushing (24) and insulating packings (27) and (28).


- 1) Remove spring (25) using similar method to that of item 3.
- 2) Loosen nut (44) holding sleeve (43) after removing (22), and remove (43) and (44) from rod (17).
- 3) Remove fixing nut (32) and draw out rod (17) from base plate (3) and adapter plate (7).
- 4) Remove seal packing sub-assembly (15), relief spacer (6) and guide bushing (24) from plate (3) in that order, and install the exchanged parts in regular order.
 - * Face the wider side of spacer (6) to packing sub-assembly (15) side.
- 5) Fix plate (7) by vice and remove (8) and (24), while tapping bushing (24) slightly with bar (a little smaller than hole diameter of plate) from the opposite hole of spring holder (8).
 - * When (8) is difficult to remove, turn (8) using a pipe wrench then remove it.
 - * In this case, exchange (8) with new part.
- 6) Make a hole (5mm) in plate (7) , then apply thread tightener and position packing (27) so that the hole of packing (27) is aligned with the hole of plate (7). 
 - plate : Thread tightener (LT-2)
- 7) Place bushing (24) in spring holder (8), then apply thread tightener to pilot portion of plate (7) and align holes of packing (27) and spring holder (8) to install spring holder (8).
 - plate : Thread tightener (LT-2)
- 8) Place insulating packing (28) in to plate (7).
- 9)  ie pilot of plate (7) to align with base plate (3), and install rod (17) from plate (3) side.
- 10) Place nut (44) onto rod (17) so that the flat face of the nut meets sleeve (43).
- 11) Adjust the distance from the rod (17) end to sleeve (43) to approx. 27 mm, by use of nut (44).
- 12) Fix sleeve (43) by vice and tighten the nut (44).
 - Nut : 2.5 kgm

- 13) Place collar (22) on sleeve (43) and apply LOCK- to 8 mm screw and 8 mm diameter portions of rod (17).

Screw, rod : Adhesive (LT-2)

- 14) After this, assemble using similar method to item

**5. Exchange piston rod (17)**


- 1) Remove rod (17) using similar method to item 4.
- 2) Place T block (4) and guide (42) onto exchanged rod (17).
- 3) Tighten nut (32) so that the chamfered side of nut (32) faces guide (42).
 - Nut : 5.5 kgm
- 4) Calk the nut at three places using a punch to avoid  ing .
- 5) After this, assemble using similar method to item 4.

6. Matters to be attended to before assembly housing (1) when carrying out items 3, 4 and 5.

- 1) Install air piping to PT 1/4 of poppet cover, raise air pressure to approx. 1 - 2 kg/cm² , float T block (4) and remove gate valve (2).
 - * When reducing air pressure to 0 kg/cm² , position an approx. 10 mm block so that T block (4) does not contact base plate (3) directly.
- 2) Then reduce air pressure to 0 kg/cm² .
- 3) Adjust by turning T block (4) so that the seat side of gate valve (2) for liner guide (42) is approximately parallel with the longitude direction of base plate (3).
- 4) If operation is smooth after carrying out the operation of T block several times, float T block (4) and remove block.
- 5) After this, assemble using similar method to item 2.
 - * Silicon grease.
Pertinent brand : SHINETSU KAGAKU (FG721A) or equivalent.
 - * Antifriction compound
Pertinent brand : LC-G MORI court 1000 or equivalent.

ENGINE

15 MAINTENANCE STANDARD



INTAKE AND EXHAUST SYSTEM

Turbocharger 15-002

ENGINE BODY

Cylinder head 15-004

Valve and valve guide 15-005

Rocker arm shaft 15-007

Crosshead 15-008

Cylinder block 15-009

Cylinder liner 15-011

Crankshaft 15-012

Camshaft 15-013

Cam follower and push rod 15-014

Piston, piston ring and piston pin 15-015

Connecting rod 15-021

Timing gear 15-022

Flywheel and flywheel housing 15-023

Vibration damper 15-024

COOLING SYSTEM

Water pump and thermostat 15-025

Oil cooler 15-026

LUBRICATION SYSTEM

Oil pump 15-027

Main relief valve 15-028


Regulator valve and safety valve 15-029

ACCESSORY

Air compressor 15-030

TURBOCHARGER


TV77



Unit: mm

| No. | Item | Criteria | | | Remedy |
|-----|---|-----------------|--|-------------------|-----------|
| 1 | Radial play of rotor | Standard | | Repair limit | Replace |
| | | 0.08 - 0.18 | | 0.18 | |
| 2 | End play of rotor | 0.08 - 0.25 | | 0.25 | |
| 3 | Tightening torque of back plate mounting bolt | Target (kgm) | | Range (kgm) | Retighten |
| | | 1.25 | | 1.15 - 1.38 | |
| 4 | Tightening torque of V-band locknut | Order | Target (kgm) | Range (kgm) | |
| | | 1st step | 1.8 | 1.6 - 2.0 | |
| | | 2nd step | 0 | Loosen completely | |
| | | 3rd step | 1.4 | 1.27 - 1.50 | |
| 5 | Thickness of thrust bearing | Standard | | Repair limit | Replace |
| | | 2.315 | | 2.29 | |
| 6 | Outer diameter of wheel shaft | Measuring point | Standard | Repair limit | |
| | | A | 17.53 | 17.48 | |
| | | B | 15.88 | 15.88 | |
| | Bend of wheel shaft | | Repair limit: 0.010 (Total indicated runout) | | |
| 7 | Inside diameter of back plate | Standard | | Repair limit | |
| | | 17.47 | | 17.49 | |
| 8 | Inside diameter of center housing | Measuring point | Standard | Repair limit | |
| | | C | 20.90 | 20.93 | |
| | | D | 24.97 | 24.97 | |


(For BE300-3 AND BE300LC-3)



Unit: mm

| No. | item | Criteria | | | Remedy |
|-----|---|---|----------|--------------|-----------|
| 1 | Radial play of rotor | Standard | | Repair limit | Replace |
| | | 0.075 - 0.150 | | 0.180 | |
| 2 | End play of rotor | 0.025 - 0.075 | | 0.10 | |
| 3 | Thickness of thrust bearing | 4.36 | | 4.35 | |
| 4 | Outer diameter of wheel shaft | Measuring point | Standard | Repair limit | |
| | | A | 17.34 | 17.25 | |
| | | B | 10.16 | 10.15 | |
| | Bend of wheel shaft | Repair limit: 0.010 (Total indicator reading) | | | |
| 5 | Inside diameter of back plate | Standard | | Repair limit | |
| | | 12.70 | | 12.73 | |
| 6 | Depth of back plate | 11.66 | | 11.68 | |
| 7 | Inside diameter of center housing | Measuring point | Standard | Repair limit | |
| | | C | 15.80 | 15.81 | |
| | | D | 18.03 | 18.08 | |
| 8 | Tightening torque of turbine housing bolt | Target (kgm) | | Range(kgm) | Retighten |
| | | 2.0 | | 1.8 - 2.2 | |
| 9 | Tightening torque of blower housing bolts | 1.3 | | 1.15 - 1.5 | |


CYLINDER HEAD



Unit: mm

| No. | Item | Criteria | | | | Remedy |
|-----|--|---|----------|--------------------|------------|--|
| 1 | Distortion of cylinder head mounting surface | Standard | | Repair limit | | Repair by grinding or replace |
| | | 0 - 0.06 | | 0.09 | | |
| 2 | Protrusion of nozzle | Applicable model | | Standard | | Replace Sleeve |
| | | B6D125-1 | | S.T.D | | |
| | | S.T.D | | 4.90 - 5.70 | | |
| | | D75S-5 (23193 and up) D85E.P-1 BE300-3 (23689 and up) HD205-3 GD705A-4 (23599 and up) | | 4.90 - 5.70 | | |
| | | BS6D125-1 | | S.T.D | | |
| | | BSA6D125-1 | | D135A-1 | | |
| 3 | Tightening torque of cylinder head mounting bolts (Coat the thread areas with molybdenum disulfide or engine oil) | Bolt No. | Order | Target (kgm) | Range(kgm) | Tighten bolts in accordance with bolts No. |
| | | ① - ⑥ | 1st step | 10 | 9 - 11 | |
| | | | 2nd step | 14 | 13 - 15 | |
| | | | 3rd step | Retighten with 90° | 90°-120° | |
| | | ⑦ | - | 7 | 6 - 7.5 | |
| 4 | Tightening torque of nozzle holder mounting bolt | 2.2 ± 0.3 kgm | | | | Retighten |
| 5 | Tightening torque of rocker arm housing | 6.75 ± 0.75 kgm | | | | |

VALVE AND VALVE GUIDE




unit: mm

| No. | Item | Criteria | | | | Remedy |
|-----|-------------------------|----------|----------|------------|--------------|-----------------------------|
| | | Valve | Standard | Tolerance | Repair limit | |
| 1 | Amount of valve sinking | Intake | 0 | ± 0.10 | 0.63 | Replace valve or valve seat |
| | | Exhaust | 0 | ± 0.10 | 0.70 | |

Unit: mm

| No. | Item | Criteria | | | Remedy | | | |
|-----|--|---------------------------|---|------------------|----------------------------------|----------------|---------|--------------|
| 2 | Thickness of valve lip | Valve | Standard | Repair limit | Replace | | | |
| | | Intake | 2.10 | 1.7 | | | | |
| | | Exhaust | 1.50 | 1.2 | | | | |
| 3 | Valve seat angle | Valve | Standard | Tolerance | Repair or replace | | | |
| | | Intake | 30° | ± 0°15’ | | | | |
| | | Exhaust | 45° | ± 0°15’ | | | | |
| 4 | Outside diameter of valve stem | Valve | Standard | Tolerance | Replace | | | |
| | | Intake | 9 | -0.045 -0.065 | | | | |
| | | Exhaust | 9 | -0.050 -0.070 | | | | |
| | Inside diameter of valve guide | Before inserting | 9 | +0.015 -0.005 | Replace | | | |
| | | After inserting | 9 | ±0.010 | | | | |
| | Clearance between valve guide and valve stem | Valve | Standard | Clearance limit | Replace | | | |
| | | Intake | 0.035 - 0.075 | 0.22 | | | | |
| | | Exhaust | 0.040 - 0.080 | 0.24 | | | | |
| | Bend of valve stem | | Repair limit: 0.02 (Total indicator reading for 100 mm) | | | Replace | | |
| 5 | Protrusion of valve guide | Standard | | Tolerance | | Repair | | |
| | | 20 | | ±0.2 | | | | |
| 6 | Free length of Valve spring | Engine | Valve | Color code | Free length | Repair limit | Replace | |
| | | B6D125-1 | Intake | Yellow | 66.9 | 64.7 | | |
| | | | Exhaust | Yellow | 66.9 | 64.7 | | |
| | | BS6D125-1 | Intake | Purple | 61.3 | 58.9 | | |
| | | | Exhaust | Yellow | 66.9 | 64.7 | | |
| | Installed load of valve spring | Engine | Valve | Color code | Installed length | Installed load | | Repair limit |
| | | B6D125-1 | Intake | Yellow | 56.0 | 30.0± 1.5kg | | 27.0 kg |
| | | | Exhaust | Yellow | 56.0 | 30.0± 1.5kg | | 27.0 kg |
| | | BS6D125-1 | Intake | Purple | 49.5 | 40.0± 2.0kg | | 36.0 kg |
| | | | Exhaust | Yellow | 56.0 | 30.0± 1.5kg | | 27.0 kg |
| | | Squarence of valve spring | | | Repair limit : 2° (For both end) | | | |


ROCKER ARM SHAFT



unit: mm

| No. | Item | Criteria | | | Remedy |
|-----|---|---|-------------------|-----------|--|
| 1 | Outside diameter of rocker arm shaft | Standard | Tolerance | | Replace rocker arm shaft |
| | | 28.6 | −0.055 -0.065 | | |
| | Inside diameter of rocker arm shaft hole | 28.6 | +0.035 - 0.025 | | Replace rocker arm |
| | Clearance between rocker arm and rocker arm shaft | Standard clearance | Clearance limit | | Replace rocker arm or rocker arm shaft |
| | | 0.025 - 0.100 | 0.130 | | |
| | Bend of rocker arm shaft | Repair limit : 0.20 (Total indicator reading) | | | Replace rocker arm shaft |
| 2 | Tightening torque of rocker arm adjustment nut | 6.75 ± 0.75 kgm | | | Retighten |
| 3 | Valve clearance (at cold) | Valve | Standard | Tolerance | Adjust |
| | | Intake | 0.33 | ± 0.02 | |
| | | Exhaust | 0.71 | ± 0.02 | |



CROSSHEAD



unit: mm

| No. | Check item | Criteria | | | Remedy |
|-----|---|---------------------|------------------|--------------|-----------|
| | | Standard | Tolerance | Repair limit | |
| 1 | Depth of crosshead stem | 3 | +0.56 -0.46 | 3.67 | Replace |
| 2 | Inside diameter of crosshead | 11 | +0.075 +0.025 | 11.18 | |
| | Outside diameter of crosshead guide | 11 | +0.010 0 | 10.95 | |
| 3 | Protrusion of crosshead guide | 45.5 | ± 0.25 | - | Repair |
| 4 | Tightening torque of crosshead lock nut | 6.75 ± 0.75 kgm | | | Retighten |


CYLINDER BLOCK



unit: mm

| No. | Item | Criteria | | | Remedy | |
|-----|---|---|--------------------|--------------------|-------------------------------|---------|
| 1 | Distorsion of cylinder head mounting surface | Standard | | Repair limit | Repair by grinding or replace | |
| | | 0 - 0.080 | | 0.120 | | |
| 2 | Inside diameter of main bearing hole | Standard | | Tolerance | Repalce main bearing cap | |
| | | 116 | | +0.022 0 | | |
| | Thickness of main bearing | 3 | | -0.003 -0.013 | Replace | |
| | Roundness of main bearing hole | Repair limit : 0.005 bearing | | | | |
| 3 | Inside diameter of main bearing | Standard | Tolerance | Repair limit | Replace bearing | |
| | | 110 | +0.040 -0.010 | 110.15 | | |
| 4 | Inside diameter of cam bushing mounting hole | 63 | +0.030 0 | | Repair or replace | |
| 5 | Inside diameter of cam bushing | 60 | +0.070 0 | 60.30 | Replace | |
| 6 | Difference between lower face of cylinder block & flywheel housing | Repair limit : 0.35 | | | Repair | |
| 7 | Difference between lower face of cylinder block and front cover | Repair limit : 0.28 | | | | |
| 8 | Tightening torque of main bearing cap bolt (Coat thread area with engine oil) | Order | Target(kgm) | | Range (kgm) | Tighten |
| | | 1st step | 10 | | 9 - 11 | |
| | | 2nd step | 20 | | 19 - 21 | |
| | | 3rd step | Retighten with 90° | | 90° - 120° | |
| 9 | Tightening torque of crankshaft pulley mounting bolt | M16 (5 bolts), for BD60P-8, BD60S | 1st | 15 | 14 - 16 | |
| | | | 2nd | 30 | 29 - 31 | |
| | | | 3rd | Retighten with 90° | Retighten with 90° - 120° | |
| | | M14 (1 bolt) | 18 | | 16 - 20 | |
| 10 | Tightening torque of oil pan mounting bolt | 5.5 ± 2.0 kgm | | | | |


CYLINDER LINER



unit: mm

| No. | Item | Criteria | | | Remedy |
|--------------------------------|---|-----------------------------|------------------|--------------|---------------------------|
| 1 | Protrusion of cylinder liner | Repair limit : 0.07 to 0.15 | | | Replace liner or block |
| 2 | Inside diameter of cylinder liner | Standard | Tolerance | Repair limit | Replace liner |
| | | 125 | +0.040 0 | 125.20 | |
| | Roundness of cylinder liner | Repair limit: 0.08 | | | |
| Cylindricity of cylinder liner | Repair limit: 0.08 | | | | |
| 3 | Outside diameter of cylinder liner(Counter bore) | Standard | | Tolerance | |
| | 153 | | ± 0.025 | | |
| | Interference between cylinder liner and block (Counter bore) | Standard : 0 - 0.115 | | | Replace liner liner block |
| 4 | Outside diameter of cylinder liner(Counter bore bottom) | Standard | | Tolerance | Replace liner |
| | 145 | | +0.090 +0.040 | | |
| | Interference between cylinder liner Standard Interference limit | Replace liner | | | |
| 5 | & block(Counter bore bottom) | 0.01 - 0.12 | | 0.01 | block |
| | Outside diameter of cylinder liner (O-ring) | Standard | | Tolerance | Replace or liner |
| | 141 | | +0.385 | | |
| | Clearance between cylinder liner and block (O-ring) | +0.360 | | | Replace liner or block |
| | | Standard : 0.015 - 0.080 | | | |


CRANKSHAFT



unit: mm

| No. | Item | Criteria | | | | Remedy |
|-----|---------------------------------------|----------------|----------|------------------|--------------|--|
| 1 | End play | Standard | | Repair limit | | Repair by using over size thrust-bearing/replace |
| | | 0.0140 - 0.320 | | 0.50 | | |
| 2 | Outside diameter of main journal | | Standard | Tolerance | Repair limit | Repair by using under size main bearing or replace |
| | | S.T.D. | 110 | -0.050 -0.070 | 109.88 | |
| | | 0.25US | | | 109.63 | |
| | | 0.50US | | | 109.38 | |
| | | 0.75US | | | 109.13 | |
| | | 1.00US | | | 108.88 | |
| | Roundness of main journal | Standard | | Repair limit | | Replace main bearing |
| | | 0 - 0.010 | | 0.020 | | |
| | Clearance of main journal | Standard | | Clearance limit | | Replace main bearing |
| | | 0.060 - 0.105 | | 0.27 | | |
| 3 | Outside diameter of crank pin journal | | Standard | Tolerance | Repair limit | Repair by using under size bearing or replace |
| | | S.T.D | 80.00 | -0.050 -0.070 | 79.88 | |
| | | 0.25US | 79.75 | | 79.63 | |
| | | 0.50US | 79.50 | | 79.38 | |
| | | 0.75US | 79.25 | | 79.13 | |
| | | 1.00US | 79.00 | | 78.88 | |
| | Roundness of crankpin journal | Standard | | Repair limit | | Replace connecting rod bearing |
| | | 0 - 0.010 | | 0.020 | | |
| | Clearance of crankpin journal | Standard | | Clearance limit | | Replace connecting rod bearing |
| | | 0.045 - 0.090 | | 0.24 | | |
| 4 | Bend of crankshaft | Standard | | Repair limit | | Repair by using under size bearing or replace |
| | | 0 - 0.090 | | 0.20 | | |

CAMSHAFT




unit: mm

| No. | Item | Criteria | | | Remedy |
|-----|--------------------------------------|--|-------------------------|--------------|----------------------|
| 1 | End play | Standard | Repair limit | | Replace thrust plate |
| | | 0.15 - 0.35 | 0.50 | | |
| 2 | Outside diameter of camshaft journal | Standard | Tolerance | | Replace camshaft |
| | | 60 | -0.080 -0.110 | | |
| | Clearance of camshaft journal | Standard 0.080 - 0.180 | Clearance limit 0.28 | | Replace cam bushing |
| 3 | Bend of camshaft | Repair limit: 0.03 (Total indicator reading) | | | |
| 4 | Cam height | Standard | Tolerance | Repair limit | Replace |
| | | 52 | + 0.395 + 0.195 | 51.73 | |

CAM FOLLOWER AND PUSH ROD

B6D125-1

BS(A)6D125-1




6150F412

Unit : mm

| No. | Item | Criteria | | | Remedy |
|-----|---|---|--------------------|--------------|---------|
| 1 | Outside diameter of cam follower shaft | Standard | Tolerance | Repair limit | Replace |
| | | 19.8 | -0.040 -0.050 | 19.73 | |
| | Inside diameter of cam follower shaft hole | 19.8 | +0.020 0 | | |
| 2 | Outside diameter of cam roller | 32 | - 0.250 - 0.280 | 31.71 | |
| 3 | Inside diameter of cam roller | 13 | - 0.260 - 0.285 | 12.78 | |
| | Outside diameter of cam roller pin | 13 | - 0.365 -0.375 | 12.62 | |
| 4 | Radius of push rod ball end | Standard size | | Tolerance | |
| | | 12.7 | | 0 -0.20 | |
| 5 | Radius of push rod socket end | 12.7 | | 0 -0.20 | |
| | | Repair limit : 0.50 (Total indicator reading) | | | |
| 6 | Bend of push rod | | | | |
| 7 | Tightening torque of cam follower housing mounting bolt | 5.25 ± 0.75 kgm | | | |

PISTON, PISTON RING AND PISTON PIN

B6D125-1 (Aluminum alloy)




B6D125-1 (Aluminum alloy)

unit: mm

| No. | Item | Criteria | | | | Remedy |
|-------------|---|---------------|-----------------|-------------------------------|------------------|---|
| 1 | Outside diameter of piston (Aluminum piston) | Standard | | Tolerance | Repair limit | Replace piston |
| | | 125 | | -0.295 -0.325 | 124.59 | |
| 2 3 4 | Thickness of piston ring | No. | Measuring point | Standard | Tolerace | Replace piston ring |
| | | 2 | Top ring | 2.4 | -0.015 -0.035 | |
| | | 3 | Second ring | 2.4 | -0.010 -0.030 | |
| | | 4 | Oil ring | 4.0 | -0.010 -0.030 | |
| | Width of piston ring groove | 2 | Top ring | Judge using groove wear gauge | | Replace piston |
| | | 3 | Second ring | | | |
| | | 4 | Oil ring | 4.0 | +0.025 +0.010 | |
| | Clearance between piston ring and ring groove | No. | Measuring point | Standard | Clearance limit | Replace piston or piston ring |
| | | 2 | Top ring | Judge using groove wear gauge | | |
| | | 3 | Second ring | | | |
| | | 4 | Oil ring | 0.020 - 0.055 | 0.15 | |
| | Piston ring gap | 2 | Top ring | 0.37 - 0.52 | 2.0 | Replace pis piston ring or cylinder liner |
| | | 3 | Second ring | 0.50 - 0.62 | 1.5 | |
| | | 4 | Oil ring | 0.28 - 0.43 | 1.0 | |
| 5 | Outside diameter of piston pin | Standard | | Tolerance | | Replace piston pin |
| | | 48 | | 0 -0.006 | | |
| | Inside diameter of piston pin hole | 48 | | +0.012 +0.004 | | Replace piston |
| | | Standard | | Clearance limit | | |
| | Clearance between piston pin and piston | 0.004 - 0.018 | | 0.030 | | Replace piston or piston pin |

BS6D125-1, BSA6D125-1 (Ductile cast iron (FCD))




BS6D125-1, BSA6D125-1 (Ductile cast iron (FCD))

unit: mm

| No. | Item | Criteria | | | | Remedy |
|---------------|---|---------------|-----------------|-------------------------------|------------------|---|
| 1 | Outside diameter of piston | Standard | | Tolerance | Repair limit | Replace piston |
| | | 125 | | -0.075 -0.105 | 124.80 | |
| 2 3 4 | Thickness of piston ring | No. | Measuring point | Standard | Tolerace | Replace piston ring |
| | | 2 | Top ring | 2.4 | -0.015 -0.035 | |
| | | 3 | Secong ring | 2.4 | -0.010 -0.030 | |
| | | 4 | Oil ring | 4.0 | -0.010 -0.030 | |
| | Width of piston ring groove | 2 | Top ring | Judge using groove wear gauge | | Replace piston |
| | | 3 | Second ring | | | |
| | | 4 | Oil ring | 4.0 | +0.040 +0.020 | |
| | Clearance between piston ring and ring groove | No. | Measuring point | Standard | Clearance limit | Replace piston or piston ring |
| | | 2 | Top ring | Judge using groove wear gauge | | |
| | | 3 | Second ring | | | |
| | | 4 | Oil ring | 0.03- 0.07 | 0.15 | |
| | Piston ring gap | 2 | Top ring | 0.37 - 0.52 | 2.0 | Replace pis piston ring or cylinder liner |
| | | 3 | Second ring | 0.50 - 0.62 | 1.5 | |
| | | 4 | Oil ring | 0.28 - 0.43 | 1.0 | |
| 5 | Outside diameter of piston pin | Standard size | | Tolerance | | Replace piston pin |
| | | 48 | | 0 -0.006 | | |
| | Inside diameter of piston pin hole | 48 | | - 0.045 - 0.035 | | Replace piston |
| | Clearance between piston pin and piston | Standard | | Repair limit | | Replace piston or piston pin |
| 0.035 - 0.051 | | 0.063 | | | | |

BS6D125-1 (Aluminum alloy)




BS6D125-1 (Aluminum alloy)


unit: mm

| No. | Item | Criteria | | | | Remedy | |
|---------------|---|---|-----------------|-------------------------------|------------------|--------------------|---------------------------------------|
| 1 | Outside diameter of piston | Standard | | Tolerance | Repair limit | Replace piston | |
| | | 125 | | -0.255 -0.285 | 124.59 | | |
| 2 3 4 | Thickness of piston ring | No. | Measuring point | Standard | | Tolerace | Replace piston ring |
| | | 2 | Top ring | 2.4 | | -0.015 -0.035 | |
| | | 3 | Secong ring | 2.4 | | -0.010 -0.030 | |
| | | 4 | Oil ring | 4.0 | | -0.010 -0.030 | |
| | Width of piston ring groove | 2 | Top ring | Judge using groove wear gauge | | | Replace piston |
| | | 3 | Second ring | | | | |
| | | 4 | Oil ring | 4.0 | +0.025 +0.010 | | |
| | Clearance between piston ring and ring groove | No. | Measuring point | Standard | | Clearance limit | Replace piston or piston ring |
| | | 2 | Top ring | Judge using groove wear gauge | | | |
| | | 3 | Second ring | | | | |
| | | 4 | Oil ring | 0.020- 0.055 | 0.15 | | |
| | Piston ring gap | 2 | Top ring | 0.37 - 0.52 | | 2.0 | Replace piston ring or cylinder liner |
| | | 3 | Second ring | 0.50 - 0.62 | | 1.5 | |
| | | 4 | Oil ring | 0.28 - 0.43 | | 1.0 | |
| 5 | Outside diameter of piston pin | Standard | | Tolerance | | Replace piston pin | |
| | | 48 | | 0 -0.006 | | | |
| | Inside diameter of piston pin hole | 48 | | +0.012 +0.004 | | Replace piston | |
| | | Clearance between piston pin and piston | Standard | | Clearance limit | | Replace piston or piston pin |
| 0.004 - 0.018 | | | 0.030 | | | | |


CONNECTING ROD



unit: mm


| No. | Item | Criteria | | | | Remedy | |
|-----|---|---|-----------------------|------------------|--------------|-------------------------------|------------------------|
| 1 | Inside diameter of bushing at connecting rod small end | Standard | Tolerance | | Repair limit | Replace bushing | |
| | | 48 | +0.041 +0.025 | | 48.08 | | |
| | Clearance between bushing at connecting rod small end piston pin | Standard | | Clearance limit | | Replace bushing or piston pin | |
| | | 0.025 - 0.047 | | 0.10 | | | |
| 2 | Inside diameter of bushing hole at connecting rod small end. | Standard size | | Tolerance | | Replace connecting rod | |
| | | 53 | | +0.030 0 | | | |
| 3 | Inside diameter of bearing at connecting rod big end | Standard size | Tolerance | | Repair limit | Replace bearing | |
| | | 80 | +0.020 -0.010 | | 80.12 | | |
| 4 | Inside diameter of bearing at connecting rod big end | 85 | | +0.022 -0.004 | | Replace connecting | |
| | | Measure after tightening connecting rod cap with specified torque | | | | | |
| | Thickness of connecting rod | 2.5 | +0.005 -0.005 | | | Replace bearing | |
| 5 | Bend and twist of connecting rod |  | | | Standard | Repair limit | Replace connecting rod |
| | | | | Bend | 0 - 0.20 | 0.25 | |
| | | | | Twist | 0 - 0.30 | 0.35 | |
| 6 | Tightening torque of connecting rod cap mounting bolt (Coat bolt threads & nut seats with engine oil) | Order | Target (kgm) | | Range (kgm) | | Retighten |
| | | 1st step | 10 | | 9.5 - 10.5 | | |
| | | 2nd step | Retightening with 90° | | 90° - 120° | | |

TIMING GEAR




| No. | Check item | Criteria | | | | | Remedy |
|-----|---|--------------------|--|------------------|-----------------------|--------------------|------------------------------|
| 1 | Backlash of each gears | Meas- ing point | Gears | | Standard Size | Repair limit | Replace |
| | | A | Crankshaft gear and main idler gear (Large) | | 0.140-0.425 | 0.6 | |
| | | B | Main idler gear (small) and camshaft gear | | 0.125-0.395 | | |
| | | C | Camshaft gear and fuel injection pump drive gear | | 0.125-0.395 | | |
| | | a | Main idler gear (Large)and water pump drive gear | | 0.155-0.440 | | |
| | | b | Main idler gear(Large) and oil pump idler gear | | 0.130-0.405 | | |
| | | c | Oil pump idler gear and oil pump drive gear | | 0.080- 0.390 | | |
| 2 | Clearance between main idler gear bushing and shaft | Standard size | Tolerance | | Standard Clearance | Clearance limit | Replace bushing |
| | | | Shaft | Hole | | | |
| | | 47.5 | +0.165 +0.140 | +0.115 +0.100 | 0.025 - 0.060 | 0.20 | |
| 3 | Clearance between oil pump idler gear and shaft | 35 | -0.025 -0.040 | +0.065 0 | 0.025 - 0.105 | 0.20 | |
| 4 | End play of main idler gear | Standard | | | Repair limit | | Replace thrust bearing |
| | | 0.05 - 0.07 | | | 0.4 | | |
| 5 | End play of oil pump idler gear | 0.05 - 0.21 | | | 0.4 | | |


FLYWHEEL AND FLYWHEEL HOUSING



unit: mm


| No. | Item | Criteria | | | | Remedy |
|-----|--|---|----------|-------------|-------------|-----------|
| 1 | Face runout of flywheel housing | Repair limit : 0.35 | | | | Replace |
| 2 | Radial runout of flywheel housing | Repair limit : 0.30 | | | | |
| 3 | Face runout of flywheel | Repair limit : 0.20 | | | | |
| 4 | Radial runout of flywheel | Repair limit : 0.15 | | | | |
| 5 | Tightening torque of flywheel housing mounting bolts | Bolt | Order | Targer(kgm) | Range (kgm) | Retighten |
| | | M16 | 1st step | 14.5 | 8.5 - 20 | |
| | | | 2nd step | 28.5 | 25 - 31.5 | |
| | | M10 | - | 7 | 6 - 7.5 | |
| 6 | Tightening torque of flywheel mounting bolts (Coat the bolt threads with engine oil) |  | 1st step | 15 | 13 - 17 | |
| | | | 2nd step | 29.5 | 27.5 - 31.5 | |

VIBRATION DAMPER




| No. | Item | Criteria | | | unit: mm |
|-----|---|---|--------------|-------------|-----------|
| | | | | | Remedy |
| 1 | Visual check | Not appear any cracks on the rubber part. | | | Replace |
| 2 | Face runout of vibration damper(For D60P -17) | Repair limit : 0.80 | | | Replace |
| 3 | Radial runout of vibration damper (For D60P-17) | Repair limit : 0.80 | | | Replace |
| 4 | Tightening torque of vibration damper mounting blot | Bolt | Target (kgm) | Range (kgm) | Retighten |
| | | M12 (Except D60P-17) | 11.3 | 10 - 12.5 | |
| | | M14 (For D60p-17) | 18 | 16 - 20 | |


WATER PUMP AND THERMOSTAT



unit: mm


| No. | Item | Criteria | | | | | Remedy |
|-----|--|---|------------------|------------------|-----------------------|--------------------|------------------|
| 1 | Interference between impeller and shaft | Standard size | Tolerance | | Standard interference | Interference limit | Replace impeller |
| | | 15.9 | Shaft | Hole | 0.025 - 0.070 | - | |
| | | | +0.020 +0.005 | -0.020 -0.050 | | | |
| 2 | Interference between drive gear and shaft | 20 | +0.015 0 | -0.025 -0.055 | 0.025 - 0.070 | - | Replace impeller |
| 3 | Clearance between impeller and body | Standard clearance : 0.30 - 1.10 (Include end play) | | | | | Replace |
| 4 | Abrasion of seal ring in water seal |  <p>Repair limit A: 1.5</p> | | | | | |
| 5 | Lift of thermostat valve | Min. 10 (Check after immersion in a hot water bath of 90°C for 4 or 5 minutes.) | | | | | Replace |
| | Opening and closing of valve in thermostat | Valve must be close fully when immersed in a hot water bath (71° C) for 4 or 5 minutes after being immersed in a hot water bath (90°C) to fully open the valve. | | | | | |

OIL COOLER



| | | | | unit: mm |
|-----|--|---|---|----------|
| No. | Item | Criteria | | Remedy |
| 1 | Lift of thermostat valve | B6D125-1 BS6D125-1 | Min. 8 (check after immersion in a hot oil bath of 115°C for 4 or 5 minutes.) | Replace |
| | Opening and closing of valve in thermostat | Valve must be close fully when immersed in a hot oil bath (104° C) for 4 or 5 minutes after being immersed in a hot oil bath (115°C) to fully open the valve. | | |


OIL PUMP



unit: mm

| No. | Item | Criteria | | | | | | Remedy |
|-----|--|---------------|-----------------------------|-------------------------|------------------------------------|---------------------------------|-----------------|--------------|
| 1 | Axial clearance of pump gear | Engine | Standard size | Tolerance | | Standard clearance | Clearance limit | Replace gear |
| | | B6D125-1 | 23 | 0 -0.021 | +0.065 +0.040 | 0.03 - 0.09 | 0.10 | |
| | | BS6D125-1 | 47 | 0 -0.025 | +0.065 +0.040 | 0.03 - 0.09 | 0.10 | |
| 2 | Radial clearance of pump gear | Standard size | Tolerance | | Standard clearance | Clearance limit | | |
| | | 51.4 | Gear O.D. -0.15 -0.21 | Gear I.D. +0.06 0 | 0.03- 0.10 | 0.13 | | |
| 3 | Interference between pump drive gear and drive shaft | Standard size | Tolerance | | Standard clearence or interference | Clearance or interference limit | Replace | |
| | | 18 | +0.105 +0.090 | +0.065 +0.045 | 0.025- 0.060 | - | | |
| 4 | Clearance between drive shaft and cover bushing | 18 | -0.005 -0.025 | +0.060 +0.035 | 0.040- 0.085 | - | Replace bushing | |
| 5 | Inteference between pump gear and drive shaft | 18 | +0.105 +0.090 | +0.065 +0.030 | 0.025- 0.080 | - | Replace | |
| 6 | Clearance between drive shaft and body bushing | 18 | +0.105 +0.090 | +0.175 +0.145 | 0.040- 0.085 | - | Replace bushing | |
| 7 | Clearance between driven shaft and body | 18 | +0.090 +0.070 | +0.130 +0.100 | 0.010 - 0.060 | - | Replace | |
| 8 | clearance between driven shaft and gear bushing | 18 | +0.090 +0.070 | +0.145 +0.120 | 0.030 - 0.080 | - | Replace bushing | |
| 9 | Interference between driven shaft and cover | 18 | +0.090 +0.070 | +0.040 +0.020 | 0.030 - 0.070 | - | Replace | |


MAIN RELIEF VALVE



unit: mm

| No. | Item | Criteria | | | | | Remedy |
|-----|----------------------------------|---------------------------------|------------------|----------------|--------------------|-----------------|---------|
| 1 | Clearance between valve and body | Standard size | Tolerance | | Standard Clearance | Clearance limit | Replace |
| | | | Shaft | Hole | | | |
| | | 16 | -0.040 -0.060 | +0.045 0 | 0.040 - 0.105 | | |
| 2 | Relief valve spring | Standard size | | | Repair limit | | |
| | | Free length | Installed length | Installed load | Free length | Installed load | |
| | | 49.1 | 34.8 | 10.8kg | 46.2 | 9.8 kg | |
| 3 | Relief valve set pressure | $7^{+0.1}_0$ kg/cm ² | | | | | |


REGULATOR VALVE AND SAFETY VALVE



unit: mm

| No. | Item | | Criteria | | | | | Remedy |
|-----|--|----------------------|---|------------------|----------------|--------------------|-----------------|---------|
| 1 | Clearance between regulator valve and body | | Standard size | Tolerance | | Standard Clearance | Clearance limit | Replace |
| | | | 22 | Valve | Body | 0.07 - 0.16 | | |
| | | | | +0.15 | +0.28 | | | |
| | | | +0.12 | +0.22 | | | | |
| 2 | Regulator valve spring | | Standard size | | | Repair limit | | |
| | | | Free length | Installed length | Installed load | Free length | Installed load | |
| | Remote mounting type | Outer spring | 65.0 | 42.3 | 8.63 kg | | | |
| | | Innser spring | 56.3 | | 4.248 kg | | | |
| | | Direct mounting type | | 106.2 | 75.5 | 11.02 kg | | |
| 3 | Regulator valve set pressure | | +0.1 kg/cm ² BS6D125-1 : 3.75 ± 0.15kg/cm ² B6D125-1:3.0 -0.2 BSA6D125-1 | | | | | |
| 4 | Safety valve set pressure | | 2.0 ± 0.2 kg/cm ² | | | | | |

AIR COMPRESSOR



unit: mm

| No. | Item | Criteria | | | Remedy |
|-----|---|--------------------|--------------------|--------------|-------------------|
| | | Standard clearance | | Repair limit | |
| 1 | Piston ring gap 1st,2nd ring | 0.1 - 0.3 | | 2.0 | Repair or Replace |
| | Oil ring | 0.2 - 0.6 | | 1.5 | |
| 2 | Clearance between piston ring and ring 1st,2nd ring | Standard size | Standard clearance | Repair limit | |
| | groove Oil ring | 3 | 0.015 - 0.050 | 0.15 | |
| 3 | Clearance between piston and cylinder | 85 | 0.090 - 0.150 | 0.25 | |
| 4 | Clearance between piston pin and piston | 16 | 0.006 - 0.026 | 0.1 | |
| 5 | Clearance between piston pin and connecting rod small end | 16 | 0.006 - 0.026 | 0.1 | |
| 6 | Clearance between crankpin metal and crankpin | 35 | 0.034 - 0.075 | 0.15 | |